



FortiGate-7000 - Handbook

Version 5.6.12

FORTINET DOCUMENT LIBRARY

<https://docs.fortinet.com>

FORTINET VIDEO GUIDE

<https://video.fortinet.com>

FORTINET BLOG

<https://blog.fortinet.com>

CUSTOMER SERVICE & SUPPORT

<https://support.fortinet.com>

FORTINET TRAINING & CERTIFICATION PROGRAM

<https://www.fortinet.com/support-and-training/training.html>

NSE INSTITUTE

<https://training.fortinet.com>

FORTIGUARD CENTER

<https://fortiguard.com/>

END USER LICENSE AGREEMENT

<https://www.fortinet.com/doc/legal/EULA.pdf>

FEEDBACK

Email: techdoc@fortinet.com



April 22, 2020

FortiGate-7000 5.6.12 Handbook

01-5612-396655-20200422

TABLE OF CONTENTS

| | |
|---|-----------|
| Change log | 8 |
| What's new for FortiGate-7000 5.6.12 | 9 |
| What's new for FortiGate-7000 5.6.11 | 10 |
| What's new for FortiGate-7000 v5.6.7 | 11 |
| What's new for FortiGate-7000 5.6.6 | 12 |
| New IPsec VPN features | 12 |
| IPsec VPN features supported by FortiOS 5.6.6 for FortiGate-7000 | 12 |
| IPsec VPN features not supported by FortiOS 5.6.6 for FortiGate-7000 | 13 |
| New High Availability features and changes | 13 |
| FortiGate-7000 overview | 14 |
| Licenses, device registration, and support | 14 |
| FortiGate-7060E | 15 |
| FortiGate-7060E front panel | 15 |
| FortiGate-7060E schematic | 16 |
| FortiGate-7040E | 17 |
| FortiGate-7040E front panel | 17 |
| FortiGate-7040E schematic | 18 |
| FortiGate-7030E | 18 |
| FortiGate-7030E front panel | 19 |
| FortiGate-7030E schematic | 19 |
| FIM-7901E interface module | 20 |
| FIM-7901E front panel interfaces | 21 |
| FIM-7901E schematic | 22 |
| FIM-7904E interface module | 23 |
| FIM-7904E front panel interfaces | 23 |
| Splitting the FIM-7904E B1 to B8 interfaces | 24 |
| FIM-7904E hardware schematic | 25 |
| FIM-7910E interface module | 26 |
| FIM-7904E front panel interfaces | 26 |
| Splitting the FIM-7910E C1 to C4 interfaces | 27 |
| FIM-7910E hardware schematic | 28 |
| FIM-7920E interface module | 29 |
| FIM-7920E front panel interfaces | 29 |
| Changing the interface type and splitting the FIM-7920E C1 to C4 interfaces | 30 |
| Changing the interface type | 30 |
| Splitting the C1 to C4 interfaces | 31 |
| FIM-7920E hardware schematic | 31 |
| FPM-7620E processing module | 32 |
| FIM-7920E hardware schematic | 33 |
| Getting started with FortiGate-7000 | 34 |
| Multi VDOM mode | 34 |
| Confirming startup status | 35 |
| Configuration synchronization | 36 |

| | |
|--|-----------|
| FortiGate-7000 dashboard widgets | 36 |
| Security Fabric | 36 |
| Interface Bandwidth | 36 |
| Resource Usage | 37 |
| Sensor Information | 37 |
| Setting up management connections | 37 |
| Adding a password to the admin administrator account | 38 |
| Using data interfaces for management traffic | 38 |
| Setting the MTU for a data interface | 39 |
| Replacing a failed FPM or FIM | 39 |
| Replacing a failed module in a standalone FortiGate-7000 chassis | 39 |
| Replacing a failed module in a FortiGate-7000 chassis in an HA cluster | 40 |
| Connecting to module CLIs using the System Management Module | 41 |
| Connecting to the FortiOS CLI of the FIM in slot 1 | 41 |
| Failover in a standalone FortiGate-7000 | 42 |
| Changing data interface network settings | 42 |
| Resetting to factory defaults | 42 |
| Restarting the FortiGate-7000E | 43 |
| Packet sniffing for FIM and FPM packets | 43 |
| Managing individual FortiGate-7000 FIMs and FPMs | 45 |
| Special management port numbers | 45 |
| HA mode special management port numbers | 46 |
| Managing individual FIMs and FPMs from the CLI | 47 |
| Firmware upgrades | 48 |
| Firmware upgrade basics | 48 |
| Verifying that a firmware upgrade is successful | 48 |
| Upgrading the firmware running on individual FIMs or FPMs | 49 |
| Upgrading FIM firmware | 49 |
| Upgrading FPM firmware | 50 |
| Installing FIM firmware from the BIOS after a reboot | 51 |
| Installing FPM firmware from the BIOS after a reboot | 53 |
| Synchronizing FIMs and FPMs after upgrading the primary FIM firmware from the BIOS | 55 |
| Load balancing and flow rules | 56 |
| Setting the load balancing method | 56 |
| Flow rules for sessions that cannot be load balanced | 57 |
| Determining the primary FPM | 58 |
| SSL VPN load balancing | 58 |
| If you change the SSL VPN server listening port | 59 |
| Adding the SSL VPN server IP address | 59 |
| FortiOS Carrier GTP load balancing | 60 |
| Optimizing NPU GTP performance | 60 |
| GTP-C load balancing | 60 |
| GTP-U load balancing | 60 |
| Adding a flow rule to support DHCP relay | 61 |
| Default configuration for traffic that cannot be load balanced | 62 |

| | |
|--|-----------|
| FortiGate-7000 IPsec VPN | 69 |
| New IPsec VPN features | 69 |
| IPsec VPN features supported by FortiOS 5.6 for FortiGate-7000 | 69 |
| IPsec VPN features not supported by FortiOS 5.6 for FortiGate-7000 | 69 |
| Configuring the FortiGate-7000 as a dialup IPsec VPN server | 70 |
| Example dialup IPsec VPN server configuration | 70 |
| Troubleshooting | 71 |
| FortiGate-7000 high availability | 73 |
| New HA features and changes | 74 |
| Failover protection | 74 |
| Device failure | 75 |
| Module failure | 75 |
| Link failure | 75 |
| Session failover | 76 |
| Primary FortiGate-6000 recovery | 76 |
| Before you begin configuring HA | 76 |
| Configure split ports | 76 |
| Connect the M1 and M2 interfaces for HA heartbeat communication | 77 |
| Recommended HA heartbeat interface configuration | 78 |
| Example FortiGate-7000 switch configuration | 78 |
| Basic FortiGate-7000 HA configuration | 80 |
| Verifying that the cluster is operating normally | 81 |
| Verifying that the cluster is synchronized | 82 |
| Setting up HA management connections | 83 |
| Setting up single management connections to each of the FIMs | 83 |
| Setting up redundant management connections to each of the FIMs | 84 |
| Firmware upgrades | 84 |
| Verifying that a firmware upgrade is successful | 85 |
| Distributed clustering | 86 |
| Modifying heartbeat timing | 87 |
| Changing the lost heartbeat threshold | 87 |
| Adjusting the heartbeat interval and lost heartbeat threshold | 88 |
| Changing the time to wait in the hello state | 88 |
| Session failover (session-pickup) | 89 |
| Enabling session pickup for TCP and UDP | 89 |
| If session pickup is disabled | 89 |
| Primary FortiGate-7000 selection | 90 |
| Age and primary FortiGate-7000 selection | 92 |
| Device priority and primary FortiGate-7000 selection | 92 |
| Override and primary FortiGate-7000 selection | 92 |
| Module failure and primary FortiGate-7000 selection | 93 |
| Verifying primary FortiGate-7000 selection | 93 |
| Primary FortiGate-7000 selection and override | 93 |
| Enabling override changes primary FortiGate-7000 selection | 94 |
| Link failover (port monitoring or interface monitoring) | 96 |
| To enable interface monitoring | 96 |
| If a monitored interface on the primary FortiGate-7000 fails | 96 |

| | |
|---|------------|
| If a monitored interface on the secondary FortiGate-7000 fails | 97 |
| Remote link failover | 97 |
| Configuring remote IP monitoring | 98 |
| FortiGate-7000 support for VRRP | 99 |
| ICAP support | 100 |
| Example ICAP configuration | 100 |
| SSL mirroring support | 101 |
| Example SSL mirroring configuration | 102 |
| FortiGate-7000 v5.6.12 special features and limitations | 103 |
| Managing the FortiGate-7000 | 103 |
| Default management VDOM | 103 |
| Default Security Fabric configuration | 103 |
| Maximum number of LAGs and interfaces per LAG | 104 |
| Firewall | 104 |
| IP multicast | 104 |
| High availability | 105 |
| Use of the diagnose sys ha checksum cluster command not recommended | 105 |
| Shelf manager module | 105 |
| FortiOS features not supported by FortiGate-7000 v5.6.12 | 105 |
| IPsec VPN tunnels terminated by the FortiGate-7000 | 106 |
| SSL VPN | 106 |
| Traffic shaping and DDoS policies | 106 |
| FortiGuard web filtering and spam filtering queries | 107 |
| Web filtering quotas | 107 |
| Log messages include a slot field | 107 |
| FortiOS Carrier | 107 |
| Special notice for new deployment connectivity testing | 107 |
| FortiGate-7000 v5.6.11 special features and limitations | 108 |
| Managing the FortiGate-7000 | 108 |
| Default management VDOM | 108 |
| Default Security Fabric configuration | 108 |
| Maximum number of LAGs and interfaces per LAG | 109 |
| Firewall | 109 |
| IP multicast | 109 |
| High availability | 110 |
| Use of the diagnose sys ha checksum cluster command not recommended | 110 |
| Shelf manager module | 110 |
| FortiOS features not supported by FortiGate-7000 v5.6.11 | 110 |
| IPsec VPN tunnels terminated by the FortiGate-7000 | 111 |
| SSL VPN | 111 |
| Traffic shaping and DDoS policies | 111 |
| FortiGuard web filtering and spam filtering queries | 112 |
| Web filtering quotas | 112 |
| Log messages include a slot field | 112 |

| | |
|---|------------|
| FortiOS Carrier | 112 |
| Special notice for new deployment connectivity testing | 112 |
| FortiGate-7000 v5.6.7 special features and limitations | 113 |
| Managing the FortiGate-7000 | 113 |
| Default management VDOM | 113 |
| Default Security Fabric configuration | 113 |
| Maximum number of LAGs and interfaces per LAG | 114 |
| Firewall | 114 |
| IP multicast | 114 |
| High availability | 115 |
| Use of the diagnose sys ha checksum cluster command not recommended | 115 |
| Shelf manager module | 115 |
| FortiOS features not supported by FortiGate-7000 v5.6.7 | 115 |
| IPsec VPN tunnels terminated by the FortiGate-7000 | 116 |
| SSL VPN | 116 |
| Traffic shaping and DDoS policies | 116 |
| FortiGuard web filtering and spam filtering queries | 117 |
| Web filtering quotas | 117 |
| Log messages include a slot field | 117 |
| FortiOS Carrier | 117 |
| Special notice for new deployment connectivity testing | 117 |
| FortiGate-7000 v5.6.6 special features and limitations | 118 |
| Managing the FortiGate-7000 | 118 |
| Default management VDOM | 118 |
| Default Security Fabric configuration | 118 |
| Maximum number of LAGs and interfaces per LAG | 119 |
| Firewall | 119 |
| IP multicast | 119 |
| High availability | 120 |
| Use of the diagnose sys ha checksum cluster command not recommended | 120 |
| Shelf manager module | 120 |
| FortiOS features not supported by FortiGate-7000 v5.6.6 | 120 |
| IPsec VPN tunnels terminated by the FortiGate-7000 | 121 |
| SSL VPN | 121 |
| Traffic shaping and DDoS policies | 121 |
| FortiGuard web filtering and spam filtering queries | 122 |
| Web filtering quotas | 122 |
| Log messages include a slot field | 122 |
| FortiOS Carrier | 122 |
| Special notice for new deployment connectivity testing | 122 |
| FortiGate-7000 Load balancing commands | 123 |

Change log

| Date | Change description |
|------------------|---|
| April 24, 2020 | FortiOS 5.6.12 document release. New and changed sections: <ul style="list-style-type: none">• Failover protection on page 74.• Primary FortiGate-7000 selection on page 90.• Override and primary FortiGate-7000 selection on page 1. |
| January 22, 2020 | Usage-based ECMP load balancing is not supported. See FortiOS features not supported by FortiGate-7000 v5.6.11 on page 110 . |
| November 7, 2019 | New sections: ICAP support on page 100 and SSL mirroring support on page 101 . |
| October 29, 2019 | Added more information and corrections to Special management port numbers on page 45 , Installing FPM firmware from the BIOS after a reboot on page 53 , and Maximum number of LAGs and interfaces per LAG on page 109 . As well, misc change throughout. |
| October 16, 2019 | Removed an incorrect restriction on one-arm sniffer functionality. |
| October 3, 2019 | Initial FortiOS 5.6.11 document release. |

What's new for FortiGate-7000 5.6.12

FortiGate-7000 for FortiOS 5.6.12 is a bug fix release. See the [FortiGate-7000 for FortiOS 5.6.12 Release Notes](#) for details about the content of this release.

What's new for FortiGate-7000 5.6.11

FortiGate-7000 for FortiOS 5.6.11 is a bug fix release. See the [FortiGate-7000 for FortiOS 5.6.11 Release Notes](#) for details about the content of this release.

What's new for FortiGate-7000 v5.6.7

The following new features have been added to FortiGate-7000 v5.6.7 build 4214:

- The FortiGate-7000 supports 64000 explicit proxy web proxy users.
- The HA group ID range is now from 0 to 31 (was 0 to 15).

What's new for FortiGate-7000 5.6.6

Version 5.6.6 enhancements include adding FortiOS 5.6.6 to the FortiGate-7000 platform. This release also includes bug fixes and improvements and the following new features.

- Support for FortiOS 5.6.6 and most 5.6.6 features including FortiOS 5.6.6 GUI features.
- You can configure new Resource Usage dashboard widgets to show CPU use, log rate, memory use, session creation rate, and the number of active sessions for individual FIMs, the management plane, the data plan and the security fabric.
- The Security Fabric dashboard widget shows high level status and configuration information for all of the FPMs.
- The Sensor Information dashboard widget displays temperature information and allows you to drill down for information about individual temperature sensors.
- DP2 firmware upgrade
- VRRP support.
- The management VDOM is now named mgmt-vdom (was dmngmt-vdom).
- The `diagnose sniffer packet` command now shows the name of the FPM that processed the packet.
- You can now use the `execute ping` and `execute traceroute` commands from an FIM CLI to an external destination.
- FIMs directly query LDAP/FSSO/RADIUS servers. These queries no longer have to go through the management VDOM.
- The Route Monitor displays accurate routing information.
- SNMP integration improvements including new MIBs.
- The following FortiOS 5.6.6 features are not supported:
 - SD-WAN
 - Some IPsec VPN features
 - Policy learning mode
 - HA dedicated management interfaces

New IPsec VPN features

FortiOS 5.6.6 includes the following IPsec VPN improvements:

- Including a phase 2 selector is no longer mandatory.
- Dynamic routing (RIP, OSPF, BGP) is supported over IPsec VPN tunnels.

IPsec VPN features supported by FortiOS 5.6.6 for FortiGate-7000

FortiOS 5.6.6 for FortiGate-7000 supports the following IPsec VPN features.

- Interface-based IPsec VPN (also called route-based IPsec VPN).
- Static routes can point IPsec VPN interfaces.
- Dynamic routing (RIP, OSPF, BGP) over IPsec VPN tunnels.
- Remote networks with 16- to 32-bit netmasks.
- IPsec VPN tunnels must terminate on the primary FPM (the ELBC master).

- Site-to-Site IPsec VPN.
- Dialup IPsec VPN. The FortiGate-7000 can be the dialup server or client.
- IPv4 clear-text traffic (IPv4 over IPv4 or IPv4 over IPv6)

IPsec VPN features not supported by FortiOS 5.6.6 for FortiGate-7000

FortiOS 5.6.6 for FortiGate-7000 does not support the following IPsec VPN features.

- Policy-based IPsec VPN.
- Policy routes for VPN traffic.
- Remote networks with 0- to 15-bit netmasks.
- IPv6 clear-text traffic (IPv6 over IPv4 or IPv6 over IPv6).
- Load-balancing IPsec VPN tunnels to multiple FPMs.
- IPsec SA synchronization between both FortiGate-7000s in an HA configuration.

New High Availability features and changes

Configuring FortiGate-7000 HA has been simplified for FortiOS 5.6.6. To set up HA, you no longer have to configure HA settings for both of the FIMs in a FortiGate-7000. Instead, you configure HA settings on the primary FIM and this configuration is synchronized to the other FIM.

As well, FortiGate-7000 HA is configured and operates more like standard FGCP HA. The link failure threshold concept that was part of FortiGate-7000 for FortiOS 5.4 has been removed and board failover tolerance has been simplified. As well, primary unit selection has been simplified to be more like FGCP primary unit selection.

FortiOS 5.6.6 also includes the following new features and changes:

- The **System > HA** GUI page now appears and can be used to configure most HA settings.
- You can configure HA interface monitoring (or port monitoring) to detect link failures.
- You can configure HA remote link failover (also called remote IP monitoring) to detect remote link failures using the following options:
 - Enable remote IP monitoring with the `pingserver-monitor-interface` option.
 - Set the remote IP monitoring failover threshold with the `pingserver-failover-threshold` option.
 - Force the cluster to negotiate after a remote IP monitoring failover with the `pingserver-slave-force-reset` option.
 - Adjust the time to wait in minutes before renegotiating after a remote IP monitoring failover with the `pingserver-flip-timeout` option.
- You can use the `get system ha status` command to display HA status. The `diagnose sys ha status` command is no longer available.
- The `diagnose sys ha force-slave-state` command is no longer available. To force the primary FortiGate-7000 into a secondary (or slave) state you can use the `diagnose sys ha reset-uptime` command.
- The HA `link-failure-threshold` option has been removed.
- The `board-failover-tolerance` option has been simplified and determines how the cluster responds to failed FIMs.

FortiGate-7000 overview

A FortiGate-7000 product consists of a FortiGate-7000 series chassis (for example, the FortiGate-7040E) with FortiGate-7000 modules installed in the chassis slots. A FortiGate-7040E chassis comes with two interface modules (FIM) to be installed in slots 1 and 2 to provide network connections and session-aware load balancing to two processor modules (FPM) to be installed in slots 3 and 4.

FortiGate-7000 products are sold and licensed as packages that include the chassis as well as the modules to be included in the chassis. When you receive your FortiGate-7000 series product the chassis has to be installed in a rack and the modules installed in the chassis. Interface modules always go in slots 1 and 2 and processor modules in slots 3 and up.

If your FortiGate-7000 product includes two different interfaces modules, for optimal configuration you should install the module with the lower model number in slot 1 and the module with the higher model number in slot 2. For example, if your chassis includes a FIM-7901E and a FIM-7904E, install the FIM-7901E in chassis slot 1 and the FIM-7904E in chassis slot 2. This applies to any combination of two different interface modules.

As an administrator, when you browse to the FortiGate-7000 management IP address you log into the interface module in slot 1 (the primary or master interface module or FIM) to view the status of the FortiGate-7000 and make configuration changes. The FortiOS firmware running on each module has the same configuration and when you make configuration changes to the primary interface module, the configuration changes are synchronized to all modules.

The same FortiOS firmware build runs on each module in the chassis. You can upgrade FortiGate-7000 firmware by logging into the primary interface module and performing a firmware upgrade as you would for any FortiGate. During the upgrade process the firmware of all of the modules in the chassis upgrades in one step. Firmware upgrades should be done during a quiet time because traffic will briefly be interrupted during the upgrade process.

Licenses, device registration, and support

A FortiGate-7000 product is made up of a FortiGate-7000 series chassis, one or two FIM interface modules and two to four FPM processor modules. The entire package is licensed and configured as a single product under the FortiGate-7000 chassis serial number. When you receive a new FortiGate-7000 product you register it on <https://support.fortinet.com> using the chassis serial number. Use the chassis serial number when requesting support from Fortinet for the product.

All Fortinet licensing, including FortiCare Support, IPS, AntiVirus, Web Filtering, Mobile Malware, FortiClient, FortiCloud, and additional virtual domains (VDOM) is for the entire FortiGate-7000 product and not for individual components.

If an individual component, such as a single interface or processor fails you can RMA and replace just that component.


FortiGate-7060E

The FortiGate-7060E is a 8U 19-inch rackmount 6-slot chassis with a 80Gbps fabric and 1Gbps base backplane designed by Fortinet. The fabric backplane provides network data communication and the base backplane provides management and synch communication among the chassis slots.

FortiGate-7060E front panel

The chassis is managed by two redundant System Management Modules (SMM). Each module includes an Ethernet connection as well as two switchable console ports that provide console connections to the modules in the chassis slots. The active SMM controls chassis cooling and power management and provides an interface for managing the modules installed in the chassis.

FortiGate-7060E front panel, (example module configuration)




Power is provided to the chassis using four hot swappable 3+1 redundant 100-240 VAC, 50-60 Hz power supply units (PSUs). You can also optionally add up to six PSUs to provide 3+3 redundancy. The FortiGate-7060E can also be equipped with DC PSUs allowing you to connect the chassis to -48V DC power

The standard configuration of the FortiGate-7060E includes two FIM (interface) modules in chassis slots 1 and 2 and up to four FPM (processing) modules in chassis slots 3 to 6.

FortiGate-7060E schematic

The FortiGate-7060E chassis schematic below shows the communication channels between chassis components including the SMMs (MGMT), the FIMs (called FIM1 and FIM2) and the FPMs (FPM3, FPM4, FPM5, and FPM6).



By default, MGMT2 is the active SMM and MGMT1 is inactive. The active SMM always has the Intelligent Platform Management Bus (IPMB) address 0x20 and the inactive SMM always has the IPMB address 0x22.

The active SMM communicates with all modules in the chassis over the base backplane. Each module, including the SMMs has a Shelf Management Controller (SMC). These SMCs support IPMB communication between the active SMM and the FIM and FPMs for storing and sharing sensor data that the SMM uses to control chassis cooling and power distribution. The base backplane also supports serial communications to allow console access from the SMM to all modules, and 1Gbps Ethernet communication for management and heartbeat communication between modules.

FIM1 and FIM2 (IPMB addresses 0x82 and 0x84) are the FIMs in slots 1 and 2. The interfaces of these modules connect the chassis to data networks and can be used for Ethernet management access to chassis components. The FIMs include DP2 processors that distribute sessions over the Integrated Switch Fabric (ISF) to the NP6 processors in the FPMs. Data sessions are communicated to the FPMs over the 80Gbps chassis fabric backplane.

FPM03, FPM04, FPM05, and FPM06 (IPMB addresses 0x86, 0x88, 0x8A, and 0x8C) are the FPM processor modules in slots 3 to 6. These worker modules process sessions distributed to them by the FIMs. FPMs include NP6 processors to offload sessions from the FPM CPU and CP9 processors that accelerate content processing.


FortiGate-7040E

The FortiGate-7040E is a 6U 19-inch rackmount 4-slot chassis with a 80Gbps fabric and 1Gbps base backplane designed by Fortinet. The fabric backplane provides network data communication and the base backplane provides management and synch communication among the chassis slots.

FortiGate-7040E front panel


The FortiGate-7040E chassis is managed by a single System Management Module (SMM) that includes an Ethernet connection as well as two switchable console ports that provide console connections to the modules in the chassis slots. The SMM controls chassis cooling and power management and provides an interface for managing the modules installed in the chassis. The standard configuration of the FortiGate-7040E includes two FIM (interface) modules in chassis slots 1 and 2 and two FPM (processing) modules in chassis slots 3 and 4.

FortiGate-7040E front panel



FortiGate-7040E schematic

The FortiGate-7040E chassis schematic below shows the communication channels between chassis components including the System Management Module (MGMT), the FIMs (called FIM1 and FIM2) and the FPMs (FPM3 and FPM4).



The SMM (MGMT), with Intelligent Platform Management Bus (IPMB) address 0x20 communicates with all modules in the chassis over the base backplane. Each module, including the SMM, includes a Shelf Management Controller (SMC). These SMCs support IPMB communication between the SMM and the FIM and FPMs for storing and sharing sensor data that the SMM uses to control chassis cooling and power distribution. The base backplane also supports serial communications to allow console access from the SMM to all modules, and 1Gbps Ethernet communication for management and heartbeat communication between modules.

FIM1 and FIM2 (IPMB addresses 0x82 and 0x84) are the FIMs in slots 1 and 2. The interfaces of these modules connect the chassis to data networks and can be used for Ethernet management access to chassis components. The FIMs include DP2 processors that distribute sessions over the Integrated Switch Fabric (ISF) to the NP6 processors in the FPMs. Data sessions are communicated to the FPMs over the 80Gbps chassis fabric backplane.

FPM3 and FPM4 (IPMB addresses 0x86 and 0x88) are the FPM processor modules in slots 3 and 4. These worker modules process sessions distributed to them by the FIMs. FPMs include NP6 processors to offload sessions from the FPM CPU and CP9 processors that accelerate content processing.


FortiGate-7030E

The FortiGate-7030E is a 6U 19-inch rackmount 3-slot chassis with a 80Gbps fabric and 1Gbps base backplane designed by Fortinet. The fabric backplane provides network data communication and the base backplane provides management and synch communication among the chassis slots.

FortiGate-7030E front panel


The FortiGate-7030E chassis is managed by a single System Management Module (SMM) that includes an Ethernet connection as well as two switchable console ports that provide console connections to the modules in the chassis slots. The SMM controls chassis cooling and power management and provides an interface for managing the modules installed in the chassis. The standard configuration of the FortiGate-7030E includes one FIM (interface) module in chassis slot 1 and two FPM (processing) modules in chassis slots 3 and 4. The front panel also includes a sealed blank panel. Breaking the seal or removing the panel voids your FortiGate-7030E warranty.

FortiGate-7030E front panel (example module configuration)



FortiGate-7030E schematic

The FortiGate-7030E chassis schematic below shows the communication channels between chassis components including the System Management Module (MGMT), the FIM (called FIM1) and the FPMs (FPM3 and FPM4).



The SMM (MGMT), with Intelligent Platform Management Bus (IPMB) address 0x20) communicates with all modules in the chassis over the base backplane. Each module, including the SMM includes a Shelf Management Controller (SMC). These SMCs support IPMB communication between the SMM and the FIM and FPMs for storing and sharing sensor data that the SMM uses to control chassis cooling and power distribution. The base backplane also supports serial communications to allow console access from the SMM to all modules, and 1Gbps Ethernet communication for management and heartbeat communication between modules.

FIM1 (IPMB address 0x82) is the FIM in slot 1. The interfaces of this module connect the chassis to data networks and can be used for Ethernet management access to chassis components. The FIM includes DP2 processors that distribute sessions over the Integrated Switch Fabric (ISF) to the NP6 processors in the FPMs. Data sessions are communicated to the FPMs over the 80Gbps chassis fabric backplane.

FPM3 and FPM4 (IPMB addresses 0x86 and 0x88) are the FPM processor modules in slots 3 and 4. These worker modules process sessions distributed to them by the FIM. FPMs include NP6 processors to offload sessions from the FPM CPU and CP9 processors that accelerate content processing.


FIM-7901E interface module

The FIM-7901E interface module is a hot swappable module that provides data, management, and session sync/heartbeat interfaces, base backplane switching, and fabric backplane session-aware load balancing for a FortiGate-7000 series chassis. The FIM-7901E includes an integrated switch fabric and DP2 processors to load balance millions of data sessions over the chassis fabric backplane to FPM processor modules. The FIM-7901E also includes a 1Gbps base backplane channel for base backplane management communication with each FPM module in the chassis, one 40Gbps fabric backplane channel for fabric backplane communication with the FIM module(s) in the chassis, and a second 1Gbps base backplane channel for base backplane communication with the FIM module(s) in the chassis.

The FIM-7901E can be installed in any FortiGate-7000 series chassis in chassis hub/switch slots 1 or 2. The FIM-7901E provides thirty-two 10GigE small form-factor pluggable plus (SPF+) interfaces for a FortiGate-7000 chassis.

You can also install FIM-7901Es in a second chassis and operate the chassis in HA mode to provide chassis failover protection.

FIM-7901E front panel



FIM-7901E front panel interfaces

You connect the FIM-7901E to your 10Gbps networks using the A1 to A32 front panel SFP+ interfaces. The front panel also includes M1 and M2 SFP+ interfaces for the base channel, four Ethernet management interfaces (MGMT1 to MGMT4), and a USB port. The USB port can be used with any USB key for backing up and restoring configuration files.

| Connector | Type | Speed | Protocol | Description |
|-----------|------|--------------|----------|--|
| A1 to A32 | SPF+ | 10Gbps/1Gpbs | Ethernet | Thirty-two front panel 10GigE SFP+ fabric channel interfaces. These interfaces are connected to 10Gbps networks to distribute sessions to the FPM processor modules installed in chassis slots 3 and up. These interfaces can also be configured to operate as Gigabit Ethernet interfaces using SFP transceivers. These interfaces also support creating link aggregation groups (LAGs) that can include interfaces from both FIM-7901Es. |
| M1 and M2 | SFP+ | 10Gbps/1Gpbs | Ethernet | Two front panel 10GigE SFP+ interfaces that connect to the base backplane channel. These interfaces are used for heartbeat, session sync, and management communication between FIM-7901Es in different chassis. These interfaces can also be configured to operate as Gigabit Ethernet interfaces using SFP transceivers, but should not normally be changed. If you use switches to connect these interfaces, the switch ports should be able to accept packets with a maximum frame size of at least 1526. The M1 and M2 interfaces need to be on different broadcast domains. If M1 |

| Connector | Type | Speed | Protocol | Description |
|----------------|----------------|-----------------|-----------------|---|
| | | | | and M2 are connected to the same switch, Q-in-Q must be enabled on the switch |
| MGMT1 to MGMT4 | RJ-45 | 10/100/1000Mbps | Ethernet | Four 10/100/1000BASE-T copper out of band management Ethernet interfaces. |
| USB | USB 3.0 Type A | | USB 3.0 USB 2.0 | Standard USB connector. |


FIM-7901E schematic

The FIM-7901E includes an integrated switch fabric (ISF) that connects the front panel interfaces to the DP2 session-aware load balancers and to the chassis backplanes. The ISF also allows the DP2 processors to distribute sessions among all NP6 processors on the FPM modules in the same chassis.

The FIM-7901E also includes the following backplane communication channels:

- One 80Gbps fabric backplane channel to distribute traffic to the FPMs.
- One 1Gbps base backplane channel for base backplane communication with the FPMs.
- One 40Gbps fabric backplane channel for fabric backplane communication with the other FIM.
- One 1Gbps base backplane channel for base backplane communication with the other FIM.

FIM-7901E hardware architecture




FIM-7904E interface module

The FIM-7904E interface module is a hot swappable module that provides data, management, and session sync/heartbeat interfaces, base backplane switching, and fabric backplane session-aware load balancing for a FortiGate-7000 series chassis. The FIM-7904E includes an integrated switch fabric and DP2 processors to load balance millions of data sessions over the chassis fabric backplane to FPM processor modules. The FIM-7904E also includes a 1Gbps base backplane channel for base backplane management communication with each FPM module in the chassis, one 40Gbps fabric backplane channel for fabric backplane communication with the FIM module(s) in the chassis, and a second 1Gbps base backplane channel for base backplane communication with the FIM module(s) in the chassis.

The FIM-7904E can be installed in any FortiGate-7000 series chassis in chassis hub/switch slots 1 or 2. The FIM-7904E provides four Quad Small Form-factor Pluggable plus (QSFP+) interfaces for a FortiGate-7000 chassis. Using a 40GBASE-SR10 multimode QSFP+ transceiver, each QSFP+ interface can also be split into four 10GBASE-SR interfaces.

You can also install FIM-7904Es in a second chassis and operate the chassis in HA mode to provide chassis failover protection.

FIM-7904E front panel



FIM-7904E front panel interfaces

You connect the FIM-7904E to your 40Gbps networks using the B1 to B8 front panel QSFP+ interfaces. The front panel also includes M1 and M2 SFP+ interfaces for the base channel, four Ethernet management interfaces (MGMT1 to MGMT4), and a USB port. The USB port can be used with any USB key for backing up and restoring configuration files.

| Connector | Type | Speed | Protocol | Description |
|-----------|-------|---------------|----------|---|
| B1 to B8 | QSFP+ | 40Gbps/10Gbps | Ethernet | Eight front panel 40GigE QSFP+ fabric channel interfaces. These interfaces are connected to 40Gbps networks to distribute sessions to the FPM processor modules installed in chassis slots 3 and up. Using 40GBASE-SR10 multimode |

| Connector | Type | Speed | Protocol | Description |
|----------------|----------------|-----------------|-----------------|--|
| | | | | QSFP+ transceivers, each QSFP+ interface can also be split into four 10GBASE-SR interfaces. These interfaces also support creating link aggregation groups (LAGs) that can include interfaces from both FIM-7904Es. |
| M1 and M2 | SFP+ | 10Gbps/1Gbps | Ethernet | Two front panel 10GigE SFP+ interfaces that connect to the base backplane channel. These interfaces are used for heartbeat, session sync, and management communication between FIM-7904Es in different chassis. These interfaces can also be configured to operate as Gigabit Ethernet interfaces using SFP transceivers, but should not normally be changed. If you use switches to connect these interfaces, the switch ports should be able to accept packets with a maximum frame size of at least 1526. The M1 and M2 interfaces need to be on different broadcast domains. If M1 and M2 are connected to the same switch, Q-in-Q must be enabled on the switch |
| MGMT1 to MGMT4 | RJ-45 | 10/100/1000Mbps | Ethernet | Four 10/100/1000BASE-T copper out of band management Ethernet interfaces. |
| USB | USB 3.0 Type A | | USB 3.0 USB 2.0 | Standard USB connector. |

Splitting the FIM-7904E B1 to B8 interfaces

Each 40GE interface (B1 to B8) on the FIM-7904Es in slot 1 and slot 2 of a FortiGate-7000 system can be split into 4x10GBE interfaces. You split these interfaces after the FIM-7904Es are installed in your FortiGate-7000 system and the system is up and running. You can split the interfaces of the FIM-7904Es in slot 1 and slot 2 at the same time by entering a single CLI command. Enabling, disabling, or changing the split interfaces configuration requires a system reboot. Fortinet recommends that you split multiple interfaces at the same time according to your requirements to avoid traffic disruption.

For example, to split the B1 interface of the FIM-7904E in slot 1 (this interface is named 1-B1) and the B1 and B4 interfaces of the FIM-7904E in slot 2 (these interfaces are named 2-B1 and 2-B4) connect to the CLI of your FortiGate-7000 system using the management IP and enter the following command:

```
config system global
    set split-port 1-B1 2-B1 2-B4
end
```

After you enter the command, the FortiGate-7000 reboots and when it comes up:

- The 1-B1 interface will no longer be available. Instead the 1-B1/1, 1-B1/2, 1-B1/3, and 1-B1/4 interfaces will be available.

- The 2-B1 interface will no longer be available. Instead the 2-B1/1, 2-B1/2, 2-B1/3, and 2-B1/4 interfaces will be available.
- The 2-B4 interface will no longer be available. Instead the 2-B4/1, 2-B4/2, 2-B4/3, and 2-B4/4 interfaces will be available.

You can now connect breakout cables to these interfaces and configure traffic between them just like any other FortiGate interface.


FIM-7904E hardware schematic

The FIM-7904E includes an integrated switch fabric (ISF) that connects the front panel interfaces to the DP2 session-aware load balancers and to the chassis backplanes. The ISF also allows the DP2 processors to distribute sessions among all NP6 processors on the FPM modules in the same chassis.

The FIM-7904E also includes the following backplane communication channels:

- One 80Gbps fabric backplane channel to distribute traffic to the FPMs.
- One 1Gbps base backplane channel for base backplane communication with the FPMs.
- One 40Gbps fabric backplane channel for fabric backplane communication with the other FIM.
- One 1Gbps base backplane channel for base backplane communication with the other FIM.

FIM-7904E hardware architecture




FIM-7910E interface module

The FIM-7910E interface module is a hot swappable module that provides data, management, and session sync/heartbeat interfaces, base backplane switching, and fabric backplane session-aware load balancing for a FortiGate-7000 series chassis. The FIM-7910E includes an integrated switch fabric and DP2 processors to load balance millions of data sessions over the 80Gbps fabric backplane channel to FPM processor modules. The FIM-7910E also includes a 1Gbps base backplane channel for base backplane management communication with each FPM module in the chassis, one 40Gbps fabric backplane channel for fabric backplane communication with the FIM module(s) in the chassis, and a second 1Gbps base backplane channel for base backplane communication with the FIM module(s) in the chassis.

The FIM-7910E can be installed in any FortiGate-7000 series chassis in chassis hub/switch slots 1 or 2. The FIM-7910E provides four C form-factor pluggable 2 (CFP2) interfaces for a FortiGate-7000 chassis. Using a 100GBASE-SR10 multimode CFP2 transceiver, each CFP2 interface can also be split into ten 10GBASE-SR SFP+ interfaces.

You can also install FIM-7910Es in a second chassis and operate the chassis in HA mode to provide chassis failover protection.

FIM-7910E front panel



FIM-7904E front panel interfaces

You connect the FIM-7910E to your 100Gbps networks using the C1 to C4 front panel CFP2 interfaces. The front panel also includes M1 and M2 SFP+ interfaces for the base channel, four Ethernet management interfaces (MGMT1 to MGMT4), and a USB port. The USB port can be used with any USB key for backing up and restoring configuration files.

| Connector | Type | Speed | Protocol | Description |
|-----------|------|----------------|----------|---|
| C1 to C4 | CFP2 | 100Gbps/10Gbps | Ethernet | Four front panel 100GigE CFP2 fabric channel interfaces (C1 to C4). These interfaces are connected to 100Gbps networks to distribute sessions to the FPM processor modules installed in chassis slots 3 and up. Using 100GBASE-SR10 |

| Connector | Type | Speed | Protocol | Description |
|----------------|----------------|-----------------|-----------------|--|
| | | | | multimode CFP2 transceivers, each CFP2 interface can also be split into ten 10GBASE-SR SFP+ interfaces. These interfaces also support creating link aggregation groups (LAGs) that can include interfaces from both FIM-7910Es. |
| M1 and M2 | SFP+ | 10Gbps/1Gbps | Ethernet | Two front panel 10GigE SFP+ interfaces that connect to the base backplane channel. These interfaces are used for heartbeat, session sync, and management communication between FIM-7910Es in different chassis. These interfaces can also be configured to operate as Gigabit Ethernet interfaces using SFP transceivers, but should not normally be changed. If you use switches to connect these interfaces, the switch ports should be able to accept packets with a maximum frame size of at least 1526. The M1 and M2 interfaces need to be on different broadcast domains. If M1 and M2 are connected to the same switch, Q-in-Q must be enabled on the switch |
| MGMT1 to MGMT4 | RJ-45 | 10/100/1000Mbps | Ethernet | Four 10/100/1000BASE-T copper out of band management Ethernet interfaces. |
| USB | USB 3.0 Type A | | USB 3.0 USB 2.0 | Standard USB connector. |

Splitting the FIM-7910E C1 to C4 interfaces

Each 100GE interface (C1 to C4) on the FIM-7910Es in slot 1 and slot 2 of a FortiGate-7000 system can be split into 10 x 10GBE SFP+ interfaces. You split these interfaces after the FIM-7910Es are installed in your FortiGate-7000 system and the system is up and running. You can split the interfaces of the FIM-7910Es in slot 1 and slot 2 at the same time by entering a single CLI command. Enabling, disabling, or changing the split interfaces configuration requires a system reboot. Fortinet recommends that you split multiple interfaces at the same time according to your requirements to avoid traffic disruption.

For example, to split the C1 interface of the FIM-7910E in slot 1 (this interface is named 1-C1) and the C1 and C4 interfaces of the FIM-7910E in slot 2 (these interfaces are named 2-C1 and 2-C4) connect to the CLI of your FortiGate-7000 system using the management IP and enter the following command:

```
config system global
    set split-port 1-C1 2-C1 2-C4
end
```

After you enter the command, the FortiGate-7000 reboots and when it comes up:

- The 1-C1 interface will no longer be available. Instead the 1-C1/1, 1-C1/2, ..., and 1-C1/10 interfaces will be available.

- The 2-C1 interface will no longer be available. Instead the 2-C1/1, 2-C1/2, ..., and 2-C1/10 interfaces will be available.
- The 2-C4 interface will no longer be available. Instead the 2-C4/1, 2-C4/2, ..., and 2-C4/10 interfaces will be available.

You can now connect breakout cables to these interfaces and configure traffic between them just like any other FortiGate interface.


FIM-7910E hardware schematic

The FIM-7910E includes an integrated switch fabric (ISF) that connects the front panel interfaces to the DP2 session-aware load balancers and to the chassis backplanes. The ISF also allows the DP2 processors to distribute sessions among all NP6 processors on the FPM modules in the same chassis.

The FIM-7910E also includes the following backplane communication channels:

- One 80Gbps fabric backplane channel to distribute traffic to the FPMs.
- One 1Gbps base backplane channel for base backplane communication with the FPMs.
- One 40Gbps fabric backplane channel for fabric backplane communication with the other FIM.
- One 1Gbps base backplane channel for base backplane communication with the other FIM.

FIM-7910E hardware architecture




FIM-7920E interface module

The FIM-7920E interface module is a hot swappable module that provides data, management, and session sync/heartbeat interfaces, base backplane switching, and fabric backplane session-aware load balancing for a FortiGate-7000 series chassis. The FIM-7920E includes an integrated switch fabric and DP2 processors to load balance millions of data sessions over the 80Gbps fabric backplane channel to FPM processor modules. The FIM-7920E also includes a 1Gbps base backplane channel for base backplane management communication with each FPM module in the chassis, one 40Gbps fabric backplane channel for fabric backplane communication with the FIM module(s) in the chassis, and a second 1Gbps base backplane channel for base backplane communication with the FIM module(s) in the chassis.

The FIM-7920E can be installed in any FortiGate-7000 series chassis in chassis hub/switch slots 1 or 2. The FIM-7920E provides four Quad Small Form-factor Pluggable 28 (QSFP28) 100GigE interfaces for a FortiGate-7000 chassis. Using a 100GBASE-SR4 QSFP28 or 40GBASE-SR4 QSFP+ transceiver, each QSFP28 interface can also be split into four 10GBASE-SR SFP+ interfaces.

You can also install FIM-7920Es in a second chassis and operate the chassis in HA mode to provide chassis failover protection.

FIM-7920E front panel



FIM-7920E front panel interfaces

You connect the FIM-7920E to your 100Gbps networks using the C1 to C4 front panel QSFP28 interfaces. The front panel also includes M1 and M2 SFP+ interfaces for the base channel, four Ethernet management interfaces (MGMT1 to MGMT4), and a USB port. The USB port can be used with any USB key for backing up and restoring configuration files.

| Connector | Type | Speed | Protocol | Description |
|-----------|--------|-----------------------|----------|---|
| C1 to C4 | QSFP28 | 100Gbps/40Gbps/10Gbps | Ethernet | Four front panel 100GigE QSFP28 fabric channel interfaces that can be connected to 100Gbps networks to distribute sessions to |

| Connector | Type | Speed | Protocol | Description |
|----------------|----------------|-----------------|--------------------|--|
| | | | | the FPM processor modules installed in chassis slots 3 and up. Using a 100GBASE-SR4 QSFP28 or 40GBASE-SR4 QSFP+ transceiver, each QSFP28 interface can also be split into four 10GBASE-SR interfaces. These interfaces also support creating link aggregation groups (LAGs) that can include interfaces from multiple FIM-7920Es. |
| M1 and M2 | SFP+ | 10Gbps/1Gbps | Ethernet | Two front panel 10GigE SFP+ interfaces that connect to the base backplane channel. These interfaces are used for heartbeat, session sync, and management communication between FIM-7920Es in different chassis. These interfaces can also be configured to operate as Gigabit Ethernet interfaces using SFP transceivers, but should not normally be changed. If you use switches to connect these interfaces, the switch ports should be able to accept packets with a maximum frame size of at least 1526. The M1 and M2 interfaces need to be on different broadcast domains. If M1 and M2 are connected to the same switch, Q-in-Q must be enabled on the switch |
| MGMT1 to MGMT4 | RJ-45 | 10/100/1000Mbps | Ethernet | Four 10/100/1000BASE-T copper out of band management Ethernet interfaces. |
| USB | USB 3.0 Type A | | USB 3.0 USB 2.0 | Standard USB connector. |

Changing the interface type and splitting the FIM-7920E C1 to C4 interfaces

By default, the FIM-7920E C1 to C4 interfaces are configured as 100GE QSFP28 interfaces. You can use the following command to convert them to 40GE QSFP+ interfaces. Once converted, you can use the other command below to split them into four 10GBASE-SR interfaces.

Changing the interface type

For example, to change the interface type of the C1 interface of the FIM-7920E in slot 1 to 40GE QSFP+ connect to the CLI of your FortiGate-7000 system using the management IP and enter the following command:

```
config system global
    set qsfp28-40g-port 1-C1
end
```

The FortiGate-7000 system reboots and when it starts up interface C1 of the FIM-7920E in slot 1 is operating as a 40GE QSFP+ interface .

To change the interface type of the C3 and C4 ports of the FIM-7920E in slot 2 to 40GE QSFP+ enter the following command:

```
config system global
    set qsfp28-40g-port 2-C3 2-C4
end
```

The FortiGate-7000 system reboots and when it starts up interfaces C3 and C4 of the FIM-7920E in slot 2 are operating as a 40GE QSFP+ interfaces.

Splitting the C1 to C4 interfaces

Each 40GE interface (C1 to C4) on the FIM-7920Es in slot 1 and slot 2 of a FortiGate-7000 system can be split into 4 x 10GBE interfaces. You split these interfaces after the FIM-7920Es are installed in your FortiGate-7000 system and the system is up and running. You can split the interfaces of the FIM-7920Es in slot 1 and slot 2 at the same time by entering a single CLI command. Enabling, disabling, or changing the split interfaces configuration requires a system reboot. Fortinet recommends that you split multiple interfaces at the same time according to your requirements to avoid traffic disruption.

For example, to split the C1 interface of the FIM-7920E in slot 1 (this interface is named 1-C1) and the C1 and C4 interfaces of the FIM-7920E in slot 2 (these interfaces are named 2-C1 and 2-C4) connect to the CLI of your FortiGate-7000 system using the management IP and enter the following command:

```
config system global
    set split-port 1-C1 2-C1 2-C4
end
```

After you enter the command, the FortiGate-7000 reboots and when it comes up:

- The 1-C1 interface will no longer be available. Instead the 1-C1/1, 1-C1/2, 1-C1/3, and 1-C1/4 interfaces will be available.
- The 2-C1 interface will no longer be available. Instead the 2-C1/1, 2-C1/2, 2-C1/3, and 2-C1/4 interfaces will be available.
- The 2-C4 interface will no longer be available. Instead the 2-C4/1, 2-C4/2, 2-C4/3, and 2-C4/4 interfaces will be available.

You can now connect breakout cables to these interfaces and configure traffic between them just like any other FortiGate interface.


FIM-7920E hardware schematic

The FIM-7920E includes an integrated switch fabric (ISF) that connects the front panel interfaces to the DP2 session-aware load balancers and to the chassis backplanes. The ISF also allows the DP2 processors to distribute sessions among all NP6 processors on the FPM modules in the same chassis.

The FIM-7920E also includes the following backplane communication channels:

- One 80Gbps fabric backplane channel to distribute traffic to the FPMs.
- One 1Gbps base backplane channel for base backplane communication with the FPMs.
- One 40Gbps fabric backplane channel for fabric backplane communication with the other FIM.
- One 1Gbps base backplane channel for base backplane communication with the other FIM.

FIM-7920E hardware architecture




FPM-7620E processing module

The FPM-7620E processing module is a high-performance worker module that processes sessions load balanced to it by FortiGate-7000 series interface (FIM) modules over the chassis fabric backplane. The FPM-7620E can be installed in any FortiGate-7000 series chassis in slots 3 and up.

The FPM-7620E includes two 80Gbps connections to the chassis fabric backplane and two 1Gbps connections to the base backplane. The FPM-7620E processes sessions using a dual CPU configuration, accelerates network traffic processing with four NP6 processors, and accelerates content processing with eight CP9 processors. The NP6 network processors are connected by the FIM switch fabric so all supported traffic types can be fast path accelerated by the NP6 processors.


FPM-7620E front panel



FIM-7920E hardware schematic

The four FPM-7620E NP6 network processors, eight CP9 processors, and FIM module integrated switch fabric (ISF) provide hardware acceleration by offloading data traffic from the FPM-7620E CPUs. The result is enhanced network performance provided by the NP6 processors plus the network processing load is removed from the CPU. The NP6 processor can also handle some CPU intensive tasks, like IPsec VPN encryption/decryption. Because of the integrated switch fabric, all sessions are fast-pathed and accelerated.

FPM-7620E hardware architecture



Getting started with FortiGate-7000

Begin by installing your FortiGate-7000 chassis in a rack and installing FIM interface modules and FPM processing modules in it. Then you can power on the chassis and all modules in the chassis will power up.

Whenever a chassis is first powered on, it takes about 5 minutes for all modules to start up and become completely initialized and synchronized. During this time the chassis will not allow traffic to pass through and you may not be able to log into the GUI, or if you manage to log in, the session could time out as the FortiGate-7000 continues negotiating.

Review the PSU, fan tray, System Management Module (SMM), FIM, and FPM LEDs to verify that everything is operating normally. Wait until the chassis has completely started up and synchronized before making configuration changes.

When the system has initialized, you have a few options for connecting to the FortiGate-7000 GUI or CLI:

- Log in to the GUI by connecting the MGMT1 interface of the FIM in slot 1 to your network. Then browse to <https://192.168.1.99>.
- Log in to the CLI by connecting the MGMT1 interface of the FIM in slot 1 to your network. Then use an SSH client to connect to 192.168.1.99 and use the same admin account to log in.
- Log in to the primary FIM CLI by connecting to the RJ-45 RS-232 Console 1 serial port on the FortiGate-7000 SMM with settings: BPS: 9600, data bits: 8, parity: none, stop bits: 1, flow control: none.

The FortiGate-7000 ships with the following factory default configuration.

| Option | Default Configuration |
|---------------------------------|--|
| Administrator Account User Name | admin |
| Password | (none) For security reasons you should add a password to the admin account before connecting the FortiGate-7000 to your network. |
| MGMT1 IP/Netmask | 192.168.1.99/24 (the MGMT1 interface is part of the mgmt redundant interface that also includes MGMT2, MGMT3, and MGMT4). |

All configuration changes must be made from the primary FIM GUI or CLI and not from the secondary FIM or the FPMs.

All other management communication (for example, SNMP queries, remote logging, and so on) use the management aggregate interface and are handled by the primary FIM.

Multi VDOM mode

By default, when you first start up a FortiGate-7000F it is operating in Multi VDOM mode. The default Multi VDOM configuration includes the **root** VDOM and a management VDOM named **mgmt-vdom**. The management interface (mgmt) and the HA heartbeat interfaces (M1 and M2) are in mgmt-vdom and all of the data interfaces are in the root VDOM.

You cannot delete or rename mgmt-vdom. You also cannot remove interfaces from it or add interfaces to it. You can however, configure other settings such as routing required for management communication, interface IP addresses, and so on. You can also add VLANs to the interfaces in mgmt-vdom.

You can use the root VDOM for data traffic and you can also add more VDOMs as required, depending on your Multi VDOM license.

Confirming startup status

Before verifying normal operation and making configuration changes and so on you should wait until the FortiGate-7000 is completely started up and synchronized. This can take a few minutes.

To confirm that the FortiGate-7000 is synchronized, go to **Monitor > Configuration Sync Monitor**. If the system is synchronized, all of the FIMs and FPMs should be visible and their **Configuration Status** should be **In Sync**. The Configuration Sync Monitor also indicates if any modules are not synchronized.

| Serial | Slot ID | Configuration Status | Role | Up Time | Last Heartbeat |
|------------------|---------|----------------------|--------|---------|----------------|
| FIM10E3E17000043 | 1 | In Sync | Master | 1d 5m | |
| FIM20E3E17000068 | 2 | In Sync | Slave | 1d 5m | 12 seconds ago |
| FPM20E3E16900213 | 4 | In Sync | Slave | 1d 5m | 12 seconds ago |
| FPM20E3E17900152 | 5 | In Sync | Slave | 1d 5m | 12 seconds ago |
| FPM20E3E17900223 | 3 | In Sync | Slave | 1d 5m | 12 seconds ago |
| FPM30E3E17900003 | 6 | In Sync | Slave | 1d 5m | 12 seconds ago |

You can also view the **Sensor Information** dashboard widget to confirm that system temperatures are normal and that all power supplies and fans are operating normally.



From the menu bar at the top of the GUI, you can click on the host name and pull down a list of the FIMs and FPMs in the FortiGate-7000. From the list you can see the status of each FIM or FPM, change the host name, or log into the GUI using the special management port number.

From the CLI you can use the `diagnose sys confsync status | grep in_sy` command to view the synchronization status of the FIMs and FPMs. If all of the FIMs and FPMs are synchronized, each output line should include `in_sync=1`. If a line ends with `in_sync=0`, that FIM or FPM is not synchronized. The following example just shows a few output lines:

```
diagnose sys confsync status | grep in_sy
FIM10E3E16000062, Slave, uptime=53740.68, priority=2, slot_id=2:2, idx=3, flag=0x10, in_sync=1
FIM04E3E16000010, Slave, uptime=53790.94, priority=3, slot_id=1:1, idx=0, flag=0x10, in_sync=1
FIM04E3E16000014, Master, uptime=53781.29, priority=1, slot_id=2:1, idx=1, flag=0x10, in_sync=1
FIM10E3E16000040, Slave, uptime=53707.36, priority=4, slot_id=1:2, idx=2, flag=0x10, in_sync=1
FPM20E3E16900234, Slave, uptime=53790.98, priority=16, slot_id=2:3, idx=4, flag=0x64, in_sync=1
FPM20E3E16900269, Slave, uptime=53783.67, priority=17, slot_id=2:4, idx=5, flag=0x64, in_sync=1
FPM20E3E17900113, Slave, uptime=53783.78, priority=116, slot_id=1:3, idx=6, flag=0x64, in_sync=1
FPM20E3E17900217, Slave, uptime=53784.11, priority=117, slot_id=1:4, idx=7, flag=0x64, in_sync=1
...
```

Configuration synchronization

When you log into the FortiGate-7000 GUI or CLI by connecting to the IP address of the aggregate management interface, or through a console connection, you are logging into the FIM in slot 1 (the address of slot 1 is FIM01). The FIM in slot 1 is the FortiGate-7000 config-sync master. All configuration changes must be made from the GUI or CLI of the FIM in slot 1. The FIM in slot 1 synchronizes configuration changes to the other modules and makes sure module configurations remain synchronized with the FIM in slot 1.

If the FIM in slot 1 fails or reboots, the FIM in slot 2 becomes the config-sync master.

Once you have logged into the GUI or CLI of the FIM in slot 1 and verified that the system is operating normally, you can view and change the configuration of your FortiGate-7000 just like any FortiGate. For example, you can configure firewall policies between any two interfaces. You can also configure aggregates of the front panel interfaces.

You can use the following command to confirm that the configurations of all of the FIMs and FPMs are synchronized:

```
diagnose sys confsync showcsum
```

The command output shows sets of checksums for each FIM and FPM in the FortiGate-7000. If the corresponding checksums are the same the configurations are synchronized.

FortiGate-7000 dashboard widgets

The FortiGate-7000 includes a number of custom dashboard widgets that provide extra or custom information for FortiGate-7000 systems.

Security Fabric

The Security Fabric dashboard widget shows the FIMs and FPMs in your FortiGate-7000 system. You can hover over the components in the Security Fabric dashboard widget to see details about each component's host name, serial number, model, firmware version, and management IP address.

Interface Bandwidth

You can add Interface Bandwidth dashboard widgets to view traffic in and out of any FortiGate-7000 interface. You can add an Interface Bandwidth widget to the dashboard for:

- Any physical interface
- Any link aggregation (LAG) interface
- Any member of a LAG
- Any VLAN interface
- Any IPsec VPN tunnel interface
- Any redundant interface

The displayed data includes all of the traffic processed by the interface, independent of how the traffic is load balanced.

You can add individual Interface Bandwidth widgets for each interface that you want to monitor. After you have added the widget you can choose to display traffic for the last hour, 24 hours or week. The data displayed on the widget updates in real time.

From the CLI, for physical interfaces, you can use the `diagnose hardware deviceinfo nic <interface-name>` command to view transmitted and received packets.

For LAG and VLAN interfaces you can display transmitted and received packets using the `diagnose netlink interface list <interface-name>` command.

Resource Usage

You can create multiple Resource Usage dashboard widgets to show CPU use, log rate, memory use, session creation rate, and the number of active sessions for the management board and for individual FPMs. After you have added the widget you can choose to display data for times ranging between 1 minute to 24 hours. The data displayed on the widget updates in real time.

Sensor Information

The Sensor Information dashboard widget displays temperature information for the FortiGate-7000 hardware and allows you to drill down for information about individual temperature sensors.

Setting up management connections

When your FortiGate-7000 first starts up, the MGMT1 to MGMT4 interfaces of both of the FIMs are part of a static 802.3 aggregate interface with a default IP address of 192.168.1.99. On the GUI or CLI the 802.3 aggregate interface is named **mgmt**.

Example mgmt interface configuration

| | |
|-------------------|---|
| Interface Name | mgmt |
| Alias | <input type="text"/> |
| Link Status | Up |
| Type | 802.3ad Aggregate |
| Virtual Domain | mgmt-vdom |
| Interface Members | <div> <div>1-mgmt1 ✕</div> <div>1-mgmt2 ✕</div> <div>1-mgmt3 ✕</div> <div>1-mgmt4 ✕</div> <div>2-mgmt1 ✕</div> <div>2-mgmt2 ✕</div> <div>2-mgmt3 ✕</div> <div>2-mgmt4 ✕</div> <div>+</div> </div> |
| Role | LAN ▼ |

Adding a password to the admin administrator account

For security purposes one of the first things you should do is add a password to the admin account.

Depending on your firmware version, when you first log into the GUI you maybe presented with an option to change the admin account password.

From the GUI, access the Global GUI and go to **System > Administrators**, edit the **admin** account, and select **Change Password**.

From the CLI:

```
config global
  config system admin
    edit admin
      set password <new-password>
    end
```

Using data interfaces for management traffic

Normally, all management traffic connects with the FortiGate-7000 through the FIM MGMT1, MGMT2, MGMT3, and MGMT4 interfaces. The FortiGate-7000 does also support management traffic connections to the FIM data interfaces. To enable management connections to these interfaces you must configure the VDOM that the data interfaces are included in to allow traffic forwarding to the primary FIM. By default, the root VDOM includes all of the data interfaces. To allow management communication between the root VDOM and the primary FIM, edit the root VDOM from the CLI and use the following command:

```
config vdom
  edit root
```

```
config system settings
    set motherboard-traffic-forwarding {icmp | admin}
end
```

The `icmp` option, enabled by default, allows you to log into the primary FIM from one of the MGMT interfaces and use the `execute ping` command to ping an address through one of the FIM data interfaces. The interface used depends on the routing configuration.

The `admin` option allows Telnet, SSH, HTTP, and HTTPS administrator connections from a management PC to a data interface. You cannot configure data interfaces to accept management connections using non-standard ports.



Currently, the `admin` setting is in development and not recommended.

Setting the MTU for a data interface

You can use the following command to change the MTU for a FortiGate-7000 data interface:

```
config system interface
    edit 1B5/1
        set mtu-override enable
        set mtu <value>
    end
```

For the FortGate-7000 the default `<value>` is 1500 and the range is 256 to 9198.

Replacing a failed FPM or FIM

This section describes how to remove a failed FPM or FIM and replace it with a new one. The procedure is slightly different depending on if you are operating in HA mode with two chassis or just operating a standalone chassis.

Replacing a failed module in a standalone FortiGate-7000 chassis

1. Power down the failed module by pressing the front panel power button.
2. Remove the module from the chassis.
3. Insert the replacement module. It should power up when inserted into the chassis if the chassis has power.
4. The module's configuration is synchronized and its firmware is upgraded to match the firmware version on the primary module. The new module reboots.
5. Confirm that the new module is running the correct firmware version either from the GUI or by using the `get system status` command.

Manually update the module to the correct firmware version if required. You can do this by logging into the module and performing a firmware upgrade. See [Firmware upgrades on page 48](#).

6. Verify that the configuration has been synchronized.

The following command output shows the sync status of the FIMs in a FortiGate-7000 chassis. The field `in_sync=1` indicates that the configurations of the modules are synchronized.

```
diagnose sys confsync status | grep in_sy
FIM04E3E16000080, Slave, uptime=177426.45, priority=2, slot_id=1:2, idx=0, flag=0x0, in_
sync=1
FIM10E3E16000063, Master, uptime=177415.38, priority=1, slot_id=1:1, idx=1, flag=0x0, in_
sync=1
...
```

If `in_sync` is not equal to 1 or if a module is missing in the command output you can try restarting the modules in the chassis by entering `execute reboot` from any module CLI. If this does not solve the problem, contact Fortinet support.

Replacing a failed module in a FortiGate-7000 chassis in an HA cluster

1. Power down the failed module by pressing the front panel power button.
2. Remove the module from the chassis.
3. Insert the replacement module. It should power up when inserted into the chassis if the chassis has power.
4. The module's configuration is synchronized and its firmware is upgraded to match the configuration and firmware version on the primary module. The new module reboots.
5. Confirm that the module is running the correct firmware version.

Manually update the module to the correct version if required. You can do this by logging into the module and performing a firmware upgrade.

6. Configure the new module for HA operation. For example:

```
config system ha
  set mode a-p
  set chassis-id 1
  set hbdev m1 m2
  set hbdev-vlan-id 999
  set hbdev-second-vlan-id 990
end
```

7. Optionally configure the hostname:

```
config system global
  set hostname <name>
end
```

The HA configuration and the hostname must be set manually because HA settings and the hostname is not synchronized.

8. Verify that the configuration has been synchronized.

The following command output shows the sync status of the FIMs in a FortiGate-7000 chassis. The field `in_sync=1` indicates that the configurations of the modules are synchronized.


```
diagnose sys confsync status | grep in_sy
FIM04E3E16000080, Slave, uptime=177426.45, priority=2, slot_id=1:2, idx=0, flag=0x0, in_
sync=1
FIM10E3E16000063, Master, uptime=177415.38, priority=1, slot_id=1:1, idx=1, flag=0x0, in_
sync=1
```

If `in_sync` is not equal to 1 or if a module is missing in the command output you can try restarting the modules in the chassis by entering `execute reboot` from any module CLI. If this does not solve the problem, contact Fortinet support at <https://support.fortinet.com>.

Connecting to module CLIs using the System Management Module

All FortiGate-7000 chassis includes a System Management Module (SMM) (also called a shelf manager) on the chassis front panel. See the system guide for your chassis for details about the SMM.

FortiGate-7040E SMM front panel



The SMM includes two console ports named Console 1 and Console 2 that can be used to connect to the CLI of the FIM and FPMs in the chassis. As described in the system guide, the console ports are also used to connect to SMC CLIs of the SMM and the FIM and FPMs

By default when the chassis first starts up, Console 1 is connected to the FortiOS CLI of the FIM in slot 1 and Console 2 is disconnected. The default settings for connecting to each console port are:

Baud Rate (bps) 9600, Data bits 8, Parity None, Stop bits 1, and Flow Control None.

You can use the console connection change buttons to select the CLI that each console port is connected to. Press the button to cycle through the FIM and FPM FortiOS CLIs and disconnect this console. The console's LEDs indicate what it is connected to. If no LED is lit the console is either connected to the SMM SMC SDI console or disconnected. Both console ports cannot be connected to the same CLI at the same time. If a console button press would cause a conflict that module is skipped. If one of the console ports is disconnected then the other console port can connect to any CLI.

If you connect a PC to one of the SMM console ports with a serial cable and open a terminal session you begin by pressing Ctrl-T to enable console switching mode. Press Ctrl-T multiple times to cycle through the FIM and FPM FortiOS CLIs (the new destination is displayed in the terminal window). If you press Ctrl-T after connecting to the FPM in the highest slot number, the console is disconnected. Press Ctrl-T again to start over again at slot 1.

Once the console port is connected to the CLI that you want to use, press Enter to enable the CLI and log in. The default administrator account for accessing the FortiOS CLIs is admin with no password.

When your session is complete you can press Ctrl-T until the prompt shows you have disconnected from the console.

Connecting to the FortiOS CLI of the FIM in slot 1

Use the following steps to connect to the FortiOS CLI of the FIM in slot 1:

1. Connect the console cable supplied with your chassis to Console 1 and to your PC or other device RS-232 console port.

2. Start a terminal emulation program on the management computer. Use these settings:
Baud Rate (bps) 9600, Data bits 8, Parity None, Stop bits 1, and Flow Control None.
3. Press Ctrl-T to enter console switch mode.
4. Repeat pressing Ctrl-T until you have connected to slot 1. Example prompt:
<Switching to Console: FIM01 (9600)>
5. Login with an administrator name and password.
The default is admin with no password. For security reasons, it is strongly recommended that you change the password.
6. When your session is complete, enter the `exit` command to log out.

Failover in a standalone FortiGate-7000

A FortiGate-7000 will continue to operate even if one of the FIMs or FPMs fails or is removed. If an FPM fails, sessions being processed by that FPM fail. All sessions are then load balanced to the remaining FPMs. Sessions that were being processed by the failed FPM are restarted and load balanced to the remaining FPMs.

If an FIM fails, the other FIM will continue to operate and will become the config-sync master. However, traffic received by the failed FIM will be lost.

You can use LACP or redundant interfaces to connect interfaces of both FIMs to the same network. In this way, if one of the FIMs fails, traffic will continue to be received by the other FIM.

Changing data interface network settings

To change the IP address of any FortiGate-7000E data interface:

- From the GUI access the Global GUI and go to **Network > Interfaces**. Edit any interface to change its IP address and other settings.
- From the CLI:

```
config system interface
    edit <interface-name>
        set ip <ip-address> <netmask>
    end
```

Resetting to factory defaults

At any time during the configuration process, if you run into problems, you can reset the FortiGate-7000E to factory defaults and start over. From the primary FIM CLI enter:

```
config global
    execute factoryreset
```

Restarting the FortiGate-7000E

To restart all of the modules in a FortiGate-7000E, connect to the primary FIM CLI and enter the `execute reboot` command. When you enter this command from the primary FIM, all of the modules restart.

To restart individual FIMs or FPMs, log in to the CLI of the module to restart and run the `execute reboot` command.

Packet sniffing for FIM and FPM packets

You can use the `diagnose sniffer packet` command to view or sniff packets as they are processed by FIM or FPMs. To use this command you have to be logged into a VDOM. You can run this command from any FIM or FPM CLI.

The command output includes the address of the slot containing the module that processed the packet. From the primary FIM, you can see packets processed by all of the FIMs and FPMs. From individual FIMs or FPMs you can see packets processed by that FIM or FPM.

From the primary FIM, you can enter the `diagnose sniffer options slot current` command to only see packets processed by the primary FIM. You can also enter the `diagnose sniffer options slot default` command to see packets processed by all modules.

The command syntax is:

```
diagnose sniffer packet <interface> <protocol-filter> <verbose> <count> <timestamp> <slot>
```

Where:

<interface> is the name of one or more interfaces on which to sniff for packets. Use `any` to sniff packets for all interfaces. To view management traffic use the `elbc-base-ctrl` interface name.

<protocol-filter> a filter to select the protocol for which to view traffic. This can be simple, such as entering `udp` to view UDP traffic or complex to specify a protocol, port, and source and destination interface and so on.

<verbose> the amount of detail in the output, and can be:

- 1 display packet headers only.
- 2 display packet headers and IP data.
- 3 display packet headers and Ethernet data (if available).
- 4 display packet headers and interface names.
- 5 display packet headers, IP data, and interface names.
- 6 display packet headers, Ethernet data (if available), and interface names.

<count> the number of packets to view. You can enter Ctrl-C to stop the sniffer before the count is reached.

<timestamp> the timestamp format, `a` for UTC time and `l` for local time.

Sample diagnose sniffer packet output from the primary FIM

```
[FPM04] 1.598890 3ffe:1:1:4::97b.13344 -> 3ffe:1:2:4::105.25: syn 151843506
[FPM03] 1.214394 802.1Q vlan#4022 P0 3ffe:1:1:2::214.10012 -> 3ffe:1:2:2::103.53: udp 30
[FIM02] 2.177930 llc unnumbered, 23, flags [poll], length 40
[FIM01] 1.583778 172.30.248.99.57167 -> 10.160.19.70.443: ack 2403720303
[FPM04] 1.598891 17.3.8.3.14471 -> 18.3.1.107.143: syn 2715027438 ^C
```

```
[FPM03] 1.214395 3ffe:1:1:2::214.10012 -> 3ffe:1:2:2::103.53: udp 30  
[FIM01] 1.583779 172.30.248.99.57167 -> 10.160.19.70.443: ack 2403720303
```

Managing individual FortiGate-7000 FIMs and FPMs

You can manage individual FIMs and FPMs using special port numbers or the `execute load-balance slot manage` command. You can also use the `execute ha manage` command to log in to the other FortiGate-7000 in an HA configuration.

Special management port numbers

In some cases you may want to connect to individual FIMs or FPMs to view status information or perform a maintenance task such as installing firmware or performing a restart. You can connect to the GUI or CLI of individual FIMs or FPMs in a FortiGate-7000 using the mgmt interface IP address with a special port number.



To enable using the special management port numbers to connect to individual FIMs and FPMs, the mgmt interface must be connected to a network, have a valid IP address, and have management or administrative access enabled. To block access to the special management port numbers, disconnect the mgmt interface from a network, configure the mgmt interface with an invalid IP address, or disable management or administrative access for the mgmt interface.

For example, if the mgmt interface IP address is 192.168.1.99, you can connect to the GUI of the FPM in slot 3 using the mgmt interface IP address followed by the special port number, for example:

```
https://192.168.1.99:44303
```

The special port number (in this case 44303) is a combination of the service port (for HTTPS, the service port is 443) and the slot number (in this example, 03).

You can view the special HTTPS management port number for and log in to the GUI of an FIM or FPM from the Configuration Sync Monitor.

The following table lists the special port numbers to use to connect to each FortiGate-7000 slot using common management protocols.



You can't change the special management port numbers. Changing configurable management port numbers, for example the HTTPS management port (which you might change to support SSL VPN), does not affect the special management port numbers.

FortiGate-7000 special management port numbers

| Slot Number | Slot Address | HTTP (80) | HTTPS (443) | Telnet (23) | SSH (22) | SNMP (161) |
|-------------|--------------|-----------|-------------|-------------|----------|------------|
| 5 | FPM05 | 8005 | 44305 | 2305 | 2205 | 16105 |

| Slot Number | Slot Address | HTTP (80) | HTTPS (443) | Telnet (23) | SSH (22) | SNMP (161) |
|-------------|--------------|-----------|-------------|-------------|----------|------------|
| 3 | FPM03 | 8003 | 44303 | 2303 | 2203 | 16103 |
| 1 | FIM01 | 8001 | 44301 | 2301 | 2201 | 16101 |
| 2 | FIM02 | 8002 | 44302 | 2302 | 2202 | 16102 |
| 4 | FPM04 | 8004 | 44304 | 2304 | 2204 | 16104 |
| 6 | FPM06 | 8006 | 44306 | 2306 | 2206 | 16106 |

For example, to connect to the GUI of the FIM in slot 2 using HTTPS you would browse to <https://192.168.1.99:44302>.

To verify which module you have logged into, the GUI header banner and the CLI prompt shows its hostname. The CLI prompt also shows slot address in the format `<hostname> [<slot address>] #`.

Logging in to different modules allows you to use FortiView or Monitor GUI pages to view the activity of that module. Even though you can log in to different modules, you can only make configuration changes from the primary FIM; which is usually the FIM in slot 1.

HA mode special management port numbers

In HA mode, you use the same special port numbers to connect to FIMs and FPMs in chassis 1 (chassis ID = 1) and different special port numbers to connect to FIMs and FPMs in chassis 2 (chassis ID = 2):

FortiGate-7000 HA special management port numbers

| Chassis and Slot Number | Slot Address | HTTP (80) | HTTPS (443) | Telnet (23) | SSH (22) | SNMP (161) |
|-------------------------|--------------|-----------|-------------|-------------|----------|------------|
| Ch1 slot 5 | FPM05 | 8005 | 44305 | 2305 | 2205 | 16105 |
| Ch1 slot 3 | FPM03 | 8005 | 44303 | 2303 | 2203 | 16103 |
| Ch1 slot 1 | FIM01 | 8003 | 44301 | 2301 | 2201 | 16101 |
| Ch1 slot 2 | FIM02 | 8002 | 44302 | 2302 | 2202 | 16102 |
| Ch1 slot 4 | FPM04 | 8004 | 44304 | 2304 | 2204 | 16104 |
| Ch1 slot 6 | FPM06 | 8006 | 44306 | 2306 | 2206 | 16106 |
| Ch2 slot 5 | FPM05 | 8005 | 44325 | 2325 | 2225 | 16125 |
| Ch2 slot 3 | FPM03 | 8005 | 44323 | 2323 | 2223 | 16123 |
| Ch2 slot 1 | FIM01 | 8003 | 44321 | 2321 | 2221 | 16121 |
| Ch2 slot 2 | FIM02 | 8002 | 44322 | 2322 | 2222 | 16122 |
| Ch2 slot 4 | FPM04 | 8004 | 44324 | 2324 | 2224 | 16124 |
| Ch2 slot 6 | FPM06 | 8006 | 44326 | 2326 | 2226 | 16126 |

Managing individual FIMs and FPMs from the CLI

From any CLI, you can use the `execute load-balance slot manage <slot>` command to log into the CLI of different FIMs and FPMs. You can use this command to view the status or configuration of the module, restart the module, or perform other operations. You should not change the configuration of individual FIMs or FPMs because this can cause configuration synchronization errors.

`<slot>` is the slot number of the slot that you want to log in to.

After you log in to a different module in this way, you can't use the `execute load-balance slot manage` command to log in to another module. Instead you must use the `exit` command to revert back to the CLI of the component that you originally logged in to. Then you can use the `execute load-balance slot manage` command to log into another module.

Firmware upgrades

In addition to introducing the basics of upgrading FortiGate-7000E firmware, this section describes how to:

- Upgrade the firmware running on individual FPCs.
- Upgrade the management board firmware from the BIOS and reset the configuration of all of the FPCs.

Firmware upgrade basics

All of the FIMs and FPMs in your FortiGate-7000 system run the same firmware image. You upgrade the firmware from the primary FIM GUI or CLI just as you would any FortiGate product.

You can perform a graceful firmware upgrade of a FortiGate-7000 FGCP HA cluster by enabling `uninterruptible-upgrade` and `session-pickup`. A graceful firmware upgrade only causes minimal traffic interruption. For more information about graceful HA upgrades, see [HA cluster firmware upgrades](#).

Upgrading the firmware of a standalone FortiGate-7000, or FortiGate-7000 HA cluster with `uninterruptable-upgrade` disabled interrupts traffic because the firmware running on the FIMs and FPMs upgrades in one step. These firmware upgrades should be done during a quiet time because traffic will be interrupted during the upgrade process.

A firmware upgrade takes a few minutes, depending on the number of FIMs and FPMs in your FortiGate-7000 system. Some firmware upgrades may take longer depending on factors such as the size of the configuration and whether an upgrade of the DP2 processor is included.

Before beginning a firmware upgrade, Fortinet recommends that you perform the following tasks:

- Review the latest release notes for the firmware version that you are upgrading to.
- Verify the recommended upgrade path as documented in the release notes.
- Back up your FortiGate-7000 configuration.



Fortinet recommends that you review the services provided by your FortiGate-7000 before a firmware upgrade and then again after the upgrade to make sure the services continues to operate normally. For example, you might want to verify that you can successfully access an important server used by your organization before the upgrade and make sure that you can still reach the server after the upgrade, and performance is comparable. You can also take a snapshot of key performance indicators (for example, number of sessions, CPU usage, and memory usage) before the upgrade and verify that you see comparable performance after the upgrade.

Verifying that a firmware upgrade is successful

After a FortiGate-7000 firmware upgrade, you should verify that all of the FIMs and FPMs have been successfully upgraded to the new firmware version.

After the firmware upgrade appears to be complete:

1. Log into the primary FIM and verify that it is running the expected firmware version.
You can verify the firmware version running on the primary FIM from the System Information dashboard widget or by using the `get system status` command.
2. Confirm that the FortiGate-7000 is synchronized.
Go to **Monitor > Configuration Sync Monitor** to verify the configuration status of the FIMs and FPMs. You can also use the `diagnose sys confsync status | grep in_sy` command to see if the FIMs and FPMs are all synchronized. In the command output, `in_sync=1` means the FIM or FPM is synchronized. `in_sync=0` means the FIM or FPM is not synchronized, which could indicate the FIM or FPM is running a different firmware build than the primary FIM.
3. Optionally, you can also log into the other FIM and FPMs, and in the same way confirm that they are also running the expected firmware version and are synchronized.

Upgrading the firmware running on individual FIMs or FPMs

You can install firmware on individual FIMs or FPMs by logging into the FIM or FPM GUI or CLI. You can also setup a console connection to the FortiGate-7000 front panel SMM and install firmware on individual FIMs or FPMs from a TFTP server after interrupting the FIM or FPM boot up sequence from the BIOS.

Normally you wouldn't need to upgrade the firmware on individual FIMs or FPMs because the FortiGate-7000 keeps the firmware on all of the FIMs and FPMs synchronized. However, FIM or FPM firmware may go out of sync in the following situations:

- Communication issues during a normal FortiGate-7000 firmware upgrade.
- Installing a replacement FIM or FPM that is running a different firmware version.
- Installing firmware on or formatting an FIM or FPM from the BIOS.

To verify the firmware versions on each FIM or FPM you can check individual FIM and FPM GUIs or enter the `get system status` command from each FIM or FPM CLI. You can also use the `diagnose sys confsync status | grep in_sy` command to see if the FIMs and FPMs are all synchronized. In the command output, `in_sync=1` means the FIM or FPM is synchronized. `in_sync=0` means the FIM or FPM is not synchronized, which could indicate the FIM or FPM is running a different firmware build than the primary FIM.

The procedures in this section work for FIMs or FPMs in a standalone FortiGate-7000. These procedures also work for FIMs or FPMs in the primary FortiGate-7000 in an HA configuration. To upgrade firmware on an FIM or FPM in the secondary FortiGate-7000 in an HA configuration, you should either remove the secondary FortiGate-7000 from the HA configuration or cause a failover so that the secondary FortiGate-7000 becomes the primary FortiGate-7000.

In general, if you need to update both FIMs and FPMs in the same FortiGate-7000, you should update the FIMs first as the FPMs can only communicate through FIM interfaces.

Upgrading FIM firmware

Use the following procedure to upgrade the firmware running on a single FIM. For this procedure to work, you must connect at least one of the FIM MGMT interfaces to a network. You must also be able to log in to the FIM GUI or CLI from that MGMT interface. If you perform the firmware upgrade from the CLI, the FIM must be able to communicate with an FTP or TFTP server.

During the upgrade, the FIM will not be able to process traffic. However, the other FIM and the FPMs should continue to operate normally.

1. Log into the FIM GUI or CLI and perform a normal firmware upgrade.
You may need to use the special port number to log in to the FIM in slot two (for example, browse to <https://192.168.1.99:44302>).
2. Once the FIM restarts, verify that the new firmware has been installed.
You can do this from the FIM GUI dashboard or from the FIM CLI using the `get system status` command.
3. Verify that the configuration has been synchronized to the upgraded FIM. The following command output shows the synchronization status of a FortiGate-7040E. The field `in_sync=1` indicates that the configurations of the FIMs and FPMs are synchronized.

```
diagnose sys confsync status | grep in_sy
FIM10E3E16000040, Slave, uptime=346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x4, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
```

FIMs and FPMs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FIM or FPM that is not synchronized, log into the CLI of the FIM or FPM and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.

The example output also shows that the uptime of the FIM in slot 2 is lower than the uptime of the other modules, indicating that the FIM in slot 2 has recently restarted.

If you enter the `diagnose sys confsync status | grep in_sy` command before the FIM has completely restarted, it will not appear in the command output. As well, the Configuration Sync Monitor will temporarily show that it is not synchronized.

Upgrading FPM firmware

Use the following procedure to upgrade the firmware running on an individual FPM. To perform the upgrade, you must enter a command from the primary FIM CLI to allow ELBC communication with the FPM. Then you can just log in to the FPM GUI or CLI and perform the firmware upgrade.

During this procedure, the FPM will not be able to process traffic. However, the other FPMs and the FIMs should continue to operate normally.

After verifying that the FPM is running the right firmware, you must log back into the primary FIM CLI and return the FPM to normal operation.

1. Log in to the primary FIM CLI and enter the following command:
`diagnose load-balance switch set-compatible <slot> enable elbc`
Where `<slot>` is the number of the FortiGate-7000 slot containing the FPM to be upgraded.
2. Log in to the FPM GUI or CLI using its special port number (for example, for the FPM in slot 3, browse to <https://192.168.1.99:44303> to connect to the GUI) and perform a normal firmware upgrade of the FPM.
3. After the FPM restarts, verify that the new firmware has been installed.
You can do this from the FPM GUI dashboard or from the FPM CLI using the `get system status` command.
4. Verify that the configuration has been synchronized. The following command output shows the sync status of a FortiGate-7040E. The field `in_sync=1` indicates that the configurations of the FIMs and FPMs are synchronized.

```
diagnose sys confsync status | grep in_sy
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
FPM20E3E17900217, Slave, uptime=387.74, priority=20, slot_id=1:4, idx=2, flag=0x4, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
```

FIMs and FPMs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FIM or FPM that is not synchronized, log into the CLI of the FIM or FPM and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.

The command output also shows that the uptime of the FPM in slot 4 is lower than the uptime of the other modules, indicating that the FPM in slot 4 has recently restarted.

If you enter the `diagnose sys confsync status | grep in_sy` command before the FIM has completely restarted, it will not appear in the command output. As well, the Configuration Sync Monitor will temporarily show that it is not synchronized.

5. Once the FPM is operating normally, log back in to the primary FIM CLI and enter the following command to reset the FPM to normal operation:

```
diagnose load-balance switch set-compatible <slot> disable
```

Configuration synchronization errors will occur if you do not reset the FPM to normal operation.

Installing FIM firmware from the BIOS after a reboot

Use the following procedure to upload firmware from a TFTP server to an FIM. The procedure involves creating a connection between the TFTP server and one of the FIM MGMT interfaces. You don't have to use a MGMT interface on the FIM that you are upgrading.

This procedure also involves connecting to the FIM CLI using a FortiGate-7000 front panel System Management Module console port. From the console session, the procedure describes how to restart the FIM, interrupting the boot process, and follow FIM BIOS prompts to install the firmware.

During this procedure, the FIM will not be able to process traffic. However, the other FIM and the FPMs should continue to operate normally.

1. Set up a TFTP server and copy the firmware file to the TFTP server default folder.
2. Set up your network to allow traffic between the TFTP server and one of the FIM MGMT interfaces.
If the MGMT interface you are using is one of the MGMT interfaces connected as a LAG to a switch, you must shutdown or disconnect all of the other interfaces that are part of the LAG from the switch. This includes MGMT interfaces from both FIMs.
3. Using the console cable supplied with your FortiGate-7000, connect the SMM Console 1 port on the FortiGate-7000 to the USB port on your management computer.
4. Start a terminal emulation program on the management computer. Use these settings:
Baud Rate (bps) 9600, Data bits 8, Parity None, Stop bits 1, and Flow Control None.
5. Press Ctrl-T to enter console switch mode.
6. Repeat pressing Ctrl-T until you have connected to the FIM to be updated. Example prompt for the FIM in slot 2:
<Switching to Console: FIM02 (9600)>

7. Optionally log in to the FIM's CLI.
8. Reboot the FIM.
You can do this using the `execute reboot` command from the CLI or by pressing the power switch on the FIM front panel.
9. When the FIM starts up, follow the boot process in the terminal session, and press any key when prompted to interrupt the boot process.
10. To set up the TFTP configuration, press C.
11. Use the BIOS menu to set the following. Change settings only if required.
[P]: Set image download port: MGMT1 (the connected MGMT interface.)
[D]: Set DHCP mode: Disabled
[I]: Set local IP address: The IP address of the MGMT interface that you want to use to connect to the TFTP server. This address must not be the same as the FortiGate-7000 management IP address and cannot conflict with other addresses on your network.
[S]: Set local Subnet Mask: Set as required for your network.
[G]: Set local gateway: Set as required for your network.
[V]: Local VLAN ID: Should be set to <none>. (use -1 to set the Local VLAN ID to <none>.)
[T]: Set remote TFTP server IP address: The IP address of the TFTP server.
[F]: Set firmware image file name: The name of the firmware image file that you want to install.
12. To quit this menu, press Q.
13. To review the configuration, press R.
To make corrections, press C and make the changes as required. When the configuration is correct, proceed to the next step.
14. To start the TFTP transfer, press T.
The firmware image is uploaded from the TFTP server and installed on the FIM. The FIM then restarts with its configuration reset to factory defaults. After restarting, the FIM configuration is synchronized to match the configuration of the primary FIM. The FIM restarts again and can start processing traffic.
15. Once the FIM restarts, verify that the correct firmware is installed.
You can do this from the FIM GUI dashboard or from the FPM CLI using the `get system status` command.
16. Verify that the configuration has been synchronized.
The following command output shows the sync status of a FortiGate-7040E. The field `in_sync=1` indicates that the configurations of the FIMs and FPMs are synchronized.

```
diagnose sys confsync status | grep in_sy
FIM10E3E16000040, Slave, uptime=346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x4, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
```

FIMs and FPMs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FIM or FPM that is not synchronized, log into the CLI of the FIM or FPM and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.

The command output also shows that the uptime of the FIM in slot 2 is lower than the uptime of the other modules, indicating that the FIM in slot 2 has recently restarted.

If you enter the `diagnose sys confsync status | grep in_sy` command before the FIM has restarted, it will not appear in the command output. As well, the Configuration Sync Monitor will temporarily show that it is not synchronized.

Installing FPM firmware from the BIOS after a reboot

Use the following procedure to upload firmware from a TFTP server to an FPM. To perform the upgrade, you must enter a command from the primary FIM CLI to allow the FPM BIOS to communicate through an FIM MGMT interface. The procedure involves creating a connection between the TFTP server and one of the FIM MGMT interfaces.

This procedure also involves connecting to the FPM CLI using a FortiGate-7000 front panel SMM console port, rebooting the FPM, interrupting the boot from the console session, and following FPM BIOS prompts to install the firmware.

During this procedure, the FPM will not be able to process traffic. However, the other FPMs and the FIMs should continue to operate normally.

After you verify that the FPM is running the right firmware, you must log back in to the primary FIM CLI and return the FPM to normal operation.

1. Set up a TFTP server and copy the firmware file into the TFTP server default folder.
2. Log into to the primary FIM CLI and enter the following command:
`diagnose load-balance switch set-compatible <slot> enable bios`
Where `<slot>` is the number of the FortiGate-7000 slot containing the FPM to be upgraded.
3. Set up your network to allow traffic between the TFTP server and a MGMT interface of one of the FIMs.
You can use any MGMT interface of either of the FIMs. When you set up the FPM TFTP settings below, you select the FIM that can connect to the TFTP server. If the MGMT interface you are using is one of the MGMT interfaces connected as a LAG to a switch, you must shutdown or disconnect all of the other interfaces that are part of the LAG from the switch. This includes MGMT interfaces from both FIMs
4. Using the console cable supplied with your FortiGate-7000, connect the SMM Console 1 port on the FortiGate-7000 to the USB port on your management computer.
5. Start a terminal emulation program on the management computer. Use these settings:
Baud Rate (bps) 9600, Data bits 8, Parity None, Stop bits 1, and Flow Control None.
6. Press Ctrl-T to enter console switch mode.
7. Repeat pressing Ctrl-T until you have connected to the module to be updated. Example prompt:
`<Switching to Console: FPM03 (9600)>`
8. Optionally log into the FPM's CLI.
9. Reboot the FPM.
You can do this using the `execute reboot` command from the FPM's CLI or by pressing the power switch on the FPM front panel.
10. When the FPM starts up, follow the boot process in the terminal session and press any key when prompted to interrupt the boot process.
11. To set up the TFTP configuration, press C.
12. Use the BIOS menu to set the following. Change settings only if required.
[P]: Set image download port: FIM01 (the FIM that can communicate with the TFTP server).
[D]: Set DHCP mode: Disabled.

[I]: Set local IP address: The IP address of the MGMT interface of the selected FIM that you want to use to connect to the TFTP server. This address must not be the same as the FortiGate-7000 management IP address and cannot conflict with other addresses on your network.

[S]: Set local Subnet Mask: Set as required for your network.

[G]: Set local gateway: Set as required for your network.

[V]: Local VLAN ID: Should be set to <none>. (use -1 to set the Local VLAN ID to <none>.)

[T]: Set remote TFTP server IP address: The IP address of the TFTP server.

[F]: Set firmware image file name: The name of the firmware image file that you want to install.

13. To quit this menu, press Q.

14. To review the configuration, press R.

To make corrections, press C and make the changes as required. When the configuration is correct proceed to the next step.

15. To start the TFTP transfer, press T.

The firmware image is uploaded from the TFTP server and installed on the FPM. The FPM then restarts with its configuration reset to factory defaults. After restarting, the FPM configuration is synchronized to match the configuration of the primary FPM. The FPM restarts again and can start processing traffic.

16. Once the FPM restarts, verify that the correct firmware is installed.

You can do this from the FPM GUI dashboard or from the FPM CLI using the `get system status` command.

17. Verify that the configuration has been synchronized.

The following command output shows the sync status of a FortiGate-7040E. The field `in_sync=1` indicates that the configurations of the FIMs and FPMs are synchronized.

```
diagnose sys confsync status | grep in_sy
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
FPM20E3E17900217, Slave, uptime=387.74, priority=20, slot_id=1:4, idx=2, flag=0x4, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
```

FIMs and FPMs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FIM or FPM that is not synchronized, log into the CLI of the FIM or FPM and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.

The command output also shows that the uptime of the FPM in slot 4 is lower than the uptime of the other modules, indicating that the FPM in slot 4 has recently restarted.

If you enter the `diagnose sys confsync status | grep in_sy` command before the FPM has restarted, it will not appear in the command output. As well, the Configuration Sync Monitor will temporarily show that it is not synchronized.

18. Once the FPM is operating normally, log back in to the primary FIM CLI and enter the following command to reset the FPM to normal operation:

```
diagnose load-balance switch set-compatible <slot> disable
```

Configuration synchronization errors will occur if you do not reset the FPM to normal operation.

Synchronizing FIMs and FPMs after upgrading the primary FIM firmware from the BIOS

After you install firmware on the primary FIM from the BIOS after a reboot, the firmware version and configuration of the primary FIM will most likely be not be synchronized with the other FIMs and FPMs. You can verify this from the primary FIM CLI using the `diagnose sys confsync status | grep in_sy` command. The `in_sync=0` entries in the following example output show that the management board (serial number ending in 10) is not synchronized with the other FIM and the FPMs shown in the example.

```
diagnose sys confsync status | grep in_sy
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=0
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=0
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
...
```

You can also verify synchronization status from the primary FIM Configuration Sync Monitor.

To re-synchronize the FortiGate-7000, which has the effect of resetting the other FIM and the FPMs, re-install firmware on the primary FIM.



You can also manually install firmware on each individual FIM and FPM from the BIOS after a reboot. This manual process is just as effective as installing the firmware for a second time on the primary FIM to trigger synchronization to the FIM and the FPMs, but takes much longer.

1. Log into the primary FIM GUI.
2. Install a firmware build on the primary FIM from the GUI or CLI. The firmware build you install on the primary FIM can either be the same firmware build or a different one.
Installing firmware synchronizes the firmware build and configuration from the primary FIM to the other FIM and the FPMs.
3. Check the synchronization status from the Configuration Sync Monitor or using the `diagnose sys confsync status | grep in_sy` command. The following example ForGate-7040E shows that the primary FIM is synchronized with the other FIM and all of the FPMs because each line includes `in_sync=1`:

```
diagnose sys confsync status | grep in_sy
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x4, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FIM04E3E16000010, Master, uptime=69398.91, priority=1, slot_id=1:1, idx=0, flag=0x0, in_sync=1
FIM10E3E16000040, Slave, uptime=69346.99, priority=2, slot_id=1:2, idx=1, flag=0x0, in_sync=1
FPM20E3E17900217, Slave, uptime=69387.74, priority=20, slot_id=1:4, idx=2, flag=0x64, in_sync=1
```

Load balancing and flow rules

This chapter provides an overview of how FortiGate-7000 Session-Aware Load Balancing (SLBC) works and then breaks down the details and explains why you might want to change some load balancing settings.

FortiGate-7000 SLBC works as follows.

1. The FortiGate-7000 directs all traffic that does not match a load balancing flow rule to the DP2 processors.
If a session matches a flow rule, the session skips the DP2 processors and is directed according to the action setting of the flow rule. Default flow rules send traffic that can't be load balanced to the primary (master) FPM. See [Default configuration for traffic that cannot be load balanced on page 62](#).
2. The DP2 processors load balance TCP, UDP, SCTP, and IPv4 ICMP sessions among the FPMs according to the load balancing method set by the `dp-load-distribution-method` option of the `config load-balance setting` command.
3. The DP2 processors send other sessions that cannot be load balanced to the primary (or master) FPM.

Setting the load balancing method

Sessions are load balanced or distributed based on the load balancing method set by the following command:

```
config load-balance setting
    set dp-load-distribution-method {to-master | src-ip | dst-ip | src-dst-ip | src-ip-sport |
        dst-ip-dport | src-dst-ip-sport-dport}
end
```

Where:

`to-master` directs all session to the primary FPM. This method is for troubleshooting only and should not be used for normal operation. Directing all sessions to the primary FPM will have a negative impact on performance.

`src-ip` sessions are distributed across all FPMs according to their source IP address.

`dst-ip` sessions are statically distributed across all FPMs according to their destination IP address.

`src-dst-ip` sessions are distributed across all FPMs according to their source and destination IP addresses.

`src-ip-sport` sessions are distributed across all FPMs according to their source IP address and source port.

`dst-ip-dport` sessions are distributed across all FPMs according to their destination IP address and destination port.

`src-dst-ip-sport-dport` sessions are distributed across all FPMs according to their source and destination IP address, source port, and destination port. This is the default load balance algorithm and represents true session-aware load balancing. All session information is taken into account when deciding where to send new sessions and where to send additional packets that are part of an already established session.

The `src-ip` and `dst-ip` load balancing methods use layer 3 information (IP addresses) to identify and load balance sessions. All of the other load balancing methods (except for `to-master`) use both layer 3 and layer 4 information (IP addresses and port numbers) to identify a TCP and UDP session. The layer 3 and layer 4 load balancing methods only

use layer 3 information for other types of traffic (SCTP, ICMP, and ESP). If GTP load balancing is enabled, Tunnel Endpoint Identifiers (TEIDs) are used to identify GTP sessions.

Flow rules for sessions that cannot be load balanced

Some traffic types cannot be load balanced. Sessions for traffic types that cannot be load balanced should normally be sent to the primary (or master) FPM by configuring flow rules for that traffic. You can also configure flow rules to send traffic that cannot be load balanced to specific FPMs.

Create flow rules using the `config load-balance flow-rule` command. The default configuration uses this command to send IKE, GRE, session helper, Kerberos, BGP, RIP, IPv4 and IPv6 DHCP, PPTP, BFD, IPv4 multicast and IPv6 multicast to the primary FPM. You can view the default configuration of the `config loadbalance flow-rule` command to see how this is all configured or see [Default configuration for traffic that cannot be load balanced on page 62](#).

For example, the following configuration sends all IKE sessions to the primary FPM:

```
config load-balance flow-rule
edit 1
    set status enable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 500-500
    set dst-l4port 500-500
    set action forward
    set forward-slot master
    set priority 5
    set comment "ike"
next
edit 2
    set status disable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 4500-4500
    set dst-l4port 0-0
    set action forward
    set forward-slot master
    set priority 5
    set comment "ike-natt src"
next
edit 3
    set status disable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 4500-4500
    set action forward
    set forward-slot master
    set priority 5
    set comment "ike-natt dst"
next
```

Determining the primary FPM

You can determine which FPM is operating as the primary (master) FPM by hovering over the FPMs in the Security Fabric dashboard widget. The FPM operating as the primary FPM will have a **Status** of **Master Blade**.

You can also use the `diagnose load-balance status` command to determine which FPM is operating as the primary FPM.

The following example `diagnose load-balance status` output for a FortiGate-7060E shows that the FPM in slot 3 is the primary (master) FPM. The command output also shows the status of all of the FPMs in the FortiGate-7060E. The output also shows that the FPM in slot 4 is either missing or down.

```
diagnose load-balance status
=====
Slot: 2  Module SN: FIM04E3E16000222
  FIM02: FIM04E3E16000222
  Master FPM Blade: slot-3

  Slot 3: FPM20E3E17900133
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good  Data: Good
    Status Message:"Running"
  Slot 4:
    Status:Dead      Function:Active
    Link:          Base: Up          Fabric: Down
    Heartbeat: Management: Failed Data: Failed
    Status Message:"Waiting for management heartbeat."
  Slot 5: FPM20E3E17900152
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good  Data: Good
    Status Message:"Running"
  Slot 6: FPM20E3E17900202
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good  Data: Good
    Status Message:"Running"
```

SSL VPN load balancing

FortiGate-7000s do not support load balancing SSL VPN sessions terminated by the FortiGate-7000. The recommended configuration is to direct SSL VPN sessions terminated by the FortiGate-7000 to the primary FPM.



SSL VPN sessions are sessions from an SSL VPN client to your configured SSL VPN server listening port.

Using a FortiGate-7000 as an SSL VPN server requires you to manually add an SSL VPN load balance flow rule to configure the FortiGate-7000 to send all SSL VPN sessions to the primary (master) FPM. To match with the SSL VPN

server traffic, the rule should include a destination port that matches the destination port of the SSL VPN server. A basic rule to allow SSL VPN traffic could be:

```
config load-balance flow-rule
  edit 0
    set status enable
    set ether-type ipv4
    set protocol tcp
    set dst-l4port 443-443
    set forward-slot master
    set comment "ssl vpn server to primary FPM"
  end
```

This flow rule matches all sessions sent to port 443 (the default SSL VPN server listening port) and sends these sessions to the primary FPM. This should match all of your SSL VPN traffic if you are using the default SSL VPN server listening port (443). This flow rule also matches all other sessions using 443 as the destination port so all of this traffic is also sent to the primary FPM.

If you change the SSL VPN server listening port

If you have changed the SSL VPN server listening port to 10443, you can change the SSL VPN flow rule as follows. This example also sets the source interface to port12, which is the SSL VPN server interfaces, instead of adding the IP address of port12 to the configuration:

```
config load-balance flow-rule
  edit 26
    set status enable
    set ether-type ipv4
    set protocol tcp
    set src-interface port12
    set dst-l4port 10443-10443
    set forward-slot master
    set comment "ssl vpn server to primary FPM"
  end
```

Adding the SSL VPN server IP address

You can add the IP address of the FortiGate-7000 interface that receives SSL VPN traffic to the SSL VPN flow rule to make sure that the flow rule only matches SSL VPN server settings. For example, if the IP address of the interface is 172.25.176.32 and the SSL VPN flow rule ID is 26:

```
config load-balance flow-rule
  edit 26
    set status enable
    set ether-type ipv4
    set protocol tcp
    set dst-addr-ipv4 172.25.176.32 255.255.255.255
    set dst-l4port 10443-10443
    set forward-slot master
    set comment "ssl vpn server to primary FPM"
  end
```

This flow rule will now only match SSL VPN sessions with 172.25.176.32 as the destination address and send all of these sessions to the primary FPM.

FortiOS Carrier GTP load balancing

If you are operating a FortiGate-7000 system that is licensed for FortiOS Carrier (also called FortiCarrier), you can use the information in this section to optimize GTP performance. The commands and settings in this chapter only apply if your FortiGate-7000 has a FortiOS Carrier license.

Optimizing NPU GTP performance

You can use the following command to optimize GTP performance:

```
config system npu
    set gtp-enhance-mode enable
end
```

Enabling `gtp-enhance-mode` usually improves GTP performance.

GTP-C load balancing

By default and for the best GTP-C tunnel setup and throughput performance, FortiGate-7000 systems licensed for FortiOS Carrier load balance GTP-C traffic to all FPMs. Normally you should use this default configuration for optimum GTP-C performance.

If you want GTP-C traffic to only be processed by the primary (or master) FPM, you can edit the following flow rule and set `status` to `enable`. When enabled, this flow rule sends all GTP-C traffic to the primary FPM. Enabling this flow rule can reduce GTP performance, since all GTP-C tunnel setup sessions will be done by the primary FPM and not distributed among all of the FPMs.

```
config load-balance flow-rule
    edit 17
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 0.0.0.0 0.0.0.0
        set protocol udp
        set src-l4port 0-0
        set dst-l4port 2123-2123
        set action forward
        set forward-slot master
        set priority 5
        set comment "gtp-c to master blade"
    end
```

GTP-U load balancing

To load balance GTP-U traffic, in addition to enabling `gtp-enhance-mode`, you should enable the following option:

```
config load-balance setting
    set gtp-load-balance enable
end
```

Enabling this option load balances GTP-U sessions to all of the FPMs. GTP-U load balancing uses Tunnel Endpoint Identifiers (TEIDs) to identify and load balance sessions.

Adding a flow rule to support DHCP relay

The FortiGate-7000 default flow rules may not handle DHCP relay traffic correctly.

The default configuration includes the following flow rules for DHCP traffic:

```
config load-balance flow-rule
  edit 7
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 67-67
    set dst-l4port 68-68
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv4 server to client"
  next
  edit 8
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 68-68
    set dst-l4port 67-67
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv4 client to server"
  end
```

These flow rules handle traffic when the DHCP client sends requests to a DHCP server using port 68 and the DHCP server responds using port 67. However, if DHCP relay is involved, requests from the DHCP relay to the DHCP server and replies from the DHCP server to the DHCP relay both use port 67. If this DHCP relay traffic passes through the FortiGate-7000 you must add a flow rule similar to the following to support port 67 DHCP traffic in both directions:

```
config load-balance flow-rule
  edit 8
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 67-67
    set dst-l4port 67-67
    set action forward
```

```
set forward-slot master
set priority 5
set comment "dhcpv4 relay"
next
```

Default configuration for traffic that cannot be load balanced

The default FortiGate-7000 `configure load-balance flow-rule` command contains the recommended default rules for how the FortiGate-7000 handles traffic types that cannot be load balanced. All of these flow rules identify the traffic type using the options available in the command and direct the traffic to the primary (or master) FPM. The rules also include a comment that identifies the traffic type.

Most of the flow rules are enabled (status set to `enable`) and they will direct matching traffic to the primary FPM. However, the configuration does include some disabled flow rules. You can enable these flow rules if required for your network.

The CLI syntax below was created with the `show` command and just shows the configuration changes. All other options are set to their defaults. Flow rules with no `status` option are disabled by default. Also the default `forward-slot` setting is `master`, which directs matching traffic to the primary FPM.

```
config load-balance flow-rule
  edit 1
    set status disable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 88-88
    set dst-l4port 0-0
    set action forward
    set forward-slot master
    set priority 5
    set comment "kerberos src"
  next
  edit 2
    set status disable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 88-88
    set action forward
    set forward-slot master
    set priority 5
    set comment "kerberos dst"
  next
  edit 3
    set status enable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 179-179
    set dst-l4port 0-0
    set tcp-flag any
```

```
        set action forward
        set forward-slot master
        set priority 5
        set comment "bgp src"
    next
    edit 4
        set status enable
        set vlan 0
        set ether-type ip
        set protocol tcp
        set src-l4port 0-0
        set dst-l4port 179-179
        set tcp-flag any
        set action forward
        set forward-slot master
        set priority 5
        set comment "bgp dst"
    next
    edit 5
        set status enable
        set vlan 0
        set ether-type ip
        set protocol udp
        set src-l4port 520-520
        set dst-l4port 520-520
        set action forward
        set forward-slot master
        set priority 5
        set comment "rip"
    next
    edit 6
        set status enable
        set vlan 0
        set ether-type ipv6
        set src-addr-ipv6 ::/0
        set dst-addr-ipv6 ::/0
        set protocol udp
        set src-l4port 521-521
        set dst-l4port 521-521
        set action forward
        set forward-slot master
        set priority 5
        set comment "ripng"
    next
    edit 7
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 0.0.0.0 0.0.0.0
        set protocol udp
        set src-l4port 67-67
        set dst-l4port 68-68
        set action forward
        set forward-slot master
        set priority 5
```

```
        set comment "dhcpv4 server to client"
next
edit 8
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 68-68
    set dst-l4port 67-67
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv4 client to server"
next
edit 9
    set status disable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 1723-1723
    set dst-l4port 0-0
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "pptp src"
next
edit 10
    set status disable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 0-0
    set dst-l4port 1723-1723
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "pptp dst"
next
edit 11
    set status enable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 3784-3784
    set action forward
    set forward-slot master
    set priority 5
    set comment "bfd control"
next
edit 12
    set status enable
```



```
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 3785-3785
    set action forward
    set forward-slot master
    set priority 5
    set comment "bfd echo"
next
edit 13
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol udp
    set src-l4port 547-547
    set dst-l4port 546-546
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv6 server to client"
next
edit 14
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol udp
    set src-l4port 546-546
    set dst-l4port 547-547
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv6 client to server"
next
edit 15
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 224.0.0.0 240.0.0.0
    set protocol any
    set action forward
    set forward-slot master
    set priority 5
    set comment "ipv4 multicast"
next
edit 16
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ff00::/8
```

```
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv6 multicast"
    next
edit 17
    set status disable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 2123-2123
    set action forward
    set forward-slot master
    set priority 5
    set comment "gtp-c to master blade"
next
edit 18
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 500-500
    set action forward
    set forward-slot master
    set priority 5
    set comment "ipv6 ike"
next
edit 19
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 4500-4500
    set action forward
    set forward-slot master
    set priority 5
    set comment "ipv6 ike-natt dst"
next
edit 20
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol esp
    set action forward
```

```
        set forward-slot master
        set priority 5
        set comment "ipv6 esp"
    next
    edit 21
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 0.0.0.0 0.0.0.0
        set protocol udp
        set src-l4port 0-0
        set dst-l4port 500-500
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv4 ike"
    next
    edit 22
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 0.0.0.0 0.0.0.0
        set protocol udp
        set src-l4port 0-0
        set dst-l4port 4500-4500
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv4 ike-natt dst"
    next
    edit 23
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 0.0.0.0 0.0.0.0
        set protocol esp
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv4 esp"
    next
    edit 24
        set status enable
        set vlan 0
        set ether-type ip
        set protocol tcp
        set src-l4port 0-0
        set dst-l4port 1000-1000
        set tcp-flag any
        set action forward
        set forward-slot master
        set priority 5
        set comment "authd http to master blade"
```

```
next
edit 25
    set status enable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 0-0
    set dst-l4port 1003-1003
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "authd https to master blade"
next
edit 26
    set status enable
    set vlan 0
    set ether-type ip
    set protocol vrrp
    set action forward
    set forward-slot all
    set priority 6
    set comment "vrrp to all blades"
next
end
```

FortiGate-7000 IPsec VPN

This chapter highlights special FortiGate-7000 VPN features and configurations.

New IPsec VPN features

FortiOS 5.6 includes the following IPsec VPN improvements:

- Including a phase 2 selector is no longer mandatory.
- Dynamic routing (RIP, OSPF, BGP) is supported over IPsec VPN tunnels.

IPsec VPN features supported by FortiOS 5.6 for FortiGate-7000

FortiOS 5.6 for FortiGate-7000 supports the following IPsec VPN features.

- Interface-based IPsec VPN (also called route-based IPsec VPN) is supported.
- Static routes can point at IPsec VPN interfaces.
- Dynamic routing (RIP, OSPF, BGP) over IPsec VPN tunnels is supported.
- Remote networks with 16- to 32-bit netmasks are supported.
- IPsec VPN tunnels must terminate on the primary (master) FPM.
- Site-to-Site IPsec VPN is supported.
- Dialup IPsec VPN is supported. The FortiGate-7000 can be the dialup server or client.
- IPv4 clear-text traffic (IPv4 over IPv4 or IPv4 over IPv6) is supported.

IPsec VPN features not supported by FortiOS 5.6 for FortiGate-7000

FortiOS 5.6 for FortiGate-7000 does not support the following IPsec VPN features.


- Policy-based IPsec VPN is not supported. Only tunnel or interface mode IPsec VPN is supported.
- Policy routes cannot be used for communication over IPsec VPN tunnels.
- Remote networks with 0- to 15-bit netmasks are not supported. Remote networks with 16- to 32-bit netmasks are supported.
- IPv6 clear-text traffic (IPv6 over IPv4 or IPv6 over IPv6) is not supported.
- Load balancing IPsec VPN tunnels to multiple FPMs is not supported.
- IPsec SA synchronization between HA peers is not supported. After an HA failover, IPsec VPN tunnels have to be re-initialized.

Configuring the FortiGate-7000 as a dialup IPsec VPN server

FortiGate-7000s can be configured as dialup IPsec VPN servers or clients.

Example dialup IPsec VPN server configuration

The following shows how to setup a dialup IPsec VPN configuration where the FortiGate-7000 acts as a dialup IPsec VPN server.



To configure the FortiGate-7000 as a dialup IPsec VPN server:

```
Configure the phase1, set type to dynamic.
config vpn ipsec phase1-interface
  edit dialup-server
    set type dynamic
    set interface "v0020"
    set peertype any
    set psksecret < password>
  end
```

Configure the phase 2, to support dialup IPsec VPN, set the destination subnet to 0.0.0.0 0.0.0.0.

```
config vpn ipsec phase2-interface
  edit dialup-server
    set phase1name dialup-server
    set src-subnet 4.2.0.0 255.255.0.0
    set dst-subnet 0.0.0.0 0.0.0.0
  end
```

To configure the remote FortiGate as a dialup IPsec VPN client

The dialup IPsec VPN client should advertise its local subnet(s) using the phase 2 src-subnet option.



If there are multiple local subnets create a phase 2 for each one. Each phase 2 only advertises one local subnet to the dialup IPsec VPN server. If more than one local subnet is added to the phase 2, only the first one is advertised to the server.

Dialup client configuration:

```
config vpn ipsec phase1-interface
  edit "to-fgt7k"
    set interface "v0020"
    set peertype any
    set remote-gw 1.2.0.1
    set psksecret <password>
  end
config vpn ipsec phase2-interface
  edit "to-fgt7k"
    set phase1name "to-fgt7k"
    set src-subnet 4.2.6.0 255.255.255.0
    set dst-subnet 4.2.0.0 255.255.0.0
  next
  edit "to-fgt7k-2"
    set phase1name "to-fgt7k"
    set src-subnet 4.2.7.0 255.255.255.0
    set dst-subnet 4.2.0.0 255.255.0.0
  end
```

Troubleshooting

Use the following commands to verify that IPsec VPN sessions are up and running.

Use the `diagnose load-balance status` command from the primary FIM interface module to determine the primary FPM processor module. For FortiGate-7000 HA, run this command from the primary FortiGate-7000. The third line of the command output shows which FPM is operating as the primary FPM.

```
diagnose load-balance status
FIM01: FIM04E3E16000074
Master FPM Blade: slot-4

Slot 3: FPM20E3E17900113
  Status:Working  Function:Active
  Link:          Base: Up          Fabric: Up
  Heartbeat: Management: Good      Data: Good
  Status Message:"Running"
Slot 4: FPM20E3E16800033
  Status:Working  Function:Active
  Link:          Base: Up          Fabric: Up
  Heartbeat: Management: Good      Data: Good
  Status Message:"Running"

FIM02: FIM10E3E16000040
Master FPM Blade: slot-4

Slot 3: FPM20E3E17900113
```

```

Status:Working   Function:Active
Link:           Base: Up           Fabric: Up
Heartbeat: Management: Good   Data: Good
Status Message:"Running"
Slot 4: FPM20E3E16800033
Status:Working   Function:Active
Link:           Base: Up           Fabric: Up
Heartbeat: Management: Good   Data: Good
Status Message:"Running"

```

Log into the primary FPM CLI and from here log into the VDOM that you added the tunnel configuration to and run the command `diagnose vpn tunnel list <phase2-name>` to show the sessions for the phase 2 configuration. The example below is for the `to-fgt2` phase 2 configuration configured previously in this chapter. The command output shows the security association (SA) setup for this phase 2 and the all of the destination subnets .

From the command output, make sure the SA is installed and the `dst` addresses are correct.

```

CH15 [FPM04] (002ipsecvpn) # diagnose vpn tunnel list name to-fgt2
list ipsec tunnel by names in vd 11
-----
name=to-fgt2 ver=1 serial=2 4.2.0.1:0->4.2.0.2:0
bound_if=199 lgwy=static/1 tun=intf/0 mode=auto/1 encap=none/40 options[0028]=npu ike_assit
proxyid_num=1 child_num=0 refcnt=8581 ilast=0 olast=0 auto-discovery=0
ike_asssit_last_sent=4318202512
stat: rxp=142020528 txp=147843214 rxb=16537003048 txb=11392723577
dpd: mode=on-demand on=1 idle=20000ms retry=3 count=0 seqno=2
natt: mode=none draft=0 interval=0 remote_port=0
proxyid=to-fgt2 proto=0 sa=1 ref=8560 serial=8
src: 0:4.2.1.0/255.255.255.0:0 0:4.2.2.0/255.255.255.0:0
dst: 0:4.2.3.0/255.255.255.0:0 0:4.2.4.0/255.255.255.0:0 0:4.2.5.0/255.255.255.0:0
SA: ref=7 options=22e type=00 soft=0 mtu=9134 expire=42819/0B replaywin=2048 seqno=4a26f
esn=0 replaywin_lastseq=00045e80
life: type=01 bytes=0/0 timeout=43148/43200
dec: spi=e89caf36 esp=aes key=16 26aa75c19207d423d14fd6fef2de3bcf
    ah=sha1 key=20 7d1a330af33fa914c45b80c1c96eafaf2d263ce7
enc: spi=b721b907 esp=aes key=16 acb75d21c74eabc58f52ba96ee95587f
    ah=sha1 key=20 41120083d27eb1d3c5c5e464d0a36f27b78a0f5a
dec:pkts/bytes=286338/40910978, enc:pkts/bytes=562327/62082855
npu_flag=03 npu_rgw=4.2.0.2 npu_lgwy=4.2.0.1 npu_selid=b dec_npuid=3 enc_npuid=1

```

Log into the CLI of any of the FIMs and run the command `diagnose test application fctrlproxyd 2`. The output should show matching destination subnets.

```

diagnose test application fctrlproxyd 2

fcp route dump : last_update_time 24107


Slot:4
routecache entry: (5)
checksum:27 AE 00 EA 10 8D 22 0C D6 48 AB 2E 7E 83 9D 24
vd:3 p1:to-fgt2 p2:to-fgt2 subnet:4.2.3.0 mask:255.255.255.0 enable:1
vd:3 p1:to-fgt2 p2:to-fgt2 subnet:4.2.4.0 mask:255.255.255.0 enable:1
vd:3 p1:to-fgt2 p2:to-fgt2 subnet:4.2.5.0 mask:255.255.255.0 enable:1
=====

```


FortiGate-7000 high availability

FortiGate-7000 supports a variation of active-passive FortiGate Clustering Protocol (FGCP) high availability (HA) between two identical FortiGate-7000s. With active-passive FortiGate-7000 HA, you create redundant network connections to two identical FortiGate-7000s and add redundant HA heartbeat connections. Then you configure each FortiGate-7000 for HA. The FGCP forms a cluster and selects a primary FortiGate-7000. You can set device priorities and enable override to select the primary FortiGate-7000.

Example FortiGate-7040 HA configuration



The primary FortiGate-7000 processes all traffic. The secondary FortiGate-7000 operates in hot standby mode. The FGCP synchronizes the configuration, active sessions, routing information, and so on to the secondary FortiGate-7000. If the primary FortiGate-7000 fails, traffic automatically fails over to the secondary FortiGate-7000.

New HA features and changes

Configuring FortiGate-7000 HA has been simplified for FortiOS 5.6.6. To set up HA, you no longer have to configure HA settings for both of the FIMs in a FortiGate-7000. Instead, you configure HA settings on the primary FIM and this configuration is synchronized to the other FIM.

As well, FortiGate-7000 HA is configured and operates more like standard FGCP HA. The link failure threshold concept that was part of FortiGate-7000 for FortiOS 5.4 has been removed and board failover tolerance has been simplified. As well, primary unit selection has been simplified to be more like FGCP primary unit selection.

FortiOS 5.6.6 also includes the following new features and changes:

- The **System > HA** GUI page now appears and can be used to configure most HA settings.
- You can configure HA interface monitoring (or port monitoring) to detect link failures.
- You can configure HA remote link failover (also called remote IP monitoring) to detect remote link failures using the following options:
 - Enable remote IP monitoring with the `pingserver-monitor-interface` option.
 - Set the remote IP monitoring failover threshold with the `pingserver-failover-threshold` option.
 - Force the cluster to negotiate after a remote IP monitoring failover with the `pingserver-slave-force-reset` option.
 - Adjust the time to wait in minutes before renegotiating after a remote IP monitoring failover with the `pingserver-flip-timeout` option.
- You can use the `get system ha status` command to display HA status. The `diagnose sys ha status` command is no longer available.
- The `diagnose sys ha force-slave-state` command is no longer available. To force the primary FortiGate-7000 into a secondary (or slave) state you can use the `diagnose sys ha reset-uptime` command.
- The HA `link-failure-threshold` option has been removed.
- The `board-failover-tolerance` option has been simplified and determines how the cluster responds to failed FIMs.

Failover protection

FortiGate-7000 HA supports failover protection to provide FortiOS services even when one of the FortiGate-7000s encounters a problem that would result in partial or complete loss of connectivity or reduced performance for a standalone FortiGate-7000. This failover protection provides a backup mechanism that can be used to reduce the risk of unexpected downtime, especially in a mission-critical environment.

To achieve failover protection in a FortiGate-7000 cluster, one of the FortiGate-7000s functions as the primary, processing traffic and the other as the secondary, operating in an active stand-by mode. The cluster IP addresses and HA virtual MAC addresses are associated with the interfaces of the primary. All traffic directed at the cluster is actually sent to and processed by the primary.

While the cluster is functioning, the primary FortiGate-7000 functions as the FortiGate network security device for the networks that it is connected to. In addition, the primary FortiGate-7000 and the secondary FortiGate-7000 use the HA heartbeat to keep in constant communication. The secondary FortiGate-7000 reports its status to the primary FortiGate-7000 and receives and stores connection and state table updates from the primary FortiGate-7000.

FortiGate-7000 HA supports three kinds of failover protection:

- Device failure protection automatically replaces a failed device and restarts traffic flow with minimal impact on the network.
- Module failure protection makes sure that traffic is processed by the FortiGate-6000 with the most operating FIMs and FPMs.
- Link failure protection maintains traffic flow if a link fails.
- Session failure protection resumes communication sessions with minimal loss of data if a device, module, or link failure occurs.

Device failure

If the primary FortiGate-7000 encounters a problem that is severe enough to cause it to fail, the secondary FortiGate-7000 becomes new primary FortiGate-7000. This occurs because the secondary FortiGate-7000 is constantly waiting to negotiate to become primary FortiGate-7000. Only the heartbeat packets sent by the primary FortiGate-7000 keep the secondary FortiGate-7000 from becoming the primary FortiGate-7000. Each received heartbeat packet resets a negotiation timer in the secondary FortiGate-7000. If this timer is allowed to run out because the secondary FortiGate-7000 does not receive heartbeat packets from the primary FortiGate-7000, the secondary FortiGate-7000 assumes that the primary FortiGate-7000 has failed and becomes the primary FortiGate-7000.

The new primary FortiGate-7000 will have the same MAC and IP addresses as the former primary FortiGate-7000. The new primary FortiGate-7000 then sends gratuitous ARP packets out all of its connected interfaces to inform attached switches to send traffic to the new primary FortiGate-7000. Sessions then resume with the new primary FortiGate-7000.

Module failure

If one or more modules (FIMs and FPMs) in the primary FortiGate-7000 fails, the cluster renegotiates and the FortiGate-7000 with the most operating modules becomes the primary FortiGate-7000. A module failure can occur if a module shuts down due to a software crash or hardware problem, or if the module is manually shut down or even removed from the chassis.

After the primary FortiGate-7000 experiences a module failure, the FortiGate-7000 with the most operating modules becomes the new primary FortiGate-7000. The new primary FortiGate-7000 sends gratuitous arp packets out all of its connected interfaces to inform attached switches to send traffic to it. Sessions then resume with the new primary FortiGate-7000.

If the secondary FortiGate-7000 experiences a module failure, its status in the cluster does not change. However, in future negotiations the FortiGate-7000 with an FPC failure is less likely to become the primary FortiGate-7000.

Link failure

If your HA configuration includes HA interface monitoring, if a primary FortiGate-7000 interface fails or is disconnected while a cluster is operating, a link failure occurs. When a link failure occurs, the FortiGate-7000s in the cluster negotiate to select a new primary FortiGate-7000. The link failure means that a that primary FortiGate-7000 with the most link

failures will become the secondary and the FortiGate-7000 with the fewest link failures becomes the primary FortiGate-7000.

Just as for a device failover, the new primary FortiGate-7000 sends gratuitous arp packets out all of its connected interfaces to inform attached switches to send traffic to it. Sessions then resume with the new primary FortiGate-7000.

If the secondary FortiGate-7000 experiences a link failure, its status in the cluster does not change. However, in future negotiations FortiGate-7000 with a link failure is less likely to become the primary FortiGate-7000.

If one of the FortiGate-6000s experiences a module failure and the other experiences a link failure, the FortiGate-7000 with the most operating modules becomes the primary FortiGate-7000, even if it is also experiencing a link failure.

Session failover

If you enable session failover (also called session pickup) for the cluster, during cluster operation the primary FortiGate-6000 informs the secondary FortiGate-6000 of changes to the primary FortiGate-6000 connection and state tables, keeping the secondary FortiGate-6000 up-to-date with the traffic currently being processed by the cluster.

After a failover the new primary FortiGate-6000 recognizes open sessions that were being handled by the cluster. The sessions continue to be processed by the new primary FortiGate-6000 and are handled according to their last known state.

If you leave session pickup disabled, the cluster does not keep track of sessions and after a failover, active sessions have to be restarted or resumed.

Primary FortiGate-6000 recovery

If a primary FortiGate-6000 recovers after a device, FPC, or link failure, it will operate as a subordinate unit. If `override` is enabled; however, when the FortiGate-6000 recovers, the cluster will renegotiate and the FortiGate-6000 with the highest device priority becomes the primary.

Before you begin configuring HA

Before you begin, the FortiGate-7000s to be added to an HA cluster should be running the same FortiOS firmware version and interfaces should not be configured to get their addresses from DHCP or PPPoE. Register and apply licenses to the each FortiGate-7000 before setting up the HA cluster. This includes licensing for FortiCare, IPS, AntiVirus, Web Filtering, Mobile Malware, FortiClient, FortiCloud, and additional virtual domains (VDOMs). Both FortiGate-7000s in the cluster must have the same level of licensing for FortiGuard, FortiCloud, FortiClient, and VDOMs. FortiToken licenses can be added at any time because they are synchronized to all cluster members.

Configure split ports

If required, you should configure split ports on the FIMs on both FortiGate-7000s before configuring HA because the FortiGate-7000 has to reboot if you enable, change, or disable the split port configuration.

For example, to split the C1, C2, and C4 interfaces of an FIM-7910E in slot 1, enter the following command:

```
config system global
    set split-port 1-C1 2-C1 2-C4
```

end

After configuring split ports, the FortiGate-7000 reboots and synchronizes the configuration.

On each FortiGate-7000, make sure configurations of the FIMs and FPMs are synchronized before starting to configure HA. You can use the following command to verify the synchronization status of all modules:

```
diagnose sys confsync showchsum | grep all
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
all: c0 68 d2 67 e1 23 d9 3a 10 50 45 c5 50 f1 e6 8e
```

If the modules are synchronized, the checksums displayed should all be the same.

You can also use the following command to list the modules that are synchronized. The example output shows all four modules in a FortiGate-7040E have been configured for HA and added to the cluster.

```
diagnose sys confsync status | grep in_sync
FIM10E3E16000062, Slave, uptime=58852.50, priority=2, slot_id=2:2, idx=3, flag=0x10, in_sync=1
FIM04E3E16000010, Slave, uptime=58726.83, priority=3, slot_id=1:1, idx=0, flag=0x10, in_sync=1
FIM04E3E16000014, Master, uptime=58895.30, priority=1, slot_id=2:1, idx=1, flag=0x10, in_sync=1
FIM10E3E16000040, Slave, uptime=58857.80, priority=4, slot_id=1:2, idx=2, flag=0x10, in_sync=1
FPM20E3E16900234, Slave, uptime=58895.00, priority=16, slot_id=2:3, idx=4, flag=0x64, in_sync=1
FPM20E3E16900269, Slave, uptime=58333.37, priority=120, slot_id=2:4, idx=5, flag=0x64, in_sync=1
FPM20E3E17900113, Slave, uptime=58858.90, priority=116, slot_id=1:3, idx=6, flag=0x64, in_sync=1
FPM20E3E17900217, Slave, uptime=58858.93, priority=117, slot_id=1:4, idx=7, flag=0x64, in_sync=1
...
```

In this command output, `in_sync=1` means the module is synchronized with the primary FIM and `in_sync=0` means the module is not synchronized.

Connect the M1 and M2 interfaces for HA heartbeat communication


HA heartbeat communication between FortiGate-7000s happens over the 10Gbit M1 and M2 interfaces of the FIMs in each chassis. To set up HA heartbeat connections:

- Connect the M1 interfaces of all FIMs together using a switch.
- Connect the M2 interfaces of all FIMs together using another switch.

All of the M1 interfaces must be connected together with a switch and all of the M2 interfaces must be connected together with another switch. Connecting M1 interfaces or M2 interfaces directly is not supported as each FIM needs to communicate with all other FIMs.



Connect the M1 and M2 interfaces before enabling HA. Enabling HA moves heartbeat communication between the FIMs in the same chassis to the M1 and M2 interfaces. So if these interfaces are not connected before you enable HA, FIMs in the same chassis will not be able to communicate with each other.



Heartbeat packets are VLAN packets with VLAN ID 999 and ethertype 8890. The MTU value for the M1 and M2 interfaces is 1500.

You can use the following command to change the HA heartbeat packet VLAN ID and ethertype values if required for your switches. By default the M1 and M2 interface heartbeat packets use the same VLAN IDs. The following example changes the M1 VLAN ID to 4086 and the M2 VLAN ID to 4087.

```
config system ha
  set hbdev "1-M1" 50 "2-M1" 50 "1-M2" 50 "2-M2" 50
  set hbdev-vlan-id 4086
  set hbdev-second-vlan-id 4087
  set ha-eth-type <eth-type>
end
```

For this configuration to work, you must change both VLAN IDs. You cannot use the default value of 999.

Recommended HA heartbeat interface configuration

If you are setting up an HA configuration of two FortiGate-7030Es installed in the same location, you can directly connect their M1 interfaces and their M2 interfaces without using switches.

For redundancy, for other FortiGate-7000s, Fortinet recommends using separate switches for the M1 and M2 connections. These switches should be dedicated to HA heartbeat communication and not used for other traffic.

If you use the same switch for the M1 and M2 interfaces, separate the M1 and M2 traffic on the switch and set the heartbeat traffic on the M1 and M2 interfaces to have different VLAN IDs.

If you don't set different VLAN IDs for the M1 and M2 heartbeat packets, you must enable q-in-q on the switch.

Example FortiGate-7000 switch configuration

The switch that you use for connecting HA heartbeat interfaces does not have to support IEEE 802.1ad (also known as Q-in-Q, double-tagging). But the switch should be able to forward the double-tagged frames. Some switches will strip out the inner tag and Fortinet recommends avoiding these switches. FortiSwitch D and E series can correctly forward double-tagged frames.



This configuration is not required for FortiGate-7030E HA configurations if you have set up direct connections between the HA heartbeat interfaces.

This example shows how to configure a FortiGate-7000 to use different VLAN IDs for the M1 and M2 HA heartbeat interfaces and then how to configure two ports on a Cisco switch to allow HA heartbeat packets.



This example sets the native VLAN ID for both switch ports to 777. You can use any VLAN ID as the native VLAN ID as long as the native VLAN ID is not the same as the allowed VLAN ID.

1. On both FortiGate-7000s in the HA configuration, enter the following command to use different VLAN IDs for the M1 and M2 interfaces. The command sets the M1 VLAN ID to 4086 and the M2 VLAN ID to 4087:

```
config system ha
    set hbdev "1-M1" 50 "2-M1" 50 "1-M2" 50 "2-M2" 50
    set hbdev-vlan-id 4086
    set hbdev-second-vlan-id 4087
end
```

2. Use the `get system ha status` command to confirm the VLAN IDs.

```
get system ha status
...
HBDEV stats:
FG74E83E16000015(updated 1 seconds ago):
    1-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=579602089/2290683/0/0,
tx=215982465/761929/0/0, vlan-id=4086
    2-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=577890866/2285570/0/0,
tx=215966839/761871/0/0, vlan-id=4086
    1-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=579601846/2290682/0/0,
tx=215982465/761929/0/0, vlan-id=4087
    2-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=577890651/2285569/0/0,
tx=215966811/761871/0/0, vlan-id=4087
FG74E83E16000016(updated 1 seconds ago):
    1-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=598602425/2290687/0/0,
tx=196974887/761899/0/0, vlan-id=4086
    2-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=596895956/2285588/0/0,
tx=196965052/761864/0/0, vlan-id=4086
    1-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=598602154/2290686/0/0,
tx=196974915/761899/0/0, vlan-id=4087
    2-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=596895685/2285587/0/0,
tx=196965080/761864/0/0, vlan-id=4087
...
```

3. Configure the Cisco switch port that connects the M1 interfaces to allow packets with a VLAN ID of 4086:

```
interface <name>
switchport mode trunk
switchport trunk native vlan 777
switchport trunk allowed vlan 4086
```

4. Configure the Cisco switch port that connects the M2 interfaces to allow packets with a VLAN ID of 4087:

```
interface <name>
switchport mode trunk
```

```
switchport trunk native vlan 777
switchport trunk allowed vlan 4087
```

Basic FortiGate-7000 HA configuration

Use the following steps to set up HA between two FortiGate-7000s. To configure HA, you assign a chassis ID (1 and 2) to each of the FortiGate-7000s. These IDs allow the FGCP to identify the chassis and do not influence primary FortiGate-7000 selection. Before you start, determine which FortiGate-7000 should be chassis 1 and which should be chassis 2.

1. Set up HA heartbeat communication as described in [Connect the M1 and M2 interfaces for HA heartbeat communication on page 77](#).
2. Log into the GUI or CLI of the FIM in slot 1 of the FortiGate-7000 that will become chassis 1. Usually you would do this by connecting the management IP address of this FortiGate-7000.
3. Use the following CLI command to change the host name. This step is optional, but setting a host name makes the FortiGate-7000 easier to identify after the cluster has formed.

```
config system global
    set hostname 7K-Chassis-1
end
```

From the GUI you can configure the host name by going to **System > Settings** and changing the **Host name**.

4. Enter the following command to configure basic HA settings for the chassis 1 FortiGate-7000:

```
config system ha
    set group-id <id>
    set group-name My-7K-Cluster
    set mode a-p
    set hbdev 1-M1 50 1-M2 50 2-M1 50 2-M2 50
    set chassis-id 1
    set hbdev-vlan-id 4086
    set hbdev-second-vlan-id 4087
    set password <password>
end
```

From the GUI you can configure HA by going to **System > HA**. Set the **Mode** to **Active-Passive**, set the **Group Name**, add a **Password**, and set the **Heartbeat Interface Priority** for the heartbeat interfaces (1-M1, 1-M2, 2-M1, and 2-M2). You must configure the chassis ID and group ID from the CLI.

5. Log into the chassis 2 FortiGate-7000 and configure its host name, for example:

```
config system global
    set hostname 7K-Chassis-2
end
```

From the GUI you can configure the host name by going to **System > Settings** and changing the **Host name**.

6. Enter the following command to configure basic HA settings. The configuration must be the same as the chassis 1 configuration, except for the chassis ID.

```
config system ha
    set group-id <id>
    set group-name My-7K-Cluster
    set mode a-p
    set hbdev 1-M1 50 1-M2 50 2-M1 50 2-M2 50
    set chassis-id 2
    set hbdev-vlan-id 4086
    set hbdev-second-vlan-id 4087
    set password <password>
```


end

From the GUI you can configure HA by going to **System > HA**. Set the **Mode** to **Active-Passive**, set the **Group Name**, add a **Password**, and set the **Heartbeat Interface Priority** for the heartbeat interfaces (1-M1, 1-M2, 2-M1, and 2-M2). You must configure the chassis ID and group ID from the CLI.

Once you save your configuration changes, if the HA heartbeat interfaces are connected, the FortiGate-7000s negotiate to establish a cluster. You may temporarily lose connectivity with the FortiGate-7000s as the cluster negotiates and the FGCP changes the MAC addresses of the FortiGate-7000 interfaces. To be able to reconnect sooner, you can update the ARP table of your management PC by deleting the ARP table entry for the FortiGate (or just deleting all ARP table entries). You may be able to delete the ARP table of your management PC from a command prompt using a command similar to `arp -d`. When the cluster has completed negotiating, you can log into it using the management IP address of the primary FortiGate-7000.

7. Log into the cluster and view the HA Status dashboard widget or enter the `get system ha status` command to confirm that the cluster has formed and is operating normally.

If the cluster is operating normally, you can connect network equipment, add your configuration, and start operating the cluster.

Verifying that the cluster is operating normally

You view the cluster status from the HA Status dashboard widget or by using the `get system ha status` command.

If the HA Status widget or the `get system ha status` command shows a cluster has not formed, check the HA heartbeat connections. They should be configured as described in [Connect the M1 and M2 interfaces for HA heartbeat communication on page 77](#).

You should also review the HA configurations of the FortiGate-7000s. When checking the configurations, make sure both FortiGate-7000s have the same HA configuration, including identical HA group IDs, group names, passwords, and HA heartbeat VLAN IDs.

The following example FortiGate-7000 `get system ha status` output shows a FortiGate-7000 cluster that is operating normally. The output shows which FortiGate-7000 has become the primary (master) FortiGate-7000 and how it was chosen. You can also see CPU and memory use data, HA heartbeat VLAN IDs, and so on.

```
get system ha status
Master selected using:
HA Health Status: OK
Model: FortiGate-7000E
Mode: HA A-P
Group: 7
Debug: 0
Cluster Uptime: 0 days 16:42:5
Cluster state change time: 2019-01-14 16:26:30
    <2019/01/14 16:26:30> FG74E83E16000016 is selected as the master because it has more active switch blade.
    <2019/01/14 16:26:12> FG74E83E16000016 is selected as the master because it's the only member in the cluster.
ses_pickup: disable
override: disable
Configuration Status:
    FG74E83E16000016(updated 4 seconds ago): in-sync
    FG74E83E16000015(updated 0 seconds ago): in-sync
System Usage stats:
    FG74E83E16000016(updated 4 seconds ago):
```

```

sessions=198, average-cpu-user/nice/system/idle=1%/0%/0%/97%, memory=5%
FG74E83E16000015(updated 0 seconds ago):
sessions=0, average-cpu-user/nice/system/idle=2%/0%/0%/96%, memory=6%
HBDEV stats:
FG74E83E16000016(updated 4 seconds ago):
  1-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=227791977/902055/0/0,
tx=85589814/300318/0/0, vlan-id=4086
  2-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=227119632/900048/0/0,
tx=85589814/300318/0/0, vlan-id=4086
  1-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=227791977/902055/0/0,
tx=85589814/300318/0/0, vlan-id=4087
  2-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=227119632/900048/0/0,
tx=85589814/300318/0/0, vlan-id=4087
FG74E83E16000015(updated 0 seconds ago):
  1-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=0/0/0/0,
tx=85067/331/0/0, vlan-id=4086
  2-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=947346/3022/0/0,
tx=206768/804/0/0, vlan-id=4086
  1-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=0/0/0/0,
tx=85067/331/0/0, vlan-id=4087
  2-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=946804/3020/0/0,
tx=206768/804/0/0, vlan-id=4087
Master: 7K-Chassis-1      , FG74E83E16000016, cluster index = 0
Slave : 7K-Chassis-2      , FG74E83E16000015, cluster index = 1
number of vcluster: 1
vcluster 1: work 10.101.11.20
Master: FG74E83E16000016, operating cluster index = 0
Slave : FG74E83E16000015, operating cluster index = 1
Chassis Status: (Local chassis ID: 2)
  Chassis ID 1: Slave Chassis
    Slot ID 1: Master Slot
    Slot ID 2: Slave Slot
  Chassis ID 2: Master Chassis
    Slot ID 1: Master Slot
    Slot ID 2: Slave Slot

```

Verifying that the cluster is synchronized

After the HA cluster is up and running, you can use the following command to confirm that the configurations of the FIMs and FPMs in both FortiGate-7000s in the cluster are synchronized:

```
diagnose sys confsync showcsum
```

Run this command from the management board CLI of each FortiGate-7000 in the cluster. The command output displays configuration checksums for the FIMs and FPMs. If the cluster is synchronized, all of the FIMs and FPMs in both FortiGate-7000s should have the same checksums. As well these checksums should match the checksums shown by the output of the `diagnose sys ha checksum cluster` command.



The FortiGate-7000 uses a custom FGCP HA implementation and the `diagnose sys ha checksum cluster` command may show incorrect checksums so can't be used to check cluster synchronization.

Setting up HA management connections

Fortinet recommends the following configurations for redundant management connections to a FortiGate-7000 HA configuration.

- Single management connections to each of the FIMs.
- Redundant management connections to each of the FIMs.

These management connections involve connecting the static redundant management interfaces (MGMT1 to MGMT4) of each FIM in the HA configuration to one or more switches. You do not have to change the FortiGate-7000 configuration to set up redundant management connections. However, specific switch configurations are required for each of these configurations as described below.



LACP is not supported for the mgmt aggregate interface.


Setting up single management connections to each of the FIMs

The simplest way to provide redundant management connections to a FortiGate-7000 HA configuration involves connecting the MGMT1 interface of each of the FIMs to four ports on a switch. On the switch you must add the four switch ports to the same VLAN. Then connect the switch to your management network and allow traffic from the VLAN to the management network.



A FortiGate-7030E HA configuration only has two FIMs so would only require two switch ports.

Example FortiGate-7000 HA redundant management connections



Setting up redundant management connections to each of the FIMs


You can enhance redundancy by setting up two redundant management connections to each FIM. To support this configuration, on the switch you must create a port channel for each FIM interface. Create a total of four port channels, one for each FIM and add each of the port channels to the same VLAN. Then connect the switch to your management network and allow traffic from the VLAN to the management network.

If you use two switches, the VLAN should span across both switches.



A FortiGate-7030E HA configuration only has two FIMs so would only require two port channels.

Example FortiGate-7000 HA redundant management connections with redundant connections to each FIM



Firmware upgrades

All of the FIMs and FPMs in your FortiGate-7000 system run the same firmware image. You upgrade the firmware from the primary FIM GUI or CLI just as you would any FortiGate product.

You can perform a graceful firmware upgrade of a FortiGate-7000 FGCP HA cluster by enabling `uninterruptible-upgrade` and `session-pickup`. A graceful firmware upgrade only causes minimal traffic interruption. For more information about graceful HA upgrades, see [HA cluster firmware upgrades](#).

Upgrading the firmware of a standalone FortiGate-7000, or FortiGate-7000 HA cluster with `uninterruptible-upgrade` disabled interrupts traffic because the firmware running on the FIMs and FPMs upgrades in one step. These firmware upgrades should be done during a quiet time because traffic will be interrupted during the upgrade process.

A firmware upgrade takes a few minutes, depending on the number of FIMs and FPMs in your FortiGate-7000 system. Some firmware upgrades may take longer depending on factors such as the size of the configuration and whether an upgrade of the DP2 processor is included.

Before beginning a firmware upgrade, Fortinet recommends that you perform the following tasks:

- Review the latest release notes for the firmware version that you are upgrading to.
- Verify the recommended upgrade path as documented in the release notes.
- Back up your FortiGate-7000 configuration.



Fortinet recommends that you review the services provided by your FortiGate-7000 before a firmware upgrade and then again after the upgrade to make sure the services continues to operate normally. For example, you might want to verify that you can successfully access an important server used by your organization before the upgrade and make sure that you can still reach the server after the upgrade, and performance is comparable. You can also take a snapshot of key performance indicators (for example, number of sessions, CPU usage, and memory usage) before the upgrade and verify that you see comparable performance after the upgrade.

If you are operating two FortiGate-7000s in HA mode with `uninterruptible-upgrade` and `session-pickup` enabled, firmware upgrades should only cause a minimal traffic interruption. Use the following command to enable these settings. These settings are synchronized to all FIMs and FPMs.

```
config system ha
  set uninterruptible-upgrade enable
  set session-pickup enable
end
```

Verifying that a firmware upgrade is successful

After a FortiGate-7000 cluster firmware upgrade, you should verify that all of the FIMs and FPMs have been successfully upgraded to the new firmware version.

After the firmware upgrade appears to be complete:

1. Log into the primary FIM and verify that it is running the expected firmware version.
You can verify the firmware version running on the primary FIM from the dashboard or by using the `get system status` command.
2. Log into the other FIMs and the FPMs, and in the same way confirm that they are also running the expected firmware version.
You can log into individual FIMs or FPMs using the system management IP address and the special port number for each module. For example, `https://192.268.1.99:44303` connects to the module in slot 3. The special port number (in this case 44303) is a combination of the service port (for HTTPS the service port is 443) and the slot number (in this example, 03). For more information, see [Managing individual FortiGate-7000 FIMs and FPMs on page 45](#).
If you are using a SMM console port to connect to the primary FIM CLI you can use Ctrl-T to switch between the CLIs of each of the modules.
3. If one or more of the FIMs or FPMs are not running the correct firmware version, use the procedures described in [Upgrading FPM firmware on page 50](#) to upgrade these FIMs or FPMs.

Distributed clustering

FortiGate-7000 HA supports separating the FortiGate-7000s in different physical locations. Distributed FortiGate-7000 HA clustering (or geographically distributed FortiGate-7000 HA or geo clustering) can involve two FortiGate-7000s in different rooms in the same building, different buildings in the same location, or even different geographical sites such as different cities, countries or continents.


Just like any FortiGate-7000 HA configuration, distributed FortiGate-7000 HA requires heartbeat communication between the FortiGate-7000s over the M1 and M2 interfaces. In a distributed FortiGate-7000 HA configuration this heartbeat communication can take place over the Internet or over other transmission methods including satellite linkups.

Most Data Center Interconnect (DCI) or MPLS-based solutions that support layer 2 extensions and VLAN tags between the remote data centers should also support HA heartbeat communication between the FortiGates in the distributed locations. Using VLANs and switches in promiscuous mode to pass all traffic between the locations can also be helpful.

You cannot change HA heartbeat IP addresses, so the heartbeat interfaces have to be able to communicate over the same subnet.

The M1 and M2 interface traffic must be separated. You can do this by using separate channels for each interface or by configuring the M1 and M2 interfaces to use different VLANs.

Example FortiGate-7000 distributed clustering configuration



Because of the possible distance between sites, it may take a relatively long time for heartbeat packets to be transmitted between the FortiGate-7000s. This could lead to a split brain scenario. To avoid a split brain scenario you can modify heartbeat timing so that the cluster expects extra time between heartbeat packets. As a general rule, set the heartbeat failover time (`hb-interval`) to be longer than the max latency or round trip time (RTT). You could also increase the `hb-lost-threshold` to tolerate losing heartbeat packets if the network connection is less reliable.

In addition you could use different link paths for heartbeat packets to optimize HA heartbeat communication. You could also configure QoS on the links used for HA heartbeat traffic to make sure heartbeat communication has the highest priority.

Modifying heartbeat timing

If the FortiGate-7000s in the HA cluster do not receive heartbeat packets on time, the FortiGate-7000s in the HA configuration may each determine that the other FortiGate-7000 has failed. HA heartbeat packets may not be sent on time because of network issues. For example, if the M1 and M2 communications links between the FortiGate-7000s become too busy to handle the heartbeat traffic. Also, in a distributed clustering configuration the round trip time (RTT) between the FortiGate-7000s may be longer the expected time between heartbeat packets.

In addition, if the FortiGate-7000s becomes excessively busy, they may delay sending heartbeat packets.

Even with these delays, the FortiGate-7000 HA cluster can continue to function normally as long as the HA heartbeat configuration supports longer delays between heartbeat packets and more missed heartbeat packets.

You can use the following commands to configure heartbeat timing:

```
config system ha
    set hb-interval <interval_integer>
    set hb-lost-threshold <threshold_integer>
    set hello-holddown <holddown_integer>
end
```

Changing the heartbeat interval

The heartbeat interval is the time between sending HA heartbeat packets. The heartbeat interval range is 1 to 20 (100*ms). The heartbeat interval default is 2 (200 ms).

A heartbeat interval of 2 means the time between heartbeat packets is 200 ms. Changing the heartbeat interval to 5 changes the time between heartbeat packets to 500 ms (5 * 100ms = 500ms).

Use the following CLI command to increase the heartbeat interval to 10:

```
config system ha
    set hb-interval 10
end
```

Changing the lost heartbeat threshold

The lost heartbeat threshold is the number of consecutive heartbeat packets that a FortiGate does not receive before assuming that a failure has occurred. The default value of 6 means that if a FortiGate-7000 does not receive 6 heartbeat packets it determines that the other FortiGate-7000 in the cluster has failed. The range is 1 to 60 packets.

The lower the `hb-lost-threshold`, the faster a FortiGate-7000 HA configuration responds when a failure occurs. However, sometimes heartbeat packets may not be received because the other FortiGate-7000 is very busy or because of network conditions. This can lead to a false positive failure detection. To reduce these false positives you can increase the `hb-lost-threshold`.

Use the following command to increase the lost heartbeat threshold to 12:

```
config system ha
    set hb-lost-threshold 12
end
```

Adjusting the heartbeat interval and lost heartbeat threshold

The heartbeat interval combines with the lost heartbeat threshold to set how long a FortiGate-7000 waits before assuming that the other FortiGate-7000 has failed and is no longer sending heartbeat packets. By default, if a FortiGate-7000 does not receive a heartbeat packet from a cluster unit for $6 * 200 = 1200$ milliseconds or 1.2 seconds the FortiGate-7000 assumes that the other FortiGate-7000 has failed.

You can increase both the heartbeat interval and the lost heartbeat threshold to reduce false positives. For example, increasing the heartbeat interval to 20 and the lost heartbeat threshold to 30 means a failure will be assumed if no heartbeat packets are received after $30 * 2000$ milliseconds = 60,000 milliseconds, or 60 seconds.

Use the following command to increase the heartbeat interval to 20 and the lost heartbeat threshold to 30:

```
config system ha
    set hb-lost-threshold 20
    set hb-interval 30
end
```

Changing the time to wait in the hello state

The hello state hold-down time is the number of seconds that a FortiGate-7000 waits before changing from hello state to work state. After a failure or when starting up, FortiGate-7000s in HA mode operate in the hello state to send and receive heartbeat packets to find each other and form a cluster. A FortiGate-7000 should change from the hello state to work state after it finds the FortiGate-7000 to form a cluster with. If for some reason the FortiGate-7000s cannot find each other during the hello state both FortiGate-7000s may assume that the other one has failed and each could form separate clusters of one FortiGate-7000. The FortiGate-7000s could eventually find each other and negotiate to form a cluster, possibly causing a network interruption as they re-negotiate.

One reason for a delay of the FortiGate-7000s finding each other could be the FortiGate-7000s are located at different sites or for some other reason communication is delayed between the heartbeat interfaces. If you find that your FortiGate-7000s leave the hello state before finding each other you can increase the time that they wait in the hello state. The hello state hold-down time range is 5 to 300 seconds. The hello state hold-down time default is 20 seconds.

Use the following command to increase the time to wait in the hello state to 1 minute (60 seconds):

```
config system ha
    set hello-holddown 60
end
```


Session failover (session-pickup)

Session failover means that after a failover, communications sessions resume on the new primary FortiGate-7000 with minimal or no interruption. Two categories of sessions need to be resumed after a failover:

- Sessions passing through the cluster
- Sessions terminated by the cluster

Session failover (also called session-pickup) is not enabled by default for FortiGate-7000 HA. If sessions pickup is enabled, while the FortiGate-7000 HA cluster is operating the primary FortiGate-7000 informs the secondary FortiGate-7000 of changes to the primary FortiGate-7000 connection and state tables for TCP and UDP sessions passing through the cluster, keeping the secondary FortiGate-7000 up-to-date with the traffic currently being processed by the cluster.

After a failover the new primary FortiGate-7000 recognizes open sessions that were being handled by the cluster. The sessions continue to be processed by the new primary FortiGate-7000 and are handled according to their last known state.



Session-pickup has some limitations. For example, session failover is not supported for sessions being scanned by proxy-based security profiles. Session failover is supported for sessions being scanned by flow-based security profiles; however, flow-based sessions that fail over are not inspected after they fail over.

Sessions terminated by the cluster include management sessions (such as HTTPS connections to the FortiGate GUI or SSH connection to the CLI as well as SNMP and logging and so on). Also included in this category are IPsec VPN, SSL VPN, sessions terminated by the cluster, and explicit proxy sessions. In general, whether or not session-pickup is enabled, these sessions do not failover and have to be restarted.

Enabling session pickup for TCP and UDP

To enable session-pickup, from the CLI enter:

```
config system ha
    set session-pickup enable
end
```

When session-pickup is enabled, sessions in the primary FortiGate-7000 TCP and UDP session tables are synchronized to the secondary FortiGate-7000. As soon as a new TCP or UDP session is added to the primary FortiGate-7000 session table, that session is synchronized to the secondary FortiGate-7000. This synchronization happens as quickly as possible to keep the session tables synchronized.

If the primary FortiGate-7000 fails, the new primary FortiGate-7000 uses its synchronized session tables to resume all TCP and UDP sessions that were being processed by the former primary FortiGate-7000 with only minimal interruption. Under ideal conditions all TCP and UDP sessions should be resumed. This is not guaranteed though and under less than ideal conditions some sessions may need to be restarted.

If session pickup is disabled

If you disable session pickup, the FortiGate-7000 HA cluster does not keep track of sessions and after a failover, active sessions have to be restarted or resumed. Most session can be resumed as a normal result of how TCP and UDP resumes communication after any routine network interruption.



The session-pickup setting does not affect session failover for sessions terminated by the cluster.


If you do not require session failover protection, leaving session pickup disabled may reduce CPU usage and reduce HA heartbeat network bandwidth usage. Also if your FortiGate-7000 HA cluster is mainly being used for traffic that is not synchronized (for example, for proxy-based security profile processing) enabling session pickup is not recommended since most sessions will not be failed over anyway.

Primary FortiGate-7000 selection

Once two FortiGate-7000s recognize that they can form a cluster, they negotiate to select a primary FortiGate-7000. Primary FortiGate-7000 selection occurs automatically based on the selection criteria shown in the diagram below. After the cluster selects the primary FortiGate-7000, the other FortiGate-7000 becomes the secondary.

Negotiation and primary FortiGate-7000 selection also takes place if the one of the criteria for selecting the primary FortiGate-7000 changes. For example, an interface can become disconnected or a module can fail. After this happens, the cluster can renegotiate to select a new primary FortiGate-7000 using the same selection criteria.

Selecting the Primary FortiGate-7000



If there are no module failures and if you haven't configured any settings to influence primary FortiGate-7000 selection, the FortiGate-7000 with the highest serial number becomes the primary FortiGate-7000.

Age and primary FortiGate-7000 selection

Age (or uptime) is also a factor in primary FortiGate-7000 selection. Normally when two FortiGate-7000s start, their uptimes are similar and do not affect primary FortiGate-7000 selection. However, during operation, if one of the FortiGate-7000s goes down the other will have a much higher age or uptime and will be selected as the primary FortiGate-7000 before checking priority and serial number.

In some cases, age differences can result in the wrong FortiGate-7000 becoming the primary FortiGate-7000. For example, if the FortiGate-7000 set to a high priority reboots, it will have a lower age than other FortiGate-7000 when it rejoins the cluster. Since age takes precedence over priority it will become the secondary FortiGate-7000 when it rejoins the cluster.

One way to resolve this issue is to reboot both FortiGate-7000s in the cluster at the same time to reset the age of both FortiGate-7000s. However, doing this would disrupt traffic. Instead you can use the following command to reset the age of one the primary FortiGate-7000 to zero.

```
diagnose sys ha reset-uptime
```

The primary FortiGate-7000 now has the lowest age and the other FortiGate-7000 will have the highest age and can then become the primary FortiGate-7000.



The `diagnose sys ha reset-uptime` command should only be used as a temporary solution. You should reboot the FortiGate-7000s during a maintenance window to permanently bring their ages back together.

Device priority and primary FortiGate-7000 selection

In some situations you may want to select a FortiGate-7000 to always become the primary FortiGate-7000. You can do this by setting its device priority higher. You can change the device priority of an FIM from the **System > HA** GUI page or by using the following command:

```
config system ha
    set priority <number>
end
```

The default priority is 128.

During negotiation, the FortiGate-7000 with the highest device priority becomes the primary FortiGate-7000.

Override and primary FortiGate-7000 selection

You can enable override to select a FortiGate-7000 to always becomes the primary FortiGate-7000. Enabling override changes how primary select works. For details, see [Primary FortiGate-7000 selection and override on page 93](#).

Module failure and primary FortiGate-7000 selection

If a module fails, the FortiGate-7000 cluster negotiates to select a new primary FortiGate-7000 and the FortiGate-7000 with the most operating modules becomes the primary FortiGate-7000.

You can also configure board failover tolerance to control how a FortiGate-7000 cluster responds to a module failure.

```
config system ha
    set board-failover-tolerance <tolerance>
end
```

Where <tolerance> can be 0 or 1. A tolerance of 0 (the default) means that if a single module fails in the primary FortiGate-7000, a failover occurs and the FortiGate-7000 with the fewest failed modules becomes the new primary FortiGate-7000. A failover tolerance of 1 means that both modules must fail before a failover occurs.

Verifying primary FortiGate-7000 selection

You can use the `get system ha status` command to verify which FortiGate-7000 has become the primary FortiGate-7000. The command output shows which FortiGate-7000 is currently operating as the primary FortiGate-7000. The following command output excerpt shows that the FortiGate-7000 labeled as chassis 2 has become the primary (master) FortiGate-7000:

```
get system ha status
Master selected using:
HA Health Status: OK
Model: FortiGate-7000E
Mode: HA A-P
Group: 7
Debug: 0
Cluster Uptime: 0 days 16:42:5
...
Master: CH16, FG74E83E16000016, cluster index = 0
Slave : FG74E83E16000015, FG74E83E16000015, cluster index = 1
number of vcluster: 1
vcluster 1: work 10.101.11.20
Master: FG74E83E16000016, operating cluster index = 0
Slave : FG74E83E16000015, operating cluster index = 1
Chassis Status: (Local chassis ID: 2)
    Chassis ID 1: Slave Chassis
        Slot ID 1: Master Slot
        Slot ID 2: Slave Slot
    Chassis ID 2: Master Chassis
        Slot ID 1: Master Slot
        Slot ID 2: Slave Slot
```

Primary FortiGate-7000 selection and override

When configuring FortiGate-7000 HA, if you want one of the FortiGate-7000s to always become the primary FortiGate-7000 you can enable `override` on that FortiGate-7000. For `override` to be effective, you must also set the device priority highest on this FortiGate-7000.

To enable override and increase device priority:

```
config system ha
  set override enable
  set priority 200
end
```

The FortiGate-7000 with override enabled and the highest device priority always becomes the primary FortiGate-7000.


In most cases, with override enabled the cluster will negotiate more often. For example, with override enabled it is more likely that changes to the secondary FortiGate-7000 may cause the cluster to negotiate. More frequent negotiation can lead to more traffic disruptions.

Enabling override changes primary FortiGate-7000 selection

Enabling `override` changes the order of primary FortiGate-7000 selection. As shown below, if `override` is enabled, primary FortiGate-7000 selection considers device priority before age and serial number. This means that if you set the device priority higher on one FortiGate-7000, with `override` enabled this FortiGate-7000 becomes the primary FortiGate-7000 even if its age and serial number are lower.

Similar to when `override` is disabled, when `override` is enabled primary FortiGate-7000 selection checks for operating modules and connected monitored interfaces first. So if interface monitoring is enabled, the FortiGate-7000 with the most disconnected monitored interfaces cannot become the primary FortiGate-7000, even if this FortiGate-7000 has the highest device priority.

Selecting the Primary FortiGate-7000 with Override enabled



Link failover (port monitoring or interface monitoring)

Link failover means that if a monitored interface fails, the FortiGate-7000 cluster reorganizes to reestablish a link to the network that the monitored interface was connected to and to continue operating with minimal or no disruption of network traffic.

You configure monitored interfaces (also called interface monitoring or port monitoring) by selecting FIM front panel interfaces to monitor as part of the HA configuration.

You can monitor up to 64 interfaces. The FGCP synchronizes the interface monitoring configurations to both FortiGate-7000s in the cluster.

The interfaces that you can monitor appear on the HA GUI page **Monitor Interfaces** list. You can monitor any FIM interfaces including redundant interfaces and 802.3ad aggregate interfaces.

You cannot monitor the following types of interfaces (you cannot select these types of interfaces on the Monitor Interfaces list):

- VLAN subinterfaces.
- IPsec VPN interfaces.
- Individual physical interfaces that have been added to a redundant or 802.3ad aggregate interface.



You should only monitor interfaces that are connected to networks, because a failover may occur if you monitor an unconnected interface. For this reason, you should also wait until your FortiGate-7000 HA setup has been configured and connected and is operating as expected before enabling interface monitoring.

To enable interface monitoring

From the GUI, go to **System > HA** and add interfaces to the **Monitor Interfaces** list.

From the CLI, enter the following command to monitor the 1-B1/2 and 2-C1/10 interfaces:

```
config system ha
    set monitor 1-B1/2 2-C1/10
end
```

With interface monitoring enabled, during FortiGate-7000 cluster operation, the cluster monitors each FIM in the cluster to determine if the monitored interfaces are operating and connected. Each FIM can detect a failure of its network interface hardware.



FIMs cannot determine if the switches that its interfaces are connected to are still connected to networks. However, you can use remote IP monitoring to make sure that the cluster unit can connect to downstream network devices. See [Remote link failover on page 97](#).

If a monitored interface on the primary FortiGate-7000 fails

Because the primary FortiGate-7000 receives all traffic processed by the cluster, a FortiGate-7000 cluster can only process traffic from a network if the primary FortiGate-7000 can connect to it. So, if the link between a network and the

primary FortiGate-7000 fails, to maintain communication with this network, the cluster must set the FortiGate-7000 that is still connected to this network to become the primary FortiGate-7000. Unless another link failure has occurred, the new primary FortiGate-7000 will have an active link to the network and will be able to maintain communication with it.

To support link failover, the FortiGate-7000s store link state information for all monitored interfaces in a link state database. If one of the monitored interfaces on one of the FortiGate-7000s becomes disconnected or fails, this information is immediately shared with the other FortiGate-7000 in the cluster.


If a monitored interface on the primary FortiGate-7000 fails, the cluster renegotiates to select the primary FortiGate-7000 using the process described in [Primary FortiGate-7000 selection on page 90](#). Because the FortiGate-7000 with the failed monitored interface has the lowest monitor priority, the other FortiGate-7000 becomes the primary FortiGate-7000. The new primary FortiGate-7000 should have fewer link failures.

If a monitored interface on the secondary FortiGate-7000 fails

If a monitored interface on a the secondary FortiGate-7000 fails, this information is shared with the primary FortiGate-7000. The cluster does not renegotiate. The secondary FortiGate-7000 with the failed monitored interface continues to function in the cluster.

Remote link failover

Remote link failover (also called remote IP monitoring) is similar to interface monitoring and link health monitoring (also known as dead gateway detection). Remote IP monitoring uses link health monitors to test connectivity between the primary FortiGate-7000 and remote network devices such as a downstream router. Remote IP monitoring causes a failover if one or more of these remote IP addresses does not respond to link health checking.



In the simplified example topology shown above, the switch connected directly to the primary FortiGate-7000 is operating normally but the link on the other side of the switches fails. As a result, traffic can no longer flow between the primary FortiGate-7000 and the Internet.

This section highlights some aspects of primary FortiGate-7000 selection. For more details about how this works, see [Remote link failover](#).

Configuring remote IP monitoring

Enter the following command to enable HA remote IP monitoring on the 1-B1/1 interface:

```
config system ha
    set pingserver-monitor-interface 1-B1/1
    set pingserver-failover-threshold 5
    set pingserver-flip-timeout 120
end
```

Keep the `pingserver-failover-threshold` set to the default value of 5. This means a failover occurs if the link health monitor doesn't get a response after 5 attempts.

Set the `pingserver-flip-timeout` set to 120 minutes. After a failover, if HA remote IP monitoring on the new primary unit also causes a failover, the flip timeout prevents the failover from occurring until the timer runs out. Setting the `pingserver-flip-timeout` to 120 means that remote IP monitoring can only cause a failover every 120 minutes. This flip timeout is required to prevent repeating failovers if remote IP monitoring causes a failover from all cluster units because none of the cluster units can connect to the monitored IP addresses.

Enter the following command to add a link health monitor for the 1-B1/1 interface and to set HA remote IP monitoring priority for this link health monitor.

```
config system link-monitor
  edit ha-link-monitor
    set server 192.168.20.20
    set srcintf port2
    set ha-priority 1
    set interval 5
    set failtime 2
  end
```

The `detectserver` option sets the remote IP address to monitor to 192.168.20.20.

Leave the `ha-priority` keyword set to the default value of 1. You only need to change this priority if you change the HA `pingserver-failover-threshold`. The `ha-priority` setting is not synchronized among the FortiGate-7000s in the HA configuration.



The `ha-priority` setting is not synchronized. So if you want to change the `ha-priority` setting you must change it separately on each FortiGate-7000. Otherwise it will remain set to the default value of 1.

Use the `interval` option to set the time between link health checks and use the `failtime` keyword to set the number of times that a health check can fail before a failure is detected (the failover threshold). The example reduces the failover threshold to 2 but keeps the health check interval at the default value of 5.

FortiGate-7000 support for VRRP

The FortiGate-7000 platform supports the Virtual Router Redundancy Protocol (VRRP), allowing you to configure VRRP HA between FortiGate-7000 devices. You can also add a FortiGate-7000 to a VRRP group with other VRRP routers.

Configure VRRP on the FortiGate-7000 by creating a VRRP group and adding one or more front panel interfaces to the group.

During normal operation, the primary FortiGate-7000 sends outgoing VRRP routing advertisements. Both the primary and secondary FortiGate-7000s listen for incoming VRRP advertisements from other routers in the VRRP group. If the primary FortiGate-7000 fails, the new primary FortiGate-7000 takes over the role of both sending and receiving VRRP advertisements, maintaining the FortiGate-7000 within the VRRP group.

ICAP support

You can configure your FortiGate-7000 to use Internet Content Adaptation Protocol (ICAP) to offload processing that would normally take place on the FortiGate-7000 to a separate server specifically set up for the required specialized processing.

ICAP servers are focused on a specific function, for example:

- Ad insertion
- Virus scanning
- Content translation
- HTTP header or URL manipulation
- Language translation
- Content filtering

FortiGate-7000 supports ICAP without any special configuration. This includes using ICAP to offload decrypted SSL traffic to an ICAP server. FortiOS decrypts the content stream before forwarding it to the ICAP server.

For more information about FortiOS support for ICAP, see [ICAP support](#).

Example ICAP configuration

ICAP is available for VDOMs operating in proxy mode. You can enable proxy mode from the **Global** GUI by going to **System > VDOM**, editing the VDOM for which to configure ICAP, and setting **Inspection Mode** to **Proxy**.

Then go to the VDOM, and go to **System > Feature Visibility** and enable **ICAP**.

From the CLI you can edit the VDOM, enable proxy inspection mode and enable ICAP. You can only enable ICAP from `config system settings` if proxy mode is already enabled.

```
config vdom
  edit VDOM-2
    config system settings
      set inspection-mode proxy
    end
    config system settings
      set gui-icap enable
    end
```

From the GUI you can add an ICAP profile by going to **Security Profiles > ICAP** and selecting **Create New** to create a new ICAP profile.

From the CLI you can use the following command to create an ICAP profile:

```
config icap profile
  edit "default"
  next
  edit "icap-test-profile"
    set request enable
    set response enable
    set request-server "icap-test"
    set response-server "icap-test"
    set request-failure bypass
    set response-failure bypass
```

```
set request-path "echo"
set response-path "echo"
end
```

From the GUI you can add an ICAP server by going to **Security Profiles > ICAP Servers** and selecting **Create New** to create a new ICAP server.

From the CLI you can use the following command to create an ICAP server:

```
config icap server
edit "icap-test"
set ip-address 10.98.0.88
set max-connections 1000
end
```

Then create a firewall policy for the traffic to be sent to the ICAP server and include the ICAP profile.

```
config firewall policy
edit 4
set name "any-any"
set uuid f4b612d0-2300-51e8-f15f-507d96056a96
set srcintf "1-C1/5" "1-C1/6"
set dstintf "1-C1/6" "1-C1/5"
set srcaddr "all"
set dstaddr "all"
set action accept
set schedule "always"
set service "ALL"
set utm-status enable
set logtraffic all
set av-profile "default"
set icap-profile "icap-test-profile"
set profile-protocol-options "default"
set ssl-ssh-profile "deep-inspection"
end
```

SSL mirroring support

You can configure your FortiGate-7000 to "mirror" or send a copy of traffic decrypted by SSL inspection to one or more interfaces so that the traffic can be collected by a raw packet capture tool for archiving or analysis.



Decryption, storage, inspection, and use decrypted content is subject to local privacy rules. Use of these features could enable malicious users with administrative access to your FortiGate to harvest sensitive information submitted using an encrypted channel.

For more information about FortiOS support for SSL mirroring, see [Mirroring SSL inspected traffic](#),

Example SSL mirroring configuration

SSL mirroring is available for VDOMs operating in flow mode. You can enable flow mode from the **Global** GUI by going to **System > VDOM**, editing the VDOM for which to configure SSL mirroring, and setting **Inspection Mode** to **Flow-based**.

From the CLI you can edit the VDOM and enable flow inspection mode.

```
config vdom
  edit mirror-vdom
    config system settings
      set inspection-mode flow
    end
```

To enable SSL mirroring, add a firewall policy to accept the traffic that you want to be mirrored. In the policy, enable the **SSL-mirror** option and set **ssl-mirror-intf** to the interface to which to send decrypted packets.

```
config firewall policy
  edit 4
    set name "ssl-mirror-example"
    set uuid f4b612d0-2300-51e8-f15f-507d96056a96
    set srcintf "1-C1/5"
    set dstintf "1-C1/6"
    set srcaddr "all"
    set dstaddr "all"
    set action accept
    set schedule "always"
    set service "ALL"
    set utm-status enable
    set logtraffic all
    set ssl-mirror enable
    set ssl-mirror-intf "1-C1/7"
    set ips-sensor "default"
    set application-list "default"
    set profile-protocol-options "default"
    set ssl-ssh-profile "deep-inspection"
  end
```

You can use the following command from an FPM CLI to verify the mirrored traffic:

```
diagnose sniffer packet 1-C1/7 'port 443' -c 50
interfaces=[1-C1/7]
filters=[port 443]
pcap_lookupnet: 1-C1/7: no IPv4 address assigned
0.440714 8.1.1.69.18478 -> 9.2.1.130.443: syn 582300852
0.440729 9.2.1.130.443 -> 8.1.1.69.18478: syn 3198605956 ack 582300853
0.440733 8.1.1.69.18478 -> 9.2.1.130.443: ack 3198605957
0.440738 8.1.1.69.18478 -> 9.2.1.130.443: psh 582300853 ack 3198605957
0.441450 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198605957 ack 582301211
0.441535 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198607351 ack 582301211
0.441597 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198608747 ack 582301211
0.441636 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198610143 ack 582301211
0.441664 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198611539 ack 582301211
0.441689 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198612935 ack 582301211
0.441715 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198614331 ack 582301211
0.441739 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198615727 ack 582301211
0.441764 9.2.1.130.443 -> 8.1.1.69.18478: psh 3198617123 ack 582301211
```

FortiGate-7000 v5.6.12 special features and limitations

This section describes special features and limitations for FortiGate-7000 v5.6.12.

Managing the FortiGate-7000

Management is only possible through the MGMT1 to MGMT4 front panel management interfaces. By default the MGMT1 to MGMT4 interfaces of the FIMs in slot 1 and slot 2 are in a single static aggregate interface named mgmt with IP address 192.168.1.99. You manage the FortiGate-7000 by connecting any one of these eight interfaces to your network, opening a web browser and browsing to the management IP address. For a factory default configuration, browse to <https://192.168.1.99>.



The FortiGate-7030E has one FIM and the MGMT1 to MGMT4 interfaces of that module are the only interfaces in the aggregate interface.

Default management VDOM

By default the FortiGate-7000 configuration includes a management VDOM named mgmt-vdom. For the FortiGate-7000 system to operate normally you should not change the configuration of this VDOM and this VDOM should always be the management VDOM. You should also not add or remove interfaces from this VDOM.

You have full control over the configurations of other FortiGate-7000 VDOMs.

Default Security Fabric configuration

The FortiGate-7000 uses the Security Fabric for communication and synchronization among FIMs and FPMs. Changing the default Security Fabric configuration could disrupt this communication and affect system performance.

Default Security Fabric configuration:

```
config system csf
  set status enable
  set configuration-sync local
  set management-ip 0.0.0.0
  set management-port 0
end
```

For the FortiGate-7000 to operate normally, you must not change the Security Fabric configuration.

Maximum number of LAGs and interfaces per LAG

FortiGate-7000 systems support up to 16 link aggregation groups (LAGs). This includes both normal link aggregation groups and redundant interfaces and including the redundant interface that contains the M1 to M4 management interfaces. A FortiGate-7000 LAG can include up to 20 interfaces.

Firewall

TCP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal TCP timer (which is 3605 seconds) should only be distributed to the master FPM using a flow rule. You can configure the distributed normal TCP timer using the following command:

```
config system global
    set dp-tcp-normal-timer <timer>
end
```

UDP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal UDP timer should only be distributed to the primary FPM using a flow rule.

IP multicast

IPv4 and IPv6 Multicast traffic is only sent to the primary FPM (usually the FPM in slot 3). This is controlled by the following configuration:

```
config load-balance flow-rule
    edit 18
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 224.0.0.0 240.0.0.0
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv4 multicast"
    next
    edit 19
        set status enable
        set vlan 0
        set ether-type ipv6
        set src-addr-ipv6 ::/0
        set dst-addr-ipv6 ff00::/8
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv6 multicast"
    end
end
```


High availability

Only the M1 and M2 interfaces are used for the HA heartbeat communication. For information on how to set up HA heartbeat communication using the M1 and M2 interfaces, see [Connect the M1 and M2 interfaces for HA heartbeat communication on page 77](#)

The following FortiOS HA features are not supported or are supported differently by FortiGate-7000 v5.6.12:

- Active-active HA is not supported.
- The range for the HA `group-id` is 0 to 31.
- Failover logic for FortiGate-7000 HA is not the same as FGCP for other FortiGate clusters.
- HA heartbeat configuration is specific to FortiGate-7000 systems and differs from standard HA.
- FortiGate Session Life Support Protocol (FGSP) HA (also called standalone session synchronization) is not supported.
- FortiGate-7000 HA does not support the `route-ttl`, `route-wait`, and `route-hold` options for tuning route synchronization between FortiGate-7000s.

Use of the `diagnose sys ha checksum cluster` command not recommended

The FortiGate-7000 uses a custom FGCP HA implementation and the `diagnose sys ha checksum cluster` command may show incorrect checksums so can't be used to check cluster synchronization. Instead you can log into the primary FIM of each FortiGate-7000 in the cluster and use the `diagnose sys confsync showcsum` and compare the results.

Shelf manager module

It is not possible to access SMM CLI using Telnet or SSH. Only console access is supported using the chassis front panel console ports as described in the FortiGate-7000 system guide.

For monitoring purpose, IPMI over IP is supported on SMM Ethernet ports. See your FortiGate-7000 system guide for details.

FortiOS features not supported by FortiGate-7000 v5.6.12

The following mainstream FortiOS 5.6.12 features are not supported by the FortiGate-7000 v5.6.12:

- Hardware switch
- Usage-based ECMP load balancing is not supported. If the `config system settings v4-ecmp-mode` option is set to `usage-based`, all traffic uses the first ECMP route instead of being load balanced among all ECMP routes. All other ECMP load balancing options are supported, including `source-ip-based`, `weight-based`, and `source-dest-ip-based`.
- Switch controller
- WiFi controller
- WAN load balancing (SD-WAN)

- IPv4 over IPv6, IPv6 over IPv4, IPv6 over IPv6 features
- GRE tunneling is only supported after creating a load balance flow rule, for example:

```
config load-balance flow-rule
  edit 0
    set status enable
    set vlan 0
    set ether-type ip
    set protocol gre
    set action forward
    set forward-slot master
    set priority 3
  end
```

- Hard disk features including, WAN optimization, web caching, explicit proxy content caching, disk logging, and GUI-based packet sniffing.
- The FortiGate-7000 platform only supports quarantining files to FortiAnalyzer.
- Log messages should be sent only using the management aggregate interface
- The FortiGate-7000 does not support configuring dedicated management interfaces using the `config system dedicated-mgmt` command or by enabling the `dedicated-to management interface` option.

IPsec VPN tunnels terminated by the FortiGate-7000

For a list of new FortiOS 5.6 FortiGate-7000 IPsec VPN features and a list of IPsec VPN features not supported by FortiOS 5.6 FortiGate-7000 IPsec VPN, see [New IPsec VPN features on page 69](#).

SSL VPN

Sending all SSL VPN sessions to the primary FPM is recommended. You can do this by:

- Creating a flow rule that sends all sessions that use the SSL VPN destination port and IP address to the primary FPM.
- Creating flow rules that send all sessions that use the SSL VPN IP pool addresses to the primary FPM.

For more information about FortiGate-7000 SSL VPN support, see [SSL VPN load balancing on page 58](#).

Traffic shaping and DDoS policies

Each FPM applies traffic shaping and DDoS quotas independently. Because of load-balancing, this may allow more traffic than expected.

FortiGuard web filtering and spam filtering queries

The FortiGate-7000 sends all FortiGuard web filtering and spam filtering rating queries through a management interface from the management VDOM.

Web filtering quotas

On a VDOM operating with the **Inspection Mode** set to **Proxy**, you can go to **Security Profiles > Web Filter** and set up **Category Usage Quotas**. Each FPM has its own quota, and the FortiGate-7000 applies quotas per FPM and not per the entire FortiGate-7000 system. This could result in quotas being exceeded if sessions for the same user are processed by different FPMs.

Log messages include a slot field

An additional "slot" field has been added to log messages to identify the FPM that generated the log.

FortiOS Carrier

You have to apply a FortiOS Carrier license separately to each FIM and FPM to license a FortiGate-7000 for FortiOS Carrier.

Special notice for new deployment connectivity testing

Only the primary FPM can successfully ping external IP addresses. During a new deployment, while performing connectivity testing from the Fortigate-7000, make sure to run `execute ping tests` from the primary FPM CLI.

FortiGate-7000 v5.6.11 special features and limitations

This section describes special features and limitations for FortiGate-7000 v5.6.11.

Managing the FortiGate-7000

Management is only possible through the MGMT1 to MGMT4 front panel management interfaces. By default the MGMT1 to MGMT4 interfaces of the FIMs in slot 1 and slot 2 are in a single static aggregate interface named mgmt with IP address 192.168.1.99. You manage the FortiGate-7000 by connecting any one of these eight interfaces to your network, opening a web browser and browsing to the management IP address. For a factory default configuration, browse to <https://192.168.1.99>.



The FortiGate-7030E has one FIM and the MGMT1 to MGMT4 interfaces of that module are the only interfaces in the aggregate interface.

Default management VDOM

By default the FortiGate-7000 configuration includes a management VDOM named mgmt-vdom. For the FortiGate-7000 system to operate normally you should not change the configuration of this VDOM and this VDOM should always be the management VDOM. You should also not add or remove interfaces from this VDOM.

You have full control over the configurations of other FortiGate-7000 VDOMs.

Default Security Fabric configuration

The FortiGate-7000 uses the Security Fabric for communication and synchronization among FIMs and FPMs. Changing the default Security Fabric configuration could disrupt this communication and affect system performance.

Default Security Fabric configuration:

```
config system csf
    set status enable
    set configuration-sync local
    set management-ip 0.0.0.0
    set management-port 0
end
```

For the FortiGate-7000 to operate normally, you must not change the Security Fabric configuration.

Maximum number of LAGs and interfaces per LAG

FortiGate-7000 systems support up to 16 link aggregation groups (LAGs). This includes both normal link aggregation groups and redundant interfaces and including the redundant interface that contains the M1 to M4 management interfaces. A FortiGate-7000 LAG can include up to 20 interfaces.

Firewall

TCP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal TCP timer (which is 3605 seconds) should only be distributed to the master FPM using a flow rule. You can configure the distributed normal TCP timer using the following command:

```
config system global
    set dp-tcp-normal-timer <timer>
end
```

UDP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal UDP timer should only be distributed to the primary FPM using a flow rule.

IP multicast

IPv4 and IPv6 Multicast traffic is only sent to the primary FPM (usually the FPM in slot 3). This is controlled by the following configuration:

```
config load-balance flow-rule
    edit 18
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 224.0.0.0 240.0.0.0
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv4 multicast"
    next
    edit 19
        set status enable
        set vlan 0
        set ether-type ipv6
        set src-addr-ipv6 ::/0
        set dst-addr-ipv6 ff00::/8
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv6 multicast"
    end
end
```

High availability

Only the M1 and M2 interfaces are used for the HA heartbeat communication. For information on how to set up HA heartbeat communication using the M1 and M2 interfaces, see [Connect the M1 and M2 interfaces for HA heartbeat communication on page 77](#)

The following FortiOS HA features are not supported or are supported differently by FortiGate-7000 v5.6.11:

- Active-active HA is not supported.
- The range for the HA `group-id` is 0 to 31.
- Failover logic for FortiGate-7000 HA is not the same as FGCP for other FortiGate clusters.
- HA heartbeat configuration is specific to FortiGate-7000 systems and differs from standard HA.
- FortiGate Session Life Support Protocol (FGSP) HA (also called standalone session synchronization) is not supported.
- FortiGate-7000 HA does not support the `route-ttl`, `route-wait`, and `route-hold` options for tuning route synchronization between FortiGate-7000s.

Use of the `diagnose sys ha checksum cluster` command not recommended

The FortiGate-7000 uses a custom FGCP HA implementation and the `diagnose sys ha checksum cluster` command may show incorrect checksums so can't be used to check cluster synchronization. Instead you can log into the primary FIM of each FortiGate-7000 in the cluster and use the `diagnose sys confsync showcsum` and compare the results.

Shelf manager module

It is not possible to access SMM CLI using Telnet or SSH. Only console access is supported using the chassis front panel console ports as described in the FortiGate-7000 system guide.

For monitoring purpose, IPMI over IP is supported on SMM Ethernet ports. See your FortiGate-7000 system guide for details.

FortiOS features not supported by FortiGate-7000 v5.6.11

The following mainstream FortiOS 5.6.11 features are not supported by the FortiGate-7000 v5.6.11:

- Hardware switch
- Usage-based ECMP load balancing is not supported. If the `config system settings v4-ecmp-mode` option is set to `usage-based`, all traffic uses the first ECMP route instead of being load balanced among all ECMP routes. All other ECMP load balancing options are supported, including `source-ip-based`, `weight-based`, and `source-dest-ip-based`.
- Switch controller
- WiFi controller
- WAN load balancing (SD-WAN)

- IPv4 over IPv6, IPv6 over IPv4, IPv6 over IPv6 features
- GRE tunneling is only supported after creating a load balance flow rule, for example:

```
config load-balance flow-rule
  edit 0
    set status enable
    set vlan 0
    set ether-type ip
    set protocol gre
    set action forward
    set forward-slot master
    set priority 3
  end
```

- Hard disk features including, WAN optimization, web caching, explicit proxy content caching, disk logging, and GUI-based packet sniffing.
- The FortiGate-7000 platform only supports quarantining files to FortiAnalyzer.
- Log messages should be sent only using the management aggregate interface
- The FortiGate-7000 does not support configuring dedicated management interfaces using the `config system dedicated-mgmt` command or by enabling the `dedicated-to management interface` option.

IPsec VPN tunnels terminated by the FortiGate-7000

For a list of new FortiOS 5.6 FortiGate-7000 IPsec VPN features and a list of IPsec VPN features not supported by FortiOS 5.6 FortiGate-7000 IPsec VPN, see [New IPsec VPN features on page 69](#).

SSL VPN

Sending all SSL VPN sessions to the primary FPM is recommended. You can do this by:

- Creating a flow rule that sends all sessions that use the SSL VPN destination port and IP address to the primary FPM.
- Creating flow rules that send all sessions that use the SSL VPN IP pool addresses to the primary FPM.

For more information about FortiGate-7000 SSL VPN support, see [SSL VPN load balancing on page 58](#).

Traffic shaping and DDoS policies

Each FPM applies traffic shaping and DDoS quotas independently. Because of load-balancing, this may allow more traffic than expected.

FortiGuard web filtering and spam filtering queries

The FortiGate-7000 sends all FortiGuard web filtering and spam filtering rating queries through a management interface from the management VDOM.

Web filtering quotas

On a VDOM operating with the **Inspection Mode** set to **Proxy**, you can go to **Security Profiles > Web Filter** and set up **Category Usage Quotas**. Each FPM has its own quota, and the FortiGate-7000 applies quotas per FPM and not per the entire FortiGate-7000 system. This could result in quotas being exceeded if sessions for the same user are processed by different FPMs.

Log messages include a slot field

An additional "slot" field has been added to log messages to identify the FPM that generated the log.

FortiOS Carrier

You have to apply a FortiOS Carrier license separately to each FIM and FPM to license a FortiGate-7000 for FortiOS Carrier.

Special notice for new deployment connectivity testing

Only the primary FPM can successfully ping external IP addresses. During a new deployment, while performing connectivity testing from the Fortigate-7000, make sure to run `execute ping tests` from the primary FPM CLI.

FortiGate-7000 v5.6.7 special features and limitations

This section describes special features and limitations for FortiGate-7000 v5.6.7.

Managing the FortiGate-7000

Management is only possible through the MGMT1 to MGMT4 front panel management interfaces. By default the MGMT1 to MGMT4 interfaces of the FIMs in slot 1 and slot 2 are in a single static aggregate interface named mgmt with IP address 192.168.1.99. You manage the FortiGate-7000 by connecting any one of these eight interfaces to your network, opening a web browser and browsing to the management IP address. For a factory default configuration, browse to <https://192.168.1.99>.



The FortiGate-7030E has one FIM and the MGMT1 to MGMT4 interfaces of that module are the only interfaces in the aggregate interface.

Default management VDOM

By default the FortiGate-7000 configuration includes a management VDOM named mgmt-vdom. For the FortiGate-7000 system to operate normally you should not change the configuration of this VDOM and this VDOM should always be the management VDOM. You should also not add or remove interfaces from this VDOM.

You have full control over the configurations of other FortiGate-7000 VDOMs.

Default Security Fabric configuration

The FortiGate-7000 uses the Security Fabric for communication and synchronization among FIMs and FPMs. Changing the default Security Fabric configuration could disrupt this communication and affect system performance.

Default Security Fabric configuration:

```
config system csf
    set status enable
    set configuration-sync local
    set management-ip 0.0.0.0
    set management-port 0
end
```

For the FortiGate-7000 to operate normally, you must not change the Security Fabric configuration.

Maximum number of LAGs and interfaces per LAG

FortiGate-7000 systems support up to 16 link aggregation groups (LAGs). This includes both normal link aggregation groups and redundant interfaces and including the redundant interface that contains the M1 to M4 management interfaces. A FortiGate-7000 LAG can include up to 20 interfaces.

Firewall

TCP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal TCP timer (which is 3605 seconds) should only be distributed to the master FPM using a flow rule. You can configure the distributed normal TCP timer using the following command:

```
config system global
    set dp-tcp-normal-timer <timer>
end
```

UDP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal UDP timer should only be distributed to the primary FPM using a flow rule.

IP multicast

IPv4 and IPv6 Multicast traffic is only sent to the primary FPM (usually the FPM in slot 3). This is controlled by the following configuration:

```
config load-balance flow-rule
    edit 18
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 224.0.0.0 240.0.0.0
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv4 multicast"
    next
    edit 19
        set status enable
        set vlan 0
        set ether-type ipv6
        set src-addr-ipv6 ::/0
        set dst-addr-ipv6 ff00::/8
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv6 multicast"
end
```

High availability

Only the M1 and M2 interfaces are used for the HA heartbeat communication. For information on how to set up HA heartbeat communication using the M1 and M2 interfaces, see [Connect the M1 and M2 interfaces for HA heartbeat communication on page 77](#)

The following FortiOS HA features are not supported or are supported differently by FortiGate-7000 v5.6.7:

- Active-active HA is not supported.
- The range for the HA `group-id` is 0 to 31.
- Failover logic for FortiGate-7000 HA is not the same as FGCP for other FortiGate clusters.
- HA heartbeat configuration is specific to FortiGate-7000 systems and differs from standard HA.
- FortiGate Session Life Support Protocol (FGSP) HA (also called standalone session synchronization) is not supported.
- FortiGate-7000 HA does not support the `route-ttl`, `route-wait`, and `route-hold` options for tuning route synchronization between FortiGate-7000s.

Use of the `diagnose sys ha checksum cluster` command not recommended

The FortiGate-7000 uses a custom FGCP HA implementation and the `diagnose sys ha checksum cluster` command may show incorrect checksums so can't be used to check cluster synchronization. Instead you can log into the primary FIM of each FortiGate-7000 in the cluster and use the `diagnose sys confsync showcsum` and compare the results.

Shelf manager module

It is not possible to access SMM CLI using Telnet or SSH. Only console access is supported using the chassis front panel console ports as described in the FortiGate-7000 system guide.

For monitoring purpose, IPMI over IP is supported on SMM Ethernet ports. See your FortiGate-7000 system guide for details.

FortiOS features not supported by FortiGate-7000 v5.6.7

The following mainstream FortiOS 5.6.7 features are not supported by the FortiGate-7000 v5.6.7:

- Hardware switch
- Usage-based ECMP load balancing is not supported. If the `config system settings v4-ecmp-mode` option is set to `usage-based`, all traffic uses the first ECMP route instead of being load balanced among all ECMP routes. All other ECMP load balancing options are supported, including `source-ip-based`, `weight-based`, and `source-dest-ip-based`.
- Switch controller
- WiFi controller
- WAN load balancing (SD-WAN)

- IPv4 over IPv6, IPv6 over IPv4, IPv6 over IPv6 features
- GRE tunneling is only supported after creating a load balance flow rule, for example:

```
config load-balance flow-rule
edit 0
    set status enable
    set vlan 0
    set ether-type ip
    set protocol gre
    set action forward
    set forward-slot master
    set priority 3
end
```

- Hard disk features including, WAN optimization, web caching, explicit proxy content caching, disk logging, and GUI-based packet sniffing.
- The FortiGate-7000 platform only supports quarantining files to FortiAnalyzer.
- Log messages should be sent only using the management aggregate interface
- The FortiGate-7000 does not support configuring dedicated management interfaces using the `config system dedicated-mgmt` command or by enabling the `dedicated-to management` interface option.

IPsec VPN tunnels terminated by the FortiGate-7000

For a list of new FortiOS 5.6 FortiGate-7000 IPsec VPN features and a list of IPsec VPN features not supported by FortiOS 5.6 FortiGate-7000 IPsec VPN, see [New IPsec VPN features on page 69](#).

SSL VPN

Sending all SSL VPN sessions to the primary FPM is recommended. You can do this by:

- Creating a flow rule that sends all sessions that use the SSL VPN destination port and IP address to the primary FPM.
- Creating flow rules that send all sessions that use the SSL VPN IP pool addresses to the primary FPM.

For more information about FortiGate-7000 SSL VPN support, see [SSL VPN load balancing on page 58](#).

Traffic shaping and DDoS policies

Each FPM applies traffic shaping and DDoS quotas independently. Because of load-balancing, this may allow more traffic than expected.

FortiGuard web filtering and spam filtering queries

The FortiGate-7000 sends all FortiGuard web filtering and spam filtering rating queries through a management interface from the management VDOM.

Web filtering quotas

On a VDOM operating with the **Inspection Mode** set to **Proxy**, you can go to **Security Profiles > Web Filter** and set up **Category Usage Quotas**. Each FPM has its own quota, and the FortiGate-7000 applies quotas per FPM and not per the entire FortiGate-7000 system. This could result in quotas being exceeded if sessions for the same user are processed by different FPMs.

Log messages include a slot field

An additional "slot" field has been added to log messages to identify the FPM that generated the log.

FortiOS Carrier

You have to apply a FortiOS Carrier license separately to each FIM and FPM to license a FortiGate-7000 for FortiOS Carrier.

Special notice for new deployment connectivity testing

Only the primary FPM can successfully ping external IP addresses. During a new deployment, while performing connectivity testing from the Fortigate-7000, make sure to run `execute ping tests` from the primary FPM CLI.

FortiGate-7000 v5.6.6 special features and limitations

This section describes special features and limitations for FortiGate-7000 v5.6.6.

Managing the FortiGate-7000

Management is only possible through the MGMT1 to MGMT4 front panel management interfaces. By default the MGMT1 to MGMT4 interfaces of the FIMs in slot 1 and slot 2 are in a single static aggregate interface named mgmt with IP address 192.168.1.99. You manage the FortiGate-7000 by connecting any one of these eight interfaces to your network, opening a web browser and browsing to the management IP address. For a factory default configuration, browse to <https://192.168.1.99>.



The FortiGate-7030E has one FIM and the MGMT1 to MGMT4 interfaces of that module are the only interfaces in the aggregate interface.

Default management VDOM

By default the FortiGate-7000 configuration includes a management VDOM named mgmt-vdom. For the FortiGate-7000 system to operate normally you should not change the configuration of this VDOM and this VDOM should always be the management VDOM. You should also not add or remove interfaces from this VDOM.

You have full control over the configurations of other FortiGate-7000 VDOMs.

Default Security Fabric configuration

The FortiGate-7000 uses the Security Fabric for communication and synchronization among FIMs and FPMs. Changing the default Security Fabric configuration could disrupt this communication and affect system performance.

Default Security Fabric configuration:

```
config system csf
    set status enable
    set configuration-sync local
    set management-ip 0.0.0.0
    set management-port 0
end
```

For the FortiGate-7000 to operate normally, you must not change the Security Fabric configuration.

Maximum number of LAGs and interfaces per LAG

FortiGate-7000 systems support up to 16 link aggregation groups (LAGs). This includes both normal link aggregation groups and redundant interfaces and including the redundant interface that contains the M1 to M4 management interfaces. A FortiGate-7000 LAG can include up to 20 interfaces.

Firewall

TCP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal TCP timer (which is 3605 seconds) should only be distributed to the master FPM using a flow rule. You can configure the distributed normal TCP timer using the following command:

```
config system global
    set dp-tcp-normal-timer <timer>
end
```

UDP sessions with NAT enabled that are expected to be idle for more than the distributed processing normal UDP timer should only be distributed to the primary FPM using a flow rule.

IP multicast

IPv4 and IPv6 Multicast traffic is only sent to the primary FPM (usually the FPM in slot 3). This is controlled by the following configuration:

```
config load-balance flow-rule
    edit 18
        set status enable
        set vlan 0
        set ether-type ipv4
        set src-addr-ipv4 0.0.0.0 0.0.0.0
        set dst-addr-ipv4 224.0.0.0 240.0.0.0
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv4 multicast"
    next
    edit 19
        set status enable
        set vlan 0
        set ether-type ipv6
        set src-addr-ipv6 ::/0
        set dst-addr-ipv6 ff00::/8
        set protocol any
        set action forward
        set forward-slot master
        set priority 5
        set comment "ipv6 multicast"
    end
end
```

High availability

Only the M1 and M2 interfaces are used for the HA heartbeat communication. For information on how to set up HA heartbeat communication using the M1 and M2 interfaces, see [Connect the M1 and M2 interfaces for HA heartbeat communication on page 77](#)

The following FortiOS HA features are not supported or are supported differently by FortiGate-7000 v5.6.6:

- Active-active HA is not supported.
- The range for the HA `group-id` is 0 to 14.
- Failover logic for FortiGate-7000 HA is not the same as FGCP for other FortiGate clusters.
- HA heartbeat configuration is specific to FortiGate-7000 systems and differs from standard HA.
- FortiGate Session Life Support Protocol (FGSP) HA (also called standalone session synchronization) is not supported.
- FortiGate-7000 HA does not support the `route-ttl`, `route-wait`, and `route-hold` options for tuning route synchronization between FortiGate-7000s.

Use of the `diagnose sys ha checksum cluster` command not recommended

The FortiGate-7000 uses a custom FGCP HA implementation and the `diagnose sys ha checksum cluster` command may show incorrect checksums so can't be used to check cluster synchronization. Instead you can log into the primary FIM of each FortiGate-7000 in the cluster and use the `diagnose sys confsync showcsum` and compare the results.

Shelf manager module

It is not possible to access SMM CLI using Telnet or SSH. Only console access is supported using the chassis front panel console ports as described in the FortiGate-7000 system guide.

For monitoring purpose, IPMI over IP is supported on SMM Ethernet ports. See your FortiGate-7000 system guide for details.

FortiOS features not supported by FortiGate-7000 v5.6.6

The following mainstream FortiOS 5.6.6 features are not supported by the FortiGate-7000 v5.6.6:

- Hardware switch
- Usage-based ECMP load balancing is not supported. If the `config system settings v4-ecmp-mode` option is set to `usage-based`, all traffic uses the first ECMP route instead of being load balanced among all ECMP routes. All other ECMP load balancing options are supported, including `source-ip-based`, `weight-based`, and `source-dest-ip-based`.
- Switch controller
- WiFi controller
- WAN load balancing (SD-WAN)

- IPv4 over IPv6, IPv6 over IPv4, IPv6 over IPv6 features
- GRE tunneling is only supported after creating a load balance flow rule, for example:

```
config load-balance flow-rule
  edit 0
    set status enable
    set vlan 0
    set ether-type ip
    set protocol gre
    set action forward
    set forward-slot master
    set priority 3
  end
```

- Hard disk features including, WAN optimization, web caching, explicit proxy content caching, disk logging, and GUI-based packet sniffing.
- The FortiGate-7000 platform only supports quarantining files to FortiAnalyzer.
- Log messages should be sent only using the management aggregate interface
- The FortiGate-7000 does not support configuring dedicated management interfaces using the `config system dedicated-mgmt` command or by enabling the `dedicated-to management interface` option.

IPsec VPN tunnels terminated by the FortiGate-7000

For a list of new FortiOS 5.6.6 FortiGate-7000 IPsec VPN features and a list of IPsec VPN features not supported by FortiOS 5.6.6 FortiGate-7000 IPsec VPN, see [New IPsec VPN features on page 69](#).

SSL VPN

Sending all SSL VPN sessions to the primary FPM is recommended. You can do this by:

- Creating a flow rule that sends all sessions that use the SSL VPN destination port and IP address to the primary FPM.
- Creating flow rules that send all sessions that use the SSL VPN IP pool addresses to the primary FPM.

For more information about FortiGate-7000 SSL VPN support, see [SSL VPN load balancing on page 58](#).

Traffic shaping and DDoS policies

Each FPM applies traffic shaping and DDoS quotas independently. Because of load-balancing, this may allow more traffic than expected.

FortiGuard web filtering and spam filtering queries

The FortiGate-7000 sends all FortiGuard web filtering and spam filtering rating queries through a management interface from the management VDOM.

Web filtering quotas

On a VDOM operating with the **Inspection Mode** set to **Proxy**, you can go to **Security Profiles > Web Filter** and set up **Category Usage Quotas**. Each FPM has its own quota, and the FortiGate-7000 applies quotas per FPM and not per the entire FortiGate-7000 system. This could result in quotas being exceeded if sessions for the same user are processed by different FPMs.

Log messages include a slot field

An additional "slot" field has been added to log messages to identify the FPM that generated the log.

FortiOS Carrier

You have to apply a FortiOS Carrier license separately to each FIM and FPM to license a FortiGate-7000 for FortiOS Carrier.

Special notice for new deployment connectivity testing

Only the primary FPM can successfully ping external IP addresses. During a new deployment, while performing connectivity testing from the Fortigate-7000, make sure to run `execute ping tests` from the primary FPM CLI.

FortiGate-7000 Load balancing commands

See the [FortiOS 5.6 CLI Reference](#) for information about FortiGate-7000 CLI commands:

- [config load-balance flow-rule](#)
- [config load-balance setting](#)
- [execute load-balance](#)
- [execute system console-server](#)
- [execute reset-vd-license](#)
- [execute log filter confsync-member](#)



Copyright© 2020 Fortinet, Inc. All rights reserved. Fortinet®, FortiGate®, FortiCare® and FortiGuard®, and certain other marks are registered trademarks of Fortinet, Inc., in the U.S. and other jurisdictions, and other Fortinet names herein may also be registered and/or common law trademarks of Fortinet. All other product or company names may be trademarks of their respective owners. Performance and other metrics contained herein were attained in internal lab tests under ideal conditions, and actual performance and other results may vary. Network variables, different network environments and other conditions may affect performance results. Nothing herein represents any binding commitment by Fortinet, and Fortinet disclaims all warranties, whether express or implied, except to the extent Fortinet enters a binding written contract, signed by Fortinet's General Counsel, with a purchaser that expressly warrants that the identified product will perform according to certain expressly-identified performance metrics and, in such event, only the specific performance metrics expressly identified in such binding written contract shall be binding on Fortinet. For absolute clarity, any such warranty will be limited to performance in the same ideal conditions as in Fortinet's internal lab tests. In no event does Fortinet make any commitment related to future deliverables, features or development, and circumstances may change such that any forward-looking statements herein are not accurate. Fortinet disclaims in full any covenants, representations, and guarantees pursuant hereto, whether express or implied. Fortinet reserves the right to change, modify, transfer, or otherwise revise this publication without notice, and the most current version of the publication shall be applicable.