



FortiGate-6000 and FortiGate-7000 - Release Notes

Version 6.2.10 Build 1212

FORTINET DOCUMENT LIBRARY

<https://docs.fortinet.com>

FORTINET VIDEO GUIDE

<https://video.fortinet.com>

FORTINET BLOG

<https://blog.fortinet.com>

CUSTOMER SERVICE & SUPPORT

<https://support.fortinet.com>

FORTINET TRAINING & CERTIFICATION PROGRAM

<https://www.fortinet.com/support-and-training/training.html>

NSE INSTITUTE

<https://training.fortinet.com>

FORTIGUARD CENTER

<https://fortiguard.com/>

END USER LICENSE AGREEMENT

<https://www.fortinet.com/doc/legal/EULA.pdf>

FEEDBACK

Email: techdoc@fortinet.com



June 28, 2022

FortiGate-6000 and FortiGate-7000 6.2.10 Build 1212 Release Notes

01-6210-797452-20220628

TABLE OF CONTENTS

Change log	5
FortiGate-6000 and FortiGate-7000 6.2.10 release notes	6
Supported FortiGate-6000 and 7000 models	6
What's new	7
Special notices	8
Maximum number of flow rules limited by hardware	8
VLAN ID 1 is reserved	8
Configuring the FortiGate-7000F SLBC management interface	8
FortiGate-6000F hardware generations	9
FortiGate-6000 FPCs and power failure	9
FortiGate-6000 HA, FPCs, and power failure	11
Troubleshooting an FPC failure	11
Displaying FPC link and heartbeat status	11
If both the base and fabric links are down	12
If only one link is down	13
Updating FPC firmware to match the management board	13
Troubleshooting configuration synchronization issues	14
More management connections than expected for one device	14
More ARP queries than expected for one device - potential issue on large WiFi networks	14
FGCP HA and VDOM mode	15
Resolving FIM or FPM boot device I/O errors	15
Formatting an FIM boot device and installing new firmware	15
Formatting an FPM boot device and installing new firmware	16
Before downgrading from FortiOS 6.2.10 remove virtual clustering	19
The Fortinet Security Fabric must be enabled	19
Adding flow rules to support DHCP relay	19
Limitations of installing FortiGate-6000 firmware from the BIOS after a reboot	21
Limitations of installing FortiGate-7000 firmware from the BIOS after a reboot	21
Installing firmware on an individual FortiGate-6000 FPC	22
Installing firmware on an individual FortiGate-7000 FPM	23
IPsec VPN notes and limitations	23
Quarantine to disk not supported	24
Local out traffic is not sent to IPsec VPN interfaces	24
Special configuration required for SSL VPN	24
If you change the SSL VPN server listening port	25
Adding the SSL VPN server IP address	25
Example FortiGate-6000 HA heartbeat switch configurations	26
Example triple-tagging compatible switch configuration	26
Example double-tagging compatible switch configuration	27
Example FortiGate-7000E HA heartbeat switch configuration	28
Example triple-tagging compatible switch configuration	28
Example double-tagging compatible switch configuration	29

Default FortiGate-6000 and 7000 configuration for traffic that cannot be load balanced	31
Managing individual FortiGate-6000 management boards and FPCs	37
Special management port numbers	37
HA mode special management port numbers	38
Connecting to individual FPC consoles	39
Connecting to individual FPC CLIs	40
Performing other operations on individual FPCs	40
Managing individual FortiGate-7000 FIMs and FPMs	41
Special management port numbers	41
HA mode special management port numbers	42
Managing individual FIMs and FPMs from the CLI	43
Connecting to individual FIM and FPM CLIs of the secondary FortiGate-7000 in an HA configuration	44
Upgrade information	45
HA graceful upgrade to FortiOS 6.2.10	45
About FortiGate-6000 firmware upgrades	46
About FortiGate-7000 firmware upgrades	46
Product integration and support	48
FortiGate-6000 6.2.10 special features and limitations	48
FortiGate-7000E 6.2.10 special features and limitations	48
FortiGate-7000F 6.2.10 special features and limitations	48
Maximum values	48
Resolved issues	49
Known issues	50

Change log

Date	Change description
June 28, 2022	Known issue 792717 added to Known issues on page 50 .
April 14, 2022	Initial version.

FortiGate-6000 and FortiGate-7000 6.2.10 release notes

These platform specific release notes describe new features, special notices, upgrade information, product integration and support, resolved issues, and known issues for FortiGate-6000 and 7000 for 6.2.10 Build 1212.

In addition, special notices, upgrade information, product integration and support, resolved issues, known issues, and limitations described in the [FortiOS 6.2.10 Release Notes](#) also apply to FortiGate-6000 and 7000 for 6.2.10 Build 1212.

For FortiGate-6000 documentation for this release, see the [FortiGate-6000 Handbook](#).

For FortiGate-7000E documentation for this release, see the [FortiGate-7000E Handbook](#).

For FortiGate-7000F documentation for this release, see the [FortiGate-7000F Handbook](#).



You can find the FortiGate-6000 and 7000 for FortiOS 6.2.10 firmware images on the [Fortinet Support Download Firmware Images](#) page by selecting the **FortiGate-6K7K** product.

Supported FortiGate-6000 and 7000 models

FortiGate-6000 and 7000 for FortiOS 6.2.10 Build 1212 supports the following models:

- FortiGate-6300F
- FortiGate-6301F
- FortiGate-6500F
- FortiGate-6501F
- FortiGate-7030E
- FortiGate-7040E
- FortiGate-7060E
- FortiGate-7121F

What's new

FortiGate-6000 and 7000 for FortiOS 6.2.10 Build 1212 includes the bug fixes described in [Resolved issues on page 49](#).

Special notices

This section highlights some of the operational changes and other important features that administrators should be aware of for FortiGate-6000 and FortiGate-7000 6.2.10 Build 1212. The [Special notices](#) described in the [FortiOS 6.2.10 release notes](#) also apply to FortiGate-6000 and 7000 FortiOS 6.2.10 Build 1212.

Maximum number of flow rules limited by hardware

For all FortiGate-6000 and 7000 models, the CLI allows you to add up to 512 flow rules. However, the number of flow rules that you can add is actually limited by the FortiGate-6000 and 7000 internal switch hardware:

- All FortiGate-6000F models support up to 256 flow rules.
- All FortiGate-7000E models support up to 512 flow-rules.
- All FortiGate-7000F models support up to 52 flow-rules.

VLAN ID 1 is reserved

When setting up VLANs, do not set the VLAN ID to 1. This VLAN ID is reserved by FortiOS. Any configurations that use a VLAN with VLAN ID = 1 will not work as expected.

Configuring the FortiGate-7000F SLBC management interface

To be able to use FortiGate-7000F special SLBC management interface features, such as being able to log into any FIM or FPM using the management interface IP address and a special port number, you need to use the following command to select a FortiGate-7000F management interface to be the SLBC management interface.

You can use any of the FIM or FPM management interfaces to be the SLBC management interface. The following example uses the MGMT 1 interface of the FIM in slot 1. In the GUI and CLI the name of this interface is 1-mgmt1.

Enter the following command to set the 1-mgmt1 interface to be the SLBC management interface:

```
config global
  config load-balance setting
    set slbc-mgmt-intf 1-mgmt1
  end
```

To manage individual FIMs or FPMs using special management ports, the SLBC interface must be connected to a network.



The `slbc-mgmt-intf` option is set to `1-mgmt1` by default. If you decide to use a different management interface, you must also change the `slbc-mgmt-intf` to that interface.

FortiGate-6000F hardware generations

Two generations of FortiGate-6000F hardware are now available. Both generations support the same software features. Generation 2 has two hardware improvements:

- The FPCs include more memory.
- When connected to high-line AC power, generation 2 FortiGate-6000F models provide 1+1 PSU redundancy. When connected to high-line AC power, each PSU provides 2000W, which is enough power to run the entire system including all FPCs.

For more information on FortiGate-6000F generation 1 and generation 2, including supported firmware versions and how to determine the generation of your FortiGate-6000F hardware, see the Fortinet Knowledge base article: [Technical Tip: Information on FortiGate-6000F series Gen1 and Gen2](#).

For more information on generation 1 and generation 2 AC PSUs, see [FortiGate-6000F AC power supply units \(PSUs\)](#).

FortiGate-6000 FPCs and power failure

The FortiGate-6000 includes three hot-swappable power supplies in a 2+1 redundant configuration. At least two of the power supplies must be operating to provide power to the FortiGate-6000. If only one power supply is operating, only four of the FPCs will continue operating (usually the FPCs in slots 1 to 4).

From the management board GUI dashboard, the Sensor Information dashboard widget displays information about the status of the power supplies. If all power supplies are operating, the widget displays their **Status** as **Normal**.

From the management board CLI, you can use the `execute sensor list` command to verify if the power supplies are operating. The command displays the current status of all FortiGate-6000 sensors including the power supply sensors. Power supply sensor entries should be similar to the following (shown for a FortiGate-6301E). The power supply sensor lines start with `PS{1|2|3}`:

```
65 PS1 VIN          alarm=0 value=122 threshold_status=0
66 PS1 VOUT_12V     alarm=0 value=12.032 threshold_status=0
67 PS1 Temp 1       alarm=0 value=24 threshold_status=0
68 PS1 Temp 2       alarm=0 value=36 threshold_status=0
69 PS1 Fan 1        alarm=0 value=8832 threshold_status=0
70 PS1 Status       alarm=0
71 PS2 VIN          alarm=0 value=122 threshold_status=0
72 PS2 VOUT_12V     alarm=0 value=12.032 threshold_status=0
73 PS2 Temp 1       alarm=0 value=24 threshold_status=0
74 PS2 Temp 2       alarm=0 value=37 threshold_status=0
75 PS2 Fan 1        alarm=0 value=9088 threshold_status=0
76 PS2 Status       alarm=0
77 PS3 VIN          alarm=0 value=122 threshold_status=0
78 PS3 VOUT_12V     alarm=0 value=12.032 threshold_status=0
79 PS3 Temp 1       alarm=0 value=23 threshold_status=0
80 PS3 Temp 2       alarm=0 value=37 threshold_status=0
81 PS3 Fan 1        alarm=0 value=9088 threshold_status=0
82 PS3 Status       alarm=0
```

Any non zero `alarm` or `threshold_status` values indicate a possible problem with that power supply.

A FortiGate-6000 will continue to operate even if multiple FPCs stop operating. If an FPC stops operating, sessions being processed by that FPC also fail. All new sessions are load balanced to the remaining FPCs. The FortiGate-6000 will continue to operate but with reduced performance because fewer FPCs are operating.

If power is reconnected and the failed FPCs recover, the FortiGate-6000 will attempt to synchronize the configuration of the FPCs with the management board. If there have been few configuration changes, the failed FPCs may be able to become synchronized and operate normally. If there have been many configuration changes or a firmware upgrade, the FortiGate-6000 may not be able to re-synchronize the FPCs without administrator intervention to [Synchronize the FPCs with the management board](#).

To show the status of the FPCs, use the `diagnose load-balance status` command. In the command output, if Status Message is Running the FPC is operating normally. The following example shows the status of FPCs, for a FortiGate-6301F:

```
diagnose load-balance status
=====
MBD SN: F6KF313E17900032
  Master FPC Blade: slot-2

  Slot 1: FPC6KF3E17900200
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good      Data: Good
    Status Message:"Running"
  Slot 2: FPC6KF3E17900201
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good      Data: Good
    Status Message:"Running"
  Slot 3: FPC6KF3E17900207
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good      Data: Good
    Status Message:"Running"
  Slot 4: FPC6KF3E17900219
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good      Data: Good
    Status Message:"Running"
  Slot 5: FPC6KF3E17900235
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good      Data: Good
    Status Message:"Running"
  Slot 6: FPC6KF3E17900169
    Status:Working  Function:Active
    Link:          Base: Up          Fabric: Up
    Heartbeat: Management: Good      Data: Good
    Status Message:"Running"
```

For more information about troubleshooting FPC failures, see [Troubleshooting an FPC failure on page 11](#).

FortiGate-6000 HA, FPCs, and power failure

In a FortiGate-6000 HA cluster, if the FPCs in the primary FortiGate-6000 shut down because two of the power supplies fail or become disconnected from power, the cluster renegotiates and the FortiGate-6000 with the most operating FPCs becomes the primary FortiGate-6000.

If the FPCs in the secondary FortiGate-6000 shut down because two power supplies have failed or disconnected, its status in the cluster does not change. In future cluster negotiations the FortiGate-6000 with shut down FPCs is less likely to become the primary FortiGate-6000.



To prevent multiple failovers, if an FPC failure occurs in an HA cluster with override enabled, you should disable override until you can fix the problems and get all the FPCs up and running and synchronized.

After an FPC failure, sessions and configuration changes are not synchronized to the failed FPCs.

If failed FPCs recover in the secondary FortiGate-6000, it will continue to operate as the secondary FortiGate-6000 and will attempt to re-synchronize the FPCs with the management board. This process may take a few minutes, but if it is successful, the secondary FortiGate-6000 can return to fully participate in the cluster.

If there have been many configuration changes, the FPCs need to be manually synchronized with the management board. Log into the CLI of each out of synch FPC and enter the `execute factoryreset` command to reset the configuration. After the FPC restarts, the management board will attempt to synchronize the configuration of the FPC. If the configuration synchronization is successful, the FPC can start processing traffic again.

If there has been a firmware upgrade, and the firmware running on a failed FPC is out of date, you can upgrade the firmware of the FPC as described in the section: [Installing firmware on an individual FPC on page 1](#).

You can optionally use the following command to make sure the sessions on the FPCs in the secondary FortiGate-6000 are synchronized with the sessions on the FPCs in the primary FortiGate-6000.

```
diagnose test application chlbd 10
```

Once all of the FPCs are operating and synchronized, the secondary FortiGate-6000 can fully participate with the cluster.

Troubleshooting an FPC failure

This section describes some steps you can use to troubleshoot an FPC failure or to help provide information about the failure to Fortinet Support.

Displaying FPC link and heartbeat status

Start by running the `diagnose load-balance status` command from the management board CLI to check the status of the FPCs. The following output shows the FPC in slot 1 operating normally and a problem with the FPC in slot 2:

```
diagnose load-balance status
```

```
=====
MBD SN: F6KF31T018900143
```

```
Master FPC Blade: slot-1
```

```
Slot 1: FPC6KFT018901327
  Status:Working  Function:Active
  Link:          Base: Up          Fabric: Up
  Heartbeat: Management: Good     Data: Good
  Status Message:"Running"
Slot 2:
  Status:Dead     Function:Active
  Link:          Base: Up          Fabric: Down
  Heartbeat: Management: Failed   Data: Failed
  Status Message:"Waiting for management heartbeat."
...
```

If both the base and fabric links are down

If the `diagnose load-balance status` command shows that both the base and fabric links are down, the FPC may be powered off or shut down.

1. From the management board CLI, run the `execute sensor list` command to check the status of the power supplies. Look for the PS1, PS2, and PS3 output lines.

For example, for PS1:

```
...
65 PS1 VIN          alarm=0  value=122  threshold_status=0
66 PS1 VOUT_12V     alarm=0  value=12.032  threshold_status=0
67 PS1 Temp 1      alarm=0  value=26   threshold_status=0
68 PS1 Temp 2      alarm=0  value=38   threshold_status=0
69 PS1 Fan 1       alarm=0  value=8832  threshold_status=0
70 PS1 Status      alarm=0
...
```

If the power supplies are all OK, the output for all of the PS lines should include `Alarm=0` and `Status=0`.

2. If the command output indicates problems with the power supplies, make sure they are all connected to power. If they are connected, there may be a hardware problem. Contact Fortinet Support for assistance.
3. If the power supplies are connected and operating normally, set up two SSH sessions to the management board.
4. From SSH session 1, enter the following command to connect to the FPC console:


```
execute system console-server connect <slot_id>
```
5. Press Enter to see if there is any response.
6. From SSH session 2, use the following commands to power the FPC off and back on:


```
execute load-balance slot power-off <slot_id>
execute load-balance slot power-on <slot_id>
```
7. From SSH session1, check to see if the FPC starts up normally after running the `power-on` command.
8. If SSH session 1 shows the FPC starting up, when it has fully started, use the `get system status` command to compare the FPC and management board FortiOS versions.

If the versions don't match, see [Updating FPC firmware to match the management board on page 13](#)
9. If the FPC doesn't start up there may be a hardware problem, contact Fortinet Support for assistance.

If only one link is down

If the base or fabric link is up, then check the Heartbeat line of the `diagnose load-balance status` output. The following conditions on the FPC can cause the management heartbeat to fail:

- The FPC did not start up correctly.
- The FPC software may have stopped operating because a process has stopped.
- The FPC may have experienced a kernel panic.
- The FPC may have experienced a daemon or processes panic.

To get more information about the cause:

1. Set up two SSH sessions to the management board.
2. From SSH session 1, enter the following command to connect to the FPC console:

```
execute system console-server connect <slot_id>
```
3. Press Enter to see if there is any response.
4. If there is a response to SSH session 1 and if you can log into the FPC from SSH session 1:
 - a. Dump the crash log by entering:

```
diagnose debug crashlog read
```
 - b. Use the `get system status` command to compare the FPC and management board FortiOS versions.
If the versions don't match, see [Updating FPC firmware to match the management board on page 13](#).
5. If there is no response to SSH session 1, or if you cannot log into the FPC from SSH session 1, switch to SSH session 2.
 - a. From SSH session 2, run the NMI reset command:

```
execute load-balance slot nmi-reset <slot_id>
```
 - b. From SSH session 1, check to see if any messages appear.
 - c. If a kernel panic stack trace is displayed, save it.
The FPC should automatically reboot after displaying the stack trace.
 - d. If nothing happens on SSH session 1, go back to SSH session 2, and run the following commands to power off and power on the FPC:

```
execute load-balance slot power-off <slot_id>
execute load-balance slot power-on <slot_id>
```
 - e. If SSH session 1 shows the FPC starting up, when it has fully started, use the `get system status` command to compare the FPC and management board FortiOS versions.
If the versions don't match, see [Updating FPC firmware to match the management board on page 13](#).
 - f. If the versions match, start an SSH session to log into the FPC, and dump the comlog by entering:

```
diagnose debug comlog read
```


If the comlog was not enabled, it will be empty.
 - g. Also dump the crash log if you haven't been able to do so by entering:

```
diagnose debug crashlog read
```
 - h. Contact Fortinet Support for assistance.
If requested you can provide the comlog and crashlog to help determine the cause of the problem.

Updating FPC firmware to match the management board

Use the following steps to update the firmware running on the FPC to match the firmware running on the management board.

1. Obtain a FortiGate-6000 firmware image file that matches the version running on the management board and add it to an FTP or TFTP server or a to USB key.
2. Use the following command to upload the firmware image file to the internal FortiGate-6000 TFTP server:

```
execute upload image {ftp | tftp | usb}
```
3. Then from management board CLI, use the following command to upgrade the firmware running on the FPC:

```
execute load-balance update image <slot_id>
```
4. After the firmware has upgraded, use `get system status` on the FPC to confirm it is running the same firmware version as the management board.

Troubleshooting configuration synchronization issues

After confirming that the management board and the FPC are running the same firmware build, use the following command to determine if configuration synchronization errors remain:

```
diagnose sys confsync status
```

In the command output, `in_sync=1` means the FPC is synchronized and can operate normally, `in_sync=0` means the FPC is not synchronized. If the FPC is up but not synchronized, see [Troubleshooting Tip: FortiGate 7000 Series blade config synchronization issues \(confsync\)](#) for help troubleshooting configuration synchronization issues.

More management connections than expected for one device

The FortiGate-6000 and 7000 may show more management-related network activity than most FortiGate devices. This occurs because many management functions are handled independently by each FortiGate-6000 management board and individual FPCs and by each FortiGate-7000 FIM and FPM.

For example, when a FortiGate-6000 first starts up, the management board and all of the FPCs perform their DNS lookups. Resulting in more DNS-related traffic during startup than expected for a single device. Once the system is processing data traffic, the amount of management traffic would be proportional to the amount of traffic the system is processing.

More ARP queries than expected for one device - potential issue on large WiFi networks

The FortiGate-6000 and 7000 sends more ARP queries than expected because each FPC and FPM builds its own ARP table to be able to communicate with devices in the same broadcast domain or layer 2 network. This behavior does not cause a problem with most layer 2 networks. However, because the ARP traffic for all of the FPCs or FPMs comes from the same mac and IP address, on networks with broadcast filtering or ARP suppression, some of the FortiGate-6000 or 7000 ARP queries and replies may be suppressed. If this happens, FPCs or FPMs may not be able to build complete ARP tables. An FPC or FPM with an incomplete ARP table will not be able to forward sessions to some destinations that it should be able to reach, resulting in dropped sessions.

Broadcast filtering or ARP suppression is commonly used on large WiFi networks to control the amount of ARP traffic on the WiFi network. Dropped FortiGate-6000 or 7000 sessions have been seen when a FortiGate-6000 or 7000 is connected to the same broadcast domain as a large WiFi network with ARP suppression.

To resolve this dropped session issue, you can remove broadcast filtering or ARP suppression from the network. If this is not an option, Fortinet recommends that you install a layer 3 device to separate the FortiGate-6000 or 7000 from the WiFi network broadcast domain. ARP traffic is reduced because the FPCs or FPMs no longer need to add the addresses of all of the WiFi devices to their ARP tables since they are on a different broadcast domain. The FPCs or FPMs just need to add the address of the layer 3 device.

FGCP HA and VDOM mode

To successfully form an FGCP HA cluster, both FortiGate-6000s or 7000s must be operating in the same VDOM mode (Multi or Split-Task). You can change the VDOM mode after the cluster has formed.

Resolving FIM or FPM boot device I/O errors

If an FIM or FPM has boot device I/O errors, messages similar to the following appear during console sessions with the module:

```
EXT2-fs (sda1): previous I/O error to superblock detected
EXT2-fs (sda3): previous I/O error to superblock detected
```

If you see boot device I/O errors similar to these, you should contact Fortinet Support (<https://support.fortinet.com>) for assistance with finding the underlying cause of these errors.

Once the underlying cause is determined and resolved, you use BIOS commands to reformat and restore the affected boot device as described in the following sections.

Formatting an FIM boot device and installing new firmware

You can use the following steps to format an FIM boot device and install new firmware from a TFTP server.

1. Set up a TFTP server and copy the firmware file to the TFTP server default folder.
2. Set up your network to allow traffic between the TFTP server and one of the FIM MGMT interfaces.
3. Using the console cable supplied with your FortiGate-7000, connect the SMM Console 1 port on the FortiGate-7000 to the USB port on your management computer.
4. Start a terminal emulation program on the management computer. Use these settings:
Baud Rate (bps) 9600, Data bits 8, Parity None, Stop bits 1, and Flow Control None.
5. Press Ctrl-T to enter console switch mode.
6. Repeat pressing Ctrl-T until you have connected to the FIM to be updated. Example prompt for the FIM in slot 2:
<Switching to Console: FIM02 (9600)>
7. Optionally log in to the FIM's CLI.
8. Reboot the FIM.
You can do this using the `execute reboot` command from the CLI or by pressing the power switch on the FIM front panel.
9. When the FIM starts up, follow the boot process in the terminal session, and press any key when prompted to interrupt the boot process.
10. To format the FIM boot disk, press F.

11. Press Y to confirm that you want to erase all data on the boot disk and format it.
When the formatting is complete the FIM restarts.
12. Follow the boot process in the terminal session, and press any key when prompted to interrupt the boot process.
13. To set up the TFTP configuration, press C.
14. Use the BIOS menu to set the following. Change settings only if required.
 - [P]: Set image download port: MGMT1 (the connected MGMT interface.)
 - [D]: Set DHCP mode: Disabled
 - [I]: Set local IP address: The IP address of the MGMT interface that you want to use to connect to the TFTP server. This address must not be the same as the FortiGate-7000 management IP address and cannot conflict with other addresses on your network.
 - [S]: Set local Subnet Mask: Set as required for your network.
 - [G]: Set local gateway: Set as required for your network.
 - [V]: Local VLAN ID: Should be set to <none>. (use -1 to set the Local VLAN ID to <none>.)
 - [T]: Set remote TFTP server IP address: The IP address of the TFTP server.
 - [F]: Set firmware image file name: The name of the firmware image file that you want to install.
15. To quit this menu, press Q.
16. To review the configuration, press R.
To make corrections, press C and make the changes as required. When the configuration is correct, proceed to the next step.
17. To start the TFTP transfer, press T.
The firmware image is uploaded from the TFTP server and installed on the FIM. The FIM then restarts with its configuration reset to factory defaults. After restarting, the FIM configuration is synchronized to match the configuration of the primary FIM. The FIM restarts again and can start processing traffic.
18. Once the FIM restarts, verify that the correct firmware is installed.
You can do this from the FIM GUI dashboard or from the FPM CLI using the `get system status` command.
19. Enter the `diagnose sys confsync status | grep in_sy` command to verify that the configuration has been synchronized. The field `in_sync=1` indicates that the configurations of the FIMs and FPMs are synchronized. FIMs and FPMs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FIM or FPM that is not synchronized, log into the CLI of the FIM or FPM and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.
If you enter the `diagnose sys confsync status | grep in_sy` command before the FIM has restarted, it will not appear in the command output. As well, the Configuration Sync Monitor will temporarily show that it is not synchronized.

Formatting an FPM boot device and installing new firmware

You can use the following steps to format an FPM boot device and install new firmware from a TFTP server.

1. Set up a TFTP server and copy the firmware file into the TFTP server default folder.
2. Log into to the primary FIM CLI and enter the following command:
`diagnose load-balance switch set-compatible <slot> enable bios`
Where `<slot>` is the number of the FortiGate-7000 slot containing the FPM to be upgraded.
3. Set up your network to allow traffic between the TFTP server and a MGMT interface of one of the FIMs.
You can use any MGMT interface of either of the FIMs. When you set up the FPM TFTP settings below, you select the FIM that can connect to the TFTP server. If the MGMT interface you are using is one of the MGMT interfaces

connected as a LAG to a switch, you must shutdown or disconnect all of the other interfaces that are part of the LAG from the switch. This includes MGMT interfaces from both FIMs

4. Using the console cable supplied with your FortiGate-7000, connect the SMM Console 1 port on the FortiGate-7000 to the USB port on your management computer.
5. Start a terminal emulation program on the management computer. Use these settings:
Baud Rate (bps) 9600, Data bits 8, Parity None, Stop bits 1, and Flow Control None.
6. Press Ctrl-T to enter console switch mode.
7. Repeat pressing Ctrl-T until you have connected to the module to be updated. Example prompt:
<Switching to Console: FPM03 (9600)>
8. Optionally log into the FPM's CLI.
9. Reboot the FPM.
You can do this using the `execute reboot` command from the FPM's CLI or by pressing the power switch on the FPM front panel.
10. When the FPM starts up, follow the boot process in the terminal session and press any key when prompted to interrupt the boot process.
11. To format the FPM boot disk, press F.
12. Press Y to confirm that you want to erase all data on the boot disk and format it.
When the formatting is complete the FPM restarts.
13. Follow the boot process in the terminal session, and press any key when prompted to interrupt the boot process.
14. To set up the TFTP configuration, press C.
15. Use the BIOS menu to set the following. Change settings only if required.
[P]: Set image download port: FIM01 (the FIM that can communicate with the TFTP server).
[D]: Set DHCP mode: Disabled.
[I]: Set local IP address: The IP address of the MGMT interface of the selected FIM that you want to use to connect to the TFTP server. This address must not be the same as the FortiGate-7000 management IP address and cannot conflict with other addresses on your network.
[S]: Set local Subnet Mask: Set as required for your network.
[G]: Set local gateway: Set as required for your network.
[V]: Local VLAN ID: Should be set to <none>. (use -1 to set the Local VLAN ID to <none>.)
[T]: Set remote TFTP server IP address: The IP address of the TFTP server.
[F]: Set firmware image file name: The name of the firmware image file that you want to install.
16. To quit this menu, press Q.
17. To review the configuration, press R.
To make corrections, press C and make the changes as required. When the configuration is correct proceed to the next step.
18. To start the TFTP transfer, press T.
The firmware image is uploaded from the TFTP server and installed on the FPM. The FPM then restarts with its configuration reset to factory defaults. After restarting, the FPM configuration is synchronized to match the configuration of the primary FPM. The FPM restarts again and can start processing traffic.
19. Once the FPM restarts, verify that the correct firmware is installed.
You can do this from the FPM GUI dashboard or from the FPM CLI using the `get system status` command.
20. Enter the `diagnose sys confsync status | grep in_sy` command to verify that the configuration has been synchronized. The field `in_sync=1` indicates that the configurations of the FIMs and FPMs are synchronized.

FIMs and FPMs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FIM or FPM that is not synchronized, log into the CLI of the FIM or FPM and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.

If you enter the `diagnose sys confsync status | grep in_sy` command before the FPM has restarted, it will not appear in the command output. As well, the Configuration Sync Monitor will temporarily show that it is not synchronized.

21. Once the FPM is operating normally, log back in to the primary FIM CLI and enter the following command to reset the FPM to normal operation:

```
diagnose load-balance switch set-compatible <slot> disable
```

Configuration synchronization errors will occur if you do not reset the FPM to normal operation.

Before downgrading from FortiOS 6.2.10 remove virtual clustering

If you are operating a FortiGate-6000 or 7000 system running FortiOS 6.2.10 with virtual clustering enabled, and decide to downgrade to FortiOS 6.0.x or earlier, you must remove all VDOMs from virtual cluster 2 and disable VDOM partitioning before performing the firmware downgrade.

If there are VDOMs in virtual cluster 2 when you perform the firmware downgrade, the FortiGate-6000 FPCs or FortiGate-7000 FIMs and FPMs may not be able to start up after the previous firmware version is installed. If this happens you may have to reset the configurations of all components to factory defaults.

The Fortinet Security Fabric must be enabled

FortiGate-6000 and 7000 Session-Aware Load Balancing (SLBC) uses the Fortinet Security Fabric for internal communication and synchronization.

In both Split-Task and Multi VDOM modes you can enable Fortinet Telemetry from the GUI by going to **Security Fabric > Settings** and enabling and configuring **FortiGate Telemetry**.

In either VDOM mode, you can also enable the Security Fabric from the CLI using the following command:

```
config system global
  cong system csf
    set status enable
end
```

Adding flow rules to support DHCP relay

The FortiGate-6000 and FortiGate-7000 default flow rules may not handle DHCP relay traffic correctly.

The default configuration includes the following flow rules for DHCP traffic:

```
config load-balance flow-rule
  edit 7
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 67-67
    set dst-l4port 68-68
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv4 server to client"
  next
  edit 8
    set status enable
```

```

set vlan 0
set ether-type ipv4
set src-addr-ipv4 0.0.0.0 0.0.0.0
set dst-addr-ipv4 0.0.0.0 0.0.0.0
set protocol udp
set src-l4port 68-68
set dst-l4port 67-67
set action forward
set forward-slot master
set priority 5
set comment "dhcpv4 client to server"
end

```

These flow rules handle traffic when the DHCP client sends requests to a DHCP server using port 68 and the DHCP server responds using port 67. However, if DHCP relay is involved, requests from the DHCP relay to the DHCP server and replies from the DHCP server to the DHCP relay both use port 67. If this DHCP relay traffic passes through the FortiGate-6000 or 7000 you must add a new flow rule similar to the following to support port 67 DHCP traffic in both directions (the following example uses `edit 0` to add the DHCP relay flow using the next available flow rule index number):

```

config load-balance flow-rule
edit 0
set status enable
set vlan 0
set ether-type ipv4
set src-addr-ipv4 0.0.0.0 0.0.0.0
set dst-addr-ipv4 0.0.0.0 0.0.0.0
set protocol udp
set src-l4port 67-67
set dst-l4port 67-67
set action forward
set forward-slot master
set priority 5
set comment "dhcpv4 relay"
next

```

The default configuration also includes the following flow rules for IPv6 DHCP traffic:

```

edit 13
set status enable
set vlan 0
set ether-type ipv6
set src-addr-ipv6 ::/0
set dst-addr-ipv6 ::/0
set protocol udp
set src-l4port 547-547
set dst-l4port 546-546
set action forward
set forward-slot master
set priority 5
set comment "dhcpv6 server to client"
next
edit 14
set status enable
set vlan 0
set ether-type ipv6
set src-addr-ipv6 ::/0
set dst-addr-ipv6 ::/0

```

```

    set protocol udp
    set src-l4port 546-546
    set dst-l4port 547-547
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv6 client to server"
next

```

These flow rules handle traffic when the IPv6 DHCP client sends requests to a DHCP server using port 547 and the DHCP server responds using port 546. However, if DHCP relay is involved, requests from the DHCP relay to the DHCP server and replies from the DHCP server to the DHCP relay both use port 547. If this DHCP relay traffic passes through the FortiGate-7000 you must add a flow rule similar to the following to support port 547 DHCP traffic in both directions (the following example uses `edit 0` to add the DHCP relay flow using the next available flow rule index number):

```

config load-balance flow-rule
edit 0
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 547-547
    set dst-l4port 547-547
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv6 relay"
next

```

Limitations of installing FortiGate-6000 firmware from the BIOS after a reboot

Installing or upgrading FortiGate-6000 firmware from the BIOS installs firmware on and resets the configuration of the management board only. The FPCs will continue to operate with their current configuration and firmware build. The FortiGate-6000 system does not synchronize firmware upgrades performed from the BIOS.

See [Installing FortiGate-6000 firmware from the BIOS after a reboot](#) for detailed procedures for upgrading FortiGate-6000 firmware from the BIOS.

Limitations of installing FortiGate-7000 firmware from the BIOS after a reboot

Installing or upgrading FortiGate-7000 firmware from the BIOS installs firmware on and resets the configuration of the primary FIM only. The other FIM and the FPMs will continue to operate with their current configuration and firmware build. The FortiGate-7000 system does not synchronize firmware upgrades performed from the BIOS.

See [Installing FIM firmware from the BIOS after a reboot](#) and [Installing FPM firmware from the BIOS after a reboot](#) for detailed procedures for upgrading FortiGate-6000 firmware from the BIOS.

Installing firmware on an individual FortiGate-6000 FPC

You may want to install firmware on an individual FPC to resolve a software-related problem with the FPC or if the FPC is not running the same firmware version as the management board. The following procedure describes how to transfer a new firmware image file to the FortiGate-6000 internal TFTP server and then install the firmware on an FPC.

1. Copy the firmware image file to a TFTP server, FTP server, or USB key.
2. To upload the firmware image file onto the FortiGate-6000 internal TFTP server, from the management board CLI, enter one of the following commands.

- To upload the firmware image file from an FTP server:

```
execute upload image ftp <image-file-and-path> <comment> <ftp-server-address>
<username> <password>
```

- To upload the firmware image file from a TFTP server:

```
execute upload image tftp <image-file> <comment> <tftp-server-address>
```

- To upload the firmware image file from a USB key:

```
execute upload image usb <image-file-and-path> <comment>
```

3. Enter the following command to install the firmware image file on to an FPC:

```
execute load-balance update image <slot-number>
```

where <slot-number> is the FPC slot number.

This command uploads the firmware image to the FPC and the FPC restarts. When the FPC starts up, the configuration is reset to factory default settings and then synchronized by the management board. The FPC restarts again, rejoins the cluster, and is ready to process traffic.

4. To verify that the configuration of the FPC has been synchronized, enter the `diagnose sys confsync status | grep in_sy` command. The command output below shows an example of the synchronization status of some of the FPCs in an HA cluster of two FortiGate-6301F devices. The field `in_sync=1` indicates that the configuration of the FPC is synchronized.

```
FPC6KFT018901327, Slave, uptime=615368.33, priority=19, slot_id=1:1, idx=1, flag=0x4, in_sync=1
F6KF31T018900143, Master, uptime=615425.84, priority=1, slot_id=1:0, idx=0, flag=0x10, in_sync=1
FPC6KFT018901372, Slave, uptime=615319.63, priority=20, slot_id=1:2, idx=1, flag=0x4, in_sync=1
F6KF31T018900143, Master, uptime=615425.84, priority=1, slot_id=1:0, idx=0, flag=0x10, in_sync=1
FPC6KFT018901346, Slave, uptime=423.91, priority=21, slot_id=1:3, idx=1, flag=0x4, in_sync=1
```

FPCs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FPC that is not synchronized, log into the CLI of the FPC and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.

The example output also shows that the uptime of the FPC in slot 3 is lower than the uptime of the other FPCs, indicating that the FPC in slot 3 has recently restarted.

If you enter the `diagnose sys confsync status | grep in_sy` command before an FPC has completely restarted, it will not appear in the output. Also, the Configuration Sync Monitor will temporarily show that it is not synchronized.

Installing firmware on an individual FortiGate-7000 FPM

Use the following procedure to upgrade the firmware running on an individual FPM. To perform the upgrade, you must enter a command from the primary FIM CLI to allow ELBC communication with the FPM. Then you can just log in to the FPM GUI or CLI and perform the firmware upgrade.

During this procedure, the FPM will not be able to process traffic. However, the other FPMs and the FIMs should continue to operate normally.

After verifying that the FPM is running the right firmware, you must log back into the primary FIM CLI and return the FPM to normal operation.

1. Log in to the primary FIM CLI and enter the following command:


```
diagnose load-balance switch set-compatible <slot> enable elbc
```

 Where `<slot>` is the number of the slot containing the FPM to be upgraded.
2. Log in to the FPM GUI or CLI using its special port number.

To upgrade the firmware on the FPM in slot 3 from the GUI:

 - a. Connect to the FPM GUI by browsing to `https://<SLBC-management-ip>:44303`.
 - b. Go to **System > Firmware** and select **Browse** to select the firmware file to install.
 - c. Follow the prompts to select the firmware file, save the configuration, and upload the firmware file to the FPM.

To upgrade the firmware on an FPM from the CLI using TFTP see [Installing FPM firmware from the BIOS after a reboot](#).
3. After the FPM restarts, verify that the new firmware has been installed.

You can do this from the FPM GUI dashboard or from the FPM CLI using the `get system status` command.
4. Use the `diagnose sys confsync status | grep in_sy` to verify that the configuration has been synchronized. The field `in_sync=1` indicates that the configurations of that FIM or FPM is synchronized.

FIMs and FPMs that are missing or that show `in_sync=0` are not synchronized. To synchronize an FIM or FPM that is not synchronized, log into the CLI of the FIM or FPM and restart it using the `execute reboot` command. If this does not solve the problem, contact Fortinet Support at <https://support.fortinet.com>.

If you enter the `diagnose sys confsync status | grep in_sy` command before the FIM has completely restarted, it will not appear in the command output. As well, the Configuration Sync Monitor will temporarily show that it is not synchronized.
5. Once the FPM is operating normally, log back in to the primary FIM CLI and enter the following command to reset the FPM to normal operation:


```
diagnose load-balance switch set-compatible <slot> disable
```

Configuration synchronization errors will occur if you do not reset the FPM to normal operation.

IPsec VPN notes and limitations

FortiGate-6000 and 7000 for FortiOS 6.2.10 FortiOS 6.2.7 supports the following features for IPsec VPN tunnels terminated by the FortiGate:

- Interface-based IPsec VPN (also called route-based IPsec VPN) is supported. Policy-based IPsec VPN is not supported.
- Static and dynamic routing (BGP, OSPF, and RIP) over IPsec VPN tunnels is supported.

- The FortiGate-6000 and 7000 use load balancing to select an FPC or FPM to terminate traffic for a new tunnel instance and all traffic for that tunnel instance is terminated on the same FPC or FPM. You can optionally use the IPsec tunnel phase 1 configuration to select a specific FPC or FPM to terminate all tunnel instances started by that phase 1.
- When an IPsec VPN tunnel is initialized, the SA is synchronized to all FPCs or FPMs in the FortiGate-6000 or 7000, or in both FortiGate-6000s and 7000s in an HA configuration.
- Site-to-Site IPsec VPN is supported.
- Dialup IPsec VPN is supported. The FortiGate-6000 or 7000 can be the dialup server or client.
- Policy routes cannot be used for communication over IPsec VPN tunnels.
- VRF routes cannot be used for communication over IPsec VPN tunnels.
- IPv6 clear-text traffic (IPv6 over IPv4 or IPv6 over IPv6) is not supported.
- IPsec SA synchronization between HA peers is supported.
- Traffic between IPsec VPN tunnels is supported.

Quarantine to disk not supported

The FortiGate-6000 platform, including the FortiGate-6301F and the FortiGate-6501F, and the FortiGate-7000 platform does not support quarantining files to the internal hard disks. Instead you must set the quarantine function to quarantine files to FortiAnalyzer.

Local out traffic is not sent to IPsec VPN interfaces

On most FortiGate platforms, an administrator can test an IPsec tunnel by opening the FortiGate CLI and pinging a remote host on the network at the other end of the IPsec VPN tunnel. This is not currently supported by the FortiGate-6000 and 7000.

Special configuration required for SSL VPN

Using a FortiGate-6000 or 7000 as an SSL VPN server requires you to manually add an SSL VPN load balancing flow rule to configure the FortiGate-6000 or 7000 to send all SSL VPN sessions to the primary FPC (FortiGate-6000) or the primary FPM (FortiGate-7000). To match SSL VPN server traffic, the flow rule should include a destination port that matches the destination port of the SSL VPN server. A basic rule to allow SSL VPN traffic could be:

```
config load-balance flow-rule
  edit 0
    set status enable
    set ether-type ipv4
    set protocol tcp
    set dst-l4port 443-443
    set forward-slot master
    set comment "ssl vpn server to primary worker"
  end
```


This flow rule matches all sessions sent to port 443 (the default SSL VPN server listening port) and sends these sessions to the primary FPC or FPM. This should match all of your SSL VPN traffic if you are using the default SSL VPN server listening port (443). This flow rule also matches all other sessions using 443 as the destination port so all of this traffic is also sent to the primary FPC or FPM.



As a best practice, if you add a flow rule for SSL VPN, Fortinet recommends using a custom SSL VPN port (for example, 10443 instead of 443). This can improve performance by allowing SSL traffic on port 443 that is not part of your SSL VPN to be load balanced to FPCs or FPMs instead of being sent to the primary FPC or FPM by the SSL VPN flow rule.

If you change the SSL VPN server listening port

If you have changed the SSL VPN server listening port to 10443, you can change the SSL VPN flow rule as follows:

```
config load-balance flow-rule
  edit 26
    set status enable
    set ether-type ipv4
    set protocol tcp
    set dst-l4port 10443-10443
    set forward-slot master
    set comment "ssl vpn server to primary worker"
  end
```

You can also make the SSL VPN flow rule more specific by including the SSL VPN server interface in the flow rule. For example, if your FortiGate-6000 or 7000 listens for SSL VPN sessions on the port12 interface:

```
config load-balance flow-rule
  edit 26
    set status enable
    set ether-type ipv4
    set protocol tcp
    set src-interface port12
    set dst-l4port 10443-10443
    set forward-slot master
    set comment "ssl vpn server to primary worker"
  end
```

Adding the SSL VPN server IP address

You can also add the IP address of the FortiGate-6000 or 7000 interface that receives SSL VPN traffic to the SSL VPN flow rule to make sure that the flow rule only matches the traffic of SSL VPN clients connecting to the SSL VPN server. For example, if the IP address of the interface is 172.25.176.32:

```
config load-balance flow-rule
  edit 26
    set status enable
    set ether-type ipv4
    set protocol tcp
    set dst-addr-ipv4 172.25.176.32 255.255.255.255
    set dst-l4port 10443-10443
    set forward-slot master
    set comment "ssl vpn server to primary worker"
```

end

This flow rule will now only match SSL VPN sessions with 172.25.176.32 as the destination address and send all of these sessions to the primary FPC or FPM.

Example FortiGate-6000 HA heartbeat switch configurations

FortiGate-6000 for FortiOS 6.2.10 allows you use proprietary triple-tagging or double-tagging for HA heartbeat packets.

Example triple-tagging compatible switch configuration

The switch that you use for connecting HA heartbeat interfaces does not have to support IEEE 802.1ad (also known as Q-in-Q, double-tagging). But the switch should be able to forward the double-tagged frames. Some switches will strip out the inner tag and Fortinet recommends avoiding these switches. FortiSwitch D and E series can correctly forward double-tagged frames.



This configuration is not required for FortiGate-6000 HA configurations if you have set up direct connections between the HA heartbeat interfaces.

This example shows how to configure a FortiGate-6000 to use different VLAN IDs for the HA1 and HA2 HA heartbeat interfaces and then how to configure two interfaces on a Cisco switch to allow HA heartbeat packets.



This example sets the native VLAN ID for both switch ports to 777. You can use any VLAN ID as the native VLAN ID as long as the native VLAN ID is not the same as the allowed VLAN ID.

1. On both FortiGate-6000s, enter the following command to use different VLAN IDs for the HA1 and HA2 interfaces. The command sets the ha1 VLAN ID to 4091 and the ha2 VLAN ID to 4092:

```
config system ha
  set ha-port-dtag-mode proprietary
  set hbdev ha1 50 ha2 100
  set hbdev-vlan-id 4091
  set hbdev-second-vlan-id 4092
end
```

2. Use the `get system ha` or `get system ha status` command to confirm the VLAN IDs.

```
get system ha status
...
HBDEV stats:
F6KF51T018900026(updated 4 seconds ago):
  ha1: physical/10000full, up, rx-bytes/packets/dropped/errors=54995955/230020/0/0,
tx=63988049/225267/0/0, vlan-id=4091
  ha2: physical/10000full, up, rx-bytes/packets/dropped/errors=54995955/230020/0/0,
tx=63988021/225267/0/0, vlan-id=4092
F6KF51T018900022(updated 3 seconds ago):
  ha1: physical/10000full, up, rx-bytes/packets/dropped/errors=61237440/230023/0/0,
tx=57746989/225271/0/0, vlan-id=4091
```

```

    ha2: physical/10000full, up, rx-bytes/packets/dropped/errors=61238907/230023/0/0,
    tx=57746989/225271/0/0, vlan-id=4092
    ...

```

3. Configure the Cisco switch interface that connects the HA1 interfaces to allow packets with a VLAN ID of 4091:

```

interface <name>
switchport mode trunk
switchport trunk native vlan 777
switchport trunk allowed vlan 4091

```

4. Configure the Cisco switch port that connects the HA2 interfaces to allow packets with a VLAN ID of 4092:

```

interface <name>
switchport mode trunk
switchport trunk native vlan 777
switchport trunk allowed vlan 4092

```

Example double-tagging compatible switch configuration

The following switch configuration is compatible with FortiGate-6000 HA heartbeat double tagging and with the default TPID of 0x8100.

The FortiGate-6000 HA heartbeat configuration is.

```

config system ha
    set ha-port-dtag-mode double-tagging
    set hbdev ha1 50 ha2 50
    set hbdev-vlan-id 4091
    set hbdev-second-vlan-id 4092
end

```

Example third-party switch configuration:

Switch interfaces 37 and 38 connect to the HA1 interfaces of both FortiGate-6000s.

```

interface Ethernet37
description **** FGT-6000F HA1 HA HB ****
speed forced 10000full
switchport access vlan 660
switchport trunk native vlan 4091
switchport mode dot1q-tunnel
!
interface Ethernet38
description **** FGT-6000F HA1 HA HB ****
speed forced 10000full
switchport access vlan 660
switchport trunk native vlan 4091
switchport mode dot1q-tunnel
!

```

Switch interfaces 39 and 40 connect to the HA2 interfaces of both FortiGate-6000s.

```

interface Ethernet39
description **** FGT-6000F HA2 HA HB ****
mtu 9214
speed forced 10000full
no error-correction encoding
switchport access vlan 770

```

```

switchport trunk native vlan 4092
switchport mode dot1q-tunnel
!
interface Ethernet42
description **** FGT-6000F HA2 HA HB ****
mtu 9214
speed forced 10000full
no error-correction encoding
switchport access vlan 770
switchport trunk native vlan 4092
switchport mode dot1q-tunnel
!

```

Example FortiGate-7000E HA heartbeat switch configuration

FortiGate-7000E for FortiOS 6.2.10 allows you use proprietary triple-tagging or double-tagging for HA heartbeat packets.

Example triple-tagging compatible switch configuration

The switch that you use for connecting HA heartbeat interfaces does not have to support IEEE 802.1ad (also known as Q-in-Q, double-tagging), but the switch should be able to forward the double-tagged frames. Fortinet recommends avoiding switches that strip out the inner tag. FortiSwitch D and E series can correctly forward double-tagged frames.



This configuration is not required for FortiGate-7030E HA configurations if you have set up direct connections between the HA heartbeat interfaces.

This example shows how to configure a FortiGate-7000E to use different VLAN IDs for the M1 and M2 HA heartbeat interfaces and then how to configure two ports on a Cisco switch to allow HA heartbeat packets.



This example sets the native VLAN ID for both switch ports to 777. You can use any VLAN ID as the native VLAN ID as long as the native VLAN ID is not the same as the allowed VLAN ID.

1. On both FortiGate-7000Es in the HA configuration, enter the following command to use different VLAN IDs for the M1 and M2 interfaces. The command sets the M1 VLAN ID to 4086 and the M2 VLAN ID to 4087:

```

config system ha
  set ha-port-dtag-mode proprietary
  set hbdev "1-M1" 50 "2-M1" 50 "1-M2" 50 "2-M2" 50
  set hbdev-vlan-id 4086
  set hbdev-second-vlan-id 4087
end

```

2. Use the `get system ha` or `get system ha status` command to confirm the VLAN IDs.

```

get system ha status
...

```

HBDEV stats:

```
FG74E83E16000015(updated 1 seconds ago):
  1-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=579602089/2290683/0/0,
tx=215982465/761929/0/0, vlan-id=4086
  2-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=577890866/2285570/0/0,
tx=215966839/761871/0/0, vlan-id=4086
  1-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=579601846/2290682/0/0,
tx=215982465/761929/0/0, vlan-id=4087
  2-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=577890651/2285569/0/0,
tx=215966811/761871/0/0, vlan-id=4087
FG74E83E16000016(updated 1 seconds ago):
  1-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=598602425/2290687/0/0,
tx=196974887/761899/0/0, vlan-id=4086
  2-M1: physical/10000full, up, rx-bytes/packets/dropped/errors=596895956/2285588/0/0,
tx=196965052/761864/0/0, vlan-id=4086
  1-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=598602154/2290686/0/0,
tx=196974915/761899/0/0, vlan-id=4087
  2-M2: physical/10000full, up, rx-bytes/packets/dropped/errors=596895685/2285587/0/0,
tx=196965080/761864/0/0, vlan-id=4087
...
```

3. Configure the Cisco switch port that connects the M1 interfaces to allow packets with a VLAN ID of 4086:

```
interface <name>
switchport mode trunk
switchport trunk native vlan 777
switchport trunk allowed vlan 4086
```

4. Configure the Cisco switch port that connects the M2 interfaces to allow packets with a VLAN ID of 4087:

```
interface <name>
switchport mode trunk
switchport trunk native vlan 777
switchport trunk allowed vlan 4087
```

Example double-tagging compatible switch configuration

The following switch configuration is compatible with FortiGate-7040E HA heartbeat double tagging and with the default TPID of 0x8100.

The FortiGate-7040E HA heartbeat configuration is.

```
config system ha
  set ha-port-dtag-mode double-tagging
  set hbdev "1-M1" 50 "2-M1" 50 "1-M2" 50 "2-M2" 50
  set hbdev-vlan-id 4086
  set hbdev-second-vlan-id 4087
end
```

Example third-party switch configuration:

Switch interfaces 37 to 40 connect to the M1 interfaces of the FIMs in both FortiGate-7040E chassis.

```
interface Ethernet37
description **** FGT-7000E M1 HA HB ****
speed forced 10000full
switchport access vlan 660
switchport trunk native vlan 4086
switchport mode dot1q-tunnel
```

```

!
interface Ethernet38
description **** FGT-7000E M1 HA HB ****
speed forced 10000full
switchport access vlan 660
switchport trunk native vlan 4086
switchport mode dot1q-tunnel
!
interface Ethernet39
description **** FGT-7000E M1 HA HB ****
speed forced 10000full
switchport access vlan 660
switchport trunk native vlan 4086
switchport mode dot1q-tunnel
!
interface Ethernet40
description **** FGT-7000E M1 HA HB ****
speed forced 10000full
switchport access vlan 660
switchport trunk native vlan 4086
switchport mode dot1q-tunnel
!

```

Switch interfaces 41 to 44 connect to the M2 interfaces of the FIMs in both FortiGate-7040E chassis.

```

interface Ethernet41
description **** FGT-7000E M2 HA HB ****
mtu 9214
speed forced 10000full
no error-correction encoding
switchport access vlan 770
switchport trunk native vlan 4087
switchport mode dot1q-tunnel
!
interface Ethernet42
description **** FGT-7000E M2 HA HB ****
mtu 9214
speed forced 10000full
no error-correction encoding
switchport access vlan 770
switchport trunk native vlan 4087
switchport mode dot1q-tunnel
!
interface Ethernet43
description **** FGT-7000E M2 HA HB ****
mtu 9214
speed forced 10000full
no error-correction encoding
switchport access vlan 770
switchport trunk native vlan 4087
switchport mode dot1q-tunnel
!
interface Ethernet44
description **** FGT-7000E M2 HA HB ****
mtu 9214
speed forced 10000full

```

```
no error-correction encoding
switchport access vlan 770
switchport trunk native vlan 4087
switchport mode dot1q-tunnel
```

Default FortiGate-6000 and 7000 configuration for traffic that cannot be load balanced

The default `configure load-balance flow-rule` command contains the recommended default flow rules that control how the FortiGate-6000 or 7000 handles traffic types that cannot be load balanced. Most of the flow rules in the default configuration are enabled and are intended to send common traffic types that cannot be load balanced to the primary FPC or FPM. FortiGate-6000F, 7000E, and 7000F for FortiOS 6.2.10 have the same default flow rules with one exception.

The FortiGate-6000F and 7000E include the following flow rule:

```
config load-balance flow-rule
  edit 20
    set status enable
    set vlan 0
    set ether-type ip
    set protocol vrrp
    set action forward
    set forward-slot all
    set priority 6
    set comment "vrrp to all blades"
  next
end
```

For the FortiGate-7000F, the corresponding flow rule is:

```
config load-balance flow-rule
  edit 20
    set status enable
    set vlan 0
    set ether-type ip
    set protocol vrrp
    set action forward
    set forward-slot master
    set priority 6
    set comment "vrrp to master blade"
  next
end
```

All of the default flow rules identify the traffic type using the options available in the command and direct matching traffic to the primary (or master) FPC or FPM (`action` set to `forward` and `forward-slot` set to `master`). The default flow rules also include a comment that identifies the traffic type.

The default configuration also includes disabled flow rules for Kerberos and PPTP traffic. Normally, you would only need to enable these flow rules if you know that your FortiGate will be handling these types of traffic.

The CLI syntax below was created with the `show full configuration` command.

```
config load-balance flow-rule
edit 1
    set status disable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 88-88
    set dst-l4port 0-0
    set action forward
    set forward-slot master
    set priority 5
    set comment "kerberos src"
next
edit 2
    set status disable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 88-88
    set action forward
    set forward-slot master
    set priority 5
    set comment "kerberos dst"
next
edit 3
    set status enable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 179-179
    set dst-l4port 0-0
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "bgp src"
next
edit 4
    set status enable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 0-0
    set dst-l4port 179-179
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "bgp dst"
next
edit 5
    set status enable
    set vlan 0
    set ether-type ip
    set protocol udp
```



```
    set src-l4port 520-520
    set dst-l4port 520-520
    set action forward
    set forward-slot master
    set priority 5
    set comment "rip"
next
edit 6
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol udp
    set src-l4port 521-521
    set dst-l4port 521-521
    set action forward
    set forward-slot master
    set priority 5
    set comment "ripng"
next
edit 7
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 67-67
    set dst-l4port 68-68
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv4 server to client"
next
edit 8
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 68-68
    set dst-l4port 67-67
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv4 client to server"
next
edit 9
    set status disable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 1723-1723
    set dst-l4port 0-0
```

```
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "pptp src"
next
edit 10
    set status disable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 0-0
    set dst-l4port 1723-1723
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "pptp dst"
next
edit 11
    set status enable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 3784-3784
    set action forward
    set forward-slot master
    set priority 5
    set comment "bfd control"
next
edit 12
    set status enable
    set vlan 0
    set ether-type ip
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 3785-3785
    set action forward
    set forward-slot master
    set priority 5
    set comment "bfd echo"
next
edit 13
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol udp
    set src-l4port 547-547
    set dst-l4port 546-546
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv6 server to client"
```

```
next
edit 14
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ::/0
    set protocol udp
    set src-l4port 546-546
    set dst-l4port 547-547
    set action forward
    set forward-slot master
    set priority 5
    set comment "dhcpv6 client to server"
next
edit 15
    set status enable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 224.0.0.0 240.0.0.0
    set protocol any
    set action forward
    set forward-slot master
    set priority 5
    set comment "ipv4 multicast"
next
edit 16
    set status enable
    set vlan 0
    set ether-type ipv6
    set src-addr-ipv6 ::/0
    set dst-addr-ipv6 ff00::/8
    set protocol any
    set action forward
    set forward-slot master
    set priority 5
    set comment "ipv6 multicast"
next
edit 17
    set status disable
    set vlan 0
    set ether-type ipv4
    set src-addr-ipv4 0.0.0.0 0.0.0.0
    set dst-addr-ipv4 0.0.0.0 0.0.0.0
    set protocol udp
    set src-l4port 0-0
    set dst-l4port 2123-2123
    set action forward
    set forward-slot master
    set priority 5
    set comment "gtp-c to master blade"
next
edit 18
    set status enable
    set vlan 0
```

```
    set ether-type ip
    set protocol tcp
    set src-l4port 0-0
    set dst-l4port 1000-1000
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "authd http to master blade"
next
edit 19
    set status enable
    set vlan 0
    set ether-type ip
    set protocol tcp
    set src-l4port 0-0
    set dst-l4port 1003-1003
    set tcp-flag any
    set action forward
    set forward-slot master
    set priority 5
    set comment "authd https to master blade"
next
edit 20
    set status enable
    set vlan 0
    set ether-type ip
    set protocol vrrp
    set action forward
    set forward-slot all
    set priority 6
    set comment "vrrp to all blades"
next
end
```

Managing individual FortiGate-6000 management boards and FPCs

You can manage individual FPCs using special management port numbers, FPC consoles, or the `execute load-balance slot manage` command. You can also use the `execute ha manage` command to log in to the other FortiGate-6000 in an HA configuration.

Special management port numbers

You may want to connect to individual FPCs to view status information or perform a maintenance task, such as installing firmware or performing a restart. You can connect to the GUI or CLI of individual FPCs (or the management board) using the MGMT1 interface IP address with a special port number.



You can use the `config load-balance setting slbc-mgmt-intf` command to change the management interface used. The default is `mgmt1` and it can be changed to `mgmt2`, or `mgmt3`.

To enable using the special management port numbers to connect to individual FPCs, set `slbc-mgmt-intf` to an interface that is connected to a network, has a valid IP address, and has management or administrative access enabled. To block access to the special management port numbers you can set `slbc-mgmt-intf` to an interface that is not connected to a network, does not have a valid IP address, or has management or administrative access disabled.

For example, if the MGMT1 interface IP address is 192.168.1.99 you can connect to the GUI of the first FPC (the FPC in slot 1) by browsing to :

```
https://192.168.1.99:44301
```

The special port number (in this case, 44301) is a combination of the service port (for HTTPS, the service port is 443) and the FPC slot number (in this example, 01).

You can view the special HTTPS management port number for and log in to the GUI of an FPC from the Configuration Sync Monitor.

The following table lists the special ports you can use to connect to individual FPCs or the management board using common management protocols. The FortiGate-6300F and 6301F have 7 slots (0 to 6) and the FortiGate-6500F and 6501F have 11 slots (0 to 10). Slot 0 is the management board (MBD) slot. Slots 1 to 10 are FPC slots.



You can't change the special management port numbers. Changing configurable management port numbers, for example the HTTPS management port number (which you might change to support SSL VPN), does not affect the special management port numbers.

FortiGate-6000 special management port numbers

Slot Address	HTTP (80)	HTTPS (443)	Telnet (23)	SSH (22)	SNMP (161)
Slot 0, (MBD)	8000	44300	2300	2200	16100
Slot 1 (FPC01)	8001	44301	2301	2201	16101
Slot 2 (FPC02)	8002	44302	2302	2202	16102
Slot 3 (FPC03)	8003	44303	2303	2203	16103
Slot 4 (FPC04)	8004	44304	2304	2204	16104
Slot 5 (FPC05)	8005	44305	2305	2205	16105
Slot 6 (FPC06)	8006	44306	2306	2206	16106
Slot 7 (FPC07)	8007	44307	2307	2207	16107
Slot 8 (FPC08)	8008	44308	2308	2208	16108
Slot 9 (FPC09)	8009	44309	2309	2209	16109
Slot 10 (FPC10)	8010	44310	2310	2210	16110

For example, to connect to the CLI of the FPC in slot 3 using SSH, you would connect to `ssh://192.168.1.99:2203`.

To verify which slot you have logged into, the GUI header banner and the CLI prompt shows the current hostname. The System Information dashboard widget also shows the host name and serial number. The CLI prompt also shows slot address in the format `<hostname> [<slot address>] #`.

Logging in to different FPCs allows you to use the FortiView or Monitor GUI pages to view the activity on that FPC. You can also restart the FPC from its GUI or CLI. Even though you can log in to different FPCs, you can only make configuration changes from the management board.

HA mode special management port numbers

In an HA configuration consisting of two FortiGate-6000s in an HA cluster, you can connect to individual FPCs or to the management board in chassis 1 (chassis ID = 1) using the same special port numbers as for a standalone FortiGate-6000.

You use different special port numbers to connect to individual FPCs or the management board in the FortiGate-6000 with chassis ID 2 (chassis ID = 2).

FortiGate-6000 special management port numbers (chassis ID = 2)

Slot Address	HTTP (80)	HTTPS (443)	Telnet (23)	SSH (22)	SNMP (161)
Slot 0, (MBD)	8020	44320	2320	2220	16120
Slot 1 (FPC01)	8021	44321	2321	2221	16121
Slot 2 (FPC02)	8022	44322	2322	2222	16122

Slot Address	HTTP (80)	HTTPS (443)	Telnet (23)	SSH (22)	SNMP (161)
Slot 3 (FPC03)	8023	44323	2323	2223	16123
Slot 4 (FPC04)	8024	44324	2324	2224	16124
Slot 5 (FPC05)	8025	44325	2325	2225	16125
Slot 6 (FPC06)	8026	44326	2326	2226	16126
Slot 7 (FPC07)	8027	44327	2327	2227	16127
Slot 8 (FPC08)	8028	44328	2328	2228	16128
Slot 9 (FPC09)	8029	44329	2329	2229	16129
Slot 10 (FPC10)	8030	44330	2330	2230	16130

Connecting to individual FPC consoles

From the management board CLI, you can use the `execute system console-server` command to access individual FPC consoles. Console access can be useful for troubleshooting. For example, if an FPC does not boot properly, you can use console access to view the state of the FPC and enter commands to fix the problem or restart the FPC.

From the console, you can also perform BIOS-related operations, such as rebooting the FPC, interrupting the boot process, and installing new firmware.

For example, from the management board CLI, use the following command to log in to the console of the FPC in slot 3:

```
execute system console-server connect 3
```

Authenticate to log in to the console and use CLI commands to view information, make changes, or restart the FPC. When you are done, use **Ctrl-X** to exit from the console back to the management board CLI. Using **Ctrl-X** may not work if you are accessing the CLI console from the GUI. Instead you may need to log out of the GUI and then log in again.

Also, from the management board CLI you can use the `execute system console-server showline` command to list any active console server sessions. Only one console session can be active for each FPC, so before you connect to an FPC console, you can use the following command to verify whether or not there is an active console session. The following command output shows an active console session with the FPC in slot 4:

```
execute system console-server showline
MB console line connected - 1
Telnet-to-console line connected - 4
```

To clear an active console session, use the `execute system console-server clearline` command. For example, to clear an active console session with the FPC in slot 4, enter:

```
execute system console-server clearline 4
```



In an HA configuration, the `execute system console-server` commands only allow access to FPCs in the FortiGate-6000 that you are logged into. You can't use this command to access FPCs in the other FortiGate-6000 in an HA cluster

Connecting to individual FPC CLIs

From the management board CLI you can use the following command to log into the CLI of individual FPCs:

```
execute load-balance slot manage <slot-number>
```

Where:

<slot> is the slot number of the component that you want to log in to. The management board is in slot 0 and the FPC slot numbers start at 1.

When connected to the CLI of a FPC, you can view information about the status or configuration of the FPC, restart the FPC, or perform other operations. You should not change the configuration of individual FPCs because this can cause configuration synchronization errors.

Performing other operations on individual FPCs

You can use the following commands to restart, power off, power on, or perform an NMI reset on individual FPCs while logged into the management board CLI:

```
execute load-balance slot {nmi-reset | power-off | power on | reboot} <slots>
```

Where <slots> can be one or more slot numbers or slot number ranges separated by commas. Do not include spaces.

For example, to shut down the FPCs in slots 2, and 4 to 6 enter:

```
execute load-balance slot power-off 2,4-6
```


Managing individual FortiGate-7000 FIMs and FPMs

You can manage individual FIMs and FPMs using special port numbers or the `execute load-balance slot manage` command. You can also use the `execute ha manage` command to log in to the other FortiGate-7000 in an HA configuration.

Special management port numbers

In some cases, you may want to connect to individual FIMs or FPMs to view status information or perform a maintenance task such as installing firmware or performing a restart. You can connect to the GUI or CLI of individual FIMs or FPMs in a FortiGate-7000 using the SLBC management interface IP address with a special port number.

You use the following command to configure the SLBC management interface:

```
config global
  config load-balance setting
    set slbc-mgmt-intf <interface>
  end
```

Where <interface> becomes the SLBC management interface.



To enable using the special management port numbers to connect to individual FIMs and FPMs, the SLBC management interface must be connected to a network, have a valid IP address, and have management or administrative access enabled. To block access to the special management port numbers, disconnect the mgmt interface from a network, configure the SLBC management interface with an invalid IP address, or disable management or administrative access for the SLBC management interface.

You can connect to the GUI or CLI of individual FIMs or FPMs using the SLBC management interface IP address followed by a special port number. For example, if the SLBC management interface IP address is 192.168.1.99, to connect to the GUI of the FPM in slot 3, browse to:

```
https://192.168.1.99:44303
```

The special port number (in this case 44303) is a combination of the service port (for HTTPS, the service port is 443) and the slot number (in this example, 03).

You can view the special HTTPS management port number for and log in to the GUI of an FIM or FPM from the Configuration Sync Monitor.

The following table lists the special port numbers to use to connect to each FortiGate-7000 slot using common management protocols.



You can't change the special management port numbers. Changing configurable management port numbers, for example the HTTPS management port (which you might change to support SSL VPN), does not affect the special management port numbers.

FortiGate-7000 special management port numbers (slot numbers in order as installed in the chassis)

Slot Number	Slot Address	HTTP (80)	HTTPS (443)	Telnet (23)	SSH (22)	SNMP (161)
11	FPM11	8011	44311	2311	2211	16111
9	FPM09	8009	44309	2309	2209	16109
7	FPM07	8007	44307	2307	2207	16107
5	FPM05	8005	44305	2305	2205	16105
3	FPM03	8003	44303	2303	2203	16103
1	FIM01	8001	44301	2301	2201	16101
2	FIM02	8002	44302	2302	2202	16102
4	FPM04	8004	44304	2304	2204	16104
6	FPM06	8006	44306	2306	2206	16106
8	FPM08	8008	44308	2308	2208	16108
10	FPM10	8010	44310	2310	2210	16110
12	FPM12	8012	44312	2312	2212	16112

For example, to connect to the GUI of the FIM in slot 2 using HTTPS you would browse to <https://192.168.1.99:44302>.

To verify which FIM or FPM you have logged into, the GUI header banner and the CLI prompt shows its hostname. The System Information dashboard widget also shows the host name and serial number. The CLI prompt also shows the slot address in the format `<hostname> [<slot address>] #`.

Logging in to different FIMs or FPMs allows you to use dashboard widgets, FortiView, or Monitor GUI pages to view the activity of that FIM or FPM. Even though you can log in to different modules, you can only make configuration changes from the primary FIM; which is usually the FIM in slot 1.

HA mode special management port numbers

In HA mode, you use the same special port numbers to connect to FIMs and FPMs in chassis 1 (chassis ID = 1) and different special port numbers to connect to FIMs and FPMs in chassis 2 (chassis ID = 2):

FortiGate-7000 HA special management port numbers

Chassis and Slot Number	Slot Address	HTTP (80)	HTTPS (443)	Telnet (23)	SSH (22)	SNMP (161)
Ch1 slot 11	FPM11	8011	44311	2311	2211	16111
Ch1 slot 9	FPM09	8009	44309	2309	2209	16109
Ch1 slot 7	FPM07	8007	44307	2307	2207	16107

Chassis and Slot Number	Slot Address	HTTP (80)	HTTPS (443)	Telnet (23)	SSH (22)	SNMP (161)
Ch1 slot 5	FPM05	8005	44305	2305	2205	16105
Ch1 slot 3	FPM03	8003	44303	2303	2203	16103
Ch1 slot 1	FIM01	8001	44301	2301	2201	16101
Ch1 slot 2	FIM02	8002	44302	2302	2202	16102
Ch1 slot 4	FPM04	8004	44304	2304	2204	16104
Ch1 slot 6	FPM06	8006	44306	2306	2206	16106
Ch1 slot 8	FPM08	8008	44308	2308	2208	16108
Ch1 slot 10	FPM10	8010	44310	2310	2210	16110
Ch1 slot 12	FPM12	8012	44312	2312	2212	16112
Ch2 slot 11	FPM11	8031	44331	2331	2231	16131
Ch2 slot 9	FPM09	8029	44329	2329	2229	16129
Ch2 slot 7	FPM07	8027	44327	2327	2227	16127
Ch2 slot 5	FPM05	8025	44325	2325	2225	16125
Ch2 slot 3	FPM03	8023	44323	2323	2223	16123
Ch2 slot 1	FIM01	8021	44321	2321	2221	16121
Ch2 slot 2	FIM02	8022	44322	2322	2222	16122
Ch2 slot 4	FPM04	8024	44324	2324	2224	16124
Ch2 slot 6	FPM06	8026	44326	2326	2226	16126
Ch2 slot 8	FPM08	8028	44328	2328	2228	16128
Ch2 slot 10	FPM10	8030	44330	2330	2230	16130
Ch2 slot 12	FPM12	8032	44332	2332	2232	16132

Managing individual FIMs and FPMs from the CLI

From any CLI, you can use the `execute load-balance slot manage <slot>` command to log into the CLI of different FIMs and FPMs. You can use this command to view the status or configuration of the module, restart the module, or perform other operations. You should not change the configuration of individual FIMs or FPMs because this can cause configuration synchronization errors.

`<slot>` is the slot number of the slot that you want to log in to.

After you log in to a different module in this way, you can't use the `execute load-balance slot manage` command to log in to another module. Instead, you must use the `exit` command to revert back to the CLI of the component that you originally logged in to. Then you can use the `execute load-balance slot manage` command to log into another module.

Connecting to individual FIM and FPM CLIs of the secondary FortiGate-7000 in an HA configuration

From the primary FIM of the primary FortiGate-7000 in an HA configuration, you can use the following command to log in to the primary FIM of the secondary FortiGate-7000:

```
execute ha manage <id>
```

Where <id> is the ID of the other FortiGate-7000 in the cluster. From the primary FortiGate-7000, use an ID of 0 to log into the secondary FortiGate-7000. From the secondary FortiGate-7000, use an ID of 1 to log into the primary FortiGate-7000. You can enter the ? to see the list of IDs that you can connect to.

After you have logged in, you can manage the secondary FortiGate-7000 from the primary FIM or you can use the `execute-load-balance slot manage` command to connect to the CLIs of the other FIM and the FPMs in the secondary FortiGate-7000.

Upgrade information



FortiOS 6.2.9 increased the FortiGate-7121F boot partition size. You must upgrade your FortiGate-7121F to FortiOS 6.2.9 using the information in the [FortiGate-7000 6.2.9 Release Notes](#) before upgrading to 6.2.10. The FortiGate-7121F is not supported by FortiOS 6.0.

Use the graceful upgrade information or other firmware upgrade information in these release notes to upgrade your FortiGate-6000 or 7000 system to the latest firmware version with only minimal traffic disruption and to maintain your configuration.

You can also refer to the Upgrade Path Tool (<https://docs.fortinet.com/upgrade-tool>) in the Fortinet documentation library to find supported upgrade paths for all FortiGate models and firmware versions.

A similar upgrade path tool is also available from Fortinet Support: <https://support.fortinet.com>.

In some cases, these upgrade path tools may recommend slightly different upgrade paths. If that occurs, the paths provided by both tools are supported and you can use either one.

See also, [Upgrade information](#) in the [FortiOS 6.2.10 release notes](#).



You can find the FortiGate-6000 and 7000 for FortiOS 6.2.10 firmware images on the [Fortinet Support Download Firmware Images](#) page by selecting the **FortiGate-6K7K** product.

HA graceful upgrade to FortiOS 6.2.10

Use the following steps to upgrade a FortiGate-6000, 7000E, or 7000F HA cluster with `uninterruptible-upgrade` enabled from FortiOS 6.2.9 to FortiOS 6.2.10. You can also use the following steps to upgrade a FortiGate-6000 or 7000E HA cluster with `uninterruptible-upgrade` enabled from FortiOS 6.0.13 to FortiOS 6.2.10. FortiGate-7000F is not supported by FortiOS 6.0.x.



FortiOS 6.2.9 increased the FortiGate-7121F boot partition size. You must upgrade your FortiGate-7121F to FortiOS 6.2.9 using the information in the [FortiGate-7000 6.2.9 Release Notes](#) before upgrading to 6.2.10.

Enabling `uninterruptible-upgrade` allows you to upgrade the firmware of an operating FortiGate-6000 or 7000 HA configuration with only minimal traffic interruption. During the upgrade, the secondary FortiGate upgrades first. Then a failover occurs and the newly upgraded FortiGate becomes the primary FortiGate and the firmware of the new secondary FortiGate upgrades.

To perform a graceful upgrade of your FortiGate-6000 or 7000 from FortiOS 6.2.9 to FortiOS 6.2.10:

1. Use the following command to enable `uninterruptible-upgrade` to support HA graceful upgrade:

```
config system ha
  set uninterruptible-upgrade enable
```

```
end
```

2. Download FortiOS 6.2.10 firmware for FortiGate-6000 or 7000 from the <https://support.fortinet.com> FortiGate-6K7K 6.2.10 firmware image folder.
3. Perform a normal upgrade of your HA cluster using the downloaded firmware image file.
4. Verify that you have installed the correct firmware version. For example, for the FortiGate-6301F:

```
get system status
Version: FortiGate-6301F v6.2.10,build1212,220405 (GA)
...
```

About FortiGate-6000 firmware upgrades

The management board and the FPCs in your FortiGate-6000 system run the same firmware image. You upgrade the firmware from the management board GUI or CLI just as you would any FortiGate product.

You can perform a graceful firmware upgrade of a FortiGate-6000 FGCP HA cluster by enabling `uninterruptible-upgrade` and `session-pickup`. A graceful firmware upgrade only causes minimal traffic interruption.

Upgrading the firmware of a standalone FortiGate-6000, or FortiGate-6000 HA cluster with `uninterruptible-upgrade` disabled interrupts traffic because the firmware running on the management board and all of the FPCs upgrades in one step. These firmware upgrades should be done during a quiet time because traffic will be interrupted during the upgrade process.

A firmware upgrade takes a few minutes, depending on the number of FPCs in your FortiGate-6000 system. Some firmware upgrades may take longer depending on factors such as the size of the configuration and whether an upgrade of the DP3 processor is included.

Before beginning a firmware upgrade, Fortinet recommends that you perform the following tasks:

- Review the latest release notes for the firmware version that you are upgrading to.
- Verify the recommended upgrade path, as documented in the release notes.
- Back up your FortiGate-6000 configuration.



Fortinet recommends that you review the services provided by your FortiGate-6000 before a firmware upgrade and then again after the upgrade to make sure that these services continue to operate normally. For example, you might want to verify that you can successfully access an important server used by your organization before the upgrade and make sure that you can still reach the server after the upgrade and performance is comparable. You can also take a snapshot of key performance indicators (for example, number of sessions, CPU usage, and memory usage) before the upgrade and verify that you see comparable performance after the upgrade.

About FortiGate-7000 firmware upgrades

All of the FIMs and FPMs in your FortiGate-7000 system run the same firmware image. You upgrade the firmware from the primary FIM GUI or CLI just as you would any FortiGate product.

You can perform a graceful firmware upgrade of a FortiGate-7000 FGCP HA cluster by enabling `uninterruptible-upgrade` and `session-pickup`. A graceful firmware upgrade only causes minimal traffic interruption.

Upgrading the firmware of a standalone FortiGate-7000, or FortiGate-7000 HA cluster with `uninterruptible-upgrade` disabled interrupts traffic because the firmware running on the FIMs and FPMs upgrades in one step. These firmware upgrades should be done during a quiet time because traffic will be interrupted during the upgrade process.

A firmware upgrade takes a few minutes, depending on the number of FIMs and FPMs in your FortiGate-7000 system. Some firmware upgrades may take longer depending on factors such as the size of the configuration.

Before beginning a firmware upgrade, Fortinet recommends that you perform the following tasks:

- Review the latest release notes for the firmware version that you are upgrading to.
- Verify the recommended upgrade path as documented in the release notes.
- Back up your FortiGate-7000 configuration.



Fortinet recommends that you review the services provided by your FortiGate-7000 before a firmware upgrade and then again after the upgrade to make sure the services continues to operate normally. For example, you might want to verify that you can successfully access an important server used by your organization before the upgrade and make sure that you can still reach the server after the upgrade, and performance is comparable. You can also take a snapshot of key performance indicators (for example, number of sessions, CPU usage, and memory usage) before the upgrade and verify that you see comparable performance after the upgrade.

Product integration and support

This section describes FortiGate-6000 and 7000 for FortiOS 6.2.10 Build 1212 product integration and support information. The [Product integration and support](#) information described in the [FortiOS 6.2.10 release notes](#) also applies to FortiGate-6000 and 7000 FortiOS 6.2.10 Build 1212.

FortiGate-6000 and 7000 require the following or newer versions of FortiManager and FortiAnalyzer:

- FortiGate-6000: FortiManager or FortiAnalyzer 6.4.8, 7.0.4, 7.2.1.
- FortiGate-7000: FortiManager or FortiAnalyzer 6.4.8, 7.0.4, 7.2.1.

FortiGate-6000 6.2.10 special features and limitations

FortiGate-6000 for FortiOS 6.2.10 has specific behaviors that may differ from FortiOS features. For more information, see the [Special features and limitations for FortiGate-6000 v6.2.10](#) section of the FortiGate-6000 handbook.

FortiGate-7000E 6.2.10 special features and limitations

FortiGate-7000E for FortiOS 6.2.10 has specific behaviors that may differ from FortiOS features. For more information, see the [Special features and limitations for FortiGate-7000E v6.2.10](#) section of the FortiGate-7000E handbook.

FortiGate-7000F 6.2.10 special features and limitations

FortiGate-7000F for FortiOS 6.2.10 has specific behaviors that may differ from FortiOS features. For more information, see the [Special features and limitations for FortiGate-7000F v6.2.10](#) section of the FortiGate-7000F handbook.

Maximum values

Maximum values for FortiGate-6000 and FortiGate-7000 for FortiOS 6.2.10 are available from the FortiOS Maximum Values Table (<https://docs.fortinet.com/max-value-table>).

Resolved issues

The following issues have been fixed in FortiGate-6000 and FortiGate-7000 FortiOS 6.2.10 Build 1212. For inquiries about a particular bug, please contact [Customer Service & Support](#). The [Resolved issues](#) described in the [FortiOS 6.2.10 release notes](#) also apply to FortiGate-6000 and 7000 FortiOS 6.2.10 Build 1212.

Bug ID	Description
680789	The GUI now displays accurate proxy firewall policy data including traffic hit counters.
739043	Added the slot ID field to SSL log messages sent to FortiAnalyzer.
749074	Firewall sessions for firewall users that authenticate using RADIUS are deleted when the firewall authentication idle time is reached and the FortiGate is configured to ignore RADIUS session timeouts set by the RADIUS server. Before this bug was fixed, RADIUS user sessions would never time out if the FortiGate was configured to ignore RADIUS session timeouts.
763074	Resolved an issue that could cause two interfaces to be incorrectly assigned the same SNMP index.
778296	Resolved an issue that could block passthrough or local-in traffic for a newly-created VDOM. The issue did not affect local-out traffic.
782338	A single SSL VPN user can no longer tie up multiple client IP addresses, resulting in fewer SSL VPN users being able to get IP addresses than expected.
786659	Resolved an issue that caused the <code>confsyncd</code> process running on the primary FIM of the primary FortiGate-7121F to crash, preventing configuration changes from synchronizing to the FPMs in the primary FortiGate-7121F.
795166 795521 796821	Resolved multiple TPM issues.


Known issues

The following issues have been identified in FortiGate-6000 and FortiGate-7000 FortiOS 6.2.10 Build 1212. For inquiries about a particular bug, please contact [Customer Service & Support](#). The [Known issues](#) described in the [FortiOS 6.2.10 release notes](#) also apply to FortiGate-6000 and 7000 FortiOS 6.2.10 Build 1212.

Bug ID	Description
734898	Under some conditions when a FortiGate-6000 or 7000 is very busy, when making configuration changes either manually or using a script, the <code>cmdbsvr</code> application may crash with a signal 11 segmentation fault. This problem can occur on a standalone FortiGate-6000 or 7000 or on FortiGate-6000s or 7000s in an FGCP HA cluster.
723530	The VRRP routing status is not synchronized to the FPMs or FIMs in the secondary FortiGate-6000 or 7000 in an FGCP cluster when the FGCP cluster in a VRRP group with a router.
792717	A dialup IPSec VPN tunnel can take a couple of minutes before allowing traffic through it, even though the tunnel appears to be up when viewed from the FortiGate GUI or CLI. This can happen if dead peer detection (DPD) is enabled on a large number of VPN clients accessing the tunnel. Receiving the DPD messages from many clients at the same time can trigger this issue. To work around the problem, you can disable dead peer detection on all FortiClients that access the tunnel.



FORTINET[®]



Copyright© 2022 Fortinet, Inc. All rights reserved. Fortinet®, FortiGate®, FortiCare® and FortiGuard®, and certain other marks are registered trademarks of Fortinet, Inc., in the U.S. and other jurisdictions, and other Fortinet names herein may also be registered and/or common law trademarks of Fortinet. All other product or company names may be trademarks of their respective owners. Performance and other metrics contained herein were attained in internal lab tests under ideal conditions, and actual performance and other results may vary. Network variables, different network environments and other conditions may affect performance results. Nothing herein represents any binding commitment by Fortinet, and Fortinet disclaims all warranties, whether express or implied, except to the extent Fortinet enters a binding written contract, signed by Fortinet's General Counsel, with a purchaser that expressly warrants that the identified product will perform according to certain expressly-identified performance metrics and, in such event, only the specific performance metrics expressly identified in such binding written contract shall be binding on Fortinet. For absolute clarity, any such warranty will be limited to performance in the same ideal conditions as in Fortinet's internal lab tests. In no event does Fortinet make any commitment related to future deliverables, features or development, and circumstances may change such that any forward-looking statements herein are not accurate. Fortinet disclaims in full any covenants, representations, and guarantees pursuant hereto, whether express or implied. Fortinet reserves the right to change, modify, transfer, or otherwise revise this publication without notice, and the most current version of the publication shall be applicable.