

FortiNAC - Hyper-V Virtual Machine Deployment Guide

Version 7.2. F



FORTINET DOCUMENT LIBRARY

https://docs.fortinet.com

FORTINET VIDEO GUIDE

https://video.fortinet.com

FORTINET BLOG

https://blog.fortinet.com

CUSTOMER SERVICE & SUPPORT

https://support.fortinet.com

FORTINET TRAINING & CERTIFICATION PROGRAM

https://www.fortinet.com/training-certification

NSE INSTITUTE

https://training.fortinet.com

FORTIGUARD CENTER

https://www.fortiguard.com

END USER LICENSE AGREEMENT

https://www.fortinet.com/doc/legal/EULA.pdf

FEEDBACK

Email: techdoc@fortinet.com

TABLE OF CONTENTS

Overview	
Prerequisite: Product Registration	6
Step 1: Download the Virtual Machine	27
Step 2: Copy Virtual Hard Drive	28
Step 3: Import Virtual Machine	29
Step 4: Edit Settings	31
Step 5: Assign Static IP Address for port1	32
Step 6 (Optional): Cloud-init using config drive	33
Step 7: Set a Static MAC Address	35
VLAN tagging	36
Generate and Download Keys	37
Appliance Configuration	40

Overview

This document provides the steps necessary for installing FortiNAC appliance(s). It is intended to be used in conjunction with the FortiNAC Deployment Guide in the Fortinet Document Library.

Virtual Appliance (VM) Part Numbers

Part Number	Description
FNC-MX-VM	Control Manager
FNC-CAX-VM	Control and Application Server (CA)

Requirements

- Hyper-V Server 2012, Windows 2012, 2016 or 2019 Server with Hyper-V.
 Note: Remote management must be enabled in Hyper-V Server 2012 to use Hyper-V Manager
- · Hyper-V Server Hardware
 - The requirements for the Hyper-V server used to host your FortiNAC Virtual Machine will vary greatly depending on many different factors. Factors include:
 - The number of other Virtual Machines that are running on the same server
 - · The load those VMs place on the server
 - The number of devices, hosts and users on your network that are to be managed by FortiNAC
- Virtual appliance settings will vary depending on the underlying hardware being used for the hosting server.
 The ideal result is to yield a virtual environment where the average load does not exceed the Total GHz Rating of CPU Resources Allocated.
 - Determine the appropriate parameters for the virtual environment. It is recommended they be comparable to those of hardware-based FortiNAC appliances. Refer to the following tables in the FortiNAC Data Sheet:
 - Hardware Server Sizing Hardware server part number most appropriate for the target environment
 - Specifications Details regarding the applicable part number
 - VM Server Resource Sizing Suggested values for memory and CPU to allocate for the virtual appliance
- Virtual Machine Generation: Generation 1 (for VHD) with IDE must be used. Generation 2 (for VHDX) with SCSI and UEFI is not supported at this time.
- VLAN Tagging and Trunking are supported with CentOS-7 and Hyper-V on Windows Server version 2016, 2012 R2, 2012, or 2008 R2. When configuring adapters for Layer 2 VLAN Tagging/Trunking, see VLAN Tagging in Appendix.

Considerations

In versions 7.x and greater, FortiNAC doesn't have any ports open by default. In previous versions, this was not the case. As features are configured, ports must also be added to the allowaccess list in order for the feature to work.

Operating System and Open Ports

FortiNAC-F series appliances use the FortiNAC-OS operating system. Limited TCP/UDP ports are open by default for security purposes. This was not the case for FortiNAC appliances using the CentOS operating system.

Virtual appliances do not have any TCP/UDP ports listening by default. Opening additional ports requires the use of the "set allowaccess" command in the appliance CLI.

The configuration steps provided include opening ports for the applicable features and functions covered in this guide. As more features are configured, additional access must be enabled using the "set allowaccess" command via the appliance CLI. For details, see Open Ports in the FortiNAC Administration Guide.

The best practice is to keep the number of open ports to a minimum, and block all other ports. If there is a need to provide users access to network resources through a static port (e.g., from outside a firewall), the best option is to allow users to connect by VPN.


Prerequisite: Product Registration

Products must be registered in order for the appropriate keys to be generated for the appliances. Without these keys, the appliances will not start.

Requirements Checklist

 Registration codes: Email from do-not-reply-contract@fortinet.com with attached .zip files containing registration codes for all products

Example



File name examples:

FNC-MX-VM_xxx.zip = Manager next-gen VM Server

FC-10-FNVXM-xxx.zip = Support & Maintenance for Manager next-gen VM Server

FNC-CAX-VM_xxx.zip = Control & Application next-gen VM Server

FC-10-FNVXA-xxx.zip = Support & Maintenance for Control & Application next-gen VM Server

LIC-FNAC-BASE-xxx.zip = Perpetual License, Base level

FC1-10-FNAC0-xxx.zip = Support & Maintenance for Perpetual Base Licenses

FCx-10-FNAC1-215-xx-xx.zip = Support & Maintenance for Subscription Base Licenses

LIC-FNAC-PLUS-xxx.zip = Perpetual License, Plus level

FC2-10-FNAC0-xxx.zip = Support & Maintenance for Perpetual Plus Licenses

FCx-10-FNAC1-213-xx-xx.zip = Support & Maintenance for Subscription Plus Licenses

LIC-FNAC-PRO-xxx.zip = Perpetual License, Pro level

FC3-10-FNAC0-xxx.zip = Support & Maintenance for Perpetual Pro Licenses

FCx-10-FNAC1-209-xx-xx.zip = Support & Maintenance for Subscription Pro Licenses

FP-10-PS-801-01-01.zip = Professional Service Days*


FP-10-PS-830-01-01.zip = Professional Service Days*

*Registered on the day of engagement only. See Fortinet Professional Services Contracts in the Appendix for more information.

Within the zip files are one or more PDF's which contain the Registration Code.

Tip: If multiple appliances were purchased, save these files in separate folders for each appliance.

Example A – CAVM Example B – Support for CAVM



• Physical Appliances Only: Serial number (FNxxxxxxxxxx). The serial number (S/N) is located on the label that shipped with the hardware. This label also contains the Product Name, Model/SKU, Fortinet P/N and HW ID.

Register the "Managing" Server


1. Use the chart below to determine the "managing" server (appliance to which the Endpoint License Key will be installed). The remaining servers in multiple appliance deployments are installed with an Appliance (Base) License Key.

For more information on how licenses are distributed for each system configuration, see section License Distribution in the Appendix.

Deployment Configuration	Managing Server	Part Number
Standalone	CA Server	FNC-CAX-xx
Standalone with High Availability (HA)	Primary CA Server	FNC-CAX-xx
Multiple Independent Standalones	Each CA Server	FNC-CAX-xx
Multiple Independent with High Availability (HA)	Each Primary CA Server	FNC-CAX-xx

Deployment Configuration	Managing Server	Part Number
Distributed	Control Manager	FNC-MX-xx
Distributed with High Availability (HA)	Primary Control Manager	FNC-MX-xx


- 2. Log into the Customer Portal at https://support.fortinet.com/
- 3. Click Register Product.
- 4. In the **Registration Code** field, enter the appropriate value.
 - **Virtual appliance**: Registration code from the pdf found in file FNC-CAX-VM_xxx (or if a Manager FNC-MX-VM.xxx).
 - Physical appliance: Serial number on label.
- 5. Click Next.




This page may appear if there was a POC or active evaluation license.

If you are converting your POC to production, select Convert Evaluation.


If you not converting your POC to production, select Register.



- **6.** Under Product Description, enter managing server's hostname or "Managing Server" (this can be edited later).
- 7. Select Fortinet Partner (ignore all other fields).
- 8. Click Next.




- 9. Read terms and conditions.
- 10. Click on radio button.
- 11. Click Next.




Note: "No Entitlement" will display. This is correct.

- 12. Click on radio button to accept.
- 13. Click Confirm.




CAX(VM) product registration is now complete.

- 14. Note the Serial Number (will be used in a future step).
- **15.** Proceed to register the support contract for the appliance. Click **Register More**.




Register Support Contract for Managing Server

- 1. Enter registration code found on pdf from file FC-10-FNxxx_xxx.
- 2. Click Next.



- **3.** Associate the support contract to the appropriate Serial Number noted in previous step.
 - If only one product is registered, there will only be on choice select that radio button.
 - If more than one product is registered, select the Serial Number noted in previous step. Selecting the radio button will auto-complete the Serial Number field.
- 4. Click Next.
- 5. Click on radio button in the lower left corner.
- 6. Click Confirm.



Support contract registration is now complete and applied to the FortiNAC-OS appliance.

7. Click Register More.


Proceed to the appropriate section:

Perpetual licenses: Register Perpetual Licenses


Subscription licenses: Register Support Contract for License

Register Perpetual Licenses

- **1.** Enter the registration code from the pdf found in the appropriate License file: LIC-FNAC-xxxxx-xxx xxx
- 2. Click on Next.




- 3. Associate the License to the managing server CAX(VM).
 - If only one CAX(VM) is registered, there will only be one choice select that radio button.
 - If more than one CAX(VM) is registered, select the appropriate CAX(VM) (Primary/Control server).
 Important: DO NOT license the secondary server. The secondary server will obtain its license from the Primary after High Availability is configured.
- 4. Click Next.




Perpetual license registration is complete.

5. Next step: Register the support contract for the License. Click Register More.




Register Support Contract for License


- 1. Enter registration code from the pdf found in the appropriate License Support file:
 - FCx-10-FNAC0-xxx-xxx (support for Perpetual licenses)
 - FCx-10-FNAC1-xxx-xx-xx (support for Subscription licenses)
- 2. Click Next.




- **3.** Associate the License Support contract to the managing server CAX(VM). If registering Perpetual licenses, this is the same serial number used in previous step.
- 4. Click Next.




- 5. Click on radio button in lower left corner.
- 6. Click Confirm.





Registering the License support contract is complete.

The page will display the products and support contracts registered.



- 7. Close the PDF files used in the previous steps.
- **8.** If there are additional CAX(VM)s to register (and its support contracts), click on **Register More**. Otherwise, click **Done**.

Register Remaining Appliances

- **1.** Open the folder for the next appliance to be registered.
- 2. Open the 2 PDF files.
- 3. Register the appliance.
 - a. Click Register Product.
 - b. Enter registration code from the PDF found in file FNC-CAX-xx_xxx (or if there is a Manager FNC-MX-xx.xxx).
 - c. Click Next.
 - d. If there was a POC or active evaluation license, a special page may display. If you are converting your POC to production, select **Convert Evaluation**. If you are not converting your POC to production, select **Register**.

- e. Enter "Managing Server" under Product Description (this can be edited later).
- f. Select Fortinet Partner (ignore all other fields).
- g. Click Next.
- h. Read terms and conditions.
- i. Click on radio button.
- j. Click Next.

Note: "No Entitlement" will display. This is correct.

- k. Click on radio button to accept.
- I. Click Confirm.

CAX(VM) product registration is now complete.

- m. Note the Serial Number (will be used to register the appliance support contract).
- n. Proceed to register the support contract for the appliance. Click Register More.
- 4. Register Support Contract for Appliance.
 - a. Enter registration code found on pdf from file FC-10-NCxx xxx.
 - b. Click Next.
 - c. Associate the support contract to the appropriate CAX(VM) Serial Number noted in previous step.
 - d. If only one CAX(VM) is registered, there will only be on choice select that radio button.
 - e. If more than one CAX(VM) products are registered, select the appropriate CAX(VM).
 - f. Click Next.
 - g. Click on radio button in the lower left corner.
 - h. Click Confirm.
 - i. Support contract registration is now complete and applied to the CAX(VM).
 - j. Close the PDF files used in the previous steps.

If there are additional CAX(VM)s to register (and its support contracts), click on **Register More**. Otherwise, click **Done**


* DO NOT REGISTER THE PROFESSIONAL SERVICES CONTRACTS *

Important: If a file for Professional Services (FP-10-PS-801-01-01.zip or FP-10-PS-830-01-01.zip) was included in the email, do not attempt to register. These are ONLY to be registered one at a time and on the day of the Professional Services session. One contract is like an "admission ticket" to the Professional Services session.


End result:

Once product registrations are complete, the summary page for each appliance will look similar to the example below. Note only the managing server (example below) will have license information listed.

Perpetual License Example:



Subscription License Example:



If assistance is needed with registering devices, contact Fortinet Customer Service.


Product Registration is complete. Proceed to next step.

Step 1: Download the Virtual Machine

After registering the products, download the appropriate HyperV.zip image.

Note: Both FortiNAC CAX and Manager use the same image. The product type is defined by the license key installed.

- 1. In the Customer Portal, navigate to **Support > Downloads**
- 2. Click VM Images



3. From drop down list, click **Other** and then click on **here**.



- 4. From drop down list, select FortiNAC-F.
- **5.** Select the Download Tab to reveal the available versions. Please select the version as recommended by Fortinet or Program Manager.

Note: The suggested version may be the GA version and not the newest version.


Step 2: Copy Virtual Hard Drive

Each appliance requires its own Virtual Machine and its own license. If multiple appliances were purchased, make a copy of the .vhd file downloaded and rename it for each Virtual Machine required. Make sure all of the .vhd files are on the Hyper-V Server.

When naming the vhd files, keep in mind that you will also be naming the associated virtual machine and you will be assigning a host name when configuring FortiNAC server. If you have more than one virtual machine, it may be beneficial to use similar names for the virtual hard drive, the virtual machine and the host name of the FortiNAC server.


Step 3: Import Virtual Machine

- 1. Extract the zip file.
- 2. Start Hyper-V Manager.
- 3. Select Hyper-V Manager in the tree on the left.
- **4.** Select the appropriate **Hyper-V Server**. If it is not displayed, select **Connect to Server** in the **Actions** panel on the right.
- **5.** On the **Select Computer** dialog, choose the computer that is running the Hyper-V server and click **OK**. The server is displayed in the tree on the left.



Select Computer

- 6. Select the Hyper-V Server.
- 7. In the Actions panel select New > Virtual Machine.
- 8. The New Virtual Machine Wizard is displayed. On the Before You Begin step click Next.
- 9. On the **Specify Name and Location** step, click in **the** Name field and enter a descriptive name for this virtual machine, such as NS_server_1. You may want to name the virtual machine something that is similar to the name of the virtual hard drive and the host name of the FortiNAC server. Click **Next**.
- **10.** On the **Assign Memory** step enter the amount of memory (at least 8 GB) that will be assigned to this virtual machine and click **Next**.
- 11. On the **Configure Networking** step, select the a VLAN or Network from the **Connection** drop-down and select Default Switch or VLAN, then click **Next**.
- **12.** On the **Connect Virtual Hard Disk** step, select **Use Existing Virtual Hard Disk**. If **Generation** option is available, select **Generation 1** (Generation 2 not supported at this time).
- 13. Browse to the .vhd file you copied and renamed earlier. Select the appropriate .vhd file.
- 14. Click **Next** to continue.
- 15. On the Summary screen, review your settings and click Finish. This creates the virtual infrastructure.



New Virtual Machine Wizard - Summary

Step 4: Edit Settings

The following describes the procedures for editing Virtual Machine settings.

Important: VLAN Tagging and Trunking are supported with CentOS-7 and Hyper-V on Windows Server version 2016, 2012 R2, 2012, or 2008 R2. When configuring adapters for Layer 2 VLAN Tagging/Trunking, see VLAN Tagging in Appendix.

- **1.** In Hyper-V Manager, select the FortiNAC virtual machine.
- 2. In the Actions panel under your virtual machine, select Settings.
- **3.** On the **Settings** dialog, all settings are configured by selecting an item from the tree on the left and modifying data in the panels on the right.

Virtual Machine Settings

- 4. Modify the Memory field as necessary. See the Requirements section to determine the setting required.
- 5. Select **Processor** and configure the correct number of processors for your server.
- 6. Select IDE Controller 0, make sure Hard Drive is highlighted and click Add.
- 7. Under Virtual Disk, navigate to the datadrive.vhd from the extracted zip. (This will be the drive for data storage)
- 8. Click Apply.
- **9.** Select **Network Adapter**. In the Network Adapter panel displayed, click **Remove** to remove the existing Network Adapter.
- **10.** Click **Add Hardware** at the top of the Hardware tree. Select the **Network Adapter** option.
 - **Important**: Do not use the **Legacy Network Adapter** option. Otherwise, inconsistent network connectivity may occur.
- 11. Click Add.
- **12.** Click in the Network drop-down and select a VLAN or Default Switch. This represents port1 or the management interface for the FortiNAC configuration. Select the Network that contains the IP address you will use for port1.
- **13.** If needed, add another Network Adapter by selecting **Add Hardware** at the top of the Hardware tree and choosing **Network Adapter** (avoid selecting **Legacy Network Adapter**).
- **14.** In the Network drop-down select a VLAN or Default Switch. This represents port2. Select the Network that contains your DHCP IP addresses. This network will be used for Isolation.
 - **Note**: The port2 adapter is not necessary if the virtual machine is being set up for a Manager (FNC-MX-VM).
- 15. Click OK to save Settings.
- 16. On the Actions panel under the virtual machine, click Start.

Step 5: Assign Static IP Address for port1

FortiNAC is configured by accessing the Configuration Wizard using the Management interface (port1) IP address. Follow the instructions below to set the IP address for port1.

Port1 has the following default configurations:

- IP address: 192.168.1.99
- FortiNAC interfaces do not communicate without the required protocols added to the appliance's access list for the port. The minimum required for appliance configuration are Administration UI access (port 8443) and SSH. Additional protocols can be added to the access list in the future as needed.
- 1. Once the virtual machine is running, click Connect to bring up the console.
- 2. Login to the FortiNAC CLI using the following:

User name = admin

Password = <no password>

3. To set the IP address and default gateway, type the following:

```
config system interface
edit port1
set ip <port1 ip addr>/<mask>
set allowaccess https-adminui ssh
next.
end
config system route
edit 1
set device port1
set gateway <default gateway>
end
Example:
config system interface
edit port1
set ip 10.12.234.175/22
set allowaccess https-adminui ssh
next.
end
config system route
edit 1
set device port1
set gateway 10.12.232.1
next
end
```

4. Confirm SSH access to the port1 IP address works.

Step 6 (Optional): Cloud-init using config drive

This section describes how to bootstrap a FortiNAC VM in Hyper-V using config drive. This method can be used if deploying VMs and need to preconfigure the FortiNAC VM so that it boots with a predetermined configuration.

FortiNAC-OS supports version 2 of the config-drive capabilities. Cloud-Init config drive was initially created for OpenStack and other cloud environments and is a capability available on the FortiNAC even when booting within Hyper-V. Config drive also allows the administrator to pass day zero configuration scripts to the FortiNAC VM on initial boot.

FortiNAC day zero configuration:

- port1 IP Address
- Subnet mask
- Gateway

If not using this function, proceed to Configure Network Access for port2.

Configure

1. To pass a config drive to the FortiNAC VM, create the following directory structure:

```
config-drive/openstack/latest/
```

2. Create the FortiNAC configuration script user_data via text editor. The configuration script for a FortiNAC VM uses FortiNAC-OS CLI syntax.

Script should contain the following content:

```
#<HostName> Day0 Configuration
config system interface
edit port1
set ip <port1 IP address>/<mask>
set allowaccess https-adminui ssh
next
end
config system route
edit 1
set device port1
set gateway <Default Gateway for port1>
next
end
```

Example

```
Hostname = FNC
port1 IP address and mask = 10.12.234.175/22
Default gateway = 10.12.232.1
```

```
cat config-drive/openstack/latest/user_data
#FNC Day0 Configuration
config system interface
edit port1
set ip 10.12.234.175/22
set allowaccess https-adminui ssh
next
```

```
end
config system route
edit 1
set device port1
set gateway 10.12.232.1
next
end
```

- **3.** Create the config drive ISO:
 - a. Create the config-drive ISO using a utility such as xorriso (other utilities can also be used to create ISOs, such as mkisofs).
 - b. Place the ISO on the data store so that it can be used with the FortiNAC VM.
- 4. Attach the config-drive ISO as a CDROM device:
 - a. Power off the FortiNAC VM.
 - b. In Hyper-V Manager, right click on the newly created VM and select Settings.
 - c. Select the DVD Drive under IDE Controller 1
 - d. Click on Image File: and browse to the config-drive ISO.
 - e. Click OK
 - f. Start the FortiNAC VM.

Validate

Open the console to verify that the VM is booting and utilizing the day zero configuration file that was provided.

To verify the results:

- 1. Go to the Console.
- 2. Login to the CLI.
- 3. Review port1 configuration. Type

```
get system interface physical
```

- 4. Confirm SSH access to the port1 IP address works.
- 5. Power off the VM.
- **6.** Under the VM settings, set the VM to boot from the main drive.
- 7. Start the VM.

Step 7: Set a Static MAC Address

If your Hyper-V environment assigns MAC Addresses dynamically, you will need to set the MAC addresses for FortiNAC VMs to be Static. Use the following instructions or refer to your Hyper-V documentation.

- 1. Power off the VM.
- 2. On the VM Properties, open the vNIC Properties.
- 3. Under Advanced Features, select the Static option.
- **4.** Enter the MAC address you wish to use as the static MAC address. **Important**: Ensure the MAC address is not within the dynamic address range generated by the Hyper-V host. See https://www.dtonias.com/set-vm-static-mac-address-hyper-v/
- 5. Start the VM.

Appliance installation is complete. Proceed to the FortiNAC Deployment Guide to continue deployment.

VLAN tagging

Refer to the following documentation:

Configure virtual local area networks for Hyper-V

https://docs.microsoft.com/en-us/windows-server/virtualization/hyper-v/deploy/configure-virtual-local-areal-networks-for-hyper-v

Hyper-V PowerShell Module

Hyper-V PowerShell Module is required to configure VLAN tagging. To view a list of Hyper-V related cmdlets on the system, type

```
PS C:\> Get-Command -Module Hyper-V
```

If the system does not return results, the Hyper-V PowerShell module must be installed. The module must be imported separately, by doing the following:

- Load the ServerManager Module. Type
 Import-Module ServerManager
- 2. To respond to the security warning, type 'R' <ENTER> to proceed with loading the ServerManager module.
- **3.** Load the Hyper-V PowerShell Module located in the Remote Server Administration Tools feature. Type Add-WindowsFeature RSAT-Hyper-V-Tools -IncludeAllSubFeature
- **4.** After a few minutes you'll receive the system response that the installation was successful and that no restart (reboot) is needed.

Configure VLAN Tagging

1. To create virtual adapters and tag VLANs, type:

```
Add-VMNetworkAdapter -SwitchName HYPERV1 -VMName "NS-Application-Server" -Name "port2"

Set-VMNetworkAdapterVlan -Trunk -AllowedVlanIdList "317,318" -VMName "NS-Application-Server" -VMNetworkAdapterName "port2" -NativeVlanId 1
```

2. Confirm that the changes have been applied. Type

```
Get-VMNetworkAdapterVlan
```

For more details and additional commands regarding VLAN tagging, refer to the following Microsoft document:

Supported CentOS and Red Hat Enterprise Linux virtual machines on Hyper-V

https://docs.microsoft.com/en-us/windows-server/virtualization/hyper-v/supported-centos-andred-hatenterprise-linux-virtual-machines-on-hyper-v

Generate and Download Keys

This step updates the product records in FortiCare with the required information for each appliance in order to generate the appropriate key files.

Key Generation Procedure Overview

- 1: Collect appliance information
- 2: Generate Key for Managing Server
- 3: Generate Key for Remaining Servers (VMs Only)

Collect Appliance Information

Collect the appropriate appliance information using one of the methods below.

UI Method

1. Launch the FortiNAC Administration UI by opening a web browser and navigating to:

```
https://<FortiNAC IP Address>:8443/
or
https://<FortiNAC Host Name>:8443/
```

2. Login using the Default FortiNAC Admin UI Credentials

User: root

Password: YAMS

- 3. Read the End User License Agreement. Accept the terms and proceed.
- 4. Under Enter License Key, the UUID (virtual appliances only) and port1 MAC address are displayed.
- **5. Record** the information. This information is used in the next step to generate the license key. You cannot currently import a license file because you do not have one yet.
- 6. Close the browser window.

CLI Method

- 1. Login to the appliance CLI as admin.
- 2. Enter the command

```
get hardware status
```

Record the UUID and MAC address from the resulting output.

3. Type exit

Physical Appliances

Eth 0 MAC address (xx:xx:xx:xx:xx or xx-xx-xx-xx) can also be found in the following locations:

- · Shipping label
- · Appliance Identification Details document

• On the back or the top of the metal casing of the appliance

Generate Key for Managing Server


- 1. Log into the Customer Portal at https://support.fortinet.com/
- 2. Go to Products > Product List.
- 3. Click the serial number for the appliance.
- 4. Edit the record in **Product Information**.
- 5. Enter the following:
 - Description (if modification is required)
 - port1 MAC Address
 - UUID (Virtual appliances only)

Note: Once MAC Address and/or UUID is entered and saved, it cannot be changed online. If assistance is needed with registering devices or changing these entries, contact Fortinet Customer Service.

6. Click Save.

The summary page has updated with the link to "Get The License File"

Important: Customers with new appliances should select the FortiNAC License File.



7. Click Get the License File.

If a Control Manager is registered, this screen may appear.



- **8.** Select the serial number of the Control Manager that will be managing this appliance (select Primary Control Manager if Managers are configured for High Availability).
- Click Download License Key File.
 The .lic filename will reflect the appliance serial number.
- 10. Once the file is downloaded, click Close.

Remaining Servers

Virtual Appliances: Repeat the previous steps to update each appliance record and download the key, saving each key file to their appropriate folder.

Physical Appliances: Repeat the previous steps to update each appliance record with the MAC Address. Do not download any additional keys. The remaining appliances use the installed key shipped with the hardware.

Key generation is complete. Proceed to next step.

Appliance Configuration

1. Follow the instructions in the Guided Install section of the Administration Guide.

These steps guide the user through the following tasks:


- · License key installation
- Network settings configuration
- · Password creation
- · port2 interface configuration
- 2. Verify appliance with the Endpoint License Key has the correct entitlements.
 - a. In the appliance with the Endpoint License Key installed, access the Administration UI using one of the following URLs:

https://<FortiNAC IP Address>:8443/

https://<FortiNAC Host Name>:8443/

If "Processes are Down" is displayed, there may be a UUID or MAC address mismatch. See related KB article 192992.

b. Locate the License Information widget in the Dashboard. If not available, click the **Add Widget** button at the top of Dashboard view to add.




c. Review the entitlements in the License Information widget to ensure they are accurate.

If entitlements are populated but not correct, review the entitlements in the customer portal (https://support.fortinet.com/) for that product. Contact Customer Service for assistance.

Subscription License: If panel is blank, see KB article 191745 for troubleshooting steps.

For more information regarding the different license types, see Perpetual and Subscription Licenses in Appendix.

Appliance installation is complete. Proceed to the FortiNAC Deployment Guide to continue deployment.



Copyright© 2024 Fortinet, Inc. All rights reserved. Fortinet®, FortiCare® and FortiGuard®, and certain other marks are registered trademarks of Fortinet, Inc., in the U.S. and other jurisdictions, and other Fortinet names herein may also be registered and/or common law trademarks of Fortinet. All other product or company names may be trademarks of their respective owners. Performance and other metrics contained herein were attained in internal lab tests under ideal conditions, and actual performance and other results may vary. Network variables, different network environments and other conditions may affect performance results. Nothing herein represents any binding commitment by Fortinet, and Fortinet disclaims all warranties, whether express or implied, except to the extent Fortinet enters a binding written contract, signed by Fortinet's General Counsel, with a purchaser that expressly warrants that the identified product will perform according to certain expressly-identified performance metrics and, in such event, only the specific performance metrics expressly identified in such binding written contract shall be binding on Fortinet. For absolute clarity, any such warranty will be limited to performance in the same ideal conditions as in Fortinet's internal lab tests. In no event does Fortinet make any commitment related to future deliverables, features or development, and circumstances may change such that any forward-looking statements herein are not accurate. Fortinet disclaims in full any covenants, representations, and guarantees pursuant hereto, whether express or implied. Fortinet reserves the right to change, modify, transfer, or otherwise revise this publication without notice, and the most current version of the publication shall be applicable.