



User Guide

FortiAI Ops 2.0.1



FORTINET DOCUMENT LIBRARY

<https://docs.fortinet.com>

FORTINET VIDEO GUIDE

<https://video.fortinet.com>

FORTINET BLOG

<https://blog.fortinet.com>

CUSTOMER SERVICE & SUPPORT

<https://support.fortinet.com>

FORTINET TRAINING & CERTIFICATION PROGRAM

<https://www.fortinet.com/training-certification>

NSE INSTITUTE

<https://training.fortinet.com>

FORTIGUARD CENTER

<https://www.fortiguard.com>

END USER LICENSE AGREEMENT

<https://www.fortinet.com/doc/legal/EULA.pdf>

FEEDBACK

Email: techdoc@fortinet.com

October 04, 2024

FortiAIOps 2.0.1 User Guide

83-201-1017991-20241004

TABLE OF CONTENTS

Change log	6
Overview	7
Getting Started	12
Installing FortiAI Ops	13
Initial FortiAI Ops Configuration	13
Licensing	14
Adding FortiGate	15
Enable Log Forwarding	15
Monitoring	16
Deploying FortiAI Ops on VM Platforms	18
Pre-installation Requirements	18
Installing FortiAI Ops on VMware ESXi	18
Installing FortiAI Ops on Hyper-V	20
Installing FortiAI Ops on KVM	28
Installing FortiAI Ops on Nutanix	30
Post-installation Tasks	34
Accessing FortiAI Ops	34
Upgrading FortiAI Ops	34
Deploying FortiAI Ops on Public Cloud Platforms	36
Microsoft Azure	36
Post-installation Tasks	44
Google Cloud Platform	44
Amazon Web Services (AWS)	51
Command Line Interface (CLI) Reference	57
Dashboard	62
Summary	62
AI Insights	64
Summary	66
Impacted Clients Trend	67
Overall Network Health	67
Top 3 Impacted Apps	69
Top 5 Problematic Devices	70
Wireless	70
WAN	87
Switching	92
Service Assurance	97
AI Insights	100
Impacted SLA	100
Impacted Devices	101
SLA Configurations	104
Device Health	105

Time To Connect	107
Roaming	108
SD-WAN	110
Inventory	113
Adding and Managing FortiGates	113
Adding a FortiGate	113
Importing and Exporting FortiGates	115
Managing FortiGates	115
Device Groups	126
Wireless	128
Access Points	128
AP	128
Radio	130
Access Points Diagnostics and Tools	131
Clients	136
Clients Diagnostics and Tools	137
Channel Summary	141
Applications	143
Location Services Monitor	145
Heat Maps	147
Rogue APs	152
Map Management	153
Switch	159
FortiSwitch	159
FortiSwitch Clients	165
Security Fabric	167
Physical Topology	167
Logical Topology	168
Logs and Reports	169
Event Logs	169
Reports	172
Creating Reports	172
Viewing Reports	179
Scheduled Reports	179
PCI Reports	179
System	181
User Management	181
Users	181
User Groups	182
Backup and Restore	183
Settings	185
Licensing	188
Location Services	188
Certificates	189

Service Assurance	191
Trends	191
Results	193
Baseline	194
Schedule	199


Change log

Date	Change description
2024-04-16	FortiAIOps 2.0.1 release document.
2024-04-17	Updated Amazon Web Services (AWS) and Licensing topics.
2024-05-06	Added Installing FortiAIOps on Nutanix .
2024-07-02	Updated Creating Reports .
2024-10-04	Updated Installing FortiAIOps .

Overview

FortiAI Ops enables you to view and monitor the status of your entire wireless, wired, and SD-WAN network and provides insights into key health statistics, based on the Artificial Intelligence (AI) and Machine Learning (ML) architecture that it is built upon. FortiAI Ops ingests data for analysis and automated event correlation to precisely detect anomalies that impact the clients' network experience. It learns from numerous sources such as FortiGates, FortiAPs, FortiSwitches, and FortiExtenders to report statistics on a series of comprehensive and simple dashboards, providing visibility and deep insight into your network. This predictable network infrastructure enables you to swiftly identify the root cause with the highest probability of association to actual issues, and its resolution.

FortiAI Ops monitors integrated wireless, wired, and SD-WAN networks by supporting the monitoring of FortiGate controllers. You can monitor and manage FortiGate controllers concurrently associated with FortiAPs and stations in a large deployments. The centralized real-time data and event logs offered by FortiAI Ops, aim at diagnosing and troubleshooting network issues by analyzing potential problems and suggesting remedial steps.



The FortiAIOps application provides the following advantages.

- Maximizes the uptime of your organization's network infrastructure.
- Reduces the time taken to diagnose network issues, thereby the mean response time.
- Increases the productivity of network users and that of your organization.

Click  to download the diagnostics to aid in troubleshooting, comprising of system, application, and FortiAIOps related logs. You can create the diagnostics file and download it as required.

Diagnostics

Choose content for diagnostics

- System Diagnostics
- Application Diagnostics
- AIOps Configurations

[Create File](#) [Download Latest File](#)

FortiAIOps calculates the SLA thresholds/baselines *dynamically* using the AI-ML architecture, to enable you to diagnose network issues based on accurate and latest data trends. The algorithms identify the values for each environment by clustering clients based on the connection quality using specific parameters. The thresholds are then derived based on the calculated average of the client connection data, to report variations in your network. These AI driven algorithms are designed to learn new data regularly for changes in client activity, calculate thresholds, and report statistics. You can also provide *static* threshold values to report network issues. You can view the impacted SLA data in the dashboards.

- [Wireless](#)
- [Switching](#)
- [WAN](#)

Wireless

The following SLAs are monitored for wireless clients.

- [Throughput](#)
- [Coverage](#)
- [Roaming](#)
- [Time to Connect](#)
- [Connection Failure](#)
- [AP Health and Uptime](#)

Throughput

This SLA monitors your wireless network at the system and client level, to identify potential low throughput conditions and categorize them based on the underlying issue type, into different classifiers and sub-classifiers. Low throughput is determined based on specific network health parameters, such as, noise, retries, discards, channel utilization etc. and client health parameters, such as, MCS index, data rate.

Coverage

Network coverage issues are monitored by detecting the coverage holes and overlapping FortiAPs (crowded FortiAPs). These conditions in a network are determined by evaluating client's RSSI (low signal strength) and presence of multiple neighbouring FortiAPs.

Roaming

Wireless clients roam from one AP to another in a multi-AP deployment area swiftly and frequently. Associating with different AP requires a process of re-authentication that can take some time to complete, impeding data connectivity especially for time sensitive applications. The *Roaming* SLA identifies such slow roaming connections, determines the causes for it and suggests suitable remedy for facilitating faster client roaming.

Time to Connect

This SLA computes the time taken by clients to connect to the network. FortiAIOPS reports those clients that take longer than certain thresholds to connect to the network. These thresholds are statically configured or FortiAIOPS computes them dynamically using machine learning algorithms. The algorithms compute specific thresholds for the AP-client environment and for different connectivity phases such as association, authentication (4-way handshake) and DHCP.

Connection Failure

This SLA determines the failed/unsuccessful client connections based on different stages of connection to a network. For example, association failures due to low RSSI, authentication failures due to unreachable RADIUS server, DHCP failure due to a DHCP server process crash, or DNS failure due to an invalid DNS domain.

AP Health and Uptime

This SLA determines the health of the FortiAPs based on the configured CPU, memory, temperature thresholds, and events such as FortiAP reboot, FortiSwitch port down, FortiGate, and so on. FortiAIOPS displays relevant SLAs under different sections on the monitor dashboard.

Switching

The switching SLAs monitor the switch health and connection status.

- [Switch Health and Uptime](#)
- [Switch Connection Failure](#)

Switch Health and Uptime

The **Switch Health and Uptime** SLA determines the health of the switches based on the configured thresholds (CPU, memory, temperature) and events such as port *down*, switch *down* and so on. FortiAIOPS displays

relevant SLAs under different sections on the monitor dashboard.

Switch Connection Failure

The **Switch Connection Failure** determines the failed/unsuccessful client connections based on authentication events such as MAC authentication and 802.1x authentication and MAC learning limit.

WAN

WAN is a software-defined approach for managing Wide-Area Networks (WAN). It allows you to offload internet bound traffic, that is, private WAN services remain available for real-time and mission critical applications. This added flexibility improves traffic flow and reduces pressure on the network. WAN has member interfaces and ports that are used to run traffic.

- [Performance](#)
- [FortiExtender](#)

Performance

You can configure **Performance** SLAs to monitor member interface link quality and to detect link failures. The link quality is measured based on latency, jitter, and packet loss. FortiAIOps WAN SLA can follow the performance SLAs defined on FortiGate and report the SLA breaches. Alternately, you can configure thresholds for these link quality parameters (latency, jitter and packet loss) in FortiAIOps for SLA monitoring. The thresholds can be configured statically or dynamically by FortiAIOps using machine learning algorithms, to identify optimal threshold values for the link parameters.

FortiExtender


FortiExtender integrates with FortiGate and WAN to become a part of Fortinet's security fabric. This integration enables FortiGate's WAN to have an extension using FortiExtender, providing continuous connectivity in case FortiGate's primary WAN link fails. Also, FortiExtender enables network access for remote sites and branches located beyond fixed broadband.

FortiExtender also facilitates load balancing for network traffic along with the primary WAN link. When FortiExtender is a part of your network, FortiAIOps monitors and reports related issues/failures.

Note: FortiAIOps monitors only the FortiExtender devices managed by FortiGate.

Getting Started

This section is a tutorial to get you started with installing, setting up, and using the FortiAIOps application to monitor your networks.



The steps depicted in this graphic are described in the following sections.

- [Installing FortiAIOps on page 13](#)
- [Initial FortiAIOps Configuration on page 13](#)
- [Accessing FortiAIOps on page 34](#)
- [Licensing](#)
- [Adding FortiGate on page 15](#)
- [Enable Log Forwarding on page 15](#)
- [Configure SLA Metrics](#)
- [Monitoring](#)

Installing FortiAIOps

You can deploy FortiAIOps on VM platforms and on public cloud platforms. Refer to the following sections for detailed instructions on deployment procedures.

- **VM Platforms** - [Deploying FortiAIOps on VM Platforms](#)
- **Public Cloud Platforms** - [Deploying FortiAIOps on Public Cloud Platforms](#)

Note: The FortiAIOps CLI and GUI users are different.

Initial FortiAIOps Configuration

After FortiAIOps is successfully installed, login as an administrator with the default username (**admin**). A password is not required. For more information on the commands, see [Command Line Interface \(CLI\) Reference](#).

- [Configuring a Password](#)
- [Configuring the IP Address](#)
- [NTP/Timezone and DNS Configurations](#)
- [Viewing the Configuration](#)

Configuring a Password

Login into the CLI with the username `admin`, a password is not required. However, after you login, you are prompted to change the password.

```
Poky (Yocto Project Reference Distro) 4.0.12 FA0ESX -
FA0ESX login: admin
Password:
You are forced to change your password, please input a new password.
New Password: _
```

Configuring the IP Address

The DHCP IP address is assigned by default. Run the `get system interface` command to view the IP address. Run the `config system interface` command to configure a static IP address.

```
fortiaios # config system interface
fortiaios (interface) # edit port1
fortiaios (port1) # set mode static
fortiaios (port1) # set ip 10.34.159.xxx/xx
fortiaios (port1) # end
```

You are required to configure the gateway IP address when using a static IP address. Run the `config router static` command.

```
fortiaios # config router static
fortiaios (static) # edit 1
fortiaios (1) # set gateway 10.34.159.xx
fortiaios (1) # set device port1
fortiaios (1) # end
```

NTP/Timezone and DNS Configurations

Fortinet recommends that you configure the NTP settings and DNS server. Run the following commands.

- `config system ntp`
- `config system global [set timezone]`
- `config system dns`

You can also configure the IP address, DNS, NTP, and the timezone via the GUI. See [Settings](#).

Viewing the Configuration

Run the `show full-configuration` command to view all changes.

For detailed information on these configurations, see [Post-installation Tasks](#)

Licensing

FortiAI Ops offers Monitoring, AI Insights, and SD-WAN subscriptions, with licensing based on the type of devices you use. For more information, see [FortiAI Ops Data Sheet](#).

Perform the following steps to obtain the license.

1. **Copy System ID information:** Navigate to **Dashboard > Summary** and copy the System ID.
2. **Contract Registration:** Login to <https://support.fortinet.com> using your account credentials to register the contract received over email for the product SKU purchased. Paste the copied system id during the registration process to generate the license file.
3. **Download License file:** Once the registration is complete, validate the entitlement details and download the license file if generated successfully. Upload this file in **System > Licensing > Upload License**.

Note: Fortinet recommends that all network elements are fully licensed.

If the network elements are partially licensed, related statistics are not reported in FortiAIOps. For example, a FortiAP is licensed and the connected FortiSwitch is not licensed; a FortiAP down event is triggered due to FortiSwitch port down/FortiSwitch reboot. In this case, the FortiAP down event is reported in FortiAIOps but the FortiSwitch port issues or reboot is not reported in FortiAIOps (as the FortiSwitch is not licensed). For more information, see [Licensing](#).

Ensure that the FortiAIOps NTP settings and your time zone are synchronized.

Adding FortiGate

In the FortiAIOps application portal, manually add the FortiGate controller. Navigate to **Inventory > Managed FortiGates > Add** and provide the required configuration details. Standalone and HA FortiGate controllers can be added. Optionally, you can add FortiGates in bulk using the import operation. For detailed information on adding and managing FortiGate controllers, see [Adding and Managing FortiGates](#).

You can group FortiGate controllers into **Device Groups** for ease of management. Each controller can belong to only one group; if a controller is added to a second group, it is automatically removed from the previous group. For detailed information on creating device groups, see [Device Groups](#).

Enable Log Forwarding

FortiAIOps supports direct FortiGate log forwarding and FortiAnalyzer log forwarding.

- Run the following command to configure syslog in FortiGate.
 - `config log syslogd setting`
 - `set status enable`
 - `set server 10.34.xxx.xxx`
- Direct FortiGate log forwarding - Navigate to **Fabric Connectors > Logging & Analytics > Log Settings** in the FortiGate GUI and specify the FortiAIOps IP address. Enable FortiAnalyzer log forwarding.

The screenshot shows the 'Logging Settings' configuration page in the FortiGate GUI. The 'FortiAnalyzer' tab is active. The 'Status' is set to 'Enabled'. The 'Server' field is empty. The 'Upload option' is set to 'Every 5 Minutes'. The 'Allow access to FortiGate REST API' and 'Verify FortiAnalyzer certificate' options are both checked.

- Navigate to **Log Forwarding** in the FortiAnalyzer GUI, specify the FortiAIOps IP address and select the FortiGate controller in **Device Filters**.

Create New Log Forwarding

Name	<input type="text" value="FortiAIOps"/>
Status	<input checked="" type="checkbox"/> ON
Remote Server Type	<input type="radio"/> FortiAnalyzer <input checked="" type="radio"/> Syslog <input type="radio"/> Common Event Format(CEF)
Server IP	<input type="text" value="192.168.1.1"/>
Server Port	<input type="text" value="514"/>
Reliable Connection	<input type="checkbox"/> OFF

Log Forwarding Filters

Device Filters	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block; background-color: #f0f0f0;">[Placeholder]</div> 🗑️
	Select Device +
Log Filters	<input type="checkbox"/> OFF
Enable Exclusions	<input type="checkbox"/> OFF

Note: The syslog port is the default UDP port 514.

Monitoring

After the FortiAIOps setup and configurations are complete, you can view different aspects of your network in the following panels of the FortiAIOps application portal.

GUI Panels	Description
Dashboard	The dashboard provides a graphical overview of network elements, resource usage, and AI insights.
AI Insights	You can configure SLA metrics and the required thresholds, and monitor the AI enabled data insights of your network and the impacted SLAs and devices.
Inventory	You can add FortiGate controllers and configure management operations.
Wireless	The wireless section provides comprehensive data and statistics to monitor wireless networks.
Switch	The switch section provides comprehensive data and statistics to monitor FortiSwitches and FortiSwitch clients.

GUI Panels	Description
Security Fabric	The security fabric page represents the topology, that illustrates the logical placement of the wireless service and the physical placement of hardware devices.
Logs and Reports	The logs section provides detailed WiFi and FortiSwitch event logs, you can also generate detailed FortiAIOps reports.
System	The system section includes several pages that offer valuable insights into various aspects of system management, such as users, user groups, backup and restore, settings, licensing, location services, and certificates.
Service Assurance	The service assurance section provides an overview of the diagnostic and trouble-prevention capability of FortiAIOps.

Deploying FortiAI Ops on VM Platforms

Deploying FortiAI Ops is a simple process that involves downloading the installation files, performing the installation, and completing post-installation steps. Here is an overview of the deployment process:

1. Ensure that the [prerequisites](#) are met before performing the installation.
2. Download installation files from the [Fortinet Support](#) portal.
3. Perform the installation.
 - a. [Installing FortiAI Ops on VMware ESXi](#)
 - b. [Installing FortiAI Ops on Hyper-V](#)
 - c. [Installing FortiAI Ops on KVM](#)
 - d. [Installing FortiAI Ops on Nutanix](#)
4. Complete the [post-installation](#) tasks.

Pre-installation Requirements

Ensure that the following requirements are met before proceeding with the installation.

Supported Environments

Supported environments include:

- *VMware ESXi* - 7.0.3 and above
- *Microsoft Hyper-V*
- *KVM* - Ubuntu 20.04 and above, CentOS 9.0 and above

Hardware Requirements

The following table lists the minimum hardware requirements for deploying FortiAI Ops.

CPU	Memory	Storage	
		Disk 1	Disk 2
4	32 GB	8 GB	500 GB

Note: Disk 1 is used for OS and Disk 2 is used for data. You can extend or modify Disk 2 size based on your requirements.

Installing FortiAI Ops on VMware ESXi

Perform the following steps to deploy FortiAI Ops.


1. Download the installation file from [Fortinet Support](#) portal and unzip the file (*FAO_VM64-vx.x.x-devbuildxxx-FORTINET.out.ovf.zip*). This folder contains 4 installation files.

 datadrive1.vmdk	13-10-2023 06:42	VMDK File	131 KB
 FAOESX.ovf	13-10-2023 06:42	OVF File	25 KB
 FAOESX.vmdk	13-10-2023 06:42	VMDK File	13,19,844 KB
 FAOESX.nvram	13-10-2023 06:41	NVRAM File	265 KB

2. Connect and log in to the VMware ESXi host client with administrative rights.
3. Select **Create/Register VM** in the **Host** tab.




4. Select **Deploy a virtual machine from an OVF or OVA file** as the creation type.
5. Browse and select the downloaded installation files and enter a suitable hostname.



6. Select your preferred datastore to store the virtual machine files in the **Select storage** page.
7. Accept the end user license agreement.
8. In the **Deployment options** page:
 - a. Select you preferred VM network
 - b. Select your preferred disk provisioning method. Thin disk provisioning method is recommended.
 - c. Ensure **Power on automatically** option is selected
Note: To modify configurations, it is necessary to edit the VM configuration while the VM is in a powered off state, and then start the VM.

9. Review the summary of the deployment settings and click **Finish**.




- 10. You can monitor the progress of the deployment in the **Recent Tasks** pane. When the installation is complete, the virtual machine will be listed in the **Inventory** pane.
- 11. Perform [post-installation](#) tasks.

Installing FortiAI Ops on Hyper-V


Perform the following steps to deploy FortiAI Ops.

1. Download the installation file from [Fortinet Support](#) portal and unzip the file *FAO_VM64_HV-vx.x.xdevbuildxxx-FORTINET.out.hyperv.zip*. This folder contains 2 installation files.
2. Open the Start menu, search for **Hyper-V Manager**, and click on the application to launch it.
3. Click **New** in the Actions pane and select **Virtual Machine** to start the New Virtual Machine Wizard. Click **Next**.


4. Enter a name and select location for FortiAI Ops. Click **Next**.




5. Select **Generation 1** and click **Next**.




- Specify the memory that needs to be allocated. Click **Next**. See [Pre-installation Requirements](#).



7. Select network adapter and click **Next**.




8. Select **Use an existing virtual hard disk**. Browse and select **FAOWHV.vhd** image locally stored. Click **Next**.




9. Review the settings and click **Finish**.
10. Right click on the new virtual machine created and select **Settings**.


11. Select **IDE Controller 0** under **Hardware** in the left pane. Select **Hard Drive** and click **Add**.



12. Select the newly created hard drive. Select **Virtual hard disk** option. Browse and select the **DATADRIVE.vhd** image. Click **Ok**.



13. Select **Processor** under **Hardware** in the left pane. Enter the number of virtual processors based on your FortiAI Ops configuration. Click **Apply**. Click **Ok**.




14. Right click on the virtual machine and click **Start**. Once the virtual machine is up and running, launch the console.
15. Perform [post-installation](#) tasks.

Installing FortiAI Ops on KVM

Perform the following steps to deploy FortiAI Ops on KVM using virt-manager.

1. Download the installation file from [Fortinet Support](#) portal and unzip the file *FAO_VM64_KVM-vx.x.xdevbuildxxx-FORTINET.out.kvm.zip*.
2. Open terminal and navigate to the path of the downloaded and unzipped installation files.

3. Run the `./deploy_kvm {name of machine} {interface to run the machine}` command to deploy FortiAI Ops in the virt-manager automatically.




```
kvmserver@kvmserver-virtual-machine: ~/Downloads/FAO_...
kvmserver@kvmserver-virtual-machine:~$ cd Downloads/
kvmserver@kvmserver-virtual-machine:~/Downloads$ cd FAO_VM64_KVM-v2.0.0-devbuild
0336-FORTINET.out.kvm/
kvmserver@kvmserver-virtual-machine:~/Downloads/FAO_VM64_KVM-v2.0.0-devbuild0336
-FORTINET.out.kvm$ ls
datadrive.qcow2  FAOKVM.qcow2  KVM.xml.tpl
deploy_kvm      Fimg_VARS.fd  OVMF_CODE_4M.secboot.fd
kvmserver@kvmserver-virtual-machine:~/Downloads/FAO_VM64_KVM-v2.0.0-devbuild0336
-FORTINET.out.kvm$ ./deploy_kvm AIOPS
Usage: deploy_kvm <domain_name> <bridge_interface_name>
kvmserver@kvmserver-virtual-machine:~/Downloads/FAO_VM64_KVM-v2.0.0-devbuild0336
-FORTINET.out.kvm$ ./deploy_kvm AIOPS br0
Ubuntu
pc-q35-4.2
/usr/bin/kvm-spice
virsh define AIOPS.xml
Domain 'AIOPS' defined from AIOPS.xml


[sudo] password for kvmserver:
Domain 'AIOPS' started

kvmserver@kvmserver-virtual-machine:~/Downloads/FAO_VM64_KVM-v2.0.0-devbuild0336
-FORTINET.out.kvm$
```

4. Open the virt-manager window.



5. Click **Open** to launch the console after the virtual machine is in a running state.




6. Perform [post-installation](#) tasks.

Installing FortiAI Ops on Nutanix

Perform the following steps to deploy FortiGuest on Nutanix.

1. Obtain *FAO_VM64_HV-v2.0.1-[build0xxx]-FORTINET.out.hyperv.zip* from Fortinet and extract it to obtain the files *FAOWHV.vhd* and *DATADRIVE.vhd*.
2. Log in into the Nutanix Prism user interface and click the  icon. Select **Image Configuration**.



3. Upload both the *FAOWHV.vhd* and *DATADRIVE.vhd* files in the order as mentioned here. To upload *FAOWHV.vhd*, click **Upload Image** and update the following fields.

Create Image ?

Name
FortiAI Ops

Annotation

Image Type
DISK

Storage Container
default-container-89159414444738

Image Source

From URL

Upload a file [?] FAOWHV.vhd

- Enter a **Name** for the FortiAI Ops image file.
- Select **Disk** in as the **Image Type**.
- Select the **Storage Container**.
- In the **Image Source** section, click **Upload a file** and browse to the FortiAI Ops image file *FAOWHV.vhd*.

4. Click **Save**.
5. Repeat steps 3 and 4 to upload *DATADRIVE.vhd*.

Create Image ?

Name
FortiAI Ops

Annotation

Image Type
DISK

Storage Container
default-container-89159414444738

Image Source

From URL

Upload a file [?] DATADRIVE.vhd

6. Refresh the browser after a few seconds and the newly created images are listed in the **Image Configuration** page.
7. To create a VM, navigate to the VM dashboard and click **Create VM** and enter the following configuration.



- Enter a **Name** for the FortiAI Ops VM.
- Select your **Timezone**.
- In the **Compute Details** section, enter **4 vCPU(s)** and **8 GB of Memory**.

Create VM
? ×

General Configuration

Name

Description

Timezone

Use UTC timezone for Linux VMs and local timezone for Windows VMs.

Use this VM as an agent VM

Compute Details

vCPU(s)

Number Of Cores Per vCPU

Memory ?
 GiB

Note: By default, a CD-ROM is listed under **Disks**, delete this CD-ROM.

Disks + Add New Disk

Type	Address	Parameters	✎ · ✕
CD-ROM	ide.0	EMPTY=true; BUS=ide	

8. To create a new Boot disk, click **Add New Disk** and enter the following configuration.
 - Select **Clone from Image Service** as the **Operation** and the disk is cloned from the FortiAI Ops image files uploaded earlier in this procedure.
 - Select **SCSI** as the **Bus Type**.

- Select the uploaded FortiAI Ops disk **Image - FAOWHV.vhd**.

Add Disk ? ✕

Type

DISK
▼

Operation

Clone from Image Service
▼

Bus Type

SCSI
▼

Image ?

FortiAI Ops
▼

Size (GiB) ?

500
▼

Please note that changing the size of an image is not allowed.

Index

Next Available
▼

Cancel

Add

9. Click **Add**.
10. Add another disk for *DATADRIVE.vhd* following the previous step.
Note: Ensure to create a new disk for *FAOWHV.vhd* first and then for *DATADRIVE.vhd*.
11. Add 4 Network Adapters, click **Add New NIC**.

Create NIC ? ✕

Subnet Name

fortinet_switch
▼

Network Connection State

Connected
▼

Private IP Assignment


Network address / prefix

NONE

Cancel

Add

- Power on the VM and launch the console.



- Configure the FortiAI Ops static IP address on starting the VM. See [Post-installation Tasks](#).

Post-installation Tasks

Perform the following steps to access FortiAI Ops after successful installation.

- Turn on the newly created VM, if it is not already ON. In the virtual machine console, log in as an admin user with the username **admin**. A password is not required
- Login as FortiAI Ops administrator with username **admin**. Configure the password after the first login.

Note: By default, there is no password for logging into the CLI mode for the first time. However, you are prompted to change the password after logging in. The default login credentials (username/password) for the GUI are admin/admin. Configuring the CLI password does not modify the GUI password.
- Ensure that the IP address is configured properly. Run the `get system interface` command to view the dynamically assigned IP address. Run `config router static` command to assign a static IP address.

Accessing FortiAI Ops

After successfully generating a new password and configuring a static IP address for the FortiAI Ops server, you can access the FortiAI Ops application portal for management operations and to monitor your network. Open a compatible web browser and enter the `https://<fortiaops_server_IP>` URL, where `<fortiaops_server_IP>` is the configured static IP address. The default username/password is admin/admin; you are prompted to change the password after the first login.

Upgrading FortiAI Ops

Run the following command to upgrade FortiAI Ops.

```
execute restore image ftp <path to upgrade file><upgrade file name> <IP address>  
<username> <password>
```

Note: Upgrading FortiAI Ops is supported only via the CLI mode.

Deploying FortiAI Ops on Public Cloud Platforms

FortiAI Ops can now be deployed on the following public Cloud platforms.

- [Microsoft Azure](#)
- [Google Cloud Platform](#)
- [Amazon Web Services \(AWS\)](#)

Microsoft Azure

Perform the following steps to deploy FortiAI Ops on Microsoft Azure. For more information on the Azure portal configurations, see the [Azure documentation](#).

1. Download the file *FAO_VM64_AZURE-v2.0.1-[build0xxx]-FORTINET.out.azure.zip* from Fortinet and extract it to obtain the file *FAO_VM64_AZURE-v2.0.1-[build0xxx]-FORTINETout.vhd*.
2. Upload the extracted VHD file on to the Azure portal using the following procedure.
 - Create a new **Resource Group** or use an existing one from the portal. See [Manage Azure Resource Group](#).

[Home](#) > [Resource groups](#) >

Create a resource group ...

Basics Tags Review + create

Resource group - A container that holds related resources for an Azure solution. The resource group can include all the resources for the solution, or only those resources that you want to manage as a group. You decide how you want to allocate resources to resource groups based on what makes the most sense for your organization. [Learn more](#)

Project details

Subscription *


Resource group *

Resource details


Region *

[Review + create](#) [< Previous](#) [Next: Tags >](#)


- Create a new **Storage account** or use an existing one from the portal. See [Create a storage account](#).




- In the Storage account, select a **Container** or create a new one to upload the VHD file. See [Create a container](#).



- When uploading the VHD file, select the **Blob type** as **Page blob**.



- After the upload, verify that the file is listed in the **Containers** page.



3. Create a managed image from the uploaded VHD file. Navigate to **Images > Create** an image in the Azure portal and configure the following settings.

- Select a **Resource group**.
- Enter a **Name** for the image.
- Select the applicable **Region** from the list.
- Set the **OS type** to **Linux**.
- Set the **VM generation** to **Gen 1**.

[Home](#) > [Images](#) > [Create an image](#) >

Create an image ...

Create a managed image that can be used to deploy virtual machines and virtual machine scale sets. The image contains a list of managed blobs and metadata necessary for creating virtual machines. [Learn more](#)

Project details

Select the subscription to manage deployed resources and costs. Use resource groups like folders to organize and manage all your resources.

Subscription * 

Resource group *  [Create new](#)

Instance details

Name * 

Region * 

Zone resiliency 

OS disk

OS type *  Windows
 Linux

VM generation *  Gen 1
 Gen 2

Storage blob *  
[Browse](#)

Account type * 

Host caching * 

Encryption

You can encrypt the OS and data disks with a platform-managed or customer-managed key. [Learn more](#)

Key management 

Data disk

[+ Add data disk](#)

[Review + create](#) [< Previous](#) [Next : Tags >](#)

4. Browse and select the uploaded VHD file in the **Storage blob**.
Note: It is not required to add data disk in this step, the data disk addition is required when the virtual machine is created.
5. Click **Review + create** to create an image.
6. Create a virtual machine from the managed image that you just created. Select **Virtual machines > Create Azure virtual machine** on portal.

[Home](#) > [Virtual machines](#) >

Create a virtual machine

Try out the Azure Copilot for additional recommendations while creating a virtual machine →

[Basics](#) [Disks](#) [Networking](#) [Management](#) [Monitoring](#) [Advanced](#) [Tags](#) [Review + create](#)

Create a virtual machine that runs Linux or Windows. Select an image from Azure marketplace or use your own customized image. Complete the Basics tab then Review + create to provision a virtual machine with default parameters or review each tab for full customization. [Learn more](#)

Project details

Select the subscription to manage deployed resources and costs. Use resource groups like folders to organize and manage all your resources.

Subscription *

Resource group * [Create new](#)

Instance details

Virtual machine name *

Region

Availability options

Security type

Image * [See all images](#) | [Configure VM generation](#)

- Select a **Resource group**.
- Enter a **Name** for the virtual machine.
- Select the applicable **Region** from the list.

VM architecture Arm64 x64
 Arm64 is not supported with the selected image.

Run with Azure Spot discount

Size * [See all sizes](#)

Enable Hibernation (preview)
 To enable Hibernation, you must register your subscription. [Learn more](#)

Administrator account
 Authentication type SSH public key Password
 Azure now automatically generates an SSH key pair for you and allows you to store it for future use. It is a fast, simple, and secure way to connect to your virtual machine.

Username *

SSH public key source

7. Click **See all images** to browse and select the image that was generated in the previous step.

8. Click **See all sizes** to select a virtual machine size.

Note: It is recommended to select VM size as 4 vCPU and 32 GB RAM, and the **Local storage** as 0.

Select a VM size ...

Search by VM size... vCPUs: 4 RAM (GiB): 32 Display cost: Hourly Add filter

Showing 17 of 510 VM sizes | Subscription: Software Development/Engineering | Region: South India | Current size: Standard_E4bs_v5 | Image: fortiaios417 | Learn more about VM sizes of Group by series

VM Size ↑↓	Type ↑↓	vCPUs ↑↓	RAM (GiB) ↑↓	Data disks ↑↓	Max IOPS ↑↓	Local storage (GiB) ↑↓	Premium c
A-Series v2 Best suited for entry level workloads (development or test)							
A4m_v2	General purpose	4	32	8	6400	40 (SCSI)	Not sup
E-Series v5 The 5th generation E family sizes for your high memory needs							
E4bs_v5	Memory optimized	4	32	8	11000	0 (SCSI)	Support
E4bds_v5	Memory optimized	4	32	8	11000	150 (SCSI)	Support
E-Series v4 The 4th generation E family sizes for your high memory needs							
E4ds_v4	Memory optimized	4	32	8	6400	150 (SCSI)	Support
E-Series v3 The 3rd generation E family sizes for your high memory needs							

Select Prices presented are estimates in USD that include only Azure infrastructure costs and any discounts for the subscription and location. The prices don't include any applicable software costs. Final charges will appear in your local currency in cost analysis and billing views. View Azure pricing calculator. Give feedback

9. Configure network inbound port rules to allow SSH access in the field **Select inbound ports**.

Key pair name * fortiaios417

Inbound port rules
 Select which virtual machine network ports are accessible from the public internet. You can specify more limited or granular network access on the Networking tab.

Public inbound ports * None Allow selected ports

Select inbound ports * SSH (22)

All traffic from the internet will be blocked by default. You will be able to change inbound port rules in the VM > Networking page.

Licensing
 License type * Other

If you are using a RedHat or SLES image, you may be eligible for the Azure Hybrid Benefit and can save money on the license costs. Learn more about this benefit and how to enable it using Azure CLI for custom images from snapshots and Azure compute gallery.

Review + create < Previous Next: Disks >

https://portal.azure.com/#

10. Click **Next: Disks** and configure disk data as is depicted in the following image.
Note: The recommended minimum data disk size is 128GB.

Home > Virtual machines >

Create a virtual machine ...

Basics Disks Networking Management Monitoring Advanced Tags Review + create

Azure VMs have one operating system disk and a temporary disk for short-term storage. You can attach additional data disks. The size of the VM determines the type of storage you can use and the number of data disks allowed. [Learn more](#)

VM disk encryption

Azure disk storage encryption automatically encrypts your data stored on Azure managed disks (OS and data disks) at rest by default when persisting it to the cloud.

Encryption at host

i Encryption at host is not registered for the selected subscription. [Learn more about enabling this feature](#)

OS disk

OS disk size

OS disk type *

Delete with VM

Key management

Enable Ultra Disk compatibility

Ultra disk is not supported in South India.

Data disks for fortiaio417

You can add and configure additional data disks for your virtual machine or attach existing disks. This VM also comes with a temporary disk.

LUN	Name	Size (GiB)	Disk type	Host caching	Delete with VM
0	fortiaio417_DataDis...	512	Premium SSD LRS	Read-only	<input type="checkbox"/>

[Create and attach a new disk](#) [Attach an existing disk](#)

Advanced

[Review + create](#)

< Previous

Next: Networking >

11. Click **Next: Networking** to configure the network settings.

Home > Virtual machines >

Create a virtual machine

Basics Disks **Networking** Management Monitoring Advanced Tags Review + create

Define network connectivity for your virtual machine by configuring network interface card (NIC) settings. You can control ports, inbound and outbound connectivity with security group rules, or place behind an existing load balancing solution. [Learn more](#)

Network interface
When creating a virtual machine, a network interface will be created for you.

Virtual network * [Create new](#)

Subnet * [Manage subnet configuration](#)

Public IP [Create new](#)

NIC network security group None
 Basic
 Advanced

Public inbound ports * Allow selected ports
 None

Select inbound ports *

⚠ This will allow all IP addresses to access your virtual machine. This is only recommended for testing. Use the Advanced controls in the Networking tab to create rules to limit inbound traffic to known IP addresses.

Delete NIC when VM is deleted

Delete public IP when VM is deleted

Enable accelerated networking


The selected image does not support accelerated networking.

Load balancing
You can place this virtual machine in the backend pool of an existing Azure load balancing solution. [Learn more](#)

Load balancing options None
 Azure load balancer
 Supports all TCP/UDP network traffic, port-forwarding, and outbound flows.
 Application gateway
 Web traffic load balancer for HTTP/HTTPS with URL-based routing, SSL termination, session persistence, and web application firewall.


[Review + create](#)

12. Select the available **Virtual network** and the **Public IP** of the deploying machine.
13. Review the configurations under the tabs, **Management**, **Monitoring**, and **Advanced**.
14. Click **Next: Tags** and add the required tags.
15. Click **Next: Review + create** and click **Create** only if the virtual machine validation is passed, as depicted in the following image.



16. Connect the virtual machine in one for the following methods.


- **Connect via Serial Console** - Select the running virtual machine and then select Serial console in the menu.




- **Connect via SSH** - Obtain the public IP address of the virtual machine and use SSH to connect to the virtual machine.
ssh admin@<public_IP>

Post-installation Tasks

- The public IP address of the virtual machine is available in the **Overview** page of the virtual machine.



- Create the inbound port rules as depicted in the following image, in the **Network settings** of the virtual machine, to enable all FortiAI Ops functionality.



Note: Do not change the corresponding IP mode setting from the FortiAI Ops GUI or CLI; modify all network from the Azure portal only.

Google Cloud Platform

Perform the following steps to deploy FortiAI Ops on Google Cloud.

- Download the file *FAO_VM64_GCP-v2.0.1-[build0xxx]-FORTINET.out.gcp.zip* from Fortinet and extract it to obtain *FAO_VM64_GCP-v2.0.1-[build0xxx]-FORTINET.out.gcp.tar.gz*.
- Install and setup **gsutil** to access Cloud storage from the CLI using HTTPS. To install **gsutil**, see [Install gsutil](#).
- Alternatively, run the following command to download the Linux 64-bit archive file.
`curl -O https://dl.google.com/dl/cloudsdk/channels/rapid/downloads/google-cloud-cli-389.0.0-linux-x86_64.tar.gz`
- Extract the contents of the file to any location on your file system (preferably your Home directory). To replace an existing installation, remove the existing *google-cloud-sdk* directory and then extract the archive to the same location - `tar -xf google-cloud-cli-389.0.0-linux-x86.tar.gz`.

5. Run the `./google-cloud-sdk/install.sh` script (from the root of the folder you extracted the file to).
6. Run `./google-cloud-sdk/bin/gcloud init` to initialize GCP CLI.
7. Upload the file `FAO_VM64_GCP-v2.0.1-[build0xxx]-FORTINET.out.gcp.tar.gz` to the Cloud storage bucket in the GCP CLI.

```
./google-cloud-sdk/bin/gsutil FAO_VM64_GCP-v2.0.1-[build0xxx]-
FORTINET.out.gcp.tar.gz gs://my-some-bucket
```

8. Run the following script to create a secure boot image.

```
# bash -x import2gcpimg.sh AIOPSBUILD FAO_VM64_GCP-v2.0.1-devbuild0448-
FORTINET.out.gcp.tar.gz aiops-gcp.
```

where, `IMAGE_NAME` = [FortiAI Ops build], `SOURCE_FILE` = [FortiAI Ops image file name], and `BUCKET_NAME` = `aiops-gcp`.

Note: Make sure to create a storage bucket in the GCP GUI where the FortiAI Ops image files are uploaded.

```

initiating: db.der
[sshwin@sshwin1-virtual-machine:~/GCPcloud/build467$ bash -x import2gcpimg.sh image467 FAO_VM64_GCP-v2.0.1-devbuild0467-FORTINET.out.gcp.tar.gz aiopsin
ages
+ IMAGE_NAME=image467
+ SOURCE_FILE=FAO_VM64_GCP-v2.0.1-devbuild0467-FORTINET.out.gcp.tar.gz
+ BUCKET_NAME=aiopsimages
+ PK_DER=PK.der
+ KEK_DER=KEK.der
+ DB_DER=db.der
+ '[' -z image467 -o -z FAO_VM64_GCP-v2.0.1-devbuild0467-FORTINET.out.gcp.tar.gz -o -z aiopsimages -o -z ']'
+ '[' '!' -z '!' -o ']'
+ import_image
+ gsutil cp FAO_VM64_GCP-v2.0.1-devbuild0467-FORTINET.out.gcp.tar.gz gs://aiopsimages/FAO_VM64_GCP-v2.0.1-devbuild0467-FORTINET.out.gcp.tar.gz
Copying file://FAO_VM64_GCP-v2.0.1-devbuild0467-FORTINET.out.gcp.tar.gz [Content-Type=application/x-tar]...
==> NOTE: You are uploading one or more large file(s), which would run
significantly faster if you enable parallel composite uploads. This
feature can be enabled by editing the
"parallel_composite_upload_threshold" value in your .boto
configuration file. However, note that if you do this large files will
be uploaded as "composite objects
<https://cloud.google.com/storage/docs/composite-objects>", which
means that any user who downloads such objects will need to have a
compiled crcmod installed (see "gsutil help crcmod"). This is because
without a compiled crcmod, computing checksums on composite objects is
so slow that gsutil disables downloads of composite objects.

- [1 files][ 1.3 GiB/ 1.3 GiB] 2.2 MiB/s
Operation completed over 1 objects/1.3 GiB.
+ '[' 0 -ne 0 -o ']'
+ gcloud compute images create image467 --source-uri gs://aiopsimages/FAO_VM64_GCP-v2.0.1-devbuild0467-FORTINET.out.gcp.tar.gz --platform-key-file=PK.der --k
ey-exchange-key-file=KEK.der --signature-database-file=db.der --guest-os-features=UEFI_COMPATIBLE
Created [https://www.googleapis.com/compute/v1/projects/forti-ai-ops-gcp/global/images/image467].
NAME          PROJECT          FAMILY    DEPRECATED  STATUS
image467      fort-ai-ops-gcp  FORTNET  DEPRECATED  READY
+ '[' 0 -ne 0 -o ']'
+ echo ----
+ echo 'ENABLE Secure Boot through GUI or this CLI before instance start'
ENABLE Secure Boot through GUI or this CLI before instance start
+ echo 'gcloud compute instances update IMAGE_NAME --shielded-secure-boot'
gcloud compute instances update IMAGE_NAME --shielded-secure-boot

```

9. In the GCP portal, navigate to **Compute Engine > Images** and select the uploaded FortiAI Ops image file.
10. Click **Create instance** and update the following configurations. For more information, see [Create a VM](#).
 - Enter a **Name** for the instance.
 - Select the applicable **Region** from the list.

- In the Machine configuration, configure the E2 Standard with 4 VCPUs and 16 GB memory.

The screenshot shows the 'Create an instance' page in the AWS Management Console. On the left, there are four options: 'New VM instance from scratch', 'New VM instance from template', 'New VM instance from machine image', and 'Marketplace'. The 'New VM instance from scratch' option is selected. The 'Name' field is 'imageaiops448'. Under 'MANAGE TAGS AND LABELS', the 'Region' is 'us-central1 (Iowa)' and the 'Zone' is 'us-central1-a'. The 'Machine configuration' section has tabs for 'General purpose', 'Compute optimized', 'Memory optimized', 'Storage optimized', and 'NEW GPUs'. The 'General purpose' tab is active, showing a table of machine types. The 'E2' series is selected, which is described as 'Low cost, day-to-day computing' with 0.25-32 vCPUs and 1-128 GB memory. At the bottom, there are 'CREATE', 'CANCEL', and 'EQUIVALENT CODE' buttons.

Series	Description	vCPUs	Memory	Platform
N4	PREVIEW Flexible & cost-optimized	2 - 80	4 - 640 GB	Intel Emerald Rapids
C3	Consistently high performance	4 - 176	8 - 1,408 GB	Intel Sapphire Rapids
C3D	Consistently high performance	4 - 360	8 - 2,880 GB	AMD Genoa
E2	Low cost, day-to-day computing	0.25 - 32	1 - 128 GB	Based on availability
N2	Balanced price & performance	2 - 128	2 - 864 GB	Intel Cascade and Ice Lake
N2D	Balanced price & performance	2 - 224	2 - 896 GB	AMD EPYC
T2A	Scale-out workloads	1 - 48	4 - 192 GB	Ampere Altra Arm
T2D	Scale-out workloads	1 - 60	4 - 240 GB	AMD EPYC Milan

Note: It is recommended to use a minimum of 4 CPUs and a memory of 16 GB with the Intel Broadwell CPU platform.

The screenshot shows the 'Advanced configurations' section of the 'Create an instance' page. The 'PRESET' tab is selected, showing the 'e2-standard-4 (4 vCPU, 2 core, 16 GB memory)' preset. Below this, there are several configuration options: 'CPU platform' is set to 'Automatic'; 'vCPUs to core ratio' is set to '2 vCPUs per core'; 'Visible core count' is set to '2 cores'. There is an 'ADVANCED CONFIGURATIONS' section that is currently collapsed. Below that, the 'Availability policies' section shows 'VM provisioning model' set to 'Standard'. A note at the bottom says 'Choose "Spot" to get a discounted, preemptible VM. Otherwise, stick to "Standard". Learn more

11. Enable **Allow HTTPS traffic** for web access in Firewall.


The screenshot shows the 'Firewall' configuration panel. It has a title 'Firewall' with a help icon. Below the title, there is a text prompt: 'Add tags and firewall rules to allow specific network traffic from the I'. There are three checkboxes: 'Allow HTTP traffic' (checked), 'Allow HTTPS traffic' (checked), and 'Allow Load Balancer Health Checks' (unchecked).

12. Click **Advanced options** to configure networking, disk and security parameters for the instance.

- Set the **Network interface card** to **VirtIO** .
- Select the Virtual Private Cloud (VPC) in the **Network interfaces**.


Note: Ensure that you create VPC networks to use as network interfaces for your instance, and provide

the IP address from specified subnets. To create and use a VPC network, see [Create and manage VPC networks](#).



- Select other network parameters such as IP stack, primary Internal IPv4 address, and external IPv4 address as depicted in this image.


Note: You can select the external IPv4 address as Ephemeral (automatic /dynamic or static IP address.). To create external IPv4 addresses for GCP, see [Reserve a static external IP address](#).



13. Add another hard disk. In the **Create an instance** page, select **Add New Disk** and configure the following.


- Enter a disk **Name**.
- Set the **Disk source type** to **Blank disk**.
- Set the **Disk type** to **Standard persistent disk**.
- Set the disk **Size** to 100 GB

Note: The minimum recommended disk size is 100 GB.



14. Click **Save**.

15. In the **Security** section, enable secure boot as depicted in the following image.



16. Click **Create** to complete installation. The newly created instance is listed in the **VM instances** page. Select the instance and verify that the instance is running with the recommended CPU and machine configurations.

17. After successful installation, enable the serial console.

- Select the instance in the **VM instances** page.

The screenshot shows the Google Cloud console interface for a VM instance named 'imageaiops448'. At the top, there are navigation options: 'EDIT' (highlighted in yellow), 'RESET', and 'CREATE MACHINE IMAGE'. Below this, there are tabs for 'DETAILS', 'OBSERVABILITY', 'OS INFO', and 'SCREENSHOT'. Under the 'DETAILS' tab, there are buttons for 'SSH' and 'CONNECT TO SERIAL CONSOLE'. A message states 'Connecting to serial ports is disabled'. Below this is a 'Logs' section with links for 'Logging' and 'Serial port 1 (console)', and a 'SHOW MORE' link. At the bottom is a 'Basic information' table:

Name	imageaiops448
Instance Id	1620690093879126281
Description	None
Type	Instance


- Click **Edit** to enable the following TCP and UDP ports.

The screenshot shows the 'Edit imageaiops448 instance' page. It displays various configuration options:

- Zone:** us-central1-a
- Reservation:** Automatically choo
- Confidential VM service:** Disabled
- Rename:** A text input field for the VM instance name, currently containing 'imageaiops448'. A tip below states: 'Tip: Reference the VM by its URI in API calls and gcloud CLI commands. project isn't affected by any name changes. [Learn more](#)'
- Remote access:** A checkbox labeled 'Enable connecting to serial ports' is checked.
- Labels:** A 'MANAGE LABELS' button is visible.
- Tags:** A 'Tags' section with a help icon is partially visible at the bottom.

- 514:514/udp
- 514:514/tcp
- 4013:4013/udp
- 4013:4013/tcp
- 443:443/tcp

- 80:80/tcp



Note: Ensure that all required TCP and UDP ports are enabled.

18. Connect the VM instance and login.

- To connect via the Compute Engine console, click **VM Instances** and select the VM instance that you want to connect to. Click **Connect to Serial Console**. See [Connect to the Serial Console](#). In the console interface, login with the user name admin. A password is not required.

```

FAOGCP login: admin
Password:
You are forced to change your password, please input a new password.
New Password:
Confirm Password:
Welcome!

FAOGCP #
FAOGCP # get system status
Platform:          FAO_VM64_GCP (Debug)
Version:          FAO_VM64_GCP v2.0.1,build0448,240310 (Debug)
Architecture:    64-bit
Serial-Number:   FAOGCP
Hostname:        FAOGCP
Branch point:    0448
Uptime:          0 days, 0 hours, 20 minutes
Last reboot:     Thu Mar 28 11:44:05 GMT 2024
System time:     Thu Mar 28 12:04:24 GMT 2024
SystemID:        fb370651-3cc5-c390-a185-130000000000

FAOGCP # █
    
```

- To connect via the SSH, obtain the public IP address from the VM Instances interface and connect via SSH. The `get system interface` command displays the internal IP address assigned to the

instance.

```

login as: admin
Keyboard-interactive authentication prompts from server:
| Password:
End of keyboard-interactive prompts from server
Welcome!

FAOGCP #
FAOGCP #
FAOGCP # get system interface
== [ port1 ] (2024-03-28 11:44:14)
type: physical mode: dhcp ip: 10.128.0.8/32 allowaccess: https ping ssh http

Number of items: 1

FAOGCP # █

```

You can use the external IP address to access the FortiAI Ops GUI, *https: <external_IP_address>*.

Amazon Web Services (AWS)

Perform the following steps to deploy FortiAI Ops on AWS.

1. Download the file *FAO_VM64_AWS-v2.0.1-[build01xx]-FORTINET.out.aws.zip* from Fortinet
2. Install or gain access to the AWS CLI. See [Get started with the AWS CLI](#).
3. Configure the AWS CLI as per your access requirements. These are some sample values that you must replace with the relevant ones.

```

$ aws configure
AWS Access Key ID [None]: AKIAIOSFODNN7EXAMPLE
AWS Secret Access Key [None]: YEXAMPLEKEY
Default region name [None]: us-west-2
Default output format [None]: json

```

4. Create *vmimport* role and attach the policy to the IAM user. This operation requires IAM permissions.cat

```

<<EOF > trust-policy.json
{
  "Version": "2012-10-17",
  "Statement": [
    {
      "Effect": "Allow",
      "Principal": { "Service": "vmie.amazonaws.com" },
      "Action": "sts:AssumeRole",
      "Condition": {
        "StringEquals": {
          "sts:Externalid": "vmimport"
        }
      }
    }
  ]
}
EOF

```

```
aws iam create-role --role-name vmimport --assume-role-policy-document
```

```
file://trust-policy.json
```

- a. Create a policy for the Amazon S3 bucket and attach it to the AWS IAM user.

```
cat <<EOF > role-policy.json
{
  "Version": "2012-10-17",
  "Statement": [
    {
      "Effect": "Allow",
      "Action": [
        "s3:GetBucketLocation",
        "s3:GetObject",
        "s3:ListBucket"
      ],
      "Resource": [
        "arn:aws:s3:::$s3BucketName",
        "arn:aws:s3:::$s3BucketName/*"
      ]
    },
    {
      "Effect": "Allow",
      "Action": [
        "ec2:ModifySnapshotAttribute",
        "ec2:CopySnapshot",
        "ec2:RegisterImage",
        "ec2:Describe*"
      ],
      "Resource": "*"
    }
  ]
}
EOF
```

```
aws iam put-role-policy --role-name vmimport --policy-name vmimport --
policy-document file://role-policy.json
```

For more information, see [Importing a VM as an Image](#).

5. Enable *Amazon EC2 Full Access* and *Amazon S3 Full Access* permissions.

- a. Add permission for *create inline policy* in **Permission policies**. Enable write access (*CreateRole*) and user permission management (*PutRolePolicy*). Select **Any** as the policy name in resource selection.

The screenshot shows the AWS IAM console interface for managing permissions policies. At the top, there are buttons for 'Remove' and 'Add permissions'. Below is a search bar and a 'Filter by Type' dropdown set to 'All types'. A table lists the following policies:

Policy name	Type	Attached via
AmazonEC2FullAccess	AWS managed	Directly
AmazonS3FullAccess	AWS managed	Directly
IAMtoCreatePolicy	Customer inline	Inline

The 'IAMtoCreatePolicy' section is expanded, showing the following JSON:

```
1- [{"Version": "2012-10-17",
2-   "Statement": [
3-     {
4-       "Sid": "VisualEditor0",
5-       "Effect": "Allow",
6-       "Action": [
7-         "iam:CreateRole",
8-         "iam:PutRolePolicy"
9-       ],
10-      "Resource": "arn:aws:iam::250424965647:role/*"
11-    }
12-  ]
13- }]
```

- b. For user security credentials, create an access key (CLI) and download the CSV.

The screenshot shows the AWS IAM console interface. At the top, there are tabs for 'Permissions', 'Groups', 'Tags', 'Security credentials', and 'Access Advisor'. The 'Security credentials' tab is selected. Below this, there are sections for 'Console sign-in', 'Multi-factor authentication (MFA)', and 'Access keys'. The 'Access keys' section shows one active key with a description of '-' and a status of 'Active'. The key was created 111 days ago and last used in the us-east-2 region.

- c. If you run the `import2awsimg.sh` manually, then un-comment the line 209 in `Create_vmimport_role_and_policy`.

```
check_S3 $s3BucketName

# create vmimport role and attach policy. This requires IAM permissions.
# Need to be executed in the script, please remove the following "#"
create_vmimport_role_and_policy

import_image
```

6. Extract the file `FAO_VM64_AWS-v2.0.1-[build01xx]-FORTINET.out.aws.zip`. Post extraction, you have the VHD file and the import script.
 - a. VHD - `FAO_VM64_AWS-v2.0.1-[build01xx]-FORTINET.out.vhd`
 - b. Import script - `import2awsimg.sh`
7. Run the `import2awsimg.sh` script to import the VM.


`bash -x import2awsimg.sh <imported_image_file> <s3_bucket_name>`

Note: To import the VM, you must have read & write permissions to the Amazon bucket, EC2 Snapshot, and image creation, and import permissions.

```
-virtual-machine:~/Downloads/test$ bash -x import2awsimg.sh FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd aiopsqa
+ '[' 2 -gt 1 ']'
+ imageFile=FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd
+ s3BucketName=aiopsqa
+ '[' '!' -f FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd ']'
+ check_S3 aiopsqa
+ type aws
+ aws s3 ls s3://aiopsqa
+ '[' 0 -ne 0 ']'
+ import_image
++ basename FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd
+ imageName=FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd
+ imageName=FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out
+ echo 'Upload image file to S3..'
Upload image file to S3..
+ aws s3 cp FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd s3://aiopsqa/FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd
upload: ./FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd to s3://aiopsqa/FAO_VM64_AWS-v2.0.1-devbuild0461-FORTINET.out.vhd
+ cat
+ echo 'Start import image file as snapshot..'
Start import image file as snapshot..
++ aws ec2 import-snapshot --description 'Fimg aws' --disk-container file://container.json
++ awk -F ' ' '{if($2=="ImportTaskId")print $4}'
+ import_task_id=import-snap-05a78f80bdd0517b1
+ '[' -z import-snap-05a78f80bdd0517b1 ']'
+ echo import-snap-05a78f80bdd0517b1
import-snap-05a78f80bdd0517b1
+ true
++ aws ec2 describe-import-snapshot-tasks --import-task-ids import-snap-05a78f80bdd0517b1
```

```
+ amiId=ami-038a0845e0f322b35
+ '[' -z ami-038a0845e0f322b35 ']'
+ aws ec2 create-tags --resources ami-038a0845e0f322b35 --tags Key=Name,Value=FA0_VM64_AWS-v2.0.1-devbuil0461-FORTINET.out
+ echo 'Register AMI done..'
Register AMI done..
+ echo 'AMI ID: ami-038a0845e0f322b35'
AMI ID: ami-038a0845e0f322b35
+ echo 'AMI NAME: FA0_VM64_AWS-v2.0.1-devbuil0461-FORTINET.out'
AMI NAME: FA0_VM64_AWS-v2.0.1-devbuil0461-FORTINET.out
+ rm -f block device mappings.json container.json
```

8. Launch an instance from the Amazon Machine Images (AMI). Select **Images > AMI** in the EC2 service interface and select the image that you just imported. Click **Launch instance** from AMI.



9. Add **Name and tags** for the instance, select the **Instance type**, set the **Key pair**, and configure the **Network settings** based on your requirement. Select the required hard disk size in **Configure storage**. The default size of disk storage 2 is 10 GB, modify the size as per your requirement. Click **Launch instance**.

The screenshot displays the AWS Management Console interface for launching an EC2 instance. The main configuration area includes sections for 'Name and tags', 'Application and OS Images (Amazon Machine Image)', 'Instance type', 'Key pair (login)', and 'Network settings'. The 'Configure storage' section is expanded to show two volumes: a 9 GiB gp2 root volume and a 500 GiB gp2 EBS volume. A 'Free tier' notification is present, indicating that eligible customers can receive up to 30 GB of EBS General Purpose (SSD) or Magnetic storage. The 'Summary' panel on the right provides a high-level overview of the instance configuration, including the number of instances (1), the selected AMI, instance type (t3.micro), security group, and total storage (509 GiB). The 'Launch instance' button is prominently displayed in orange.

10. Obtain the public IP address of the instance from the EC2 service interface and connect via a private key using SSH.

```
FA0AWS #
config          Configure object.
get            Get dynamic and system information.
show          Show configuration.
diagnose       Diagnose facility.
execute       Execute static commands.
exit          Exit the CLI.
full-configuration Show full configuration.

FA0AWS-AWS-Vinod # show
config system global
    set hostname FA0AWS-AWS-Vinod
end
config system interface
    edit port1
        set type physical
        set mode dhcp
        set allowaccess https ping ssh http
        config ipv6
        end
    next
end
config router static
end
config router static6
end
config system dns
end
config system ntp
end
config system admin
    edit admin
```

Command Line Interface (CLI) Reference

The following commands are supported for FortiAI Ops.

- [Configuration Commands](#)
- [Show Commands](#)
- [Diagnostic Commands](#)
- [Management Commands](#)
- [System Information](#)

Configuration Commands

The following commands are available to configure FortiAI Ops.

Command	Parameters	Description
config system interface	edit <interface port>	Edit the interface port and enter the port setting mode in the CLI.
	?	Displays the various parameters available for this command.
	abort	Aborts the port setting mode and exits.
	next	Returns to the interface configuration mode.
	set mode <static DHCP>	Configure the port IP address mode; static or DHCP.
	set ip <IP/netmask>	Configure the port IP address (static).
	set allowaccess <ssh https http ping>	Configure the admin access type; SSH, THHP, HTTPS, Ping, or SNMP.
	get	Obtain the system information.
	show	Displays the current interface configuration details.

Command	Parameters	Description
	end	Exit the port configuration mode; the configuration changes then take effect.
config system	admin	Configures admin users. edit admin - Edit admin user details. set password - Set the admin user password.
	dns	Configures DNS and enters the DNS configuration mode. set primary - Configures the primary DNS server.
	global	Configures global settings and enters the global configuration mode.
	interface	Configures the system interface.
	ntp	Configures system NTP information. <ul style="list-style-type: none"> set ntpsync - Enable/disable the system time by synchronizing with the NTP server. set ntpserver - Configure the IP address or hostname of the NTP servers (up to 10).

Show Commands

The following commands can be used for viewing configuration information.

Command	Parameters	Description
<code>show</code>		Displays bootstrap configuration.
<code>show full-configuration</code>		Displays all configuration (includes defaults).

Diagnostic Commands

The following commands are used to diagnose and troubleshoot issues.

Command	Parameters	Description
<code>diagnose</code>	<code>?</code>	Displays the various parameters available for this command.
	<code>hardware ?</code>	Displays the various parameters available for this command.
	<code>hardware deviceinfo disk</code>	Displays information of all disks.
	<code>hardware deviceinfo nic</code>	Display the available list of NICs.
	<code>hardware deviceinfo <nic name></code>	Displays information of a specific NIC.
	<code>hardware lspci</code>	Displays the PCI parameters.
	<code>hardware lspci tree</code>	Displays PCI bus tree.
	<code>hardware lspci verbose</code>	Displays detailed information about all devices.
	<code>hardware sysinfo ?</code>	Displays the various parameters available for this command.
	<code>hardware sysinfo cpu</code>	Displays detailed information for all installed CPU(s).
	<code>hardware sysinfo interrupts</code>	Displays details of system interruptions.
	<code>hardware sysinfo iomem</code>	Displays the memory map of I/O ports.
	<code>hardware sysinfo ioports</code>	Display the address list of I/O ports.
	<code>hardware sysinfo memory</code>	Displays the system memory details.

Command	Parameters	Description
	hardware sysinfo mtrr	Displays the memory type range register.
	hardware sysinfo slab	Displays the memory allocation information.
diagnose system	top all	Displays the top threads information.
	top cpu	Displays processes with the highest CPU usage at the top of the list.
	load	Displays system uptime and load information.
	process <cpu mem> <num>	Displays the processes sorted by specified criteria (default 10 processes).

Management Commands

The following enable some management and other operations in FortiAIOps.

Command	Parameters	Description
execute	?	Displays the various parameters available for this command.
	date <YYYY-MM-DD>	Set the date in the <i>YYYY-MM-DD</i> format.
	time <HH:MM:SS>	Set the time in the <i>HH:MM:SS</i> format.
	factoryreset	Reset to the factory default settings. Restart the device after the second confirmation prompt.
	formatlogdisk	Format the log disk.
	ping <destination>	Ping the host name or IPv4 address.
	tracert <destination>	Traceroute of the host name or IPv4 address.
	reboot	Reboot the system.
	shutdown	Shut down the device.

Command	Parameters	Description
	<code>backup config ftp <path> <server fqdn ipaddr>[:port] [ftp_user] [ftp_passwd]</code>	Creates a remote backup of the configuration file from an FTP server.
	<code>backup config tftp <filename> <server fqdn ipaddr></code>	Creates a remote backup of the configuration file from a TFTP server.
	<code>restore image ftp <filename string> <ftp server>[:port] [ftp_user] [ftp_passwd]</code>	Restores the firmware image from an FTP server using specific details.
	<code>restore image tftp <filename string> <tftp server></code>	Restores the firmware image from a TFTP server.

System Information

The following commands information related to the system configurations.

Command	Parameters	Description
<code>get system</code>	?	Displays the various parameters available for this command.
	<code>status</code>	Displays system status, such as, version, serial number, BIOS details, time stamp, hostname, and so on.
	<code>admin</code>	Displays the configuration details of the admin users.
	<code>admin <username></code>	Displays the configuration details of a specific admin user.
	<code>dns</code>	Displays the DNS configuration.
	<code>global</code>	Displays the configuration details of global attributes.
	<code>interface</code>	Displays the interface details, status, and IP address.
	<code>interface <port></code>	Displays the port details, status, and IP address.
	<code>ntp</code>	Displays the configuration details and status of NTP server.

Dashboard

The FortiAI Ops dashboard provides a graphical overview of network elements, resource usage, AI insights, and Service Assurance.

- [Summary](#)
- [AI Insights](#)
- [Service Assurance](#)

Summary

This dashboard provides visual summarization of key system information, network elements, and resource usage. The interactive graphs and charts allow you to navigate into detailed views of network statistics for analytical and monitoring purpose.



The data on this dashboard is automatically refreshed every 60 seconds; the following options are available to manage the auto-refresh feature for this page.

- Click  to manually refresh data.
- Click  to pause the auto-refresh.
- Click  to resume the auto-refresh.

Use the **Add Widget** option to manage the widgets displayed on the dashboard; you can choose to add or remove the widgets.

Add Dashboard Widget

System

System Information 

General system information of the FortiAIOPs Server including Host Name, System ID and Firmware.

System Resource Summary 

Shows the Real-time System Resources (CPU, Disk, Memory) Usage summary data and it's trends over the selected period.

Pie charts

FortiGates 

Shows the status of available FortiGates.

FortiSwitches 

Shows the status of available FortiSwitches

Access Points 

Shows the status of available wireless APs.

Rogue APs 

Shows the summary of Rogue APs detected in the network.

Wireless Clients 

Shows the connected Wireless clients distribution by Band (2.4GHz/5GHz/6GHz).

Wired Clients 

Show the connected Wired clients.

Trends

FortiGates CPU Usage 

Shows the Real-time FortiGates CPU usage over the selected period.

FortiGates Memory Usage 

Shows the Real-time Fortigates memory usage over the selected period.

High Latency FortiGates 

Shows the Real-time monitoring for High Latency FortiGates and Stay updated on network events, identify latency issues.

FortiGates Events 

Shows the Real-time FortiGates events over the selected period.

FortiSwitches Events 

Shows the Real-time FortiSwitches events over the selected period.

The following widgets provide network data on this dashboard.

- **System Information** - This widget provides generic information about the FortiAIOPs such as the host name, firmware version, system ID, current system time, uptime, and the IP address.
- **System Resource Summary** - This widget provides an overview of the current system resource usage for FortiAIOPs. The statistics include the total available and used disk space, the number of CPU cores used and the average usage, and total available and used memory.
- **Wireless Clients** - Displays the total number of connected clients with their band categorization of 2.4GHz, 5GHz, and 6GHz. Click on the chart to navigate to **Wireless > Clients**.
- **Wired Clients** - Displays the total number of connected clients with their status.
- **FortiGates** - Displays the total number of FortiGate controllers in your network and their status (*Online/Offline*). Click on the chart to navigate to **Inventory > Managed FortiGates**.
- **FortiGates CPU Usage** and **FortiGates Memory Usage** - Displays the real-time FortiGate CPU and memory usage at a given time and categorizes it as *Low*, *Medium*, *High*, and *Critical*. You can select the period to view the resource usage (10 or 30 minutes, 1 or 12 hours, or 1 day). Click on the graph to view the details.

FortiGate CPU Usage 

CPU Usage =0 -> 29    Search 

Timestamp	FortiGate Name	Firmware Version	Model	Online APs	Offline APs	Clients	
2023/04/05 13:15:46	[REDACTED]	v7.2.3	FGVM64	1	14	0	
2023/04/05 13:15:49	[REDACTED]	v7.2.4	FG3H0E	7	10	3	8.

Timestamp	FortiGate Name	Firmware Version	Model	Online APs	Offline APs	Clients	Throughput
-----------	----------------	------------------	-------	------------	-------------	---------	------------

- **High Latency FortiGates** - This widget displays the FortiGates with high latency determined based on the timed out API request. Hover over the graph to view the number of FortiGates with high latency at a given period of time and click on the graph to view the details of the FortiGates. You can select the period to view the FortiGates (10 or 30 minutes, 1 or 12 hours, or 1 day).

Date/Time	Hostname	FortiGate IP Address	FortiGate Timeout	Failed API Count
2024/04/03 00:51:54	FortiGate-60E	10.37.34.11	3000	1
2024/04/03 02:22:21		10.37.44.9	3000	4
2024/04/03 02:31:54	HA-Primary	10.34.139.221	3000	7

Select a particular FortiGate and click **View stats** to view the details of the timed out APIs.

Date/Time	API Endpoint
2024/04/03 01:11:54	/api/v2/monitor/wifi/rogue_ap/select?count=5000
2024/04/03 01:21:54	/api/v2/monitor/wifi/rogue_ap/select?count=5000
2024/04/03 01:51:54	/api/v2/monitor/wifi/rogue_ap/select?count=5000


- **FortiGate Events** - Displays the FortiGate events at a given time and categorizes them based on the severity level as *Information, Debug, Notice, Warning, Error, Critical, Emergency, and Alert*. You can select the period to view the data (10 or 30 minutes, 1 or 12 hours, or 1 day).

Timestamp	Level	Action	Message	SSID	Station MAC Address	Log ID	Fortigate Serialnumber
-----------	-------	--------	---------	------	---------------------	--------	------------------------


- **Access Points** - Displays the total number of access points in your network and their status (*Online, Offline, Waiting for Authorization, or Unknown*). Click on the chart to navigate to **Wireless > Access Points**.
- **FortiSwitches** - Displays the total number of FortiSwitches in your network and their status (*Online, Offline, Waiting for Authorization, or Unknown*). Click on the chart to navigate to **Switch > FortiSwitch**.
- **FortiSwitches Events** - Displays the FortiSwitch events at a given time and categorizes them based on the severity level as *Information, Debug, Notice, Warning, Error, Critical, Emergency, and Alert*. You can select the period to view the data (10 or 30 minutes, 1 or 12 hours, or 1 day).
- **Rogue APs** - Displays the total number of rogue access points detected in your network. Click on the chart to navigate to **Wireless > Rogue APs**.

AI Insights

The AI insights dashboard present data in various panels that is displayed in a series of charts and graphs, that you can filter based on time duration. Navigate to **Dashboard > AI Insights**.



Clicking on the statistics of each of the panels in the dashboard displays detailed data graphically and in a tabular format. The data displayed in tabular format is filterable based on the columns, you can group data by a specific column or filter data for specific values. This is an example.



Dashboard data is refreshed at a configurable interval. Use the **Add Widget** option to manage the widgets displayed on the dashboard; you can choose to add or remove the widgets.

Add Dashboard Widget ✕

Pie charts

Summary ✕

Shows real-time Wireless and Switching connected clients, as well as Wireless, Switching, and WAN-impacted clients over the selected period.

Wireless ✕

Shows real-time wireless SLA-impacted clients or devices over the selected period.

Switching ✕

Shows real-time information on Switching SLA-impacted clients or devices over the selected period.

WAN ✕

Shows real-time data on WAN SLA-impacted clients or devices over the selected period.

Trends

Overall Network Health ✕

Shows real-time total connected clients and impacted clients over the selected time period.

Impacted Clients Trend ✕

Shows real-time data on all (Wireless, Switching, WAN) impacted clients over the selected period.

Top 3 Impacted Apps ✕

Shows real-time data on the top 3 impacted conference applications (e.g., WhatsApp, MS Teams, FaceTime, Google Meet) over the selected period.


Top 5 Problematic Devices ✕

Shows real-time information on the top 5 problematic devices impacted by SLAs (Wireless, Switching, WAN) over the selected period.

- [Summary](#)
- [Impacted Clients Trend on page 67](#)
- [Overall Network Health](#)
- [Top 3 Impacted Apps](#)
- [Top 5 Problematic Devices](#)
- [Wireless](#)
- [WAN](#)
- [Switching](#)


Summary

The **Summary** panel displays data in charts and statistics for the total number of connected and impacted clients for switching, wireless, and WAN. FortiAI Ops displays the connected and impacted client count during the selected duration in the dashboard. Clicking on the donut chart for the connected clients or the statistics for the impacted clients in this panel, re-directs you to the [Impacted Devices](#) page.




Impacted Clients Trend

The **Impacted Clients Trend** panel displays data trends for the total number of impacted clients for switching, wireless, and WAN, over a period of time.



Click on any given time interval for the impacted clients to view the **Impacted Clients** page. This page displays details of the various devices in your network that are associated with impacted clients. The following image depicts an example of the impacted WAN clients.



The data is displayed in the following three panels. For more information on the data and fields displayed on this page, see [Impacted Devices](#).


- **FortiGates** - Displays the number of deployed FortiGate controllers with impacted wireless, switching, and WAN clients.
- **Access Points/ Switches/ Interfaces/FortiExtenders** - Displays the number of devices, that is, APs, interfaces, FortiExtenders, and switches with impacted clients.
- **Clients** - Displays the number of impacted clients for the wireless, switching, and WAN.

Overall Network Health

This panel displays the overall client count trends and health status of all wireless, switching, and WAN clients connected to your network, at specific intervals of 15 minutes. You can view the total number of clients in your

network and the number of impacted clients at a given point in time.

Hover over the line to view the total number of clients and the line to view the number of impacted clients. In this example, at 03.30 hours, a total of 145 clients were present in the network of which 32 clients are impacted.



Click on any given time interval for total clients to view the **Connected Clients** panel. The data displayed in tabular format in all the monitor dashboard pages is filterable based on columns, you can group data by a specific column or filter data for specific values.


Connected Clients					
Wireless		Switching			
Search					
MAC Address	FortiGate	IP Address	AP Name	SSID	Device
			FP2211	simulator2.4G	
			FP2211	simulator2.4G	
			FP2211	simulator2.4G	

Click the **AP Name** to view the FortiAP details and the operational status of the radios.

Serial Number		
IP Address		
Status	Online	
Firmware Version	FP231F-v7.4.2-build0634	
Radio 1	Band	2.4 GHz
	Channel	11
	Channel Utilization	97%
	Client Count	1
	Operating TX Power	10 dbm
Radio 2	Band	5 GHz
	Channel	36
	Channel Utilization	72%
	Client Count	2
	Operating TX Power	22 dbm
MAC Address		

Click on any given time interval for total clients to view the **Overall Network Health** panel. This page displays details of the various devices in your network that are associated with impacted clients. The number of devices

are listed for each category, you can click on any of these or click on the respective section in the donut chart to view details. The data is displayed in the following three panels. Refer to [Impacted Devices](#) for more descriptions.




FortiGates - Displays the number of deployed FortiGate controllers with impacted wireless, switching, and WAN clients.

- **Access Points/ Switches/ Interfaces/FortiExtenders** - Displays the number of devices, that is, APs, interfaces, FortiExtenders, and switches with impacted clients.
- **Clients** - Displays the number of impacted clients for the wireless, switching, and WAN.

Click on the impacted SLA to view the device topology.

Top 3 Impacted Apps

This panel displays the 3 conference applications running on client devices that are most impacted. These applications are Microsoft Teams calls, Google Meet, Zoom, WhatsApp audio and video call, and Apple FaceTime. To view the details, click on the bar in the chart or on the name of the application displayed in the panel.



The applications are classified as impacted based on the downtime it experiences during various sessions in the selected time period. You can view the downtime for the latest session and the number of sessions. Furthermore, click on the number of sessions to view the downtime and other details for each session.

Top impacted apps

View details Appname == WhatsApp X Search filterable columns

Hostname	MAC Address	Timestamp	Downtime	Username	AP Serial Number	Sessions	Bandwidth Tx	Bandw
OnePlus-7	...	2024/04/05 19:33:39	4m		...	1	54 B/s	54

Note: For accurate applications related data in this panel, renew the FortiGuard license for general updates, including application control signatures for application detection.

Top 5 Problematic Devices

This panel displays the 5 devices with the highest number of impacted clients. The devices displayed here can be FortiAPs, FortiSwitches, FortiExtenders, and/or interfaces. The device name and the number of associated clients that are impacted are displayed in descending order.

Top 5 Problematic Devices

...	Impacted Clients: 37
2FLB2	Impacted Clients: 35
...	Impacted Clients: 20
...	Impacted Clients: 16
...	Impacted Clients: 12

Click on the device name to view details.


Problematic device

FortiSwitch Serial Number == S248E... FortiGate Serial Number == FGT1K... Search filterable columns

Impacted SLAs	MAC Address	FortiGate Serial Number	FortiGate IP Address	FortiSwitch Name	FortiSwitch Serial Number
2FLB2 37/93					
Switch Health and Uptime
Switch Health and Uptime
Switch Health and Uptime


Wireless

The **Wireless** panel displays the details of impacted SLAs with the associated device and client details. The **Clients** view displays the impacted client count and the **Devices** view displays the impacted AP count.




SLAs, Topology, and Logs

The impacted SLAs are detected and reported by FortiAI Ops with device and client details. The issues reported are categorized based on classifiers and sub-classifiers, with suggested remedial measures to curtail the SLA breaches and enhance network performance. The data displayed in this panel is for the time period set in the dashboard. If you select the **Devices** view in the Wireless panel and click on any SLA in the impacted SLAs list or click on the bar in the chart, the impacted devices details such as, AP name, AP serial number, AP IP address, AP status (online/offline) and state, FortiGate host name and serial number, and classifier and sub-classifier are displayed.



If you select the **Clients** view in the Wireless panel and click on any SLA in the impacted SLAs list or click on the bar in the chart, the impacted client details, such as, MAC address, hostname, associated SSID and channels, the AP name, IP address, and serial numbers, the associated FortiGate hostname and serial number, and the classifier and sub-classifiers are displayed.



Select any row and click **View Topology** to view a simplified topology with a visualization/illustration of the physical placement of devices, such as, FortiGates, FortiSwitches, and FortiAPs connected to each other in your network. This hierarchical pattern is representational; you cannot modify the placement of devices on this page. The topology displays the impacted devices, categorized based on their SLAs, classifiers, and sub-classifiers. The details of the topologies are described for each SLA in the following sections. You can toggle between different impacted SLAs on this page and filter data based on the impacted classifier and sub-classifier.

- [Throughput](#)
- [Connection Failure](#)
- [Time to Connect](#)
- [Coverage](#)
- [Roaming](#)
- [AP Health and Uptime](#)

Throughput

This SLA monitors your network for low throughput conditions and reports clients/devices based on dynamically configured threshold breaches.

Throughput Time range :1 week

Impacted Classifiers	Impacted Sub Classifiers
Interference 2	Wi-Fi Interference
Coverage 2	Non Wi-Fi Interference
	Distant Client
	Coverage Hole
	Asymmetric Data Rates

Details

[View Logs](#) Search filterable columns

Date/Time	Access Point	Radio Type	Issue Cause List	Remedies
2024/04/07 22:12:10	Desk-AP	5GHz 802.11ax/ac/n/a	High OBSS interference on the channel (36) i...	<ul style="list-style-type: none"> Enable auto Tx power Suggesting to review and reduce Wi-Fi chan... Prune lower data rates such as [6, 6-basic, 9, ...
2024/04/07 22:11:10	Desk-AP	5GHz 802.11ax/ac/n/a	High OBSS interference on the channel (36) i...	<ul style="list-style-type: none"> Enable auto Tx power Suggesting to review and reduce Wi-Fi chan...

The **Details** table displays information such as the impacted radios for the reported classifiers and sub-classifiers, issue description and the suggested remediation measure, and so on are displayed. Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
Classifiers	The classifier of the issue reported for the SLA.
Sub Classifiers	The sub-classifier of the issue for the reported classifier.
Impacted Client Count	The number of impacted clients.
Issue Cause List	Detailed cause of the SLA breach that impacted the client/AP/FortiGate.
Remedies	The suggested remedies to resolve the issue.
Radio	The AP radio that the client associated with.
Access Point	The AP name that the client associated with.
AP Serial Number	The AP serial number that the client associated with.
Bandwidth Rx	The Rx data throughput of the impacted AP.
Bandwidth Tx	The Tx data throughput of the impacted AP.
FortiGate Hostname	The hostname of the FortiGate associated with the AP/impacted client.
FortiGate Serial	The serial number of the associated FortiGate.
Radio Type	The impacted radio and band information.
Radio Impacted Minutes	The duration (in minutes) that the radio was impacted for.

In the impacted details displayed, select a specific row of throughput failure and click **View Details**. You can view details of the impacted AP and issue diagnostics. You can view throughput logs related to **Diagnostics** with the issue description and the suggested remediation, **AP Stats** with the associated AP radio details, **AP Logs** with the time of the throughput failure event and the associated AP details, **Switch Info** with the switch

port details connected to the AP, **WiFi Clients** with details of the impacted clients and a list of all WiFi clients, **Interfering APs** with the BSSID and the signal strength of the interfering APs.

Throughput Logs

- [Diagnostics](#)
[AP Stats](#)
[AP Logs](#)
[Switch Info](#)
[Neighbour APs](#)
[WiFi Clients](#)
[Interfering APs](#)

AP Info	
Name	PU431F5E19001086
Serial	PU431F5E19001086
Mac Address	00:0c:4b:7c:d7:60
IP Address	192.168.100.16
Status	connected
Version	PU431F-v6.2-build0296
FortiGate Hostname	unknown
Up Time	6 days, 2 hours, 43 minutes, 57 seconds



Issue Diagnostics	
Issue Cause	<ul style="list-style-type: none"> Half Duplex mode is detected on the uplink, affecting AP's LAN capacity; half duplex is negotiated for switch port(s) configured to use auto mode - SS24CF5C800004 (port17)
Remedy	<ul style="list-style-type: none"> Suggesting to configure Auto negotiation for switch port(s) and also to review if switch port supports full duplex

Close

Logs **Description**

Diagnostics This tab provides detailed cause of the SLA breach that impacted the client/AP/FortiGate. FortiAIOps also suggests the remedy to resolve the issue.

Issue Diagnostics	
Issue Cause	<ul style="list-style-type: none"> Asymmetric uplink and downlink rates for some clients; likely due to asymmetric power/high channel contention/retries
Remedy	<ul style="list-style-type: none"> Check client driver and update if necessary, also check the AP and client vicinities for any physical obstructions that can affect Wi-Fi data exchanges Review MBO and 802.11kvr settings for AP's SSIDs

AP Stats This tab displays the details of the AP radio that the client associated with and the WAN status details of the AP.

Radio Info						
<input type="text" value="Search"/>						
Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Po
802.11n,g-only	0	0	76	0	11	22 dBm

AP Logs This tab provides the AP event logs generated from FortiGate.

Logs		Description			
Date/Time	AP Name	Action	Message	Log Desc	
2023/11/09 12:35:48.871	43x_2F_CS_Bay	client-disconnected-by-wtp	Client 04:cf:4b:b3:3d:19 disconnected b...	Wireless client WTP disc	
2023/11/09 12:38:29.019	43x_2F_CS_Bay	auth-req	AP received authentication request fra...	Authentication request f	
2023/11/09 12:38:29.019	43x_2F_CS_Bay	auth-resp	AP sent authentication response frame t...	Authentication response	
2023/11/09 12:38:29.019	43x_2F_CS_Bay	reassoc-req	AP received reassociation request frame...	Reassociation request fr	
2023/11/09 12:38:29.019	43x_2F_CS_Bay	reassoc-resp	AP sent reassociation response frame to...	Reassociation response t	

Switch Info

This tab displays the configuration details of the switch port connected to the AP.

Switch Config							
Switch Name	Interface	Duplex	Speed	Status	Collisions	Rx Bytes	Tx bytes
Switch-1	port15	full	1000	up	0	840629319	5317837210

Neighbour APs

This tab displays details of the detected neighbour APs by the client, for distant client & coverage hole issues.

AP Radio	Band	RSSI	RSSI Age
FP231F	5 GHz	18	37
FP431F	5 GHz	22	38
FP431F	5 GHz	16	38

WIFI Clients

This tab provides details of the impacted clients and also lists all the clients associated with the AP.

Date/Time	Client Mac Address	SSID	Radio Type	Classifier	Subclassifier	Signal Streng
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ax-5G	Coverage	Asymmetric Data Rates	-54 dBm
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-58 dBm
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-58 dBm
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-54 dBm

0% 5

All Clients						
Client Mac Address	Channel	Radio Type	SSID	Data Rate	Bandwidth Rx	Bandwidth Tx
08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	456.00 Mbps	0	642.00 bps
08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	12.00 Mbps	0	1.77 Kbps
08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	797.20 Mbps	426.39 Kbps	45.10 Kbps

Interfering APs

This tab displays details of the interfering APs in your network.

Logs	Description															
	<table border="1"> <thead> <tr> <th>Date/Time</th> <th>BSSID</th> <th>Signal Strength</th> </tr> </thead> <tbody> <tr> <td>2023/11/07 16:23:26</td> <td></td> <td>-67 dBm</td> </tr> <tr> <td>2023/11/07 16:23:26</td> <td></td> <td>-67 dBm</td> </tr> <tr> <td>2023/11/07 16:23:26</td> <td></td> <td>-67 dBm</td> </tr> <tr> <td>2023/11/07 16:23:26</td> <td></td> <td>-82 dBm</td> </tr> </tbody> </table>	Date/Time	BSSID	Signal Strength	2023/11/07 16:23:26		-67 dBm	2023/11/07 16:23:26		-67 dBm	2023/11/07 16:23:26		-67 dBm	2023/11/07 16:23:26		-82 dBm
Date/Time	BSSID	Signal Strength														
2023/11/07 16:23:26		-67 dBm														
2023/11/07 16:23:26		-67 dBm														
2023/11/07 16:23:26		-67 dBm														
2023/11/07 16:23:26		-82 dBm														

Connection Failure

Displays the failed/unsuccessful client connections based on different stages of connection to a network. For example, association failures due to low RSSI, authentication failures due to unreachable RADIUS server, DHCP failure due to a DHCP server process crash, or DNS failure due to an invalid DNS domain.

Connection Failure ▾
Time range :1 week

Impacted Classifiers	Impacted Sub Classifiers
Association 1	DHCP NAK
Authentication 1	Too Many Retries
DNS 1	Poor Channel Condition
	No Domain
	Server Failure

Details

[View Logs](#)
🔍 Search filterable columns

Date/Time	MAC Address	Hostname	Issue Cause List	Remedies
2024/04/07 18:23:49	88:27:42:42:42:42	DESKTOP-VF32J4L	❗ Wireless station DNS process failed due to n...	✅ Check local domain name(s) configured for t...
2024/04/07 14:27:06	88:27:42:42:42:42	DESKTOP-VF32J4L	❗ Wireless station DNS process failed due to n...	✅ Check local domain name(s) configured for t...
2024/04/07 14:26:04	88:27:42:42:42:42	DESKTOP-VF32J4L	❗ Wireless station DNS process failed due to n...	✅ Check local domain name(s) configured for t...

The **Details** table displays details such as the client MAC address, the associated AP serial number and the SSID, the issue classifier/category and the sub-classifier, the issue description and the suggested remediation measure, and so on are displayed. Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
MAC Address	The MAC address of the impacted client device.
Hostname	The name of the device as configured by the user. If the name is not configured or available, then MAC address is displayed.
Access Point	The name of the AP that the impacted client associated with.
SSID	The SSID that the impacted client is associated with.
Classifier	The classifier of the issue reported for the SLA.
Sub Classifier	The sub-classifier of the issue for the reported classifier.
Issue Cause List	The detailed causes of the SLA breach that impacted the client/AP/FortiGate.

Attribute	Description
Remedies	The suggested remedies to resolve the issue.
AP Serial Number	The AP serial number that the client associated with.
FortiGate Hostname	The hostname of the FortiGate associated with the AP/impacted client.
FortiGate Serial	The serial number of the associated FortiGate.
User Name	The impacted client user name.

Select a specific client and click **View Logs**. You can view **Client Details** such as the client device name, the name of the AP it is associated with and the time of association, associated SSID, and operational details such as the channel and the MIMO mode. The client **Status** such as the associated bandwidth (2.5GHZ/5GHZ), signal strength (RSSI), signal noise, rate of transmission discard and rate of transmission retry between the client and the AP. The **Client Logs** display the time stamp of each action and action classification as notice, warning, etc., and the action details and the associated channel.

Client Details
✕

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Association Time</td> <td>2023-11-08 10:53:57</td> </tr> <tr> <td>Channel</td> <td>116</td> </tr> <tr> <td>FortiAP</td> <td></td> </tr> <tr> <td>MIMO</td> <td>2x2</td> </tr> <tr> <td>SSID</td> <td>Forti-Corp-Peap-2F</td> </tr> </table>	Association Time	2023-11-08 10:53:57	Channel	116	FortiAP		MIMO	2x2	SSID	Forti-Corp-Peap-2F	<div style="display: flex; flex-direction: column; gap: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> 5GHz Band </div> <div style="display: flex; justify-content: space-between; align-items: center;"> -72dBm Signal Strength </div> <div style="display: flex; justify-content: space-between; align-items: center;"> 20dB Signal Strength/Noise </div> <div style="display: flex; justify-content: space-between; align-items: center;"> 0% Transmission Discard </div> <div style="display: flex; justify-content: space-between; align-items: center;"> 2% Transmission Retry </div> </div>
Association Time	2023-11-08 10:53:57										
Channel	116										
FortiAP											
MIMO	2x2										
SSID	Forti-Corp-Peap-2F										

CLIENT LOGS

Date/Time	Level	Action	Message	Channel
2023/11/08 10:53:55.125	Notice	client-denial		116
2023/11/08 10:53:54.383	Notice	client-disconnected-by-wtp		116
2023/11/08 10:53:33.120	Notice	DHCP-ACK		-
2023/11/08 10:53:33.120	Notice	DHCP-REQUEST		-
2023/11/08 10:53:33.120	Notice	DHCP-OFFER		-
2023/11/08 10:53:12.116	Warning	DHCP-DECLINE		-
2023/11/08 10:52:57.113	Notice	DHCP-ACK		-
2023/11/08 10:52:57.113	Notice	DHCP-REQUEST		-
2023/11/08 10:52:57.113	Notice	client-authentication		116
2023/11/08 10:52:57.113	Warning	WPA-4/4-key-msg		116
2023/11/08 10:52:57.113	Warning	WPA-3/4-key-msg		116

0% 22

Time to Connect

Displays the details of clients that breach the SLA threshold values for these stages of connection, **Association**, **Authentication**, **DHCP**, and **DNS**. The actual value of time taken and the configured **Time to**

Connect threshold values (static/dynamic) are compared. For SLA configurations, see [Time To Connect](#).

Time to Connect ▾
Time range :1 week

Impacted Classifiers	Impacted Sub Classifiers	
Authentication Delay 1	Coverage or Load Issue	
DHCP Delay 1	Poor Bandwidth	

Details

View Logs
🔍 Search filterable columns
🔍

Date/Time	MAC Address	Hostname	Issue Cause List	Remedies
2024/04/05 18:15:39	██-██-██-██-██-██		! AP health - detected high channel utilization. ...	✓ Rectify the channel utilization issue. Alternati...
2024/04/04 19:51:04	██-██-██-██-██-██		! Wired Network - packet delays detected	✓ Check switch side connections and configurat...
2024/04/04 16:32:03	██-██-██-██-██-██		! Wired Network - packet delays detected	✓ Check switch side connections and configurat...

The **Details** table displays details such as the client MAC address, the associated AP serial number and the SSID, the issue classifier/category and the sub-classifier, the issue description and the suggested remediation measure, and so on are displayed. Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
MAC Address	The MAC address of the impacted client device.
Hostname	The name of the device as configured by the user. If the name is not configured or available, then MAC address is displayed.
SSID	The SSID that the impacted client is associated with.
Classifier	The classifier of the issue reported for the SLA.
Sub Classifier	The sub-classifier of the issue for the reported classifier.
Signal Strength	The signal strength of the client at the time of impact.
Issue Cause List	The detailed causes of the SLA breach that impacted the client/AP/FortiGate.
Remedies	The suggested remedies to resolve the issue.
Access Point	The name of the access point that the client associated with.
AP Serial Number	The AP serial number that the client associated with.
FortiGate Hostname	The hostname of the FortiGate associated with the AP/impacted client.
FortiGate Serial	The serial number of the associated FortiGate.
User Name	The impacted client user name.
Association Delay	The association delay measured in milliseconds.
Association Time	The total time taken by the client for association.

Attribute	Description
Authentication Delay	The authentication delay measured in milliseconds.
Authentication Time	The total time taken by the client for authentication.
DNS Delay	The DNS delay measured in milliseconds.
DNS Time	The total time taken by the client to resolve the DNS request.
DHCP Delay	The DHCP delay measured in milliseconds.
DHCP Time	The total time taken by a client to receive a DHCP address.

Select a specific row and click **View Logs** to view the raw logs associated with the impacted client. You can view **Client Details** such as the client device name, the name of the AP it is associated with and the time of association, associated SSID, and operational details such as the channel and the MIMO mode. The client **Status** such as the associated bandwidth (2.5GHZ/5GHZ), signal strength (RSSI), signal noise, rate of transmission discard and rate of transmission retry between the client and the AP. The **Client Logs** display the time stamp of each action and action classification as notice, warning, etc., and the action details and the associated channel.

Client Details
✕

Association Time	2023-11-08 10:53:57	5GHz	Band
Channel	116	-72dBm	Signal Strength
FortiAP		20dB	Signal Strength/Noise
MIMO	2x2	0%	Transmission Discard
SSID	Forti-Corp-Peap-2F	2%	Transmission Retry

CLIENT LOGS

Date/Time	Level	Action	Message	Channel
2023/11/08 10:53:55.125	Notice	client-denial		116
2023/11/08 10:53:54.383	Notice	client-disconnected-by-wtp		116
2023/11/08 10:53:33.120	Notice	DHCP-ACK		-
2023/11/08 10:53:33.120	Notice	DHCP-REQUEST		-
2023/11/08 10:53:33.120	Notice	DHCP-OFFER		-
2023/11/08 10:53:12.116	Warning	DHCP-DECLINE		-
2023/11/08 10:52:57.113	Notice	DHCP-ACK		-
2023/11/08 10:52:57.113	Notice	DHCP-REQUEST		-
2023/11/08 10:52:57.113	Notice	client-authentication		116
2023/11/08 10:52:57.113	Warning	WPA-4/4-key-msg		116
2023/11/08 10:52:57.113	Warning	WPA-3/4-key-msg		116

0% 22

Coverage

This SLA monitors your network for coverage issues and reports clients/devices based on dynamically configured threshold breaches.

Coverage ▾
Time range :1 week

Impacted Classifiers	Impacted Sub Classifiers	
Coverage hole 2	Poor Coverage	
Overlapping APs 2	No better neighbour AP f...	
	Wi-Fi Interference	

Details

View Logs
Search filterable columns
Q

Date/Time	Access Point	Radio ID	Radio Type	Issue Cause List	Remedies
2024/04/07 21:44:10	Desk-AP	2	5GHz 802.11ax/ac/n/a	High OBSS interference on the channel (36) i...	<ul style="list-style-type: none"> ✓ Enable auto Tx power ✓ Suggesting to review and rec ✓ Prune lower data rates such
2024/04/07 21:42:10	Desk-AP	2	5GHz 802.11ax/ac/n/a	High OBSS interference on the channel (36) i...	<ul style="list-style-type: none"> ✓ Enable auto Tx power ✓ Suggesting to review and rec

The **Details** table displays issue details such as the radio type, Tx power, neighbour AP count, the issue classifier/category and the sub-classifier, the issue description and the suggested remediation measure, and so on are displayed. Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
Access Point	The name of the FortiAP.
Classifiers	The classifiers of the issue reported for the SLA.
Sub Classifiers	The sub-classifiers of the issue for the reported classifier.
Issue Cause List	The detailed causes of the SLA breach that impacted the client/AP/FortiGate.
Remedies	The suggested remedies to resolve the issue.
Radio ID	The AP radio that the client associated with.
Radio Type	The impacted radio and band information associated with the client.
Radio Impacted Minutes	The duration of time (in minutes) that the Radio was impacted.
AP Serial Number	The AP serial number that the client associated with.
TX Power	The Tx power of the AP at the time of impact.
FortiGate Hostname	The hostname of the FortiGate associated with the AP/impacted client.
FortiGate Serial	The serial number of the associated FortiGate.
Radio Type	The impacted radio and band associated with the client.
Channel	The channel at which the client connected.

Attribute	Description
Impacted Client Count	The number of impacted clients.
Interfering AP	The list of interfering APs in the network.

To view the logs, select a specific row of an AP event and click **View Logs**. You can view coverage logs related to **Diagnostics** with the issue description and the suggested remediation, **AP Stats** with the associated AP radio details, **AP Logs** with the time of the throughput failure event and the associated AP details, **Switch Info** with the switch port details connected to the AP, **WiFi Clients** with details of the impacted clients and a list of all WiFi clients, **Interfering APs** with the BSSID and the signal strength of the interfering APs.

Coverage Logs

- Diagnostics
- AP Stats
- AP Logs
- Neighbour APs
- WiFi Clients
- Interfering APs

AP Info	
Name	43x_2F_...
Serial	...
Mac Address	(...)
IP Address	...
State	authorized
Status	connected
FortiGate Hostname	office-wifi-qa
Up Time	83 days, 14 hours, 13 minutes, 14 seconds



Issue Diagnostics	
Issue Cause	<ul style="list-style-type: none"> Far off clients connected to the AP
Remedy	<ul style="list-style-type: none"> Review SSID specific configurations suggested below : SSID Forti-Corp-2F-PSK - Enable MBO + v, advanced option(s) - probe response suppression/ sticky client removal/ Rx-SOP ;Review these RSSI thresholds that are currently being used - probe response suppression (-80), sticky client removal (-79 for 2.4 GHz, -76 for 5 GHz), Rx-SOP (-79 for 2.4 GHz, -76 for 5 GHz) Prune lower data rates such as [6, 6-basic, 9, 9-basic] for the following SSID(s) - Forti-Corp-2F-PSK

Logs	Description
------	-------------

Diagnostics	<p>This tab provides detailed cause of the SLA breach that impacted the client/AP/FortiGate. FortiAIOps also suggests the remedy to resolve the issue.</p> <table border="1" style="width: 100%;"> <thead> <tr> <th colspan="2">Issue Diagnostics</th> </tr> </thead> <tbody> <tr> <td>Issue Cause</td> <td> <ul style="list-style-type: none"> Far off clients connected to the AP </td> </tr> <tr> <td>Remedy</td> <td> <ul style="list-style-type: none"> Review SSID specific configurations suggested below : SSID Forti-Corp-2F-PSK - Enable MBO + v, advanced option(s) - probe response suppression/ sticky client removal/ Rx-SOP ;Review these RSSI thresholds that are currently being used - probe response suppression (-80), sticky client removal (-79 for 2.4 GHz, -76 for 5 GHz), Rx-SOP (-79 for 2.4 GHz, -76 for 5 GHz) Prune lower data rates such as [6, 6-basic, 9, 9-basic] for the following SSID(s) - Forti-Corp-2F-PSK </td> </tr> </tbody> </table>	Issue Diagnostics		Issue Cause	<ul style="list-style-type: none"> Far off clients connected to the AP 	Remedy	<ul style="list-style-type: none"> Review SSID specific configurations suggested below : SSID Forti-Corp-2F-PSK - Enable MBO + v, advanced option(s) - probe response suppression/ sticky client removal/ Rx-SOP ;Review these RSSI thresholds that are currently being used - probe response suppression (-80), sticky client removal (-79 for 2.4 GHz, -76 for 5 GHz), Rx-SOP (-79 for 2.4 GHz, -76 for 5 GHz) Prune lower data rates such as [6, 6-basic, 9, 9-basic] for the following SSID(s) - Forti-Corp-2F-PSK
Issue Diagnostics							
Issue Cause	<ul style="list-style-type: none"> Far off clients connected to the AP 						
Remedy	<ul style="list-style-type: none"> Review SSID specific configurations suggested below : SSID Forti-Corp-2F-PSK - Enable MBO + v, advanced option(s) - probe response suppression/ sticky client removal/ Rx-SOP ;Review these RSSI thresholds that are currently being used - probe response suppression (-80), sticky client removal (-79 for 2.4 GHz, -76 for 5 GHz), Rx-SOP (-79 for 2.4 GHz, -76 for 5 GHz) Prune lower data rates such as [6, 6-basic, 9, 9-basic] for the following SSID(s) - Forti-Corp-2F-PSK 						

Logs	Description																																																															
<p>AP Stats</p>	<p>This tab displays the details of the AP radio that the client associated with and the WAN status details of the AP.</p> <div style="border: 1px solid #ccc; padding: 5px;"> <p>Radio Info</p> <p><input type="text" value="Search"/> <input type="submit" value="Q"/></p> <table border="1"> <thead> <tr> <th>Radio Type</th> <th>Bandwidth Tx</th> <th>Bandwidth Rx</th> <th>Channel Utilization(%)</th> <th>Client Count</th> <th>Oper Chan</th> <th>Oper Tx Po</th> </tr> </thead> <tbody> <tr> <td>802.11n,g-only</td> <td>0</td> <td>0</td> <td>76</td> <td>0</td> <td>11</td> <td>22 dBm</td> </tr> </tbody> </table> </div>	Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Po	802.11n,g-only	0	0	76	0	11	22 dBm																																																	
Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Po																																																										
802.11n,g-only	0	0	76	0	11	22 dBm																																																										
<p>AP Logs</p>	<p>This tab provides the AP event logs generated from FortiGate.</p> <table border="1"> <thead> <tr> <th>Date/Time</th> <th>AP Name</th> <th>Action</th> <th>Message</th> <th></th> </tr> </thead> <tbody> <tr> <td>2023/11/09 13:17:34.885</td> <td>BETWEEN CALL ROOM 8F</td> <td>client-disconnected-by-wtp</td> <td></td> <td>Wireless clien</td> </tr> <tr> <td>2023/11/09 13:20:46.849</td> <td>BETWEEN CALL ROOM 8F</td> <td>DNS-no-domain</td> <td></td> <td>Wireless stat</td> </tr> <tr> <td>2023/11/09 13:19:58.783</td> <td>BETWEEN CALL ROOM 8F</td> <td>client-disconnected-by-wtp</td> <td></td> <td>Wireless clien</td> </tr> <tr> <td>2023/11/09 13:20:32.818</td> <td>BETWEEN CALL ROOM 8F</td> <td>DNS-no-domain</td> <td></td> <td>Wireless stat</td> </tr> </tbody> </table>	Date/Time	AP Name	Action	Message		2023/11/09 13:17:34.885	BETWEEN CALL ROOM 8F	client-disconnected-by-wtp		Wireless clien	2023/11/09 13:20:46.849	BETWEEN CALL ROOM 8F	DNS-no-domain		Wireless stat	2023/11/09 13:19:58.783	BETWEEN CALL ROOM 8F	client-disconnected-by-wtp		Wireless clien	2023/11/09 13:20:32.818	BETWEEN CALL ROOM 8F	DNS-no-domain		Wireless stat																																						
Date/Time	AP Name	Action	Message																																																													
2023/11/09 13:17:34.885	BETWEEN CALL ROOM 8F	client-disconnected-by-wtp		Wireless clien																																																												
2023/11/09 13:20:46.849	BETWEEN CALL ROOM 8F	DNS-no-domain		Wireless stat																																																												
2023/11/09 13:19:58.783	BETWEEN CALL ROOM 8F	client-disconnected-by-wtp		Wireless clien																																																												
2023/11/09 13:20:32.818	BETWEEN CALL ROOM 8F	DNS-no-domain		Wireless stat																																																												
<p>WIFI Clients</p>	<p>This tab provides details of the impacted clients and also lists all the clients associated with the AP.</p> <table border="1"> <thead> <tr> <th>Date/Time</th> <th>Client Mac Address</th> <th>SSID</th> <th>Radio Type</th> <th>Classifier</th> <th>Subclassifier</th> <th>Signal Streng</th> </tr> </thead> <tbody> <tr> <td>2022/05/24 13:23:42</td> <td>08:00:27:00:00:00</td> <td>Forti-Corp-3F-PSK</td> <td>802.11ax-5G</td> <td>Coverage</td> <td>Asymmetric Data Rates</td> <td>-54 dBm</td> </tr> <tr> <td>2022/05/24 13:23:42</td> <td>08:00:27:00:00:00</td> <td>Forti-Corp-3F-PSK</td> <td>802.11ac</td> <td>Coverage</td> <td>Asymmetric Data Rates</td> <td>-58 dBm</td> </tr> <tr> <td>2022/05/24 13:23:42</td> <td>08:00:27:00:00:00</td> <td>Forti-Corp-3F-PSK</td> <td>802.11ac</td> <td>Coverage</td> <td>Asymmetric Data Rates</td> <td>-58 dBm</td> </tr> <tr> <td>2022/05/24 13:23:42</td> <td>08:00:27:00:00:00</td> <td>Forti-Corp-3F-PSK</td> <td>802.11ac</td> <td>Coverage</td> <td>Asymmetric Data Rates</td> <td>-54 dBm</td> </tr> </tbody> </table> <p style="text-align: right;">0% 5</p> <div style="border: 1px solid #ccc; padding: 5px;"> <p>All Clients</p> <p><input type="text" value="Search"/> <input type="submit" value="Q"/></p> <table border="1"> <thead> <tr> <th>Client Mac Address</th> <th>Channel</th> <th>Radio Type</th> <th>SSID</th> <th>Data Rate</th> <th>Bandwidth Rx</th> <th>Bandwidth Tx</th> </tr> </thead> <tbody> <tr> <td>08:00:27:00:00:00</td> <td>60</td> <td>802.11ax-5G</td> <td>Forti-Corp-3F-PSK</td> <td>456.00 Mbps</td> <td>0</td> <td>642.00 bps</td> </tr> <tr> <td>08:00:27:00:00:00</td> <td>60</td> <td>802.11ax-5G</td> <td>Forti-Corp-3F-PSK</td> <td>12.00 Mbps</td> <td>0</td> <td>1.77 Kbps</td> </tr> <tr> <td>08:00:27:00:00:00</td> <td>60</td> <td>802.11ax-5G</td> <td>Forti-Corp-3F-PSK</td> <td>797.20 Mbps</td> <td>426.39 Kbps</td> <td>45.10 Kbps</td> </tr> </tbody> </table> </div>	Date/Time	Client Mac Address	SSID	Radio Type	Classifier	Subclassifier	Signal Streng	2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ax-5G	Coverage	Asymmetric Data Rates	-54 dBm	2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-58 dBm	2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-58 dBm	2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-54 dBm	Client Mac Address	Channel	Radio Type	SSID	Data Rate	Bandwidth Rx	Bandwidth Tx	08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	456.00 Mbps	0	642.00 bps	08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	12.00 Mbps	0	1.77 Kbps	08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	797.20 Mbps	426.39 Kbps	45.10 Kbps
Date/Time	Client Mac Address	SSID	Radio Type	Classifier	Subclassifier	Signal Streng																																																										
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ax-5G	Coverage	Asymmetric Data Rates	-54 dBm																																																										
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-58 dBm																																																										
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-58 dBm																																																										
2022/05/24 13:23:42	08:00:27:00:00:00	Forti-Corp-3F-PSK	802.11ac	Coverage	Asymmetric Data Rates	-54 dBm																																																										
Client Mac Address	Channel	Radio Type	SSID	Data Rate	Bandwidth Rx	Bandwidth Tx																																																										
08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	456.00 Mbps	0	642.00 bps																																																										
08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	12.00 Mbps	0	1.77 Kbps																																																										
08:00:27:00:00:00	60	802.11ax-5G	Forti-Corp-3F-PSK	797.20 Mbps	426.39 Kbps	45.10 Kbps																																																										
<p>Interfering APs</p>	<p>This tab displays details of the interfering APs in your network.</p> <table border="1"> <thead> <tr> <th>Date/Time</th> <th>BSSID</th> <th>Signal Strength</th> </tr> </thead> <tbody> <tr> <td>2023/11/09 13:25:09</td> <td>08:00:27:00:00:00</td> <td> -73 dBm</td> </tr> <tr> <td>2023/11/09 13:25:09</td> <td>08:00:27:00:00:00</td> <td> -46 dBm</td> </tr> <tr> <td>2023/11/09 13:25:09</td> <td>08:00:27:00:00:00</td> <td> -47 dBm</td> </tr> </tbody> </table>	Date/Time	BSSID	Signal Strength	2023/11/09 13:25:09	08:00:27:00:00:00	-73 dBm	2023/11/09 13:25:09	08:00:27:00:00:00	-46 dBm	2023/11/09 13:25:09	08:00:27:00:00:00	-47 dBm																																																			
Date/Time	BSSID	Signal Strength																																																														
2023/11/09 13:25:09	08:00:27:00:00:00	-73 dBm																																																														
2023/11/09 13:25:09	08:00:27:00:00:00	-46 dBm																																																														
2023/11/09 13:25:09	08:00:27:00:00:00	-47 dBm																																																														

Roaming

Slow roaming clients are detected based on the variation of the classifier threshold values set by the users or calculated dynamically by FortiAIops. The parameters to identify slow roaming clients are **Fast BSS Transition Roams**, **PMK Cache**, and **Opportunistic Key Caching Roams**. Any breach in the threshold values are detected and reported. For SLA configurations, see [Roaming](#).

The **Details** table displays details such as the client MAC address, the associated AP serial number and the SSID, the issue classifier/category and the sub-classifier, the issue description and the suggested remediation measure, and so on. Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
MAC Address	The MAC address of the impacted client device.
Device	The name of the device as configured by the user. If the name is not configured or available, then MAC address is displayed.
SSID	The SSID that the impacted client is associated with.
Classifier	The classifier of the issue reported for the SLA.
Sub Classifier	The sub-classifier of the issue for the reported classifier.
Roaming Delay	The delay (latency) in client roaming (milliseconds) in case of threshold breach.
Roaming Time	The duration of time the client was roaming the network.
Radio ID	The AP radio that the client associated with.
Radio Type	The impacted radio and band information.
AP Serial Number	The AP serial number that the client associated with.
Channel	The channel at which the AP/client were operating.
Issue Cause List	detailed cause of the SLA breach that impacted the client/AP/FortiGate.
Remedies	The suggested remedies to resolve the issue.
Access Point	The name of the access point.

To view the logs, select a specific row of an AP event and click **View Logs**. You can view client details such as **Diagnostics** with the issue description and the suggested remediation, **AP Stats** with the associated AP radio details, and **Client Logs** with details of the impacted clients.

Client Details x

Diagnostics
AP Stats
Client Logs

Issue Diagnostics

Issue Cause	<ul style="list-style-type: none"> Roaming delay observed for 11r roaming over-the-ds
Remedy	<ul style="list-style-type: none"> Review threshold computed/configured for 11r Roaming delay alerts.

Logs	Description				
Diagnostics	<p>This tab provides detailed cause of the SLA breach that impacted the client. FortiAIOps also suggests the remedy to resolve the issue.</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> <p>Issue Diagnostics</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Issue Cause</td> <td> <ul style="list-style-type: none"> Roaming delay observed for 11r roaming over-the-air </td> </tr> <tr> <td>Remedy</td> <td> <ul style="list-style-type: none"> Review threshold computed/configured for 11r Roaming delay alerts. </td> </tr> </table> </div>	Issue Cause	<ul style="list-style-type: none"> Roaming delay observed for 11r roaming over-the-air 	Remedy	<ul style="list-style-type: none"> Review threshold computed/configured for 11r Roaming delay alerts.
Issue Cause	<ul style="list-style-type: none"> Roaming delay observed for 11r roaming over-the-air 				
Remedy	<ul style="list-style-type: none"> Review threshold computed/configured for 11r Roaming delay alerts. 				
AP Stats	This tab displays the details of the AP radio that the client associated with.				

Logs
Description

Radio Info

Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Power
802.11ax-5G	209.92 Kbps	158.65 Kbps	31	15	60	10 dBm

Client Logs

This tab provides client event logs.

Date/Time	Level	Action	Message	Channel
2023/11/08 19:27:35.267	Notice	client-disconnected-by-wtp	[Redacted]	157
2023/11/08 19:25:55.112	Notice	client-ip-detected	[Redacted]	157
2023/11/08 19:25:55.112	Notice	client-ip-detected	[Redacted]	157
2023/11/08 19:25:54.996	Notice	DHCP-ACK	[Redacted]	-

In the various throughput logs displayed, you can right-click on the table header to select the details you want to view.

AP Health and Uptime

Displays the AP health based on the configured AP health threshold values and the AP down status due to AP/FortiGate reboot, disabled switch port etc. For SLA configurations, see [Device Health](#).

AP Health and Uptime
Time range :1 week

Impacted Classifiers	Impacted Sub Classifiers
AP Down	FGT Shutdown
CPU	FGT Reboot
Memory	FSW Port Down
Switch Health	Poor Uplink Connectivity
	FAP Reboot
	Configuration Issue or Ot...
	High Resource Utilization

Details

View Logs

Date/Time	FortiSwitch Name	Issue Cause List	Remedies	Classifier
2024/04/06 12:00:29		FortiAP Left - AP DTLS peer disconnected	Check the FortiAP configuration of FP431G...	AP Down
2024/04/06 11:59:53	S248EF	Poor FortiSwitch Health - High CPU [41%] us...	Check if there's high traffic, high device coun...	Switch Health

The **Details** table displays issue details such as the issue classifier/category and the sub-classifier, the issue description and the suggested remediation measure, and so on. Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
FortiSwitch Name	The name of the switch associated with the impacted AP/client.
Issue Cause List	The detailed causes of the SLA breach that impacted the client/AP/FortiGate.
Remedies	The suggested remedies to resolve the issue.
Classifier	The classifier of the issue reported for the SLA.

Attribute	Description
Sub Classifier	The sub-classifier of the issue for the reported classifier.
AP Serial Number	The AP serial number that the client associated with.
FortiGate Hostname	The hostname of the FortiGate associated with the AP/impacted client.
FortiGate Serial Number	The serial number of the associated FortiGate.
FortiSwitch Serial Number	The serial number of the switch associated with the impacted AP/client.

In the AP events displayed, select an event and click **View Logs**.

AP Details ✕

Diagnostics
AP Stats
Logs
WIFI Clients
Interfering APs

Issue Diagnostics

Issue Cause	<ul style="list-style-type: none"> Poor FortiAP Health - High CPU [28%] usage
Remedy	<ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network.

Logs	Description														
Diagnostics	<p>This tab provides detailed cause of the SLA breach that impacted the client/AP/FortiGate. FortiAIOps also suggests the remedy to resolve the issue.</p> <div style="border: 1px solid #ccc; padding: 5px; margin: 5px 0;"> <p>Issue Diagnostics</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">Issue Cause</td> <td> <ul style="list-style-type: none"> Poor FortiAP Health - High CPU [28%] usage </td> </tr> <tr> <td>Remedy</td> <td> <ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network. </td> </tr> </table> </div>	Issue Cause	<ul style="list-style-type: none"> Poor FortiAP Health - High CPU [28%] usage 	Remedy	<ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network. 										
Issue Cause	<ul style="list-style-type: none"> Poor FortiAP Health - High CPU [28%] usage 														
Remedy	<ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network. 														
AP Stats	<p>This tab displays the details of the AP radio that the client associated with and the WAN status details of the AP.</p> <div style="border: 1px solid #ccc; padding: 5px; margin: 5px 0;"> <p>Radio Info</p> <div style="border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;"> <input type="text" value="Q Search"/> </div> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Radio Type</th> <th>Bandwidth Tx</th> <th>Bandwidth Rx</th> <th>Channel Utilization(%)</th> <th>Client Count</th> <th>Oper Chan</th> <th>Oper Tx Po</th> </tr> </thead> <tbody> <tr> <td>802.11n,g-only</td> <td>0</td> <td>0</td> <td>76</td> <td>0</td> <td>11</td> <td>22 dBm</td> </tr> </tbody> </table> </div>	Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Po	802.11n,g-only	0	0	76	0	11	22 dBm
Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Po									
802.11n,g-only	0	0	76	0	11	22 dBm									
Logs	<ul style="list-style-type: none"> For the AP <i>down</i>/FortiSwitch health events, triggered due to FortiSwitch related failure, the FortiSwitch status and logs are displayed. For AP health related events like poor CPU and memory, the AP status and logs are displayed. For AP down events triggered due to FortiAP/FortiGate failure, the AP status and logs, and FortiGate logs are displayed. 														

Logs
Description

SWITCH Status	
CPU Usage	50%
Memory Usage	12%
Temperature	41 °C

SWITCH Logs

Date/Time	Level	Message	Log Description	Switch SN	user
2022/07/14 07:06:31	Notice	primary port port10 instance 0 chan...	FortiSwitch spanning Tree	S524DF4K16000024	Fort
2022/07/14 07:06:29	Notice	primary port port10 instance 0 chan...	FortiSwitch spanning Tree	S524DF4K16000024	Fort
2022/07/14 07:06:22	Notice	primary port port10 instance 0 chan...	FortiSwitch spanning Tree	S524DF4K16000024	Fort

WIFI Clients

This tab provides details of the impacted clients and also lists all the clients associated with the AP.

AP Details

Impacted Clients

Date/Time	Client Mac Address	Device	AP Name	Classifier	Sub Classifier
2022/07/18 15:52:32	[blurred]	CorpWiFi-6s-MBP	[blurred]	Memory	High Resource Utilization
2022/07/18 15:52:32	[blurred]	CorpWiFi-3s-MBP	[blurred]	Memory	High Resource Utilization

2

All Clients

Client Mac Address	Channel	Radio Type	SSID	Data Rate	Bandwidth Rx	Bandwidth Tx
[blurred]	6	802.11n	24ghz-25bridge	136.00 Mbps	0	0
[blurred]	6	802.11n	24ghz-25bridge	169.00 Mbps	0	0

OK
Cancel

Interfering APs

This tab displays details of the interfering APs in your network.

Date/Time	BSSID	Signal Strength
2023/11/07 16:23:26	[blurred]	-67 dBm
2023/11/07 16:23:26	[blurred]	-67 dBm
2023/11/07 16:23:26	[blurred]	-67 dBm
2023/11/07 16:23:26	[blurred]	-82 dBm

Select any impacted client and click **Show AP details** to view the detailed AP logs.

AP Details

[Diagnostics](#) [AP Stats](#) [Logs](#) [Interfering APs](#)

Issue Diagnostics


Issue Cause	<ul style="list-style-type: none"> Poor FortiAP Health - High Memory [81%] usage
Remedy	<ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network.

Select any of the tabs to view the data described in this table.

Logs	Description																												
Diagnostics	<p>This tab provides detailed cause of the SLA breach that impacted the client/AP/FortiGate. FortiAIOps also suggests the remedy to resolve the issue.</p> <table border="1"> <tr> <td colspan="2">Issue Diagnostics</td> </tr> <tr> <td>Issue Cause</td> <td> <ul style="list-style-type: none"> Poor FortiAP Health - High CPU [28%] usage </td> </tr> <tr> <td>Remedy</td> <td> <ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network. </td> </tr> </table>	Issue Diagnostics		Issue Cause	<ul style="list-style-type: none"> Poor FortiAP Health - High CPU [28%] usage 	Remedy	<ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network. 																						
Issue Diagnostics																													
Issue Cause	<ul style="list-style-type: none"> Poor FortiAP Health - High CPU [28%] usage 																												
Remedy	<ul style="list-style-type: none"> Rectify high interference and high client density issues, if any, and also check if any resource intensive features are enabled. Also, check if there's STP loop in the network. 																												
AP Stats	<p>This tab displays the details of the AP radio that the client associated with and the WAN status details of the AP.</p> <table border="1"> <tr> <td colspan="7">Radio Info</td> </tr> <tr> <td colspan="7"> <input type="text" value="Q Search"/> </td> </tr> <tr> <th>Radio Type</th> <th>Bandwidth Tx</th> <th>Bandwidth Rx</th> <th>Channel Utilization(%)</th> <th>Client Count</th> <th>Oper Chan</th> <th>Oper Tx Po</th> </tr> <tr> <td>802.11n,g-only</td> <td>0</td> <td>0</td> <td>76</td> <td>0</td> <td>11</td> <td>22 dBm</td> </tr> </table>	Radio Info							<input type="text" value="Q Search"/>							Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Po	802.11n,g-only	0	0	76	0	11	22 dBm
Radio Info																													
<input type="text" value="Q Search"/>																													
Radio Type	Bandwidth Tx	Bandwidth Rx	Channel Utilization(%)	Client Count	Oper Chan	Oper Tx Po																							
802.11n,g-only	0	0	76	0	11	22 dBm																							
Interfering APs	<p>This tab displays details of the interfering APs in your network.</p> <table border="1"> <thead> <tr> <th>Date/Time</th> <th>BSSID</th> <th>Signal Strength</th> </tr> </thead> <tbody> <tr> <td>2023/11/07 16:23:26</td> <td>XXXXXXXXXX</td> <td> -67 dBm</td> </tr> <tr> <td>2023/11/07 16:23:26</td> <td>XXXXXXXXXX</td> <td> -67 dBm</td> </tr> <tr> <td>2023/11/07 16:23:26</td> <td>XXXXXXXXXX</td> <td> -67 dBm</td> </tr> <tr> <td>2023/11/07 16:23:26</td> <td>XXXXXXXXXX</td> <td> -82 dBm</td> </tr> </tbody> </table>	Date/Time	BSSID	Signal Strength	2023/11/07 16:23:26	XXXXXXXXXX	-67 dBm	2023/11/07 16:23:26	XXXXXXXXXX	-67 dBm	2023/11/07 16:23:26	XXXXXXXXXX	-67 dBm	2023/11/07 16:23:26	XXXXXXXXXX	-82 dBm													
Date/Time	BSSID	Signal Strength																											
2023/11/07 16:23:26	XXXXXXXXXX	-67 dBm																											
2023/11/07 16:23:26	XXXXXXXXXX	-67 dBm																											
2023/11/07 16:23:26	XXXXXXXXXX	-67 dBm																											
2023/11/07 16:23:26	XXXXXXXXXX	-82 dBm																											
Logs	<p>This tab provides the AP event logs generated from FortiGate.</p>																												

WAN

The WAN panel displays the performance SLA metrics to monitor WAN member interface link quality and to detect failures and FortiExtender health data, along with the impacted client details. Any client that breaches the configured SLA thresholds are reported. In each SLA panel, you can select **Clients** to view the impacted client count or click **Devices** to view the impacted interface count.



Topology and Logs

You can click on the impacted SLA listed in the panel to view the **Performance** or **FortiExtender Health** impacted interface and client details. The issues reported are categorized based on classifiers and sub-classifiers, with suggested remedial measures. The data displayed in this panel is for the time period set in the dashboard.

Performance SLA

If you select the **Devices** view in the WAN panel and click on the Performance SLA in the impacted SLAs list or click on the bar in the chart, the impacted interfaces' details such as, destination interface, the associated FortiGate host name, IP address, and serial number, FortiSwitch serial number, and classifier and sub-classifier are displayed.

Wireless Switching WAN

SLA

- FortiExtend... 2
- Performance 2

Classifier

- Invalid Interf... 2
- Performanc... 2
- Internet Ser... 2
- Invalid Static... 1

Sub Classifier


- Wrong IP or ... 2
- Member inte... 2
- Internet Issu... 2
- Missing or in... 1

Performance

View topology Search filterable columns

Destination Interface	FortiGate Hostname	AP Serial Number	FortiSwitch Serial Number	FortiGate Serial Number	FortiGate IP Address
FEXWAN1	FortiGate-3000	FF421E7F1906A733	3424E77F22001490	FC044E101F190600	10.34.139.210
port15	FortiGate-3000	FF421E7F1906A733	3424E77F22001490	FC044E101F190600	10.34.139.210
FEXWAN1	FortiGate-3000	FF421E7F1906A733	3424E77F22001490	FC044E101F190600	10.34.139.210

If you select the **Clients** view in the WAN panel and click on the Performance SLA in the impacted SLAs list or click on the bar in the chart, the impacted client details, such as, MAC address, the AP name and serial numbers, the associated FortiGate hostname and serial number, FortiSwitch name and serial number, destination interface, and the classifier and sub-classifiers are displayed.



Performance

View topology Search filterable columns

MAC Address	FortiGate Hostname	Destination Interface	FortiGate Serial Number	Classifier	Sub Classifier
92:30:90:53:2145	FortiGate-300E	FEXWAN1	FGW48E161P788002	Performance Sla Down	Member interface down
80:24:62:4a:7c:84	FortiGate-300E	port15	FGW48E161P788002	Internet Service Provider issue	Internet Issues
48:3f:9b:48:2145	FortiGate-300E	FEXWAN1	FGW48E161P788002	Internet Service Provider issue	Internet Issues

Select a row and click **View Topology**. The **Details** table displays the following information.

Performance Time range: 1 week

Impacted Classifiers	Impacted Sub Classifiers
Performance Sla Down (1)	Member interface down
Internet Service Provider... (1)	Internet Issues

Details

View Logs Search filterable columns

Date/Time	Access Point	Issue Cause List	Remedies	FortiSwitch Name
2024/04/04 16:53:59	TaggedClient_231F	Interface [FEXWAN1] is down/disabled	Check if Interface [FEXWAN1] is connected ...	
2024/04/04 16:52:14	TaggedClient_231F	Internet Service Provider / Server side Issue	Check the issue with Internet Service Provid...	
2024/04/04 16:39:34	TaggedClient_231F	Internet Service Provider / Server side Issue	Check the issue with Internet Service Provid...	
2024/04/04 16:38:59	TaggedClient_231F	Internet Service Provider / Server side Issue	Check the issue with Internet Service Provid...	


Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
Access Point	The name of the associated AP.
FortiGate Serial Number	The serial number of the associated FortiGate.
FortiSwitch Name	The name of the associated FortiSwitch.
FortiSwitch Serial Number	The serial number of the associated FortiSwitch.
AP Serial Number	The serial number of the associated AP.
MAC Address	The MAC address of the impacted client device.
Hostname	The name of the device as configured by the user. If the name is not configured or available, then MAC address is displayed.
Issue Cause List	The detailed causes of the SLA breach that impacted the


Attribute	Description
	client/AP/FortiGate.
Remedies	The suggested remedies to resolve the issue.
Classifier	The classifier of the issue reported for the SLA.
Sub Classifier	The sub-classifier of the issue for the reported classifier.
Health Check	The performance SLA check configured in FortiGate.
Source Interface	The source interface name.
Destination Interface	The destination interface name.
Jitter	The amount of jitter (milliseconds) reported for the client.
Packet Loss	The percentage of packet loss reported for the client.
Latency	The amount of latency (milliseconds) reported for the client.
FortiGate Hostname	The hostname of the FortiGate associated with the AP/impacted client.
Breach Summary	The WAN SLA threshold that was breached.
Client Type	The client type that is impacted, wireless or wired.

FortiExtender Health SLA

If you select the **Devices** view in the WAN panel and click on the FortiExtender Health SLA in the impacted SLAs list or click on the bar in the chart, the impacted interfaces' details such as, destination interface, AP serial number, the associated FortiGate host name, IP address, and serial number, FortiSwitch serial number, FortiExtender name and serial number, and classifier and sub-classifier are displayed.



If you select the **Clients** view in the WAN panel and click on the FortiExtender Health SLA in the impacted SLAs list or click on the bar in the chart, the impacted client details, such as, MAC address, the AP name and serial number, the associated FortiGate hostname and serial number, FortiSwitch name and serial number, FortiExtender name and serial number, destination interface, and the classifier and sub-classifiers are displayed.



FortiExtender Health

View topology Search filterable columns

MAC Address	FortiGate Hostname	Destination Interface	FortiGate Serial Number	FortiExtender Name	FortiExtender Serial	Classifier
80:0a:2d:aa:7c:04	FortiGate-300E	FE1/ANAL	FG13481811P00000	FX211E1P00003777	FX211E1P00003777	Tempera...
80:0a:2d:aa:7c:04	FortiGate-300E	FE1/ANAL	FG13481811P00000	FX211E1P00003777	FX211E1P00003777	Memory
80:0a:2d:aa:7c:04	FortiGate-300E	FE1/ANAL	FG13481811P00000	FX211E1P00003777	FX211E1P00003777	CPU

Select a row and click **View Topology**. The **Details** table displays the following information.



Details

View Logs Search filterable columns

Date/Time	MAC Address	Hostname	Issue Cause List	Remedies
2024/04/07 20:41:05	80:0a:2d:aa:7c:04	DESKTOP-V380338	High CPU usage [3%] detected on FortiExten...	Check if there is high traffic on FortiExtende...
2024/04/07 20:41:05	80:0a:2d:aa:7c:04	DESKTOP-V380338	High memory usage [19%] detected on Forti...	Check if there is high traffic on FortiExtende...
2024/04/07 20:41:05	80:0a:2d:aa:7c:04	DESKTOP-V380338	Device temperature high [65.20°C] on FortiE...	Please ensure FortiExtender is placed in a sp...

Right-click on the header of the table to select the following columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
FortiGate Serial Number	The serial number of the associated FortiGate.
AP Serial	The serial number of the associated AP.
Access Point	The name of the associated AP.
MAC Address	The MAC address of the impacted client device.
Hostname	The name of the device as configured by the user. If the name is not configured or available, then MAC address is displayed.
Issue Cause List	The detailed cause of the SLA breach that impacted the client/AP/FortiGate/FortiExtender.
Remedies	The suggested remedies to resolve the issue.
Classifier	The classifier of the issue reported for the SLA.

Attribute	Description
Sub Classifier	The sub-classifier of the issue for the reported classifier.
Source and Destination Interface	The WAN interface name.
FortiSwitch Serial Number	The serial number of the impacted switch.
FortiSwitch Name	The name of the impacted switch.
FortiExtender Serial Number	The serial number of the impacted FortiExtender.
FortiExtender Name	The name of the impacted FortiExtender.
FortiGate Hostname	The hostname of the FortiGate with which the impacted FortiExtender is associated.
Client Type	The client type that is impacted, wireless or wired.

Select a particular client and click **View Logs**, to view the impacted client logs.


Client Details ✕


CLIENT LOGS

Date/Time	Health Check	Interface	Status	Latency	Jitter	Packet Loss(%)	
2022/07/06 16:56:29	google_dns	wan1	up	188.792ms	0.035ms	0.000	Health Check
2022/07/06 16:56:29	google_dns	wan1	up	188.792ms	0.035ms	0.000	Health Check
2022/07/06 16:56:29	google_dns	wan1	up	188.792ms	0.035ms	0.000	Health Check

Switching

The Switching panel displays the total number of impacted clients and SLA data. Select **Devices** to view the impacted switch count or click **Clients** to view the impacted client count.






SLAs, Topology and Logs

The following SLAs are detected and reported by FortiAI Ops for switching. The issues reported are categorized based on classifiers and sub-classifiers, with suggested remedial measures to curtail the SLA breaches and enhance network performance.

- [Switch Connection Failure](#)
- [Switch Health and Uptime](#)

Switch Health and Uptime

Displays the switch health based on the configured switch health threshold values and the status of the switch (Up/Down). The associated impacted FortiGate controller, switch, and client count are displayed in a collapsible topology. If you select the **Devices** view in the Switching panel and click on the SLA in the impacted SLAs list or click on the bar in the chart, the impacted switches' details such as, OS version, the associated FortiGate host name and serial number, FortiSwitch name and serial number, FortiSwitch state and status, and classifier and sub-classifier are displayed.




Switch Health and Uptime

View topology Search

FortiGate Hostname	FortiSwitch Name	OS Version	Classifier	Sub Classifier	Connecting From	FortiGate Serial
2FLB2	S424DF-v7.0.7-build096,230804 (GA)	S424DF-v7.0.7-build096,230804 (GA)	Temperature	Temperature Poor	SR254.1.7	FGT1KD3917
FortiGate-300E	S424EF-v7.4.1-build787,230921 (GA)	S424EF-v7.4.1-build787,230921 (GA)	Memory	Memory Log Full	SR254.1.2	FG3H0E5819
2FLB2	S524DF-v7.2.5-build453,230707 (GA)	S524DF-v7.2.5-build453,230707 (GA)	CPU	CPU Poor	SR254.1.2	FGT1KD3917

If you select the **Clients** view in the Switching panel and click on the SLA in the impacted SLAs list or click on the bar in the chart, the impacted client details, such as, MAC address, OS version, the associated FortiGate host name and serial number, FortiSwitch name and serial number, FortiSwitch state and status, and classifier and sub-classifier are displayed.



Switch Health and Uptime

View topology Search filterable columns

MAC Address	FortiGate Hostname	FortiSwitch Name	Classifier	Sub Classifier
08:35:71:ac:34:92	2FLB2	S424DF3X15000076	Temperature	Temperature Poor
48:3a:8e:a0:2f:38	FortiGate-300E	S424DF4K15000486	Memory	Memory Log Full
08:35:71:ac:34:92	2FLB2	2FLB2	CPU	CPU Poor

Select a row and click **View Topology**. The **Details** table displays the following information.



Details View Logs Search filterable columns

Date/Time	FortiSwitch Name	Client MAC Address	Hostname	Issue Cause List	Remedies
2024/04/08 01:53:00	S424DF3X15000076	08:35:71:ac:34:92	08:35:71:ac:34:92	High CPU usage [13%] on switch S424DF3X...	Check if there's
2024/04/08 01:53:00	S424DF3X15000076	08:35:71:ac:34:92	08:35:71:ac:34:92	High memory usage [21%] on switch S524D...	Check if there's
2024/04/08 01:53:00	S424DF3X15000076	08:35:71:ac:34:92	08:35:71:ac:34:92	High CPU usage [6%] on switch S524DF4K1...	Check if there's

Right-click on the header of the table to select the following columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
FortiSwitch Name	The name of the impacted switch.
Client MAC Address	The MAC address of the impacted client device.
Hostname	The name of the device as configured by the user. If the name is not configured or available, then MAC address is displayed.
Issue Cause List	Detailed cause of the SLA breach that impacted the client/switch.
Remedies	The suggested remedy to resolve the issue.
Classifier	The classifier of the issue reported for the SLA.
Sub Classifier	The sub-classifier of the issue for the reported classifier.
FortiGate Hostname	The hostname of the FortiGate associated with the impacted client.

Attribute	Description
FortiGate Serial Number	The serial number of the FortiGate associated with the impacted client.
FortiSwitch Serial Number	The serial number of the impacted switch.

Select a particular switch and click **View Logs**, the issue diagnostics and the suggested remedy are displayed.

Switch Logs ✕

[Diagnostics](#) [Logs](#)

Issue Diagnostics

Issue Cause	<ul style="list-style-type: none"> High CPU usage [40%] on switch [REDACTED]
Remedy	<ul style="list-style-type: none"> Check if there's high traffic, high device count or other causes for high resource utilization

The **Logs** tab displays the time stamp of each action, the type of action such as notice, warning, etc., and the impact details are displayed. Different data tabs are displayed based on the selected issue/failure.

Switch Logs

[Diagnostics](#) [Logs](#)


Date/Time	Level	Message
2022/07/06 12:48:52	Notice	cpu value is 40

Switch Connection Failure

Displays the failed/unsuccessful client connections based on authentication events such as MAC authentication and 801x authentication and MAC learning limit.

Wireless [Switching](#) WAN [Devices](#) [Clients](#) 6 hours ↻

SLA



2 Total

- Switch H... 2
- Switch Co... 1

Classifier



1 Total

- MAC Li... 1

Sub Classifier



1 Total

- Port MA... 1

Switch Connection Failure

View topology

FortiGate Hostname	FortiSwitch Name	OS Version	Classifier	Sub Classifier
[REDACTED]	[REDACTED]	S424EF-v7.4.1-build787,230921 (GA)	MAC Limit Exceed	Port MAC Limit Exceed

Select a row and click **View Topology**. The **Details** table displays the following information.

Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Date/Time	The date and time of the impact as per your timezone.
FortiSwitch Name	The name of the impacted switch.
Client MAC Address	The MAC address of the impacted client device.
Hostname	The name of the device as configured by the user. If the name is not configured or available, then MAC address is displayed.
Issue Cause List	Detailed cause of the SLA breach that impacted the client/switch.
Remedies	The suggested remedy to resolve the issue.
Classifier	The classifier of the issue reported for the SLA.
Sub Classifier	The sub-classifier of the issue for the reported classifier.
FortiGate Hostname	The hostname of the FortiGate associated with the impacted client.
FortiGate Serial Number	The serial number of the FortiGate associated with the impacted client.
FortiSwitch Serial Number	The serial number of the impacted switch.

Select a particular switch and click **View Logs**, the issue diagnostics and the suggested remedy are displayed.

Switch Logs

[Diagnostics](#) [Logs](#)

Issue Diagnostics

Issue Cause	<ul style="list-style-type: none"> Interface MAC learning limit exceeded on port7 Packet VID 100
Remedy	<ul style="list-style-type: none"> Review the MAC learning limit configured for the port7

The **Logs** tab displays the time stamp of each action, the type of action such as notice, warning, etc., and the impact details are displayed. Different data tabs are displayed based on the selected issue/failure.

Switch Logs

[Diagnostics](#) [Logs](#)

Date/Time	Level	Message
2022/07/13 16:57:05	Notice	primary port port14 instance 0 changed state from disc...
2022/07/13 16:57:02	Notice	primary port port14 instance 0 changed role from disabl...
2022/07/13 16:57:02	Notice	primary switch port port14 has come up
2022/07/13 16:57:00	Error	send dhcp packet failed errno = 6
2022/07/13 16:57:00	Error	send arp packet failed errno = 6
2022/07/13 16:55:58	Notice	primary port port14 instance 0 changed state from forw...
2022/07/13 16:55:58	Notice	primary port port14 instance 0 changed role from desig...
2022/07/13 16:55:58	Notice	primary switch port port14 has gone down
2022/07/13 16:55:46	Information	Config download successful

Service Assurance

The Service Assurance dashboard for FortiAIOps is designed to provide comprehensive insights and monitoring of network performance. It consists of various widgets that offer visual representations and classifications of different metrics.



The data on this dashboard is based on scheduled test results and is automatically refreshed every 60 seconds; the following options are available to manage the auto-refresh feature for this page.

- Click to manually refresh data.
- Click to pause the auto-refresh.
- Click to resume the auto-refresh.

The dashboard provides an option to select the duration of the data displayed. You can choose between 1 day, 1 week, 1 hour, and 10 minutes.

Use the **Add Widget** option to manage the widgets displayed on the dashboard; you can choose to add or remove the widgets.

Add Dashboard Widget
✕

Trends

Throughput ✕

Shows the measured throughput results and classifies them as bar chart with Good, Fair and Bad markings.

Connectivity ✕

Shows the measured Connectivity results and classifies them as bar chart with Good, Fair and Bad markings.

Channel Health ✕

Shows the channel health based on the SAM Connectivity and Throughput test results.

RF Health ✕

Shows the RF health based on the SAM Connectivity and Throughput test results for each RF Band (2.4GHz/5GHz/6GHz)

Top 5 APs by failure ✕

Shows the sorted APs list based on the number of failed SAM test results.

Top 5 SSIDs by Failure ✕

Shows the SSIDs list sorted based on the number of failed SAM test results.

The following widgets provide network data on this dashboard.

- Throughput** - This widget displays the measured throughput results of your network. Throughput refers to the amount of data transferred through the network over a given time period. It presents the data in the form of a bar chart, indicating the performance levels as *Good*, *Fair*, or *Bad*. Click on the charts to view additional information.

Throughput ✕

🔍 Search

Test name	Test Type	AP name	SSID	Radio ID	Band	Serial Number	Baseline Name
sche_test_thru	Throughput	FP431FTF20001051	sam-ssid-86	2	5GHz		sam-thru-base

Best Fit Columns

Reset Table

Select Columns

- Test name
- Test Type
- AP name
- SSID
- Radio ID
- Band
- Serial Number
- Baseline Name
- Channel
- Status
- Start Time
- Packet Loss
- Throughput

Right-click on the header of the table to select the columns that you wish to view.

Attribute	Description
Test Name	The name of the associated test.
Test Type	The type of test, <i>throughput</i> or <i>connectivity</i> .
AP Name	The name of the access point used during the test.
SSID	The SSID associated with the network.
Radio ID	The associated radio ID .
Band	The frequency band utilized, <i>2.5 GHz</i> or <i>5 GHz</i> .
Serial Number	The serial number of the associated FortiGate.
Baseline Name	The name of associated baseline.
Channel	The channel number utilized.
Status	The status of the test, <i>Good</i> , <i>Fair</i> , or <i>Bad</i> .
Start Time	The timestamp indicating when the test was initiated.

Attribute	Description
Packet Loss	The amount of data lost during transmission, expressed as a percentage.
Throughput	The measured network throughput, indicating the amount of data transferred.

- Connectivity** - This widget displays the measured Connectivity results using a bar chart and classifies the results as *Good*, *Fair*, or *Bad*. Connectivity refers to the ability of devices to establish and maintain a connection to the network. Click on the charts to view additional information.

Connectivity							
+ Q Search							
Test name	Test Type	AP name	SSID	Radio ID	Band	Serial Number	Baseline Name
sche_test_conn	Connectivity	FP431FTF20001051	sam-ssid-86	2	5GHz		sam_conn_base

- RF Health** - This widget displays the radio frequency (RF) health based on the Service Assurance Manager (SAM) Connectivity and Throughput test results for each RF Band(2.4GHz/ 5GHz). Click on the charts to view additional information.

RF Health							
+ Q Search							
Test name	Test Type	AP name	SSID	Radio ID	Band	Serial Number	Baseline Name
sche_test_conn	Connectivity	FP431FTF20001051	sam-ssid-86	2	5GHz		sam_conn_base

- Top 5 APs by Failure** - This widget displays a sorted list of Access Points (APs) based on the highest number of bad results. Click on the charts to view additional information.

Top 5 APs By Failure							
+ Q Search							
Test name	Test Type	AP name	SSID	Radio ID	Band	Serial Number	Baseline Name
sche_test_thru	Throughput	FP431FTF20001051	sam-ssid-86	2	5GHz		sam-thru-base

- Top 5 SSIDs by Failure** - This widget displays a sorted list of SSIDs based on the highest number of bad results. Click on the charts to view additional information.

Top 5 SSIDs By Failure							
+ Q Search							
Test name	Test Type	AP name	SSID	Radio ID	Band	Serial Number	Baseline Name
sche_test_conn	Connectivity	FP431FTF20001051	sam-ssid-86	2	5GHz		sam_conn_base

- Channel Health** - This widget displays the overall health of the network channels based on the SAM Connectivity and Throughput test results. Click on the charts to view additional information.

Channel Health							
+ Q Search							
Test name	Test Type	AP name	SSID	Radio ID	Band	Serial Number	Baseline Name
sche_test_conn	Connectivity	FP431FTF20001051	sam-ssid-86	2	5GHz		sam_conn_base

AI Insights

This section describes the FortiAI Ops AI enabled data insights of your network and SLA configurations.


- Impacted SLA
- Impacted Devices
- SLA Configurations

Impacted SLA

This page displays the impacted wireless, switching, and WAN clients, categorized based on their SLAs, classifiers, and sub-classifiers. Select any SLA and the associated classifier and sub-classifier charts are displayed. You can filter and view the SLAs as per any of these categories. In each impacted SLA panel for wireless, switching, and WAN, you can select **Clients** to view the impacted client count or click **Devices** to view the impacted device count. Navigate to **AI Insights > Impacted SLA**.


Wireless

The wireless SLA data is reported based on the classifiers and sub-classifiers displayed in this panel. The SLA data tables lists the client MAC address and hostname, FortiGate hostname and serial number, AP name, IP address, and serial number, classifier and sub-classifier, the associated SSID, and the operating channel. Select any row and click on **View topology** to view the impacted SLA details.




Switching

The switching SLA data is reported based on the classifiers and sub-classifiers listed displayed in this panel. The SLA data tables lists the client MAC address and hostname, FortiGate hostname and serial number, FortiSwitch name, serial number, and OS version, classifier and sub-classifier, FortiSwitch state and status (online/offline). Select any row and click on **View topology** to view the impacted SLA details.



WAN


The WAN SLA data is reported based on the classifiers and sub-classifiers displayed in this panel. The SLA data tables lists the client MAC address and hostname, FortiGate hostname and serial number, FortiSwitch name and serial number, AP name and serial number, classifier and sub-classifier, and the destination interface. Select any row and click on **View topology** to view the impacted SLA details.



Select any device listed in the tables and click on **View Topology** for topology and other details. For details on the SLAs, topology, and logs, see section [AI Insights](#).

Impacted Devices

This page displays details of the various devices in your network that are associated with impacted clients, that include the wireless, switching, and WAN clients. You can view and analyze the SLA data based on the device type. The data is displayed in the following three panels. The number of devices are listed for each category, you can click on any of these or click on the respective section in the donut chart to view details. Navigate to **AI Insights > Impacted Devices**.



FortiGates

Displays the number of deployed FortiGate controllers with impacted wireless, switching, and WAN clients.

The following example displays the *FortiGates-Wireless SLA* with information such as FortiGate host name, serial number, and IP address, and lists the impacted APs, clients, and SLAs. Select any row and click on the impacted SLA name to view the topology. Data is displayed for FortiGate wireless clients based on the selected SLA breaches only.

FortiGates Wireless SLA

Impacted SLAs	FortiGate Serial Number	IP Address	Impacted APs	Impacted Clients
FGVM04				
Connection Failure	FGVM0430000004	10.34.139.200	7	14
Time to Connect	FGVM0430000004	10.34.139.200	7	13
Throughput	FGVM0430000004	10.34.139.200	7	12

The following example displays the *FortiGates-WAN SLA* with information such as FortiGate host name, serial number, and IP address, and lists the impacted APs, clients, SLAs, switches, and interfaces. Select any row and click on the impacted SLA name to view the topology.

FortiGates WAN SLA

Impacted SLAs	FortiGate Serial Number	IP Address	Impacted APs	Impacted Switch	Impacted Interfaces	Impacted Clients	Extenders
FortiGate-300E							
Performance	FGVM0430000000	10.34.139.200	7	1	2	6	0
FortiExtender Health	FGVM0430000000	10.34.139.200	6	1	1	4	1

The following example displays the *FortiGates-Switching SLA* with information such as FortiGate host name, serial number, and IP address, and lists the impacted clients, SLAs, and switches. Select any row and click on the impacted SLA name to view the topology.

FortiGates Switching SLA

Impacted SLAs	FortiGate Serial Number	IP Address	Impacted Switch	Impacted Clients
1				
Switch Health and Uptime	FGVM0430000000		1	5
FGT_BACKUP_182				
Switch Health and Uptime	FGVM0430000000	10.34.139.182	1	12
FGT_PRIMARY_181				

Access Points/ Switches/ Interfaces/FortiExtenders

Displays the number of devices, that is, APs, interfaces, FortiExtenders, and switches with impacted clients.

The following example displays the *Access Points* with information such as AP name, serial number, and IP address, FortiGate host name and IP address, and lists the impacted clients and SLAs. Select any row and click on the impacted SLA name to view the topology.

Access Points

Impacted SLAs	Access Point	FortiGate Serial Number	FortiGate IP Address	AP Serial Number	AP IP Address	Impacted Clients
FGVM0 24						
Connection Failure	FG432PRTY23000176	FG4964WTHC3010454	30.34.139.207	FG432PRTY23000176	30.37.26.15	10
Time to Connect	FG432PRTY23000176	FG4964WTHC3010454	30.34.139.207	FG432PRTY23000176	30.37.26.15	8
Time to Connect	FP433GTY23001340	FG4964WTHC3010454	30.34.139.207	FP433GTY23001340	30.37.62.11	7
Connection Failure						

The following example displays the *Interfaces* with information such as the interface, FortiGate host name, serial number, and IP address, and lists the impacted clients and SLAs. Select any row and click on the impacted SLA name to view the topology.

Interfaces

Impacted SLAs	FortiGate IP Address	FortiGate Serial Number	Interface	Impacted Clients
FortiGate-300E 2				
Performance	30.34.139.200	FG4964WTHC3010454	FEXWAN1	6
Performance	30.34.139.200	FG4964WTHC3010454	port15	6

The following example displays the *Switches* with information such as the switch host name, IP address, OS version, and serial number, FortiGate host name, serial number, and IP address, and lists the impacted clients and SLAs along with the status and state of the switch. Select any row and click on the impacted SLA name to view the topology.

Switches

Impacted SLAs	Name	OS Version	Connecting From	State	Status	FortiSwitch Serial Number	For
FGT_BACKUP_182 1							
Switch Health and Uptime	30.34.139.170	S248EF-v7.4.0-build767,230602 (GA)	169.254.2.2	Authorized	Connected	30.34.139.170	FG
FGT_PRIMARY_181 1							
Switch Health and Uptime	30.34.139.170	S248EF-v7.4.0-build767,230602 (GA)	169.254.2.2	Authorized	Connected	30.34.139.170	FG

The following example displays the *FortiExtenders* with information such as the interface, FortiGate host name, and FortiExtender name, and lists the impacted clients and SLAs. Select any row and click on the impacted SLA name to view the topology.

FortiExtenders

Impacted SLAs	FortiExtender Serial	FortiExtender Name	FortiGate IP Address	FortiGate Serial Number	Interface	Impacted Clients
FortiGate-300E 1						
FortiExtender Health	FX213E1928603777	FX213E1928603777	30.34.139.200	FG4964WTHC3010454	FEXWAN1	4

Clients

Displays the number of impacted clients for the wireless, switching, and WAN.

The following example displays the *Wireless Clients* with information such as the FortiGate host name, serial number, and IP address, AP name and IP address, client MAC address, and the impacted SLAs. Select any row and click on the impacted SLA name to view the topology.

Wireless Clients

Impacted SLAs	MAC Address	FortiGate Serial Number	FortiGate IP Address	AP Serial Number	Access Point	AP IP Address
FGVM04 43						
Connection Failure	Au21444F4641	FGVM04TH2030456	10.34.139.207	F432PRTF23000176	F432PRTF23000176	10.37.26.13
Connection Failure Time to Connect	Au21444F4641	FGVM04TH2030456	10.34.139.207	FP423E2K14000713	FP423E2K14000713	10.37.26.7
AP Health and Uptime						
Throughput						

The following example displays the *WAN Clients* with information such as the FortiGate host name, serial number, and IP address, AP name, IP address, and serial number, switch name, IP address, and serial number, client MAC address, interface details, and the impacted SLAs. Select any row and click on the impacted SLA name to view the topology.

WAN Clients

Impacted SLAs	MAC Address	FortiGate Serial Number	FortiGate IP Address	AP Serial Number	FortiSwitch Serial Number	Access Point
FortiGate-300E 47						
Performance	483F646E1340	FG300E1011900003	10.34.139.230	FP233FTF23000195		FP233FTF23000195
Performance	7a443a71a5132	FG300E1011900003	10.34.139.230	FP233FTF23000176		Supernet_233
Performance	802a1a24a7a4	FG300E1011900003	10.34.139.230	FP423E2F19004733	S4C4CF2K1700034	FP423E2F19004733
FortiExtender Health						

The following example displays the *Switching Clients* with information such as the FortiGate host name, serial number, and IP address, switch name, IP address, OS version, state, and status, client MAC address, and the impacted SLAs. Select any row and click on the impacted SLA name to view the topology.

Switching Clients

Impacted SLAs	MAC Address	FortiGate Serial Number	FortiGate IP Address	FortiSwitch Name	FortiSwitch Serial Number	Connecting F
5						
Switch Health and Uptime	802a1a24a7a4	FG300E1011900003		Supernet-100	S4C4CF2K1700034	10.37.254.12
Switch Health and Uptime	40233F974a28	FG300E1011900003		Supernet-100	S4C4CF2K1700034	10.37.254.12
Switch Health and Uptime	40233F974a29	FG300E1011900003		Supernet-100	S4C4CF2K1700034	10.37.254.12

SLA Configurations

This section explains how to configure SLA metrics to define values to match network deployment and required thresholds. Navigate to **AI Insights > SLA configuration**.

- [Device Health](#)
- [Time To Connect](#)
- [Roaming](#)
- [SD-WAN](#)

Device Health

Configure AP, switch, and FortiExtender health SLA threshold values. The AP health is displayed in the *AP Health and Uptime* SLA of the [Wireless](#) section, the switch health is displayed in the *Switch Health and Uptime* SLA of the [Switching](#) section, and the FortiExtender health is displayed in the *FortiExtender Health* SLA of the [WAN](#) section.

Navigate to **AI Insights > SLA configuration > Device Health** to configure the following parameters.


- **CPU** usage
- **Memory** usage

- **Temperature**


AP Health



Switch Health



FortiExtender Health



The default value for the CPU and memory parameters is 80% and the default value for the temperature is 45 degree Celsius.

Time To Connect

You can configure static thresholds or enable FortiAI Ops to compute them dynamically. Based on the configured thresholds, the variations in the time to connect are recorded for each phase, and the statistics are displayed in the [AI Insights](#) tab.

Dynamic Baselines

You are required to provide the following information for threshold/baseline configuration.

Device Health **Time to Connect** Roaming SD-WAN

Dynamic Baselines Configuration

Scope: Device Group FortiGate **AP**

Time Selection: **Duration** Date Range

7 Day(s)

Schedule Baselines Computation: 30-05-2023 2

Repeat Cycle: 7 Day(s)

OK Cancel

DYNAMICALLY OBTAINED BASELINES VALUES

Last Updated	AP Name	FortiGate Hostname	Association	Authentication Time	DHCP Time
2023/05/11 18:03:16	43x-2F- <i>Message Card</i>	office-wifi-qa	1ms	21ms	6ms
2023/05/11 18:04:32	83x-3F- <i>Message Card</i>	office-wifi-qa	2ms	19ms	12ms

- **Scope** - Select the scope to calculate the thresholds which could either be per **Device Group**, per **FortiGate**, or per **AP**.
- **Time Selection** - Set the time range/duration for which FortiAI Ops analysis client data to derive the thresholds.
- **Schedule Baselines Computation** - Set the time when FortiAI Ops calculates the baselines and applies them to your network to obtain and report the relevant SLAs.
- **Repeat Cycle** - Configure the repetition of the above configurations, that is, the phase of analyzing client activity and the calculation/application of the algorithms.

The baseline values calculated by FortiAI Ops are displayed in the table. You can re-compute specific baseline values.


Static Threshold

Configure the time (milliseconds) for the following stages of client connection to a network.

SLA CONFIGURATIONS

Device Health Time to Connect Roaming SD-WAN

Dynamic Baselines Configuration

Association Time	<input type="text" value="164539"/>	ms
		<input type="button" value="Low"/>
Authentication Time	<input type="text" value="176276"/>	ms
		<input type="button" value="Low"/>
DHCP Time	<input type="text" value="80032"/>	ms
		<input type="button" value="Low"/>
DNS Time	<input type="text" value="300"/>	ms
		<input type="button" value="Low"/>

- **Association** - The time taken by a client to successfully associate.
- **Authentication** - The time taken by associated clients to authenticate.
- **DHCP** - The time taken by successfully associated and authenticated clients to receive a valid DHCP address.
- **DNS** - The time taken by successfully associated, authenticated, and received a DHCP address clients to resolve their first DNS request.

Notes:

- The default value for these parameters is 300 milliseconds and the valid range is 1 - 1000000 milliseconds.
- DNS is not supported.

Roaming

You can configure static thresholds or enable FortiAI Ops to compute them dynamically. Based on the configured thresholds, the variations in the time to connect are recorded for each phase, and the statistics are displayed in the [AI Insights](#) tab.

Dynamic Baselines

You are required to provide the following information for threshold/baseline configuration.

Dynamic Baselines Configuration

Scope:

Time Selection:

Schedule Baselines Computation:

Repeat Cycle: Day(s)

- **Scope** - Select the scope to calculate the thresholds which could either be per **Device Group**, per **FortiGate**, per **AP**, or per **SSID**.
- **Time Selection** - Set the time range/duration for which FortiAI Ops analysis client data to derive the thresholds.
- **Schedule Baselines Computation** - Set the time when FortiAI Ops calculates the baselines and applies them to your network to obtain and report the relevant SLAs.
- **Repeat Cycle** - Configure the repetition of the above configurations, that is, the phase of analyzing client activity and the calculation/application of the algorithms.

The baseline values calculated by FortiAI Ops are displayed in the table. You can re-compute specific baseline values.

Static Threshold

For static threshold configuration to enable faster roaming, configure the following parameters.

SLA CONFIGURATIONS

Dynamic Baselines Configuration

Fast BSS Transition Roams(11r)	<input type="text" value="113535"/>	ms	
	<input type="range" value="113535"/>		<input type="button" value="Low"/>
Opportunistic Key Caching Roams(okc)	<input type="text" value="31845"/>	ms	
	<input type="range" value="31845"/>		<input type="button" value="Low"/>
PMK Cache Roams	<input type="text" value="165648"/>	ms	
	<input type="range" value="165648"/>		<input type="button" value="Medium"/>

- **Fast BSS Transition Roams(11r)** - This is implemented as part of the 802.11r standard and enables fast roaming of wireless clients by pre-authenticating them with several APs in the network; this pre-authentication is done prior to when the client begins roaming. This feature allows immediate BSS transitions between APs and curtails the latency caused by deferred data connectivity, often experienced when a client has to transition from one BSS to another while roaming in a multi-AP deployment. The default roaming time value is 55 ms and the valid range is 1 - 600000 ms.
Note: To use this feature of FortiAI Ops, ensure that the wireless client supports 802.11r standard enable 802.11r roaming on the SSID using the `set fast-bss-transition` CLI commands on FortiGate.
- **PMK Cache Roams** – The Pairwise Master Key (PMK) caching enables a wireless client to re-associate with an AP without re-authenticating. When a wireless client associates with an AP through the 802.1x authentication process, a master key negotiated with the AP is stored in a cache. When the client roams to different APs and then wants to re-associate with this AP again, then the already cached PMK is used for authentication. This significantly reduces the authentication time as the client-AP are not required to go through the entire 802.1x authentication process again, ensuring minimal latency in data connectivity during roaming. The default roaming time value is 100 ms and the valid range is 1 - 600000 ms.
- **Opportunistic Key Caching Roams (okc)** – This feature enables swift roaming of wireless clients to APs that it has never associated with earlier, without any requisite pre-authentication. When an AP successfully completes the 802.1x authentication and associates with a wireless client, it stores a unique PMK associated with that client. This per client PMK is advertised to and stored by all the APs in that particular network. When a client roams, it associates with a new AP based on this cached PMK, without any pre-authentication. This reduces the latency caused during roaming by eliminating the re-authentication process. The default roaming time value is 100 ms and the valid range is 1 - 600000 ms.

FortiAI Ops dynamically determines the optimal roaming time for each type of roaming for a specific AP-Client environment using machine learning algorithms.

SD-WAN

You can configure the SD-WAN SLAs in FortiAI Ops or in FortiGate. The following configurations are *required* in FortiGate to receive SD-WAN logs.

- Ensure that the SD-WAN monitoring license is applied in FortiGate. This is to generate congestion logs.
- Configure the `sla-fail` and `sla-pass` log failure period, the recommended duration is 30 to 60 seconds.

Dynamic Baselines

You are required to provide the following information for threshold configuration.

SLA CONFIGURATIONS

Device Health Time to Connect Roaming **SD-WAN**

Dynamic Baselines Configuration

Scope: **FortiGate** Interface SLA

Time Selection: **Duration** Date Range

1 Hour(s)

Schedule Baselines Computation: 19-07-2022 20

Repeat Cycle: 7 Hours(s)

OK Cancel

DYNAMICALLY OBTAINED BASELINES VALUES

Refresh Recompute Baselines Search

Last Updated	FortiGate Hostname	Jitter	Latency	Packet Loss(%)	Status
2022/07/07 15:01:34		100ms	100ms	20	No data available for selected range, Hence using older dy...

- **Scope** - Select the scope to calculate the thresholds which could either be per **FortiGate**, per **Interface**, or per **SLA**. The following is the scope of SD-WAN dynamic baselines.
 - FortiGate - FortiAIops calculates the baseline for each FortiGate separately (managed in device group) and failures are reported based on the baseline of each FortiGate.
 - Interface - FortiAIops calculates the baseline for each interface separately (when multiple WANs are available) and failures are reported based on the baseline of each interface.
 - SLA - FortiAIops calculates the separate baseline per health check created in FortiGate and failures are reported when the health check thresholds are breached.
- **Time Selection** - Set the time range/duration for which FortiAIops analysis client data to derive the thresholds.
- **Schedule Baselines Computation** - Set the time when FortiAIops calculates the baselines and applies them to your network to obtain and report the relevant SLAs.
- **Repeat Cycle** - Configure the repetition of the above configurations, that is, the phase of analyzing client activity and the calculation/application of the algorithms.

The baseline values calculated by FortiAIops are displayed in the table. You can re-compute specific baseline values.

Static Threshold

Select **Baseline** to configure the threshold configuration criteria in FortiAIops or **FortiGate** to consider the SLA threshold values configured in FortiGate. For more information, see the [SD-WAN minimum SLA configuration](#).


SLA CONFIGURATIONS

Device Health Time to Connect Roaming SD-WAN

Dynamic Baselines Configuration

Baselines Type **Baseline** FortiGate

Jitter ms
 **Low**

Packet Loss %
 **Low**

Latency ms
 **Low**

- **Jitter** - The maximum amount of jitter that's acceptable on the interface. The default value is 1 ms and the valid range is 1 - 500 ms.
- **Packet Loss** - The maximum percentage of packet loss that's acceptable on the interface. The default value is 20% and the valid range is 1 - 100%.
- **Latency** - The maximum amount of latency that's acceptable on the interface. The default value is 100 ms and the valid range is 0 - 500 ms.


Inventory

This section describes adding the FortiGate controllers to FortiAIOps, grouping them, and the management operations on the added controllers.

- [Adding and Managing FortiGates](#)
- [Device Groups](#)

Adding and Managing FortiGates

This page provides a graphical representation of the FortiGate controllers deployed in your network. You can view and monitor the current status of the FortiGate controllers, the various FortiGate models in use, and the OS versions. The table beneath the charts provides the details of all FortiGate controllers; click on specific areas of the chart to filter data displayed in the table.



You can perform the following operations on this page.

- [Adding a FortiGate](#)
- [Importing and Exporting FortiGates](#)
- [Managing FortiGates](#)

Adding a FortiGate

The communication between the FortiAIOps application and FortiGate is secured by SSL/TLS encryption. Therefore, FortiAIOps can successfully discover a FortiGate only if a valid certificate is installed in FortiGate. However, FortiAIOps can also discover FortiGates with a default certificate over a trusted connection. If a 3rd party certificate is installed in FortiGate for HTTPS/web server then the corresponding CA certificate should be installed in FortiAIOps for successful discovery. For more information see [Certificates](#) and [FortiGate Certificates](#).

The managed FortiGate IP address/FQDN configured in FortiAIOps must match the Subject Alternative Name (SAN) in the FortiGate certificate, else, the FortiGate discovery fails.

- If the FortiGate IP address is configured in FortiAIOps then the SAN attribute in the certificate should be the FortiGate IP address.
- If the FortiGate FQDN is configured in FortiAIOps then the SAN attribute in the certificate should be the FortiGate FQDN.
- If the FortiGate IP address or FQDN are configured in FortiAIOps then the SAN attribute in the certificate should include both the FortiGate IP address and FQDN.

Notes:

- FortiGate discovery fails if a certificate is from an unknown authority. Ensure to install specific CA certificate of FortiGate in FortiAIOps.
- If a new certificate is installed in a managed FortiGate then Fortinet recommends to re-add the FortiGate in FortiAIOps.
- For self-signed CA certificates generated in FortiGate, valid CA certificate should be installed in FortiAIOps.
- To use a *Let's Encrypt* certificate, ensure to download and install the CA certificate of *Let's Encrypt* in FortiAIOps. For more information see [Automated Certificate Management Environment \(ACME\)](#).

To manually add a FortiGate controller, click **Add** and provide the following details.

Add new device

☰ Details

Device Type	<input checked="" type="radio"/> Standalone <input type="radio"/> HA Cluster
IP Address/Hostname	<input type="text" value="10.1.1.1"/>
Description	<input type="text" value="FortiGate"/>
Username	<input type="text" value="fortigate"/>
Password	<input type="password" value="••••••••"/>
Confirm Password	<input type="password" value="••••••••"/>
Device Group	<input type="text" value="default"/>
HTTPS port	<input type="text" value="443"/>
Timeout (milliseconds) ?	<input type="text" value="3000"/>

1. Select **Standalone** or **HA Cluster** if the FortiGate is an HA cluster.
2. Enter the **IP Address** or FQDN of the controller and an optional **Description**.
Note: If a 3rd party certificate is used by FortiGate then ensure to install a valid CA certificate in FortiAIOps.
3. Enter the **Username** and **Password** for the controller.
4. Select the **Device Group**. Controllers in the selected device group are added.
5. Specify the **HTTPS port**. The default is 443.

6. Specify the **Timeout** duration (milliseconds), that is, the maximum time allowed to establish a connection with FortiGate and obtain a response. The default value is 3000 milliseconds.


The added FortiGate controller is now listed.

Importing and Exporting FortiGates

You can import details of FortiGate controllers from a .csv file to add them. Enter the details in the format depicted in the image here.

	A	B	C	D	E	F	G	H
1	Device Type	IP address	Description	Username	Password	Device Group	HTTPS port	Timeout (milliseconds)
2	Standalone	10.20.100.20	fortigate1	admin	fortigate1	guestgroup	443	3000
3	Standalone	10.20.100.200	fortigate2	admin	fortigate2	test2	10443	3000
4	Standalone	10.20.100.210	fortigate3	admin	fortigate3	guestgroup	443	3000

You can download a sample template for populating the FortiGate details, from the **Actions** drop-down menu.



Select **Import** to upload the FortiGate configuration file.

You can export the configurations of all the existing FortiGate controllers added to FortiAIOps, in a .csv format. Click **Export All** and the file with details of the added FortiGate controllers is downloaded to your machine.

Note: The HA cluster addition does not work using the **Import** option.

Managing FortiGates

This page provides analytical information related to the performance of various elements and processes in your network. The data is visually represented with interactive options to drill-down and filter specific information. This enables monitoring, diagnostic, and troubleshooting operations for connectivity issues, data usage, and enhancing performance.

Status	FortiGate IP Address	FortiGate Name	Up Time	Cluster Name	HA Mode	License
Online	[Redacted]	FortiGate-300E	8d:20h:1m:7s		Standalone	Monitoring ✔ Licensed Analytics ✔ Licensed SDWAN ✔ Licensed
Online	[Redacted]	FGT_PRIMARY_181	3d:0h:6m:51s	VM_cluster	Active-Passive	Monitoring ✔ Licensed Analytics ✔ Licensed SDWAN ✘ Unlicense

You can perform the following operations on a FortiGate controller listed on this page.

- **Reboot** - Select a FortiGate controller to reboot and click **Reboot**.
- **CLI** - Select a FortiGate controller and select **CLI** to access the CLI interface.
- **Edit and Delete** - Select a FortiGate controller and click **Edit** (to update configuration) or **Delete** (to remove the FortiGate).
- **View Details** - Select a FortiGate for **Diagnostics and tools**. This pane displays details about the selected FortiGate and also provides diagnostic tools for your network.

Diagnostics and Tools

Hostname: FortiGate-300E
 Serial Number: [Redacted]
 Version: v7.4.3
 Model: FG3H0E
 IP Address: [Redacted]

General

- 43 % Memory Usage
- 4 % CPU Usage
- 9 day(s) Connection Uptime
- 336 Sessions

Performance | Channel Summary | FortiAPs | Clients | FortiSwitches | Logs | Tools

Environmental | Wireless | Clients

CPU Usage: [Line graph showing usage over time]

Memory Usage: [Line graph showing usage over time]

Last updated at 12:02:21 | Reload in 60 (s) | 10 minutes

To view details of the HA cluster, click on the icon in the **FortiGate Name** column.

Details

Search

Hostname	Priority	Role	Serial Number
FGT_BACKUP_182	128	Secondary	[Redacted]
FGT_PRIMARY_181	255	Primary	[Redacted]

Performance

This tab displays the performance data for your network based on various parameters. You can select the time interval to view the data (10 or 30 minutes, 1, 12, or 24 hours). The data in this tab is automatically refreshed every 60 seconds; the following options are available to manage the auto-refresh feature for this page.


- Click  to manually refresh data.
- Click  to pause the auto-refresh.
- Click  to resume the auto-refresh.

Performance is displayed for the following.

- [Environmental](#)
- [Wireless](#)
- [Clients](#)

Environmental

This tab displays resource usage such as, the maximum CPU and memory usage levels, and the maximum number of sessions at a given time.




Hover over each of these graphs to view the current statistics and click on any of these graphs to view details.

Details ✕			
+ 🔍 Search 🔍			
Timestamp ⌵	CPU Usage ⌵	Memory Usage ⌵	Sessions ⌵
2023/04/05 15:27:22	34%	54%	181

Wireless


Displays detailed information about the health of the wireless connections in the network, such as, loss%, SNR, channel utilization %, number of stations, status of the FortiAPs, low signal stations, the average throughput at a given time, and the number of rogue APs at a given time.



Hover over each of these graphs to view the current statistics and click on any of these graphs to view details.

Clients

This tab displays information about the clients connected to the network, such as, throughput, Loss (%), Retries (%), and SNR (dB) and throughput.



Hover over each of these graphs to view the current statistics and click on any of these graphs to view details.

Channel Summary

This page provides granular insights into the performance of each channel with detailed statistics and trends. For more information, see [Channel Summary](#).

Channel	Max Channel Utilization	Clients	No. Of Radios	Average Utilization Severity	Average Interfering SS
2.4 GHz 3 Number of Clients-0					
1	90 %	0	5	Poor	Good
11	97 %	0	4	Poor	Good

FortiAPs

This tab displays details about the selected access point with their status and details. To view the details, select an access point and click **View Details**. For more information on the diagnostic options and details see [Access Points](#).

Clients

This tab displays the clients currently connected to the selected access point along with their details. To view the details, select a client and click **View Details**. For more information on the diagnostic options and details see [Clients on page 136](#).

FortiSwitch

This tab displays a graphical snapshot of the FortiSwitch activity such as, the total number of FortiSwitches, their status (online/offline), and the deployed model details. To view the details, select a FortiSwitch and click **View Details**. For more information on the diagnostic options and details see [FortiSwitch](#).

Ports Cable Test Logs Statistics Clients

Port	Trunk	Mode	Port Policy	Enabled Features	Native VLAN	Allowed VLANs
port1		Static		<ul style="list-style-type: none"> Spanning Tree Protocol Edge Port 	native	bridge-static,guest,quara
port2		Static		<ul style="list-style-type: none"> Spanning Tree Protocol Edge Port 	native	bridge-static,guest,quara
port3		Static		<ul style="list-style-type: none"> Spanning Tree Protocol 	native	bridge-static,guest,quara

Logs

This tab displays the detailed FortiGate event logs and each event is assigned a severity, that is depicted with a color code. Hover over the color bar in the **Level** column to view the severity.

Performance FortiAPs Clients FortiSwitch Logs Tools

Date/Time	Level	Action	Message	SSID	Channel	Abs
1 minute ago	Emergency, Critical (red)	rogue-ap-detected	AP OnePlus 7T 8a:fa:27:58:0b:e8 chan...	OnePlus 7T		
5 minutes ago	Error, Warning (blue)	antenna-defect-detected	AP PU323E5E18012353 radio 2 antenn...	N/A		
10 minutes ago	Error, Warning (blue)	antenna-defect-detected	AP PU323E5E18012353 radio 1 antenn...	N/A		

- Emergency, Critical (red)
- Alert (orange)
- Error, Warning (blue)
- Notice, Information, Debug (green)

Select an event row and click **Details** to view the detailed log information.

Performance FortiAPs Clients FortiSwitch Logs Tools

Date/Time	Level	Action	Message	Details
2 minutes ago	Emergency, Critical (red)	rogue-ap-detected	AP OnePlus 7	<ul style="list-style-type: none"> General Source Action Security Cellular Event
6 minutes ago	Error, Warning (blue)	antenna-defect-...	AP PU323E5E	
11 minutes ago	Error, Warning (blue)	antenna-defect-...	AP PU323E5E	
17 minutes ago	Error, Warning (blue)	antenna-defect-...	AP PU323E5E	

- **General** - Generic information about the log event such as, the date and time of event logging, the associated virtual domain, and the log description.
- **Source** - The details of the associated access point such as the MAC address, interface, and SSID.

- **Action** - The reason for the log event generation.
- **Security** - The severity of the log event, the configured security mode, and the encryption type.
- **Event** - The serial number of the access point and the generated log message.
- **Other** - Generic information such as the log event time stamp, the timezone, log type, and so on.

Tools

FortiAIOps provides various utilities that you can run on the FortiAP for **Connectivity Analysis, Network Analysis**, and **Enhanced Troubleshooting**.

- [Packet Capture](#)
- [ARP Table](#)
- [Routing Table](#)
- [DHCP](#)
- [DNS Lookup](#)
- [Reverse DNS Lookup](#)
- [Web CLI](#)
- [TAC Report](#)
- [Process Monitor](#)

Packet Capture

You can use the packet capture tool to select a packet and view its header and payload information in real-time. Once completed, packets can be filtered by various fields or through the search bar. The capture can be saved as a PCAP file that you can use with a third-party application, such as Wireshark, for further analysis.

Packet Capture

 NPU hardware acceleration must be disabled on the respective firewall policy to see all packets. To do so, set "auto-asic-offload" to "disable" in the CLI.

Interface

Maximum captured packets

Filters

Filtering syntax

Host

Port

Protocol

Click **Run** and select the **Interface** and the **Maximum captured packets** (default is 10). You can enable filters, for a **Basic** filter, provide the **Host, Port,** and **Protocol Number** and for an **Advanced** filter, enter a string, such as *src host 172.16.200.254 and dst host 172.16.200.1 and dst port 443*. Click **Start capture**.

Packet Capture ✕

+ 🔍 Search 🔍

Source IP	Source Port	Destination IP	Destination Port	Protocol	Sequence Number	Ack
172.16.200.254	57224	172.16.200.1	443	TCP	1964315332	3719362240
172.16.200.254	57194	172.16.200.1	443	TCP	1964315332	3371865

0% 10

[Header](#) [Packet Data](#)

IP		L4	
Source IP	172.16.200.254	Ack	3719362240
Source Port	57224	Flags	ACK
Destination IP	172.16.200.1	Window	41488
Destination Port	443	Length	0
Protocol	TCP	Checksum	26989

ARP Table

The ARP Table records the discovered MAC address - IP address pairs of devices connected to a network and the interface details. Each connected device has its own ARP table that stores the MAC-IP address pairs that the device has communicated with. Click **Run** to view the ARP table.


ARP Table ✕

+ 🔍 Search 🔍

Age	Interface	IP	MAC Address
root 4			
1m 24s	wan1	172.16.200.1	08:00:27:00:00:00
1s	25SSID-Coverage	172.16.200.254	08:00:27:00:00:00
0s	wan1	172.16.200.1	08:00:27:00:00:00
15s	wan1	172.16.200.1	08:00:27:00:00:00


Routing Table

You can view the routing table on the FortiGate, including all static and dynamic routing protocols.



DHCP

The DHCP monitor shows all the addresses leased out by FortiGate's DHCP servers.



DNS Lookup

Enter the domain name (FQDN) to view the IP addresses associated with it.

DNS Lookup

FQDN

Run

IP Address

Reverse DNS Lookup

Enter the IP address to view the domain name (FQDN) associated with it.

Reverse DNS Lookup

IP Address

Run

FQDN

www.fortinet.com

Web CLI

Access the FortiGate's command line interface.

Web CLI

```
FortiGate-300E # show
#config-version=FG3H0E-7.2.4-FW-build1396-230131:opmode=1:vdom=0:user=admin
#conf_file_ver=818427493209189
#buildno=1396
#global_vdom=1
config system global
    set admin-server-cert "self-sign"
    set admintimeout 480
    set alias "FortiGate-300E"
    set hostname "FortiGate-300E"
    set switch-controller enable
    set timezone 47
end
config system accprofile
    edit "prof_admin"
        set secfabgrp read-write
        set ftviewgrp read-write
        set authgrp read-write
        set sysgrp read-write
        set netgrp read-write
        set loggrp read-write
        set fwgrp read-write
--More--
```

TAC Report

The Technical Assistance Center (TAC) report runs an exhaustive series of diagnostic commands for troubleshooting network issues. You are required to download the generated report (.txt) to view it; click

Download report.

TAC Report




Report generated



Download report

Process Monitor

The process monitor displays running processes with their CPU and memory usage levels. You can sort, filter, and terminate processes within the process monitor pane.



Select a process to perform any of the following operations.

- **Kill Process** - The standard kill option that produces one line in the crash log (diagnose debug crashlog read).
- **Force Kill** - The equivalent to *diagnose sys kill 9 <pid>*. This can be viewed in the crash log.
- **Kill & Trace** - The equivalent to *diagnose sys kill 11 <pid>*. This generates a longer crash log and backtrace. A crash log is displayed afterwards.

For more information on the FortiGate commands and related information, see [FortiGate documentation](#).

Device Groups

You can group FortiGate controllers for ease of management. Each controller can belong to only one group; if a controller is added to a second group, it is automatically removed from the previous group. Device groups allow administrators to manage devices in a certain way, such as, provide specific access to a set of devices. The *admin* user have access to all the device groups and devices within them. System administrators and users assigned the *super user* role can only create and configure device groups.

Group Name	Description
Default	Default Device group

If you do not set up device groups, all controllers remain assigned to the *Default* device group.

1. Navigate to **Device Groups** and click **Add**.
2. Provide a unique **Device Group Name** and an optional **Description**.
3. A list of controllers managed by FortiAIOps is displayed. Select from the listed controllers and click **Create**. The controllers are added to the device group.

×

Add new device group

Details

Device Group Name

Description

Devices

Q

Selected	FortiGate Name	FortiGate IP Address	Status	Serial Number	OS Version
<input checked="" type="checkbox"/>	office-wifi-qa	10.32.76.2	✓ Online	FGDAB1411990001	v7.2.4

You can switch the device group from the bar on the top-right of the GUI; click **Device Group** and select the available group. To add a FortiGate controller to an existing device group or move a FortiGate to a different group, select the device group where you want to add/move the FortiGate to and click **Edit**. The FortiGate controllers are listed, select the FortiGate you want to add to this group and click **Update**.


Wireless

The Wireless section of the FortiAI Ops provides a comprehensive set of tools for managing and monitoring wireless networks.

- [Access Points](#)
- [Clients](#)
- [Channel Summary](#)
- [Applications](#)
- [Location Services Monitor](#)
- [Heat Maps](#)
- [Rogue APs](#)
- [Map Management](#)

Access Points


The Access Points page displays essential information about the APs in use and consists of two views - AP and Radio view. To switch between the AP and Radio views, select the desired view from the dropdown menu located at the middle of the Access Points page. By default, the AP is displayed when the page loads.



- [AP](#)
- [Radio](#)
- [Diagnostics and Tools](#)

AP

The AP view displays information related to the Access Point and consists of three widgets - FortiAP status, Channel Utilization, and FortiAP model.



FortiAP Status

The FortiAP Status widget provides information about the status of each AP listed on the page. It displays the current status of the AP, which can be either **Online**, **Offline** or **Unauthorized**.

Band

The band widget provides the number of channels for the 2.4GHz, 5GHz and 6GHz bands. Hovering over the chart displays the number of APs in that band and the percentage of the total channels that they comprise of.

FortiAP Model

The FortiAP Model widget displays the model number of each AP listed on the page. It provides information about the hardware model of the AP and its associated count. This widget is useful for identifying the different models of APs being used in the network.

Note: Click the donut chart in the widgets, to filter the AP table. To reset the filter, click the widget name.

The APs are listed with their relevant details, including the AP name, FortiGate, FortiAP status, SSID, channel, clients, OS version, FortiAP profile and license. To view detailed information about an AP, select the desired AP from the list and click **View Details**. See, [Diagnostics and Tools](#).

Right-click on the header of the table to select the desired columns to add to the table, and then click **Apply** to update the table with the selected columns.

AP Name	FortiGate	FortiAP Status	SSID	Channel	Clients	OS Version
	FortiGate-300E	Online	R1 210-Bridge,210-Ext... R2 Test-SAM	R1 132 R2 1	2	PU431F-v6.2-build03...
	FortiGate-300E	Online	R1 210-newBridge	R1 120	1	PU433F-v6.2-build03...

Best Fit Columns
Reset Table

Select Columns

- AP Name
- FortiGate
- FortiAP Status
- SSID
- Channel
- Clients
- OS Version
- FortiAP profile
- License
- Channel Utilization
- Connected via
- FortiAP Model
- FortiGate IP Address
- FortiGate Serialnumber
- LLDP
- MAC Address

Apply Cancel

To reset the table to its default state, click **Reset** button. Click **Best Fit Columns** to automatically adjust the column width to fit the data displayed in the table.


To filter the AP list based on the column data, click the filter icon in the column header next to the title, select the value to be filtered and click **Apply**.

Type in the search term in the search bar located at the top of the AP list. The search term can be a specific AP name, client name, or any other relevant information.

Click the plus icon located to the left of the search bar to perform a more specific search based on a particular column. Select the desired column, and then enter the search term to narrow down the search results to specific criteria.

Radio

The Radio view displays information related to the radios in the AP and consists of three widgets - Status, Type and Channel.



Status

The Status widget displays the current status of each radio, either Online or Offline.

Type

The Type widget displays the type of each radio, such as 802.11a/n/ac or 802.11b/g/n, 802.11ax, 802.11ax-6G, or unknown. This information is useful for identifying the capabilities and features of each radio within the AP.

Channel

The Channel widget displays the channel being used by each radio. This information is important for optimizing the network's performance and minimizing interference between radios within the AP.

The radios are listed with their relevant details, including the AP name, AP serial number, FortiGate, FortiAP status, SSID, channel, No of clients, FortiAP profile, Band, Type, Radio ID, AP mode, Channel Utilization and license.

To view detailed information about an AP, select the desired AP from the list and click **View Details**. See, [Diagnostics and Tools](#).

Right-click on the header of the table to select the desired columns to add to the table, and then click **Apply** to update the table with the selected columns.

FortiGate	Status	AP Name	Radio ID	FortiAP profile	SSID	Clients	Band
FortiGate1	Online	AP431F-20200901	1	FAP431F-default	5ghz-25bridge	0	2.4 GHz
FortiGate2	Online	AP42E-20200422	2	FAP42E-neighbour	Radio5ghz-Dtest	0	5 GHz

- Best Fit Columns
- Remove All Filters
- Reset Table
- Select Columns
- FortiGate
- Status
- AP Name
- Radio ID
- FortiAP profile
- SSID
- Clients
- Band
- Mode
- Channel Utilization
- License
- AP Serialnumber
- Channel
- Type

To reset the table to its default state, click **Reset** button. Click **Best Fit Columns** to automatically adjust the column width to fit the data displayed in the table.

To filter the AP list based on the column data, click the filter icon in the column header next to the title, select the value to be filtered and click **Apply**.

Type in the search term in the search bar located at the top of the AP list. The search term can be a specific AP name, client name, or any other relevant information.

Click the plus icon located to the left of the search bar to perform a more specific search based on a particular column. Select the desired column, and then enter the search term to narrow down the search results to specific criteria.

Access Points Diagnostics and Tools

The *Diagnostics and Tools* pane displays the details about the selected Access Point/Radio and allows you to run diagnostic tests.



- [Performance](#)
- [Channel Summary](#)
- [Clients](#)
- [Interfering SSIDs](#)
- [Logs](#)
- [Spectrum Analysis](#)
- [VLAN Probe](#)

Performance

The performance tab displays trends for the FortiAP health, wireless, and wired clients for selected interval.



AP Health

This tab monitors and displays the CPU and memory usage by the FortiAP over the selected time interval. At any given point in time, you can view the maximum, minimum, and average CPU and memory usage. This tab also displays the operating temperature of the FortiAP collected by various sensors. The temperatures recorded by all sensors are displayed.



Wireless


It includes charts for Clients, Bandwidth and Channel Utilization. The default interval is 10 minutes and can be changed according to your requirements.



Wired

The LAN port statistics are now displayed for access points. You can view the traffic coming into a LAN port and the traffic leaving it at a given point in time. Also, the error statistics for both incoming and outgoing traffic is displayed.

Note: The LAN port status is not displayed for FAP-421E and FAP-423E.



Channel Summary

This page provides granular insights into the performance of each channel with detailed statistics and trends. For more information, see [Channel Summary](#).

Channel	Max Channel Utilization	Clients	No. Of Radios	Average Utilization Severity	Average Interfering SS
2.4 GHz	Number of Clients-0				
1	90 %	0	5	Poor	Good
11	97 %	0	4	Poor	Good

Clients

The Clients tab displays a list of clients currently connected to the selected AP, along with details such as the client MAC address, FortiGate and IP Address, FortiAP name, associated SSID, user name, operating channel and the radio details, Tx and Rx bandwidth, signal strength and noise, VLAN ID, RF band, the wireless standard, and the time of association. This information is useful for identifying any clients that may be experiencing connectivity issues or data usage problems. To view detailed information of a client, select the client and click **View details**.

MAC Address	FortiGate	IP Address	Forti AP	SSID	Device	User	Channel	Band
	FortiGate-300E			210-2Tunnel	FTNT-THINK-2		132	18.27
	FortiGate-300E			210-Bridge	FortiAlsQAsMini		132	0

Interfering SSIDs

The Interfering SSIDs tab displays the details of interfering SSIDs associated with an AP; the interfering SSID page displays the associated SSID, related AP BSSID, operating channel, signal strength and the radio details are displayed in the AP dashboard. To view the interfering SSID details, ensure that the AP radio is using Radio Resource Provisioning or a WIDS profile in FortiGate (Managed FortiAP Profile).

SSID	AP BSSID	Channel	Signal	Type
Radio Id: 1 156				
1A_no_vlan		11	-27 dBm 	Other
#####iperf_SSID		11	-61 dBm 	Other
test		11	-51 dBm 	Other
test		11	-64 dBm 	Other

Logs

The Logs tab provides detailed logs of events related to the selected AP/Radio. To view detailed information, select log and click **Details**.

Search filterable columns				Q	Details
Date/Time	Level	Action	Message	General	
2024/04/12 21:...		auth-req	AP received autf	Absolute Date/Time	2024/04/12 21:11:47
2024/04/12 21:...		auth-req	AP received autf	Time	21:11:47
2024/04/12 21:...		auth-req	AP received autf	Virtual Domain	root
2024/04/12 21:...		auth-req	AP received autf	Log Description	Authentication request from wireless station

Spectrum Analysis

Spectrum Analysis tab provides visual spectrum analysis capabilities that scan radios for RF channel conditions and sources of interference which can potentially impact WLAN efficiency. Based on the spectrum analysis data, corrective measures such as determining optimal channel planning, debugging client related connectivity issues and automatic transmit power settings are initiated. This facilitates quality wireless service levels by ensuring the optimal usage of the channels considering the information provided by the FortiAIOps spectrum analyzer. Both 802.11 and non-802.11 sources of interference can be detected and analyzed by the spectrum analyzer.

Notes:

- Spectrum analysis is not available for G Series FortiAPs.
- Spectrum analysis is only supported when the radio is in the monitor mode.
- FortiAP supports spectrum analysis and is online.

Select the channels to be scanned and configure the scan duration, the spectrum analysis is performed on both 2.4 GHz and 5 GHz frequency bands. The spectrum analyzer result displays widgets with the type of interference, signal strength, impacted channels, and wireless spectrum current utilization, start and end time and duration of the interference. It classifies wireless & non-wireless interferences to easy identification of the source.

- You can select the **AP**, **Radio**, and **Channels** to be scanned for interferences.
- The **Scan Duration** can be set to 1, 5, 30, or 60 minutes.
- The **Sampling Interval** and the number of **Spectrogram Samples** cannot be modified.


Select **Start** and the GUI periodically polls the spectrum analysis data based on the fixed sampling interval of 1000 milliseconds. Data is visualized as 4 charts representing signal interference marking the noise levels for each channel, signal interference spectrogram representing 60 samples for different channels at specific time

intervals, the duty cycle charts marking the extent to which a non-WiFi device/neighbouring AP is interfering, and the duty cycle spectrogram representing 60 such duty samples for each channel over a period of time.

The tabular data for non-WiFi interference displays the time and frequency of last detection and any of the following type of devices causing the interference.

- Microwave ovens
- Video bridges
- Wi-Fi, DSSS cordless phones
- Bluetooth, FHSS cordless phones

The tabular data for WiFi interference displays the online neighbouring AP's BSSID, SSID, maximum signal strength, and channel and time of last detection.



VLAN Probe

VLAN probe tab enables FortiAPs to probe connected VLANs and subnets. It sends DHCP probes from the FortiAP's Ethernet interface to specific VLANs on the wired interface and returns information on their availability and subnet details. This helps diagnose and troubleshoot WiFi deployment issues.


- **Probe Retries** – Configure the number of retries before timeout. The valid range is 1 to 10 with a default value of 6.
- **Timeout** – Configure the timeout for the VLAN probe. The valid range is 1 – 60 seconds with a default value of 10 seconds.
- **VLAN Range** – Select the range of VLANs to probe. The valid range is 1 - 4094.

Select **Start** to initiate VLAN probe as per configurations.

Performance	Clients	Interfering SSIDs	Logs	Spectrum Analysis	VLAN Probe
Probe Retries	<input type="text" value="10"/>				
Timeout	<input type="text" value="5"/>	Seconds			
VLAN Range	<input type="text" value="1"/>	To	<input type="text" value="10"/>		
<input type="button" value="Start"/>					

Clients

The Clients page provides information about the clients connected to the wireless network and consists of three widgets - signal strength, band, and technology.



Signal Strength

The signal strength widget provides information about the strength of the signal between each client and the access point. It displays the signal strength in dBm, which is a measure of signal power. A higher dBm value indicates a stronger signal, while a lower dBm value indicates a weaker signal.

Band

The band widget displays the band that each client is connected to. It indicates whether the client is connected to the 2.4 GHz, 5 GHz or 6 GHz band.

Technology

The technology widget displays the technology that each client is using to connect to the wireless network. It indicates whether the client is using 802.11a/b/g/n or 802.11ac technology.

The clients are listed with their relevant details, including the MAC address, FortiGate, IP address, FortiAP, SSID, channel, bandwidth, and signal strength. To view detailed information about a client, select the desired client from the list and click **View Details**. See, [Clients Diagnostics and Tools](#).

Right-click on the header of the table to select the desired columns to add to the table, and then click **Apply** to update the table with the selected columns.

MAC Address	FortiGate	IP Address	Forti AP	SSID	Channel	Bandwidth Tx/Rx	Signal Strength/Noise	Signal Strength
9c:5b:34:2b:4b:84	FortiGate-300E	192.168.20.7	FP431GTY22000103	210-2Tunnel	161	2.49 kbps	7 dB	-88 dBm
9c:5b:34:2b:4b:85	FortiGate-300E	192.168.200.12	FP431GTY22000103	210-Bridge	132	0 bps	50 dB	-42 dBm
9c:5b:34:2b:4b:86	FortiGate-300E	192.168.20.7	FP431GTY22000103	210-newBridge	120	0 bps	56 dB	-43 dBm

Best Fit Columns

Reset Table

Select Columns

- MAC Address
- FortiGate
- IP Address
- Forti AP
- SSID
- Channel
- Bandwidth Tx/Rx
- Signal Strength/Noise
- Signal Strength
- Association Time
- FortiAP Radio
- VLAN ID
- Authentication
- Band
- Bandwidth Rx
- Bandwidth Tx
- Device
- Device OS
- Encryption
- FortiAP IP

Apply Cancel

Clients Diagnostics and Tools

The *Diagnostics and Tools* pane displays the details about the selected Client and allows you to run diagnostic tests.

- Performance
- Applications
- Destinations
- Policies
- Logs

Diagnostics and Tools ✕


Device	9c:5b:34:2b:4b:84
SSID	210-2Tunnel
FortiAP	FP431GTY22000103
Channel	161
Association Time	2023/04/04 19:11
IP Address	192.168.20.7

Status

- 87 dBm Signal Strength
- 5 GHz Band
- 8.0 dB Signal Strength/Noise
- 0 Transmission Discard/Retry

Performance

The Performance tab displays information about the client's performance, including data charts for bandwidth, signal strength, and transmission discards and retries.



Applications

The Applications tab displays a list of applications in use by the selected client, along with details such as the application name, category, risk, data usage, session and bandwidth details.

Diagnostics and Tools					
Performance <u>Applications</u> Destinations Policies Logs					
+ Q Search					
Application	Category	Risk	Bytes	Sessions	Bandwidth
Windows.Push.Notification	General.Interest		89.77 KiB		
Fortiguard.Search	Cloud.IT		156 B		
Windows.Push.Notification	General.Interest		79.45 KiB		
SSL_TLSv1.3	Network.Service		2.18 KiB		
Microsoft.Teams	Collaboration		11.77 KiB		
Fortiguard.Search	Cloud.IT		156 B		
Microsoft.Teams	Collaboration		12.31 KiB		
Fortiguard.Search	Cloud.IT		156 B		
Fortiguard.Search	Cloud.IT		156 B		
SSL_TLSv1.2	Network.Service		180.92 KiB		
Fortiguard.Search	Cloud.IT		156 B		
Microsoft.SharePoint	Collaboration		15.03 KiB		
HTTPS.BROWSER	Web.Client		77.62 KiB		
Microsoft.Teams	Collaboration		7.49 KiB		

55% 18 | Updated: 17:00:13

Close

Destinations

The Destinations tab displays a list of network destinations accessed by the selected client, along with details such as the destination IP address, application name, data usage, session and bandwidth details.

Diagnostics and Tools x

Performance Applications Destinations Policies Logs v

+ Q Search Q

Destinations	Application	Bytes	Sessions	Bandwidth
208.135.201.90	AnyDesk	161.54 KiB <div style="width: 80%;"></div>		
13.44.186.106	Windows.Push.Notification	83.32 KiB <div style="width: 45%;"></div>		
13.207.136.8	Microsoft.SharePoint	5.13 KiB		
13.207.136.8	Microsoft.SharePoint	10.99 KiB		
173.243.138.194	Fortiguard.Search	156 B		
140.174.22.74	Fortiguard.Search	156 B		
173.243.138.194	Fortiguard.Search	156 B		
140.174.22.75	Fortiguard.Search	156 B		
140.174.22.75	Fortiguard.Search	156 B		
83.216.252.84	Fortiguard.Search	156 B		
132.133.207.42	Microsoft.Teams	226.05 KiB <div style="width: 60%;"></div>		
132.134.142.205	Microsoft.Teams	7.71 KiB		
10.234.87.92	SSL_TLSv1.2	202.72 KiB <div style="width: 75%;"></div>		
10.234.87.92	SSL_TLSv1.2	291.06 KiB <div style="width: 95%;"></div>		

0% 37 Updated: 17:00:48 ↻

Close

Policies

The Policies tab displays information about any policies applied to the selected client, such as policy name, policy type, source interface, destination interface, data usage, session and bandwidth details.

Diagnostics and Tools x

Performance Applications Destinations Policies Logs v

+ Q Search Q

Policy	Policy Type	Source Interface	Destination Interface	Bytes	Sessions	Bandwidth
wifi-to-internet	9	vap-data-4f	Distribution	291.06 KiB <div style="width: 95%;"></div>		

Logs

The Logs tab displays detailed logs of events related to the selected client, allowing you to troubleshoot any issues. To view detailed information, select log and click **Details**.

Diagnostics and Tools						
Performance Applications Destinations Policies <u>Logs</u>						
+ Search [] Q [] Details []						
Date/Time	Level	Action	Message	SSID	Channel	Absolute []
19 seconds ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
19 seconds ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
10 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
10 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
20 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
20 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
20 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
20 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
30 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
30 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
40 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
40 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
50 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		
50 minutes ago	■ ■ ■ ■ □ □ □ □	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-NAC-Peap-4F		

0% 831 | Updated: 17:01:50 []

Close

Channel Summary

This page provides granular insights into the performance of each channel with key insights into critical statistics, that are key in determining the health of your wireless network. This facilitates effective resolution of any potential network stability issues due to the operating channel. FortiAI Ops retrieves and aggregates all channel related statistics from the FortiAPs operating in your network and multiple radios operating on various channels.

Note: All data and trends displayed on this page are for the last 1 minute.



You can filter based on specific deployment locations such as **Site**, **Building**, and **Floor**.

Floor Slection	
Site	Region ▼
Building	Building ▼
Floor	Floor ▼

Band

This chart provides channel count based on RF bands of 5 GHz, 2.4 GHz, and 6 GHz. The total number of channels for each band are displayed along with what percentage of the total channels used by the wireless network they comprise of. Click on any band to filter channel details and view them in the table below the charts.

Average Utilization Severity

This chart provides the channel count based on the average utilization severity over the last 60 seconds. FortiAIOps automatically categorizes the channels as **Good** or **Poor**, and **Fair**. The total number of channels for each severity are displayed along with what percentage of the total channels used by the wireless network they comprise of. Click on any severity to filter channel details and view them in the table below the charts.

Average Interfering SSID Severity

This chart provides the channel count based on the average interfering SSID severity over the last 60 seconds. FortiAIOps automatically categorizes the channels as **Good** or **Poor**, and **Fair**. The total number of channels for each severity are displayed along with what percentage of the total channels used by the wireless network they comprise of. Click on any severity to filter channel details and view them in the table below the charts.


The channel data in the tabular format categorizes channels based on the RF band. To view radio level details for a particular channel number, select it and click **View details**.

Channel-6(2.4 GHz)							
+ Q Search filterable columns							
FortiGate Name	AP Name	Radio	Channel Utilization	Clients	Throughput	Utilization Severity	Interfering SSID Severity
FGT_PRIMARY	(*) HA_3flab	1	3%	0	0 B/s	Good	Good

Field	Description
FortiGate Name and AP Name	The names of the FortiGate controller and FortiAP associated with the selected channel.
Radio	The radio operating on the selected channel.
Channel Utilization	Total channel utilization (in percentage) per radio.
Clients	The number of clients connected per radio.
Throughput	The total throughput of traffic passing per radio.
Utilization Severity	The average utilization severity of the selected channel.


Field	Description
Interfering SSID Severity	The average interfering SSID severity of the selected channel.
SSIDs	The SSIDs associated with the radio.
Noise Level	The noise level detected by the by the radio.
Health Assessment	FortiAI Ops evaluates a assigns the health status of each radio.

To view trends and patterns to assess the performance of specific channels, select a channel and click **Trends**. You can view a graphical representation of the channel statistics over a period of time. These trends can be filtered for the last **10 minutes**, **1 hour**, or **12 hours**. Hover over the charts or click on a them to view the related statistics at a specific time. For example, the following image depicts a maximum channel utilization of 95% with the time stamp, clicking on this point provides similar data in a tabular format.



Applications

The Applications page provides information about the applications used by clients on the wireless network. This page consists of three widgets - Apps by usage, Apps by risk, and Users by usage.



Apps by usage

The Apps by Usage widget displays a list of applications in use on the network, sorted by the amount of data each application is using.

Application	Users	Access Points	ESSIDs	Utilization	Risk Level	Status
FortiEDR.Core	5	12	2	474.73 MB/s	Elevated	Detected
Microsoft.Teams	23	25	2	347.68 MB/s	Elevated	Detected
Citrix.Services	7	8	2	264.53 MB/s	Elevated	Detected
YouTube	0	4	1	242.44 MB/s	Elevated	Detected
Egnyte	4	7	2	116.38 MB/s	Medium	Detected
DTLS	2	2	1	74.87 MB/s	Low	Detected

Apps by risk

The Apps by Risk widget displays a list of applications in use on the network, sorted by their risk level.

Application	Utilization	Risk Level	Users
Skype	6.96 MB/s	Elevated	7
Gmail	65.58 kB/s	Medium	0
Facebook	1.13 MB/s	Medium	0
HTTP.BROWSER	5.51 kB/s	Medium	0
SSL	166.67 kB/s	Elevated	2
TeamViewer	377.33 kB/s	High	1
Twitter	85.69 kB/s	Elevated	1

User by usage

The User by usage widget displays a list of clients on the network, sorted by the amount of data each client is using.

Serial Number	Applications	Access Points	ESSIDs	Utilization
	77	16	1	1.01 GB/s
	5	1	1	350.12 MB/s
	7	1	1	117.24 MB/s


Location Services Monitor

The Location Services Monitor page plots the current location of all stations and rogue APs on the floor map imported into FortiAIOps. FortiAIOps plots the current location based on the location feed received from FortiGates (which are in turn connected to APs) and does not display the movement of the stations.

You can filter and view device locations based on the site, building, and floor. The following filters can be applied.

- Device Type
- Wireless Type
- OS Type
- Station/BLE MAC
- Accuracy
- Rogue MAC

You can set the Floor Visibility and magnify the floor view.



Select **Rogue AP** as the **Device Type**, to view the rouge AP location.

Click **Connected Stations** toggle to switch to **Connected & Discovered Stations** view.


Heat Maps

The heat map allows you to verify the coverage and performance of your WLAN APs. You can also use the maps to visually locate APs sending alarms. Use the map editor to set up your site maps.

- In the Network Heat Maps screen, select a Location from the menu on the left to see the corresponding map.
- Hover the mouse pointer over the objects on the screen to see details. For example, for this throughput map, by hovering the mouse pointer on an AP icon displays the Name, model, Mac Address, status of the AP and throughput value. If you change the Heat Map Type, be sure to click Refresh icon.
- In the Network Heat Maps screen select a floor. The following five types of heat maps can be viewed.

Throughput Heat Map

Throughput maps display the AP throughput over the represented area. The APs on the map are differentiated by using different colors to represent the corresponding AP throughput value.



Hover over AP to view the AP information including name, AP model, MAC address, AP status, and throughput in Kbps.

Name:	[REDACTED]
AP Model:	FAP433G
AP MAC:	[REDACTED]
Throughput (Kbps):	0

Right click on AP icon for details

To view AP and Station details in any of the heat maps, right-click an AP icon and click **Show Details**

- **AP Details:** AP ID, AP Name, AP MAC Address, AP IP Address, Controller, Total Stations.
- **Station Details:** MAC Address, IP Address, Last Known Association, User Name, Throughput, Loss%, RSSI, Airtime Utilization, L2 State, L3 State.
- To view Station Trend Dashboard, click MAC Address.

The filtering option comprises of All, 2.4 GHz [default], 5 GHz, 6 GHz and selected channels within the three bands.

AP Information at: 05/25/2023 23:16:06 ✕

AP ID: 17 AP Name: FP433G_6GHZ AP MAC: [REDACTED]

AP IP Address: [REDACTED] Controller: FGT_HW-1_AIOPS Total Stations: 1

Following are the stations Associated to the AP. Station performance parameters (such as Loss, Throughput, Airtime Utilization) are different from similar parameters of an AP.
 <Prev (1 - 1 of 1) Next>


MAC ADDRESS	IP ADDRESS	IPV6 ADDRESS	LAST KNOWN ASSOCIATION	USER NAME	THROUGHPUT (Kbps)	LOSS%	RSSI (dBm)	AIRTIME UTILIZATION (%)	L2 STATE	L3 STATE
[REDACTED]	[REDACTED]	[REDACTED]	5/24/2023 06:44:48		0	0	-29	0	None	Clear Active

🔒 CLOSE

Loss Heat Map

Loss maps show the AP loss over the represented area. The APs on the map are differentiated by using different colors to represent the corresponding AP Loss% value.


Hover over AP to view the AP information including name, AP model, MAC address, AP status, and loss %. Right click on AP icon and click **Show Details** to view detailed information.



Channel Utilization Heat Map

The Channel Utilization maps differentiate APs on the map by using different colors for the regions around APs corresponding to the AP channel utilization value.

Hover over AP to view the AP information including name, AP model, MAC address, AP status, and channel utilization (%). Right click on AP icon and click **Show Details** to view detailed information.



Number of Stations Heat Map

The Number of Stations Heat Map, represents the low signals over the area represented by the map. The Number of Stations maps differentiate APs on the map by using different colors for the regions around APs corresponding to the number of stations per AP.

Hover over AP to view the AP information including name, AP model, MAC address, AP status, and number of stations.




Signal Strength Heat Map

Signal strength heat map provides a distribution of signal quality over the floor map. The signal strength is represented in dBm and is divided into color buckets. The Signal Strength maps display the availability of signal over the area represented by the map. Select different cut-off values to view the signal coverage.

Note: The signal strength heat map allows you to view the signals of all the APs on the floor. Due to this, the FortiAI Ops displays heat map for all APs irrespective of whether the logged in user has scope for those APs or not. This enables you to capture accurate signal value for all APs located on the floor.

Hover over AP to view the AP information including name, AP model, MAC address, AP status, and signal strength.



With signal strength heat map having smooth transition in colors, the color at a given point may not exactly match with the bucket colors. For such cases, it should be interpreted as a value that is greater/lower than the nearest bucket color.


Coverage Cut Off: Coverage cutoff [default being none] can be used to see the signal coverage region within the cutoff value specified. The cutoff range is from -42dBm to -90dBm.

To view the signal strength heat map of a floor, follow these steps:

- Ensure that the APs are placed accurately through the map management feature.
- Click on **Heat maps** and select the desired floor.
- Select the RF band or relevant channel from the menu.
- Choose a cutoff of interest.
- Click on the **Refresh** icon.

Rogue APs

The Rogue APs page provides detailed information about rogue access points (APs) on the wireless network and consists of three widgets - Interfering APs, SSID, and Vendor Info.



Interfering APs

The Interfering APs widget displays the number of rogue APs detected by each managed FortiAP unit or FortiWiFi local radio.

SSID

The SSID widget displays the number of SSID names detected as rogue APs.

Vendor Info

The Vendor Info widget displays the vendor information for each rogue AP detected on the network.

The Rogue AP list provides detailed information about each rogue AP detected on the network, including the MAC address, SSID, state, signal interference, and vendor information.

Map Management

Map management allows you to create visual representations of your access points (APs) to accurately represent the physical layout of a site. For best results, create separate maps for each floor in multi-level buildings, and use accurate architectural drawings as a basis for your images. Crop each floor map to remove extra space and save it as a PNG, JPEG, BMP, or GIF file no larger than 2MB before adding it to FortiAI Ops.

Note: Provide a unique name to the site/building/floor plan. Do not use the same name across different device groups.

To set up a working map, you'll need to complete several tasks:

- Import a graphic map of the floor. See [Importing a Map Image](#).
- Add a new site to FortiAI Ops. See [Add a Campus, Building, and Floor to the Map](#).
- Add a building.
- Add a floor.
- Place AP icons on the map to represent the WLAN network topology. See [Add APs, Floor APs, and Landmarks to Maps](#).
- View the map. See [Viewing Maps](#).

Importing a Map Image

Follow these steps to import a topology map:

1. Navigate to **Wireless > Map Management**.
2. Select a floor.
3. Click Change Image in the Floor Map section.
4. Select Image Type as Floor and Operation as Upload. Select the Image File by using the browse tab and click on Upload.


Next, add controllers and APs to the map.

Importing a Floor Map

FortiAIOps supports importing a floor map plan created on and exported from the FortiPlanner. Once the floor plan is created in the FortiPlanner, select Export in the project menu. The floor map to be imported is a .zip file.

Note: Only exported .zip files from the FortiPlanner can be imported. Contact the Customer Support to obtain the relevant version of the FortiPlanner. For more information on creating floor plans on the FortiPlanner, see the *FortiPlanner User Guide*.

1. Navigate to **Wireless>Map Management** page.
2. Click **Import**, the Import Map Plan screen is displayed.



3. Browse to the .zip file on your system and click **Next**. A summary of map information is displayed.
4. Map the unassigned APs and click **Finish**.
5. The planner for each site is displayed. On the **Map Management** screen, you can add and delete floors in the map and manage the APs on each floor of the site.

In case of errors importing the map, click View Latest Import Planner logs, to view the error logs.

You can perform the following operations on each floor:

- **Add APs** - Select the APs to be added to the floor map.
- **Floor APs** - Select the APs to be deleted from the floor map.
- **Landmarks** - Add or delete landmarks on the floor map.
- **Change Image** - Upload a new image or delete an existing image from the floor map.

Click **Save** to save changes to the map

Adding a Site, Building, and Floor to the Map

To create a new location (site, building, floor) in the enterprise, follow these steps:

1. Navigate to **Wireless > Map Management** page. All current maps are displayed on the Map Management page.
2. To add a new site, click on the **Site Details** section and then click on **Add**. A new site can only be added to the top level, Enterprise, which is the default.

SITE DETAILS (1) (NOT SAVED)		
+ ADD DELETE		
SITE (1 - 50 CHARS)	DESCRIPTION (0 - 250 CHARS)	SORT ORDER (0 - 99)
<input type="checkbox"/> Site_1		0

- Provide a name, description, and sort order for the site.
- Click **Save Changes**.
- In the left pane, double-click on the name of the new site you just created.
- Click on the Buildings icon. In the Building Details pop-up, click **Add**.

Manage Site Buildings ⊗		
Building Details (1)		
+ ADD DELETE		
BUILDING (1 - 50 CHARS)	DESCRIPTION (0 - 250 CHARS)	SORT ORDER (0 - 99)
<input type="checkbox"/> Building_1		0

- Provide a name, description, and sort order for the building.
- Click **Save Changes**.
- In the left pane, double-click on the name of the new building you just created.
- In the Floor Details section, click **Add**.


FLOOR DETAILS (1) (NOT SAVED)				
+ ADD DELETE				
FLOOR (1 - 50 CHARS)	LENGTH ↔ X-AXIS (1 - 1500)	WIDTH ↕ Y-AXIS (1 - 1500)	METRIC	SORT ORDER (0 - 99)
<input type="checkbox"/> Floor_1			Feet ▾	0

- Provide a floor name, length, width, metric, and sort order for the floor.
- Click **Save Changes**.

Adding APs, Floor APs, and Landmarks to Maps

To create the network map of your site, follow these steps:

- Once a map image has been imported, add the APs to the map as close as possible to their actual physical location.
- Select a floor by its heading in the left column to see a map of the floor. If the floor does not have a corresponding map, complete the steps to Import a Map Image.
- Optionally, alter the map using the options Show Map and Show Scale in the Image Map section.
- Click **Add APs** and select the APs to add from the drop-down list on the AP selection pop-up, then click **Save**. Drag the selected APs into position on the map.



5. To add landmarks to the map, click Landmarks > Add.
6. Once you have finished making changes, click **Save Changes**.

Editing AP Details

To edit the details of an access point (AP), follow these steps:

1. In the Map Management screen, click **APs** to display the AP list.
2. Select the AP you want to edit by clicking on its icon on the map or by selecting it from the AP list.
3. Click **Edit** to open the AP details window.
4. Edit the required fields, such as the AP name or its location coordinates.
5. Click **Save** to save the changes made to the AP details.
6. Click **Cancel** to discard any changes and close the AP details window.

Viewing Maps

You can view the placement of APs on a map or view Heat Maps that show the following five attributes of those APs:

- Throughput
- Loss
- Channel Utilization
- Number of Stations
- Signal Strength


Heat map coloring depends on the distance between APs and selected attribute (throughput, loss, channel utilization, or stations) for all the APs on the floor. If there is only one AP on the floor, the entire floor will show the same coverage. See [Heat Maps](#).

To view maps and heat maps, follow these steps:

1. Click on **Wireless > Heat Maps**.
2. Select a floor to display the map.
3. Optionally, alter the map using the options Floor Visibility or Show Heat Map.
4. To limit the map, click Select Channels, select channels, and then click **Save Changes**.
5. After any changes, click on the Refresh icon.

RF Planner

The RF planner is a tool that enables you to plan for new access points, areas, and obstacles (walls, shafts, etc.). It allows you to place APs and draw walls or columns in both View and Edit modes.



To use the RF planner, follow these steps:

1. Navigate to Map Management > RF Planner.
2. Add the required access points to the floor map and generate a heat map to predict the expected signal strength throughout the coverage area.
3. Adjust the placement of your APs based on the predicted signal strength and try out different placements for the APs before installing them.
4. Draw a floor plan of the coverage area and place the APs on your floor plan.
5. Run heat maps to predict the signal strength.

View Mode: In View mode, the floor map displays the coverage pattern, data rate, channel, and signal strength of the access points. You can select the 2.4GHz, 5GHz, or 6GHz frequency to view the access point details.

Edit Mode: In Edit mode, you can add or edit new access points. To do this, drag the required access point from the "Add APs" panel and place it on the floor map. Right-click on an access point and edit its configuration, such as the access point transmission power in dBm, channel, orientation, placement direction (in angles), ceiling, wall, and desk.

To draw walls and columns on the floor map, use the provided widgets. Select the required widget and draw the wall or column on the map. A column is a closed drawing with four walls, while a wall is demarcated as lines.

Right-click on the created walls and columns to specify the composition or material used to construct them. Each material has a different attenuation value.


Switch

This section describes the FortiSwitch statistics and the FortiSwitch client details.

- [FortiSwitch](#)
- [FortiSwitch Clients](#)


FortiSwitch

You can monitor the FortiSwitches in your network that are in the purview of FortiAIOps. This page displays a graphical snapshot of the FortiSwitch activity such as, the total number of FortiSwitches, their status (online/offline/unauthorized), and the deployed model details.



Diagnostics and Tools

To view the FortiSwitch statistics and diagnostics in detail, select a row and click **View Details**. The **Status** including the FortiSwitch face plate, hardware summary, general status and statistics, and configuration details is displayed.



- [Ports](#)
- [Cable Test](#)
- [Logs](#)

- [Statistics](#)
- [Clients](#)

Ports

This tab displays each port details of the specific FortiSwitch unit.

Port	Trunk	Mode	Port Policy	Enabled Features	Native VLAN	Allowed VLANs	Dynamic VL
 1	msc	Static		<ul style="list-style-type: none"> ✔ Spanning Tree Protocol ✔ Edge Port 	⌵ VLAN100	⌵	
 2		Static		<ul style="list-style-type: none"> ✔ Spanning Tree Protocol ✔ Edge Port 	⌵ VLAN100	⌵ quarantine	
 3	port40	Static		<ul style="list-style-type: none"> ✔ Spanning Tree Protocol 	⌵ VLAN100	⌵	

Each entry in the port list displays the following information.

Parameter	Description
Port	The name of the port (red for port down, green for port up)
Trunk	The associated trunk that the port is a member of.
Mode	The configured access mode of the port.
Port Policy	The configured port policy.
Enabled Features	The features enabled on the port.
Native VLAN	The native VLAN assigned to the port.
Allowed VLANs	The allowed VLANs set for the port.
Dynamic VLAN	The dynamic VLAN assigned to the port.
DHCP Snooping	The status of DHCP snooping status
Transceiver	The transceiver information.
Description	The port description
LLDP Profile	The associated LLDP profile.
Loop Guard	The status of the Loop Guard (enabled/disabled)
QoS Policy	The assigned QoS policy.
Security Policy	The assigned security policy.
STP	The status of STP (enabled/disabled).
STP BPDU	The status of STP BPDU Guard (enabled/disabled).
STP Root Guard	The status of STP Root Guard (enabled/disabled).

Cable Test

This is a diagnostic and troubleshooting tool to check the state of cables between the FortiSwitch and the devices connected to its physical ports. This tool does not work on fiber ports and on very short or very long cables (more than 100 meters).

All available external physical ports of the FortiSwitch are displayed. Select one or more ports and click **Diagnose**.

Ports	Error Range	Pair A	Pair B	Pair C	Pair D
port1	+/- 10 meters	Ok / 4 meters	Ok / 2 meters	Ok / 2 meters	Ok / 2 meters

Note: Running the cable diagnostic test on a port disables it briefly. The network traffic is affected for a few seconds.

Logs


This tab displays the FortiSwitch log messages and the associated details.

Date/Time	Level	Message	Log Description	Fortigate Serialnumber	FortiSw
36 seconds ago	Info	primary port port19 instance 0 changed ...	FortiSwitch spanning Tree	FG140E1813P0001	S524I
38 seconds ago	Info	primary port port19 instance 0 changed ...	FortiSwitch spanning Tree	FG140E1813P0001	S524I
38 seconds ago	Info	primary switch port port19 has come up	FortiSwitch link	FG140E1813P0001	S524I
1 minute ago	Info	primary port port23 instance 0 changed ...	FortiSwitch spanning Tree	FG140E1813P0001	S524I

Each log entry displays the following information.

Parameter	Description
Date/Time	The Date/time of log event generation.
Level	The log severity level. <ul style="list-style-type: none"> Emergency, Critical (red) Alert (orange) Error, Warning (blue) Notice, Information, Debug (green)
Message	The event log message that is generated.
Log Description	The description of the event log.
FortiGate Serial Number	The serial number of the associated FortiGate controller.
FortiSwitch Serial Number	The serial number of the associated FortiSwitch.
Relative Date/Time	The time lapsed since the event log was generated.
Source	The event source IP/MAC address.

Select a log message and click **Details** to view specific related information. This view provides the following information.



- **General** - Generic information about the log event such as, the date and time of event logging, the associated virtual domain, and the log description.
- **Source** - The details of the user.
- **Message** - The generated log message.
- **Security** - The severity level of the log event.
- **Cellular** - The serial number of the FortiSwitch.
- **Other** - Generic information such as the log event time stamp, the timezone, log type, and so on.

Statistics

This tab displays the FortiSwitch and the associated port statistics.

Ports Switch

View Trends Search


Port	TX Bytes	TX Packets	TX Unicast	TX Multicast	TX Broadcast	TX Errors
internal	1.62 GB	618,772,760	618,772,760	0	0	0
port1	3.56 GB	9,955,125	5,103,792	2,643,865	2,207,468	0
port2	215.61 MB	748,903	73,070	313,059	362,774	0

The **Ports** view provides the following information.


Parameter	Description
TX Bytes	The transmitted bytes.
TX Packets	The transmitted packets.
TX Unicast	The transmitted unicast packets.
TX Multicast	The transmitted multicast packets.
TX Broadcast	The transmitted broadcast packets.
TX Errors	The errors in transmitted packets.

Parameter	Description
TX Drops	The dropped packets in transmitted packets.
TX Oversize	The oversized packets in transmitted packets.
RX Bytes	The received bytes.
RX Packets	The received packets.
RX Unicast	The received unicast packets.
RX Broadcast	The received broadcast packets.
RX Errors	The errors in received packets.
RX Drops	The dropped packets in received packets.
RX Oversize	The oversized packets in received packets.
Undersize	The number of undersized packets.
Fragments	The number of fragments.
Jabbers	The number of jabbers.
Collisions	The number of packet collisions.
CRC Alignments	The number of CRC/alignment errors.
L3 Packets	The number of layer-3 packets.

Select a particular port and click **View Trends** to view a graphical representation of the trends in FortiSwitch statistics over a period of time.



The **Switch** view provides a graphical representation of the trends in FortiSwitch statistics over a period of time.




Clients

This tab displays the details of the FortiSwitch clients. The following information is displayed.

Parameter	Description
Device	The client device name.
Port	The associated port details.
VLAN	The associated VLAN details.
Software OS	The client device software OS.
Hardware	The client device hardware details.

FortiSwitch Clients

You can monitor the FortiSwitch clients associated with the FortiSwitches deployed in your network. This page displays a graphical snapshot of client activity such as, the total number of FortiSwitch clients, their status (online/offline), the client device details, and the associated VLANs. Hovering over the charts provides specific statistics and clicking on a specific area on the chart filters the data displayed on this page.



The table beneath the chart displays the client details.

Parameter	Description
Device	The name of the client device.
FortiSwitch	The host name or serial number of the FortiSwitch that the client is associated with.
Port	The associated port details of the FortiSwitch unit.
VLAN	The type of the VLAN.
Software OS	The software OS used by the client device.
Hardware	The hardware used by the client device.
Status	The status of the client (online/offline).
Last Seen	The time that the client was last seen online.
IP Address	The IP address of the client.
EMS Serial Number	The FortiClient EMS serial number.
EMS Tenant ID	The FortiClient EMS tenant ID.
Endpoint Tags	The endpoint (client) tags monitored by FortiGate.

Security Fabric

The Security Fabric page represents the topology, that illustrates the logical placement of the wireless service and the physical placement of hardware devices. The hardware devices include FortiGates, APs, and wireless clients in your network.

Note: The physical and logical topologies provide wireless client information.

- [Physical Topology](#)
- [Logical Topology](#)

Physical Topology

The physical topology provides a visualization/illustration of the physical placement of devices, such as, FortiGate controllers, APs, and clients connected to each radio in your network, in an hierarchical pattern. The physical topology is representational; you cannot modify the placement of devices on this page.

You can filter and view selective devices in the topology chart, the filter options available are FortiGate controllers (**Devices**), FortiAPs (**APs**), and device OS. You can also enable viewing of online devices only, in the topology (**Show online devices**). To apply the filter settings, click **Apply Filter**.

Physical Topology Filters
✕


Select Devices	<div style="border: 1px solid #ccc; padding: 2px;">2FLB2</div> <div style="text-align: center; margin-top: 5px;">+</div>	✕
Select APs	<div style="border: 1px solid #ccc; padding: 2px;">PS223E: [REDACTED]</div> <div style="border: 1px solid #ccc; padding: 2px; margin-top: 2px;">PS423E: [REDACTED]</div> <div style="text-align: center; margin-top: 5px;">+</div>	✕ ✕
Select OS	<div style="border: 1px solid #ccc; padding: 2px;">Android12</div> <div style="border: 1px solid #ccc; padding: 2px; margin-top: 2px;">Windows</div> <div style="text-align: center; margin-top: 5px;">+</div>	✕ ✕

Show online devices

The devices/OS set in the applied filters are also displayed at the top of the topology page, hover over each of these to view the complete list.

Access Points : FP321E!
FP431FTF200...
Devices : 2FLB2, HA-Primary
OS : Android12, Windows
Online devices : Yes

The collapsible/expandable hierarchy of devices in the physical topology is **FortiGate~ FortiAP ~ radio ~ client**; each of the devices displayed is click-able to display the next level of hierarchy.



Hover over the device name to obtain additional information. The status of the FortiGate controllers and APs is marked using a color legend.

- *Green*: Online and active
- *Red*: Offline

Logical Topology

The logical topology provides a visualization/illustration of the logical placement of the configured wireless service, the associated ESS pushed through the wireless service, VLAN (if applicable), and the stations connected to each ESS in a hierarchical pattern. The logical topology is representational; you cannot perform any operations on this page.

You can filter and view selective entities, the filter options available are ESS and VLANs. To apply the filter settings, click **Apply Filter**.

Logical Topology Filters

Select ESS

+


Select VLANs

+

The ESS and VLANs set in the applied filters are also displayed at the top of the topology page, hover over each of these to view the complete list.

ESS : Load-ssid VLANS : All

The collapsible/expandable hierarchy of entities in the logical topology is wireless service ~ **ESS** ~ **VLAN** ~ **client**; each of the entities displayed is click-able to display the next level of hierarchy.



Note: The physical and logical network topology views differ based on the browser.


Logs and Reports

This section describes the WiFi and FortiSwitch event logs and the generation of the FortiAIOps reports.

- [Event Logs](#)
- [Reports](#)

Event Logs

The FortiAIOps provides a robust logging environment that enables you to monitor, store, and report WiFi events and FortiSwitch events. The **Summary** tab displays the top five most frequent events in each type of event log along with the severity level and the total count. A line chart displays aggregated events by each severity level. Clicking on a peak in the line chart displays the specific event count for the selected severity level. Clicking on any event type title opens the **Details** page for that event type filtered by the selected time span. You can select the time frame to view the logs from the top-right corner of the GUI.



The **Details** tab displays individual, detailed log views for event type. By default, all event details are displayed on this page, you can filter the **WiFi Events** or **FortiSwitch Events** data on this page.

Summary Details

Search WiFi Events Details 5 minutes

Date/Time	Level	Action	Message	SSID	Station MAC
2023/04/11 11:56:24	Notice	rogue-ap-detected	AP Syed Zabi 66:cd:7f:c1:1b:06 chan 4 live...	Syed Zabi	N/A
2023/04/11 11:56:23	Error	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-Peap-3F	7c:50:79:b7:1c
2023/04/11 11:56:23	Error	DNS-no-domain	DNS lookup of wpad.fortinet-us.com from ...	Forti-Corp-Peap-3F	7c:50:79:b7:1c
2023/04/11 11:56:21	Notice	DHCP-ACK	DHCP ACK for IP 10.32.96.75 from server ...	Forti-Corp-NAC-Peap-4F	38:7a:0e:03:6e
2023/04/11 11:56:21	Notice	DHCP-REQUEST	DHCP REQUEST for IP 10.32.96.75 from c...	Forti-Corp-NAC-Peap-4F	38:7a:0e:03:6e
2023/04/11 11:56:21	Notice	client-authentication	Client 38:7a:0e:03:6a:97 authenticated.	Forti-Corp-NAC-Peap-4F	38:7a:0e:03:6e

The following log details are displayed for each event.

Parameter	Description
Date/Time	The Date/time of log event generation.
Level	The log severity level. <ul style="list-style-type: none"> • Emergency, Critical (red) • Alert (orange) • Error, Warning (blue) • Notice, Information, Debug (green)
Action	The action leading to the event generation.
Message	The event log message that is generated.
SSID	The SSID that the client connected to.
Station MAC	The client MAC address.
Log ID	A unique identifier assigned to the event log.
FortiGate Serial Number	The serial number of the associated FortiGate controller.
AP Serial Number	The serial number of the access point that the client associated with.
Relative Date/Time	The time lapsed since the event log was generated.
Channel	The channel associated with the access point.
FortiSwitch Serial Number	The serial number of the associated FortiSwitch.
Log Description	The description of the event log.
Source	The event source IP/MAC address.
User	The user name/details.

Select a log message and click **Details** to view specific related information. This view provides the following information.



- **General** - Generic information about the log event such as, the date and time of event logging, the associated virtual domain, and the log description.
- **Source** - The details of the log event source such as, MAC address, interface, SSID, and user details.
- **Action** - The action leading to the event log and the reason.

- **Security** - The severity of the log event, the configured security mode, and the encryption type.
 - **Cellular** - The serial number of the associated access point.
 - **Event** - The serial number of the access point and the generated log message.
 - **Other** - Generic information such as the log event time stamp, the timezone, log type, and so on.\
- Click on a specific FortiSwitch event to view the details.

Summary		Details			
Date/Time	Level	Message	Log Description	FortiGate Serial Number	FortiSwitch
2023/10/16 16:33:25	■ ■ ■ ■ ■ ■ ■ ■	error:0A000126:SSL routines::unexpected...	FortiSwitch system	FC344E381F98881	S224DF3X1
2023/10/16 16:33:25	■ ■ ■ ■ ■ ■ ■ ■	error:0A000126:SSL routines::unexpected...	FortiSwitch system	FC344E381F98881	S548DF501

Reports

You can create and view multiple report categories and types on FortiAI Ops. Each report displays specific data based on the configurations and can be viewed or downloaded in multiple formats.

- [Creating Reports](#)
- [Viewing Reports](#)
- [Scheduled Reports](#)
- [PCI Reports](#)

Creating Reports

FortiAI Ops allows you to define new reports and generate one-time reports. You can select and combine multiple report categories and the subsequent report types (maximum 5) to generate a single report instead of generating multiple reports for each category. These are saved as *Report Templates* and can be scheduled similar to other reports.

Basic Information

This section allows you to choose a **Category** of report, **Report Type**, provide a **Name** and **Report Title**.

BASIC INFORMATION

<p>Category</p> <div style="border: 1px solid #ccc; padding: 5px; display: flex; flex-wrap: wrap;"> × Station Reports × AP Reports × Inventory Reports × Service Reports × Application Visibility </div>	<p>Report Type</p> <div style="border: 1px solid #ccc; padding: 5px; display: flex; flex-wrap: wrap;"> × Application Visibility × Station RF and Channel Distribution × Access Point Inventory × Service Usage Summary × Rogue Details </div> <p style="text-align: right;">Sample Reports</p>
<p>Name</p> <input type="text" value="Report Template"/> <small>[0-256] chars.</small>	<p>Report Title</p> <input type="text" value="FortiAI Ops"/> <small>[0-256] chars.</small>
<p>Rogue MAC</p> <input type="text"/> Select	

The following categories of reports are supported.

- [Station Reports](#)
- [AP Reports](#)
- [Inventory Reports](#)

- [Service Reports](#)
- [Application Visibility Reports](#)

Station Reports

The following types of station reports are supported.

Category	Description
Station RF and Channel Distribution	<p>Provides the station RF and channel distribution based on the OUI (Organizationally Unique Identifier). A graphical summary of the stations distributed by RF type, stations distributed across 2.4GHz and 5GHz bands and station density on each channel over time is displayed. The following details are displayed.</p> <ul style="list-style-type: none"> • Graphs - The graphs are of the following types. <ul style="list-style-type: none"> • <i>Station Density on each Channel Over Time</i> - This graph displays the station density on each of the channels over time plotted against the time in weeks. • <i>Station Distribution Across 2.4 GHz, 5GHz, and 6GHz Bands</i> - This graph displays the station distribution based on the 2.4GHz, 5GHz, and 6GHz. • <i>Station Distribution by RF Type</i> - This graph displays the station distribution based on the RF Type. • Station RF and Channel Distribution Details - This section provides each station's OUI, Date/Time (GMT), Station MAC, RF Type, AP Name, AP Radio, SSID and Channel.
Station Session Details	<p>Provides the average station session trend details. A graphical summary of the station session trend details of throughput, loss, airtime utilization and noise for a connected station is displayed. The following details are displayed.</p> <ul style="list-style-type: none"> • Graphs - The three types of <i>Station Session Details</i> graphs are displayed as follows. <ul style="list-style-type: none"> • <i>Trend On Throughput</i> - This graph displays the trend of Throughput for the selected station. • <i>Trend On Loss</i> - This graph displays the trend of Loss for the selected station. • <i>Trend On Airtime Utilization</i> - This graph displays the trend of Airtime Utilization for the selected station. • Station Session Details - This section provides each station's Date/Time, IP4 Address, IP6 Address, Controller, AP ID, SSID, User, Throughput (Kbps), Loss%, Airtime Utilization% and AP Name.
Top Stations	<p>The <i>Top Stations</i> report type generates reports for the busiest stations based on the <i>Throughput</i> and <i>Airtime Utilization</i>. This report type generates the top N stations based on the number of bytes transferred and received and total Rx/Tx. The information includes each station's Station Mac, Controller, AP Id, SSID, Throughput (Kbps) and Date/Time (GMT).</p>

Category	Description
Unique Stations	<p>Provides the unique station details based on all stations connected to a network within the reporting interval. A graphical summary of the stations distributed by RF type, stations distributed across 2.4GHz, 5GHz, and 6GHz bands, stations distributed by OUI, stations distributed by device type, and stations distributed by OS type is displayed. The <i>Unique Station</i> reports are available to all groups and list stations connected to network during last 24 hours. The following details are displayed.</p> <ul style="list-style-type: none"> • Summary - This section provides the total number of Unique Stations. • Graphs - The graphs are of the following types. <ul style="list-style-type: none"> • <i>Finger Print OS Distribution</i> - This graph displays the station distribution based on the OS Type. • <i>Finger Print Device Distribution</i> - This graph displays the station distribution based on the Device Type. • <i>OUI Distribution</i> - This graph displays the station distribution based on the OUI. • <i>Station Distribution</i> - This graph displays the station distribution based on the RF Type. • Unique Station Details - This section provides the station's OUI, Date/Time (CST), Station MAC, User, IPv4 Address, IPv6 Address, RF Type, SSID, Device Type, OS Type and Floor.
EAP-AKA Error	<p>The EAP-AKA Error type generates a report with details of EAP-AKA errors associated with specific ESSIDs and on specific stations connected to network within the reporting interval. The following details are displayed.</p> <ul style="list-style-type: none"> • User selected Top 5 EAP-AKA Errors - The top 5 most common EAP-AKA errors with the number of stations the errors were reported on and the number of EAP authentication failures for each station. • User selected Top 5 Station by Errors - The top 5 stations (MAC addresses) with highest EAP-AKA errors reported and the number of EAP authentication failures for each station. • EAP-AKA Errors - The list of EAP-AKA errors within the reporting interval. The details displayed are, date and time of the error, associated controller, access point, station MAC address, and the ESSID, and the error description/reason.

AP Reports

The following types of AP reports are supported.

Category	Description
Rogue Details	<p>The <i>Rogue Details</i> report type generates the report on the individual rogue. It displays the rogue mobility trend. The trend is plotted against time and APs detecting the rogue. The data displayed is a Max of hourly data sample. The following details are displayed.</p> <ul style="list-style-type: none"> • Summary - This section provides the details of the selected rogue

Category	Description
	<ul style="list-style-type: none"> Rogue Mobility Trend graph - Trend is plotted against AP which detects rogues with high strength and its time as samples. Rogue Details - This section provides details about the APs detecting the rogue along with Date/Time, Controller, AP Detecting Rogue, AP Location, SSID, Channel and RSSI.
Rogue Summary	<p>Summarizes the rogue device information on the trend of the number of rogues reported on a per controller basis, per hour. The rogue APs and rogue station count is displayed. A graphical summary of the trend on rogue AP, trend on rogue station, and trend on controllers is displayed. The following details are displayed.</p> <ul style="list-style-type: none"> Summary - This section provides the details of the total number of rogues. Graph - The graphs are of the following types. <ul style="list-style-type: none"> <i>Rogue Trend By Type</i> - The two types of <i>Rogue Trend By Type</i> graphs are displayed as follows. <ul style="list-style-type: none"> <i>Trend on Rogue Station</i> - This graph displays the trend type based on the number of rogue Stations. <i>Trend On Rogue AP</i> - This graph displays the trend type based on the number of rogue APs. <i>Rogue Trend By Controllers</i> - This graph displays the top 10 controllers with the highest number of rogues. New Rogues Detected During Reporting Interval - This section provides the details of the new rogues detected during reporting interval. The details are Date/Time, Controller, AP Detecting Rogue, AP Location, Rogue MAC, Rogue Type and Channel RSSI.
Top Radio	<p>The Top Radio report type generates a report displaying all the Top N Radios based on Station Count, Throughput, and High Loss. The top radio report type displays the AP Name, Radio, Controller Name, AP Location, Station and Date/Time (GMT).</p>

Inventory Reports

The following types of inventory reports are supported.

Category	Description
Access Points Inventory	<p>This report type generates the AP inventory summary reports for any access points that are accessible. The following details are displayed.</p> <ul style="list-style-type: none"> Summary - This section provides the total number of Access Points. AP Model Distribution graph - This provides the pictorial representation of the distribution of Access Points. AP Inventory Summary - This section provides the details of Access Point Inventory. The details are Name, Mac address, Model, Software Version, IP Address, Controller, Availability State, Connectivity Preference and Floor.

Category	Description
Controller Inventory	<p>Lists and tracks all the controllers, with its model and software versions on the network.</p> <ul style="list-style-type: none"> • Summary - This section provides the total number of Controllers. • Graph - The graphs are of the following types. <ul style="list-style-type: none"> • <i>Controller Software Version Distribution</i> - This graph displays the Controllers based on the controller software version distribution. • <i>Controller Model Distribution</i> - This graph displays the Controllers based on the controller model distribution. • Controller Inventory Summary - This section provides the details of Controller Inventory. The details are Hostname, IP Address, Mac address, Node Name, Software Version, Model, Description, Availability State, Management State and Location.
Device Availability	<p>Lists all the controllers and access points with its availability, uptime and down time of each of them. This report generates the report for each Controller and AP. It displays the Device Name, UP Duration, Down Duration time and Availability(%) for the AP and Controller.</p>

Service Reports

The following types of service reports are supported.

Category	Description
Service Usage Summary	<p>Provides the service usage summary based on the ESSIDs. A graphical summary of the top SSIDs based on throughput and number of stations is displayed.</p> <ul style="list-style-type: none"> • Graph - The graphs are of the following types. <ul style="list-style-type: none"> • <i>Top SSIDs Based on Throughput</i> - This graph displays the top SSIDs based on the throughput. • <i>Top SSIDs Based on Number Stations</i> - This graph displays the top SSIDs based on number of stations. • Network Usage Summary - The Network Usage Summary displays the ESSID, Average Station Count, Max Station Count, Time When Max Station Occurred, Total Unique Stations and Maximum Throughput are displayed.
Service Usage Trend	<p>Provides the service usage trends based on the ESSIDs. A graphical summary of the top SSIDs based on throughput and number of stations is displayed.</p> <ul style="list-style-type: none"> • Server Usage Trend graphs - These are displayed with a trend of Max, Minimum and Average stations connected and stations throughput on hourly basis during reporting interval. This is a graphical report represented with a line chart having two lines, one for Max and second one for Average station count. • Service Usage Trend Details - The service usage trend report type displays Date/Time (GMT), Max Stations Connected, Min Stations Connected, Avg Stations Connected and Throughput (Kbps).

Application Visibility Reports

The application visibility reports provide the following information.

Category	Description
Application Visibility	<p>This report provides the top 10 applications and the top 10 users in your network which allows you to monitor application usage.</p> <ul style="list-style-type: none"> • Top 10 applications graph - For each application, it provides total number of connected users, ESSIDs and traffic utilization. • Top 10 users graph - For each of the user, it displays the client MAC address, applications connected by the client, ESSIDs and traffic utilization.

Scope

This section allows you to define the scope of a report by performing the device selection followed by the service (SSID) selection.

SCOPE

Device Selection

Default Devices AP

Select

Service (SSID) Selection

423_test_fgt

Select Remove

Update the following fields as per your requirement.

- **Default** - By choosing default, report is generated for all the controllers mapped to the FortiAI Ops.
- **Devices** - Select one of multiple FortiGate controllers.
- **AP** - Select one or multiple access points.

Reporting Interval

These fields depict the time period to be covered by the selected report. These fields are supported for most report types. When these fields do not appear, the report considers the current status. Select the **Schedule** option of the **Recurrence** section, the following options in the *Reporting Interval* section is enabled.

REPORTING INTERVAL

Last One Day Last One Week Last One Month

- **Last one day** - The last one day's report is generated.
- **Last one week** - The last one week's report is generated.
- **Last one month** - The last one month's report is generated.

Recurrence

This section allows you to select the time of report recurrence. Select the **Schedule** option and the following get enabled.

RECURRENCE

One Time Schedule

Time

Daily

Weekly Every

Monthly Every *Day of Month [2-28]*

- **One Time** - Instant report is generated for the selected reporting interval.
- **Schedule** - This option allows you to define a specific time for report creation. These schedule fields establish the time that a report runs, independent of the **Scope** and **Reporting Interval**.
- **Daily** - This option allows you to generate daily reports.
- **Weekly** - This option allows you to generate weekly reports, select this option followed by selecting the day of the report generation from the **Every** drop-down list.
- **Monthly** - This option allows you to generate monthly reports, select this option and enter the day of month; 1-31 is the valid range.

Report Generation Options

You can save the generated reports in any of the following formats and email the generated reports to the specified address.

REPORT GENERATION OPTIONS

File Format HTML PDF CSV

Email To:

Customize

- **File Format** - Choose one of the following formats.
 - **HTML** - Select the HTML option to export and save the report to HTML format. The generated report is saved with the naming convention, *<report type>_report_datetime.html*.
 - **PDF** - Select the PDF option to export and save the report to PDF format. The generated report is saved with the naming convention, *<report type>_report_datetime.pdf*.

- **CSV** - Select the CSV option to export and save the report to CSV format. The generated report is saved with the naming convention, *<report type>_report_datetime.csv*.
- **Limit Report Size To** - This option is applicable only to the *Top Stations, Top Radio, Device Availability,* and *Application Visibility* reports. The maximum report size for the *Application Visibility* report is 100.

Viewing Reports

This screen displays a list of all the reports that are generated. These reports can be generated in HTML, CSV, or PDF format. They can be viewed, printed or saved locally.

REFRESH DELETE							
REPORT TYPE	NAME	CREATION TIME	FILE FORMAT	STATUS	SIZE(KB)	ACTIONS	
<input type="checkbox"/>	Template	Report Template	11 Apr 2023 13:21:15	HTML	Completed	349	
<input type="checkbox"/>	Template	Report Template	11 Apr 2023 13:19:53	HTML	Completed	351	
<input type="checkbox"/>	Template	Report Template	11 Apr 2023 13:18:05	HTML	Completed	350	
<input type="checkbox"/>	Station RF and Channel Distribution Details	Station RF and Channel Distribution Details	11 Apr 2023 12:21:57	HTML	Completed	348	
<input type="checkbox"/>	Station RF and Channel Distribution	Station RF and Channel Distribution	11 Apr 2023 12:21:30	HTML	Completed	348	

Scheduled Reports

This page displays a list of current running reports and reports scheduled to run in the future. In case of recurring reports, the next run time is displayed. To create a new report, click **Add**.

REFRESH ADD EDIT DELETE					
REPORT TYPE	NAME	SCHEDULE	LAST RUN	NEXT RUN	
<input checked="" type="checkbox"/>	Template	Report Template	Daily At 00:00	29 May 2023 00:15:00	30 May 2023 00:00:00

PCI Reports

You can validate FortiAIOps against specific PCI requirement compliance. To run a compliance test, enable **Run PCI Test**. Select the tests to validate FortiAIOps and click **Run Test**.

PCI REQ ?

Run PCI Test

Requirement	Compliance
Immediately revoke access for any terminated users.	<input checked="" type="checkbox"/>
Remove/disable inactive user accounts within 90 days.	<input checked="" type="checkbox"/>
Restrict physical access to wireless access points, gateways, handheld devices, networking/communications hardware, and telecommunication lines.	<input checked="" type="checkbox"/>

After the test is successfully completed, the page is refreshed to show the list of PCI requirements that are validated. The validation results are marked with green ticks if they are fully validated and in red if the compliance is not validated or fails. Click **Download PDF Report** to get a copy of the validation results in PDF format.

PCI REQ

Run PCI Test

PCI TEST REPORTS

Show 10 entries Search:

REQID	Validated Items	FortiAIOps Validation
<input type="button" value="Search REC"/>	<input style="width: 90%;" type="text" value="Search Validated Items"/>	
2.1.1	For wireless environments connected to the cardholder data environment or transmitting cardholder data, change ALL wireless vendor defaults at installation, including but not limited to default wireless encryption keys, passwords, and SNMP community strings.	✔
2.3	Encrypt all non-console administrative access using strong cryptography. Use technologies such as SSH, VPN, or TLS for web-based management and other non-console administrative access.	✔
4.1	Use strong cryptography and security protocols (for example, TLS, IPSEC, SSH, etc.) to safeguard sensitive cardholder data during transmission over open, public networks, including the following: Only trusted keys and certificates are accepted. The protocol in use only supports secure versions or configurations. The encryption strength is appropriate for the encryption methodology in use.	✔

System

The System section includes several pages that offer valuable insights into various aspects of system management, such as users, user groups, backup and restore, maintenance, licensing, and location services.

- [User Management](#)
- [Backup and Restore](#)
- [Settings](#)
- [Licensing](#)
- [Location Services](#)
- [Certificates](#)

User Management

The User Management in the System allows you to view the users and configure user groups and provide the access permissions.

- [Users](#)
- [User Groups](#)

Users

The FortiAIOps allows administrators to create users, who will subsequently be available in the FortiAIOps application.

User permissions are indirectly assigned through their membership in user groups. By default, all users are members of the *Default* user group. The *admin* user and all device groups are automatically members of the *Super User* user group, and cannot be moved to any other user group. All users must belong to at least one user group. It is recommended to assign both the device group and users to the user group upon its creation to ensure that users have access to the assigned device group. If a user is removed from a user group, they will be moved to the *Default* user group.

Note: User Management configuration can only be performed by users with the *System Administrator* and *Super User* roles.

Full name ⇅	Role ⇅	Status ⇅
admin	System Administrator	✓ Active
guest	Guest	✓ Active

- [Adding a New User](#)
- [Editing User Information](#)
- [Activating/Deactivating User](#)

Adding a New User

Perform the following steps to add a new user:

- Click **+Add User**.
- Enter the user information including full name, username and password.
- Specify the role. FortiAIOps supports **Guest**, **Standard_User** and **Super_User** roles.

User Role	Access Level
Guest	Read only access to all features in the system.
Standard_User	Read/Write privilege to all configurations and features except system settings .
Super_User/ System Administrator	Read/Write access across system. All super users will have access to all device groups, all devices, all system settings.

- Click **Save**.

Notes:

- Once you have created users in FortiAIOps, it is necessary to refresh the FortiAIOps application portal in order for the users list to be updated and displayed in the **User Groups** page.
- The super user or system administrator can provide device group access to a user by choosing the device group and the users in the user group option in FortiAIOps application portal. See [User Groups](#).
- The user list for the FortiAIOps CLI and GUI are different.

Editing User Information

Select a user and click **Edit** to modify user information. This includes changing the user's full name, role or password.

Activating/Deactivating User

Select a user and click **Activate/Deactivate** to enable or disable the user's ability to log in or access the system. Deactivated user accounts can be reactivated at any time.

User Groups

The FortiAIOps access assigned to a user group determines what users in that user group can do.

User Group ↕	Description ↕	Users ↕	Device Groups ↕
default	Default Users group	simig	default

Adding a User Group

To add a user group, perform the following steps:

1. Navigate to User Groups.
2. Click **+ Add**.
3. Enter a name and description.

4. Select the Device Group that the users should be part of.
5. Select the Users from the list to be added.
6. Click **Create**.

Add UserGroup

- Details

Name

Description

- Others

Select Device Groups ✕

+

Select Users ✕

+

To edit an user group, select an existing user group from the list and click **Edit**.

To delete an user group, select the user group and click **Delete**.

Backup and Restore

The Backup and Restore page provides valuable tools for managing and maintaining backups of the FortiAI Ops configuration and data. This page includes options for taking, uploading, restoring, downloading, and deleting backups.

Note: This release supports the backup and restore function only for FortiAI Ops configuration. CLI configurations are saved using the `execute backup config` command and it does not include any FortiAI Ops specific configurations.

File Name	Status	Timestamp	File Size
Backup-fortiaops_v2.0.0-build0031-admin-2023-04-04-01-05-01.tar	Available	2023/04/04 06:35	50.7M

Take Backup

The Take Backup function allows you to take a backup of the FortiAI Ops configuration and data. This information can be saved as a file(.tar) and used to restore the configuration and settings at a later time.

To perform the backup operation, perform the following steps:

1. Navigate to System>Backup and Restore.
2. Click **+ Take Backup**.

3. Select Backup Option, either **Configuration only**. Backing up only the configuration includes information like maps, controller details, and AP details except statistics data.
4. Select the Backup Type, either **Disable Backup**, **Backup now** or **Schedule for later**.
5. If schedule for later is selected, select backup schedule, day, hour and number of backups to preserve.
6. Click **Save**.

Backup	
Backup Type	<input type="button" value="Disable Backup"/> <input type="button" value="Backup now"/> <input checked="" type="button" value="Schedule for later"/>
Backup Option	<input checked="" type="button" value="Configuration only"/>
Backup Schedule	<input type="button" value="Daily"/> <input checked="" type="button" value="Weekly"/>
Backup Day	<input checked="" type="button" value="Sunday"/> <input type="button" value="Monday"/> <input type="button" value="Tuesday"/> <input type="button" value="Wednesday"/> <input type="button" value="Thursday"/> <input type="button" value="Friday"/> <input type="button" value="Saturday"/>
Backup Hour	<input type="text" value="5"/> <input type="text" value="PM"/>
Number of backups to preserve	<input type="text" value="1"/> <input type="text" value="2"/> <input checked="" type="text" value="3"/>

Upload

To upload an existing backup file, perform the following steps:

1. Navigate to System>Backup and Restore
2. Click **Upload**.
3. Browse and select the backup file (.tar) file.
4. Click **Upload**.

Restore

To restore a backup, select the a backup from the list and click **Restore**.

Notes:

- When restoring a backup file on a different FortiAIOps machine, it is necessary to configure the latest FortiAIOps IP address in the FortiGate syslog settings.
- Admin credentials are retained after restoring the backup file.

Restore	
<input checked="" type="button" value="Configuration only"/>	
<input checked="" type="button" value="Restore"/> <input type="button" value="Cancel"/>	

Download

To download a backup file to your local machine, select the backup file from the list and click **Download**.

Delete

To delete a backup file, select the backup file from the list and click **Delete**.

Settings

This page provides the following network and server maintenance parameters to be configured.

- [Network Settings](#)
- [Statistics](#)
- [OUI](#)

Network Settings

This section allows you to configure various system settings. Click  icon to edit the system settings.

 **Network Settings**

Hostname app 

System Time 2023/10/19 11:49 

IP Address 

The **Hostname** displays the hostname of the system currently in use.

Edit Hostname

Hostname

The **System Time** displays the current system time. This setting allows you to select timezone, set time and configure NTP server.

Edit System Time

Current System Time 2023/10/13 16:05

Time Zone

Time Setting method **Synchronize with NTP Server**

Set Server(s)

1	<input type="text" value="pool.ntp.org"/>	
2	<input type="text" value="ntp2.fortiguard.com"/>	<input type="button" value="remove"/>

Notes:

- Both FortiAIOPs and FortiGate must be synchronized with an NTP server.
- Reboot the system (execute `reboot` command) after the NTP and timezone settings are configured.

Configure the **IP address** settings to set dynamic or static IP address.

Edit IP Address

IPv4 Method	<input type="radio"/> DHCP <input checked="" type="radio"/> Static
IP Address	<input type="text" value="192.168.1.100"/>
Netmask	<input type="text" value="255.255.255.0"/>
Gateway	<input type="text" value="192.168.1.1"/>
Primary DNS	<input type="text" value="192.168.1.100"/>
Secondary DNS	<input type="text" value="192.168.1.100"/>

Statistics

This section allows you to configure data retention period in FortiAIOPs. All monitoring data is stored based on dynamically allocated or manually configured duration.

- **Auto config duration to keep Statistics data** - This feature allows FortiAIOPs to dynamically configure the statistics retention period based on daily data accumulation and the available space for maximum data storage. This is enabled by default for a period of 3 weeks, but based on daily monitoring of the data accumulation and available space, FortiAIOPs automatically adjusts the statistics retention period.
- **Duration to keep statistics data** - Manually configure the weeks or months to retain and preserve the statistics data. The permissible range is 1 to 3 weeks or 1 to 6 months. The statistics data older than the time period specified in this field from the current date, is automatically deleted from the FortiAIOPs server. If the duration configured here requires more than the available space for statistics retention, then FortiAIOPs throws an error.

☰ Statistics

Auto config duration to keep Statistics data i

Duration To Keep Statistics Data

Notes:

- You are allowed to configuring the statistics retention duration manually only based on the available disk space.
- The AI Insight statistics are stored for a maximum period of 1 week.
- Post-upgrade, the configured **Duration to Keep Statistics Data** is retained with **Auto config duration to keep Statistics data** enabled. Based on daily analysis, FortiAIOPs configures the statistics retention period automatically.

OUI

This section allows you to view and manage the OUI details.

- **Last update time** - Displays the date and time of the OUI details updated the last time.
- **Parsing status** - Displays the status of parsing.
- **Automatically update every week** - This option when enabled, will allow the system to automatically update the OUI details every week.
- **Upload OUI File** - To upload OUI file, click **Choose File**, browse and select the OUI file, and click **Upload**.

OUI Update

Last update time

Parsing status completed

Automatically update every week

Upload OUI File No file chosen

Mail Server

You can configure the SMTP server to receive email notifications for report generation.

SMTP Server Configuration

Name

Use default

Enable Email

Send Emails from

SMTP Server

SMTP Encryption None SSL TLS

SMTP Port

SMTP Authentication Login None

SMTP Username

SMTP Password

Confirm Password

Configure the following SMTP server settings.

- **Use default** - If enabled, the current configurations are used as the default for all SMTP server communication.
- **Send Emails from** - Enter the email address to trigger the email notifications from.
- **SMTP Server** - Enter the IP address or the hostname of the SMTP server.
- **SMTP Encryption** - Select the security mode as **SSL** or **TLS**. Select **None** to not use any encryption.
- **SMTP Port** - Enter the port number used to connect to the SMTP server.
- **SMTP Authentication** - Select the authentication via **Login** and enter the **SMTP Username** and **SMTP Password**. Select **None** to not use any authentication for the SMTP server.


Licensing

The licensing page displays the license information including the current license status, expiration date, and the number of Monitoring, Analytics and SD WAN licenses.

- **Monitoring** - displays the number of license consumed for monitoring and the number of switches or APs that are unlicensed. The doughnut chart shows the count of FortiGates that are licensed, partially licensed and unlicensed. Click on the filters to view license information in detail. For monitoring license, the consumption is based on the number of switches or APs added.
- **Analytics** - displays the number of license consumed for analytics and the number of switches or APs that are unlicensed. The doughnut chart shows the count of FortiGates that are licensed, partially licensed and unlicensed. Click on the filters to view license information in detail. For analytics license, the consumption is based on the number of switches or APs added.
- **SD WAN** - displays the number of license consumed for SD WAN and the number of FortiGates that are unlicensed. The doughnut chart shows the count of FortiGates that are licensed and unlicensed. Click on the filters to view license information in detail. For SD WAN license, the consumption is based on the number of FortiGates added.

Notes:

- If you buy additional licenses or extend the existing ones through FortiCare, the expiration date displayed will show the nearest expiry and will not include the newly added license. To see the accurate license details, please check FortiCare portal.
- To purchase a co-term license or add any required extra devices to current licenses, please contact your distributor or Fortinet renewal team.



Location Services

Enable location service on this page and configure the following the FortiAP Profile in your FortiGate. To configure the location services, you should perform all necessary configurations within FortiGate. However, the

location service status can be enabled or disabled within FortiAI Ops.

To configure the WIDS profile for the AP radio, follow these steps:

1. Navigate to Location Based Services > FortiAI Ops.
2. In the Project Name field, enter **FortiAI Ops**.
3. In the Password field, enter the secret key displayed in System>Location Services.
4. In the FortiAI Ops server IP field, enter the FortiAI Ops IP address.
5. In the FortiAI Ops server Port field, enter 4013.
6. Enable the Report Rogue APs option.
7. Configure the Report transmit frequency (seconds) as desired.

Note: that a minimum of 3 APs must be placed on the map for the locating service to detect them.

Location Services

Project Name	FortiAI Ops
Secret Key	<input type="password" value="XXXXXXXXXX"/>
Location Services Status	<input checked="" type="checkbox"/> Location Service Enabled

For information on the FortiGate configuration, see the [Configuration Guide](#).

Certificates

The Certificates page allows you to manage both local and CA certificates. Certificates provide security assurance validated by a Certificate Authority (CA).

- [Local Certificates](#)
- [CA Certificates](#)

Local Certificates

The Local Certificates section allows you to install certificate key pair by uploading a zip file containing a certificate and a private key file. The supported zip file formats include *.tar*, *.tar.gz*, *tgz*, *zip*, *tar.xz*, and *.xz*. Also you can generate a Certificate Signing Request (CSR).

Server certificates are generated based on a specific CSR. The CSR is a request sent from an applicant to a CA in order to apply for a digital identity certificate. When a CSR is generated, the associated private key to sign and/or encrypt connections is also generated. Click on the **Generate CSR** button and fill in the required information to generate a CSR for your certificate. In the **Certificate Signing Request** window, enter the following.

- **Certificate Type** - The type of the certificate, either CA signed or self signed.
- **Certificate Name** - A name for the certificate.
- **Common Name** - The FQDN or IP address of the server.
- **Organization** - The name of your establishment or organization.

- **Locality** - The city or area where your organization is located.
- **State or Province** - The state or province of the above mentioned area.
- **Key Size** - Either 2048 or 4096.
- **Subject Alternative Name (SAN)** - It is mandatory to provide SAN.
- Optionally, you can enter the **Organization Unit** and the **Country**.
- Click **Generate**.

Generate a Certificate Signing Request

Complete this form to generate a new CSR and private key.

Certificate Type*	Self Signed
Certificate Name*	Cert-01
Common Name*	10.1.1.1
Organization Unit	e.g. Marketing
Organization	My Company
Locality	Enter Locality
State/Province	Enter state
Country/Region	Enter country code
Email Address	Enter valid email address
Subject Alternative Name*	alt
Key Size*	2048

[Reset](#) [Generate](#) [Cancel](#)

CA Certificates

The CA Certificates section allows you to install and manage your CA certificate. To install a CA certificate, click **Install CA Certificate** and upload your CA certificate (.pem or .cer file). You can view details, download, or delete selected CA certificate after installation.

Notes:

- To upload certificates, the Root CA, server certificate, and key file must be bundled together and uploaded in any of the supported formats.
- Certificates can only be uploaded in PEM or CER formats. Other formats are not supported. If the certificate is in any other format, such as P12 or PFX, it must be converted to a supported format before uploading.
- When using CA2, the intermediate and root CA content must be combined into a single text file (.pem file). This is necessary because only three files can be included in the bundle uploaded: Root CA, server certificate, and key file.
- To access FortiAIOps using a custom domain name, you must install the required CA and Server certificates for the domain configured on FortiAIOps.

Service Assurance

Service Assurance Manager (SAM) is a predictive diagnostic software with trouble-prevention capability. It diagnosis the health of the wireless network and reports the issue before the users are impacted. The FortiAIOPS infrastructure is used to perform on-demand end-to-end system tests. The SAM mode is activated in FortiAP during SAM tests. In this mode, FortiAP radios operate as a client and perform tests against another AP. Once baseline network performance is established, any schedule tests that deviate from the baseline/threshold are marked based on the SAM test values. Multiple tests can be configured with SAM.

- Connectivity tests to measure packet loss
- Throughput tests to measure performance

The tests can be configured to run on a WPA2 PSK SSIDs available in the FortiGate. SSIDs can only be configured in FortiGate.

Notes:

- The SAM is supported only for the following.
 - F series FortiAPs
 - Bridge mode SSIDs
 - WPA2 PSK security mode
 - Radios in AP mode.
- While running SAM tests, FortiAIOPS modifies the FortiAP Profile that is configured on the Access Point in FortiGate. As a result, the CAPWAP on the FortiAP is restarted.


- [Trends](#)
- [Results](#)
- [Baseline](#)
- [Schedule](#)

Trends


The Trends page in the Service Assurance section of FortiAIOPS provides a comprehensive overview of network test performance. You can analyze the total number of tests performed, their categorization as Good, Fair, or Bad, and gain insights into interface-specific data such as Interface IDs and Maximum Packet Loss values.

The bar chart classifies the total number of tests performed into three categories: *Good*, *Fair*, and *Bad*. This classification allows you to quickly assess the overall performance of the network based on the test results. Each bar represents a specific time period, enabling you to identify trends and patterns in test performance over time.

If the **connectivity** test type is selected, the Trends page presents a table with the *Interface ID* and the *Maximum Packet Loss* for each interface.



If the **throughput** test type is selected, the Trends page displays a table with the *Interface ID* and the *Maximum Throughput* for each interface.



To filter the results in the bar chart, click the desired Interface ID.

Trend Filters

The Trends page offers various filters to refine the displayed data and narrow down the analysis. The available filters include:

- **Select Device** - Select a specific device from the available options to filter the test results associated with that device.
- **Test Type** - Choose between the *Connectivity* or *Throughput* test types to filter the relevant test results.
- **Test Name** - Select a specific test name to filter the test results associated with that particular test.
- **Start Date and End Date** - Specify a start date and end date to filter the test results within a specific time range.

Trend Filters

Select Device:

Test Type: Connectivity Throughput

Test Name:

Start date:

End date:

Results

Results page provides a comprehensive overview of the Connectivity/ Throughput test results, including completed tests and tests in progress.

Completed Tests

Name	SSID	Test Type	Device Name	End Time	Result
Sch_thput	sam-thrput	Throughput	FGT_PRIMARY_S81	2023/05/20 16:05:20	0 1 0 0
Sch_thput_TCP	sam_test_qa	Throughput	FGT_PRIMARY_S81	2023/05/20 16:23:37	0 1 0 0
Sch_conn_instant	sam-test-wpa	Connectivity	FGT_PRIMARY_S81	2023/05/20 16:27:56	0 1 0 0
Sch_conn_cont	sam-thrput	Connectivity	FGT_PRIMARY_S81	2023/05/20 16:37:06	1 0 0 0

The Completed Tests panel displays a list of tests that have been completed. It includes the following information for each test:

- **Test Name** - The name of the test performed.
- **SSID** - The SSID associated with the test, indicating the network or wireless access point being tested.
- **Test Type** - The type of test conducted, such as *Connectivity* or *Throughput*.
- **Device Name** - The name of the device used to perform the test, allowing users to track the source of the test data.
- **End Time** - The timestamp indicating when the test was completed.
- **Result** - The result field represents the outcome of the test. It is color-coded and displays the number of results categorized as *Good(Green)*, *Bad(Red)*, *Fair(Orange)*, or *Unknown(Blue)*. Click on the test results to view more detailed information.

Test name	Test Type	AP name	SSID	Radio ID	Band	FortiGate Name	Serial Number
Sch_conn_101F	Connectivity	(*)	sam_qa	1	2.4GHz		

- **Bad Results** - The number of bad results.
- **Device IP Address** - IP address of the device.
- **Device Serial** - The serial number of the device.
- **Fair Results** - The number of fair results.
- **Good Results** - The number of good results.

- **Start Time** - The timestamp indicating when the test was started.
- **Unknown Results** - The number of unknown results.

Tests in Progress

Tests in Progress					
+ Q Search					Q
Name ↕	SSID ↕	Test Type ↕	Sweep Mode ↕	Device Name ↕	State ↕
test_conn_binary	sam_1	Connectivity	recurring	NOT PRESENT !!!	Waiting
sch_cont_VenkatFGT	sam_qa_wpa	Connectivity	recurring	NOT PRESENT !!!	Running
Throuput_cont	sam-thrput	Throughput	recurring	NOT PRESENT !!!	Running
Sch_HA_conn	sam_1	Connectivity	recurring	NOT PRESENT !!!	Waiting

The Tests in Progress panel provides users with a list of tests that are currently in progress or scheduled. It includes the following information for each test:

- **Test Name** - The name of the test performed.
- **SSID** - The SSID associated with the test, indicating the network or wireless access point being tested.
- **Test Type** - The type of test conducted, such as *Connectivity* or *Throughput*.
- **Sweep Mode** - The sweep mode configured for the test, either recursive or baseline.
- **Device Name** - The name of the device designated to perform the test.
- **State** - The current state of the test.

Baseline

Baselines serve as reference points for evaluating the health and performance of the wireless network. Baselines play an important role in detecting deviations from expected network behavior. SAM allows for the configuration of multiple tests, including connectivity tests to measure packet loss and throughput tests to assess overall performance.

View details + Q Search							Q	+ Add	Delete
Name ↕	Test Type ↕	Baseline Type ↕	Device Name ↕	Device Serial ↕	Device IP Address ↕	Status ↕	Start Time ↕		
Base_24	Connectivity	Measured	NOT PRESENT !!!	NOT PRESENT !!!	NOT PRESENT !!!	✔ Completed	2023/05/24 12:43:06		

Add a Baseline

You have two options to execute the baseline tests.

- **Configured Test:** This option allows you to create a baseline test by providing theoretical values.
- **Measured Test:** This option allows you to create a baseline test by providing the actual baseline values. It is important to run a measured baseline when the wireless network is operating either normally or under optimal conditions, as it is used to evaluate subsequent tests.

Connectivity Baseline

To create a connectivity baseline, perform the following steps:

1. Navigate to **Service Assurance>Baseline**.
2. Click **+ Add**.
3. Provide the following details:

Field	Description
Name	Name for the baseline.
Test Type	Select Connectivity as Test Type to measure packet loss.
Device	Select the device.
AP Radios	Select AP radios.
Baseline Type	Select baseline type, Configured or Measured .
SSID	Enter SSID name. SSID must be configured on a neighboring AP in FortiGate.
Pre-shared Key	1. Enter the pre-shared key for the SSID.
Packet Loss(%)	1. Enter packet loss value in %. Note: Packet Loss(%) field is displayed only when Configured is selected as baseline type.

Add new baseline test.

Details

Name

Test Type Connectivity Throughput

Device

AP Radios ✕
+

Baseline Type Configured Measured

SSID

Pre-shared Key

Packet Loss(%)

Ping Server

2.

Ping Server	Enter IP address or FQDN of the ping server to perform connectivity tests.
--------------------	--

Add new baseline test.

 Details

Name

Test Type Connectivity Throughput

Device

AP Radios 
+

Baseline Type Configured Measured

SSID

Pre-shared Key

Ping Server

4. Click **Add**.

Throughput Baseline

To create a throughput baseline, perform the following steps:

1. Navigate to **Service Assurance>Baseline**.
2. Click **+ Add**.
3. Provide the following details:

Field	Description
Name	Name for the baseline.
Test Type	Select Throughput as test type to measure performance. Note: Ensure that the network should have Iperf server running iperf3 traffic.
Device	Select the device.
AP Radios	Select AP radios.
Baseline Type	Select baseline type, Configured or Measured .
SSID	Enter SSID name. SSID must be configured on a neighboring AP in FortiGate.
Pre-shared Key	1. Enter the pre-shared key for the SSID.
Protocol	Select the protocol, TCP or UDP .

Field	Description																						
iPerf Server	Enter iPerf server details. iPerf server generates TCP and UDP data streams which can be used to measure throughput.																						
Port	Enter the port number.																						
Throughput (MB/s)	<p>1. Enter throughput value in MB/s. Note: Throughput(MB/s) field is displayed only when Configured is selected as baseline type.</p> <div style="border: 1px solid #ccc; padding: 10px; margin: 10px 0;"> <p>Add new baseline test.</p> <p> Details</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 30%;">Name</td> <td><input type="text" value="Throughput_Baseline"/></td> </tr> <tr> <td>Test Type</td> <td>Connectivity Throughput</td> </tr> <tr> <td>Device</td> <td><input type="text" value="192.168.1.100"/> ▼</td> </tr> <tr> <td>AP Radios</td> <td><input type="text" value="192.168.1.100"/> × +</td> </tr> <tr> <td>Baseline Type</td> <td>Configured Measured</td> </tr> <tr> <td>SSID</td> <td><input type="text" value="ssid_1"/></td> </tr> <tr> <td>Pre-shared Key</td> <td><input type="text" value="••••••••"/></td> </tr> <tr> <td>Protocol</td> <td>TCP UDP</td> </tr> <tr> <td>iPerf Server</td> <td><input type="text" value="192.168.1.100"/></td> </tr> <tr> <td>Port</td> <td><input type="text" value="8001"/></td> </tr> <tr> <td>Throughput(MB/s)</td> <td><input type="text" value="50"/></td> </tr> </table> </div> <p>2.</p>	Name	<input type="text" value="Throughput_Baseline"/>	Test Type	Connectivity Throughput	Device	<input type="text" value="192.168.1.100"/> ▼	AP Radios	<input type="text" value="192.168.1.100"/> × +	Baseline Type	Configured Measured	SSID	<input type="text" value="ssid_1"/>	Pre-shared Key	<input type="text" value="••••••••"/>	Protocol	TCP UDP	iPerf Server	<input type="text" value="192.168.1.100"/>	Port	<input type="text" value="8001"/>	Throughput(MB/s)	<input type="text" value="50"/>
Name	<input type="text" value="Throughput_Baseline"/>																						
Test Type	Connectivity Throughput																						
Device	<input type="text" value="192.168.1.100"/> ▼																						
AP Radios	<input type="text" value="192.168.1.100"/> × +																						
Baseline Type	Configured Measured																						
SSID	<input type="text" value="ssid_1"/>																						
Pre-shared Key	<input type="text" value="••••••••"/>																						
Protocol	TCP UDP																						
iPerf Server	<input type="text" value="192.168.1.100"/>																						
Port	<input type="text" value="8001"/>																						
Throughput(MB/s)	<input type="text" value="50"/>																						

Add new baseline test.

Details

Name

Test Type

Device

AP Radios
+

Baseline Type

SSID

Pre-shared Key

Protocol

iPerf Server

Port

4. Click **Add**.

To view the detailed information of a baseline, navigate to *Service Assurance > Baseline*, select the desired baseline from the list and click View Details.

Baseline test details

Name = base_24 Search

Name	AP name	SSID	Radio ID	Band	Channel	Packet Loss
Base_24	192.168.1.101	sam_1	2	5GHz	36	100%

To delete a baseline, navigate to *Service Assurance > Baseline*, select the desired baseline from the list and click Delete.

Schedule

The tests are the central activity of the SAM application that is dealt the most. A baseline test is performed occasionally, but the scheduled tests and their results are monitored constantly.

Scheduled tests are measured against a baseline test for Connectivity and Throughput using the configurations provided while creating the test. Only APs and SSIDs within the baseline test is measured in subsequent tests.

Add a Scheduled Test

To add a Scheduled Test, follow these steps:

1. Navigate to **Service Assurance>Schedule**.
2. Click **+ Add**.
3. Provide the following details:
 - a. Enter a name for the test.
 - b. Select Test Type, either **Connectivity** or **Throughput**.
Note: Based on the test type selection the advanced options filed changes.
 - c. Select a device.
 - d. Select a Baseline test.
 - e. Select Interval. **Instant** option enables to run the scheduled test once, immediately after it is saved.
Continuous option enables to execute the scheduled test continuously till you disable the test.
4. Configure Advance Options:
 - If Connectivity is selected as Test Type, you can configure the following fields:

Field	Description
Packet Loss Good Threshold	Type a value for Packet Loss Good Threshold. If the measured packet loss is above this threshold and baseline, the test result is classified as <i>Bad</i> . If it falls between the threshold and the baseline, it is considered <i>Fair</i> , while values below the threshold and baseline are categorized as <i>Good</i> .

Add new schedule test.

 Details

Name

Test Type Connectivity Throughput

Device

Baseline Test

Interval Instant Continuous

 Advanced Options

Packet Loss Good Threshold(%)

- If Throughput is selected as Test Type , you can configure the following fields:

Field	Description
Protocol	Select TCP or UDP.
Throughput Good Threshold (MB/s)	Type a value for the Throughput Good Threshold in MB/s. If the measured throughput is above this threshold, the test result is classified as <i>Good</i> . If it falls between the threshold and the baseline, it is considered <i>Fair</i> , while values below the threshold are categorized as <i>Bad</i> .

Add new schedule test.

Details

Name:

Test Type: Connectivity Throughput

Device:

Baseline Test:

Interval: Instant Continuous

Advanced Options

Protocol: TCP UDP

Throughput Good Threshold (MB/s):

To delete a schedule, select a schedule from the list and click **Delete**.

To start a scheduled test, click start test icon under Actions field. To stop a running scheduled test, click stop test icon under Actions field.

Name	SSID	Test Type	Device Name	Baseline	Status	Interval	Action
Thput_UDP_2	sam_1	Throughput	FOOT_PRINTING_200	Throughput_UDP_HA	Running	Continuous	⏏
Thput_TCP_2	sam_1	Throughput	FOOT_PRINTING_200	Thput_TCP_HA	Stopped	Continuous	▶

