



Multiple Datacenter (Primary/Secondary) Deployment for Enterprise

Secure SD-WAN



DEFINE / DESIGN / **DEPLOY** / DEMO



Table of Contents

Change Log	4
Introduction	5
Audience	5
About this guide	6
Deployment objectives	6
Deployment assumptions	6
Solution overview	8
Design overview	9
Use cases and topologies	9
Product prerequisites	9
Deployment procedures	10
Prerequisites	10
Recommendations	10
Planning	11
Assumptions	11
Configuration steps	11
Creating an overlay template	12
Assigning meta data values to branch devices	15
Configuring SD-WAN rules	16
Creating normalized interfaces	17
Creating policy packages and firewall policies	19
Installing policy packages	23
Verifying the SD-WAN configuration	26
Extensions	27
ADVPN	27
Enabling ADVPN	27
Editing branch templates	28
Display policy routes	28
Adaptive FEC	28
Defining a custom service	28

Defining FEC mappings	29
Enabling FEC for hub devices	30
Enabling FEC on branch devices	30
Creating policies and installing policy packages	30
SD-WAN self-healing with BGP	31
Branch BGP signaling	31
Hub BGP signaling	34
SaaS remote internet breakout	36
Creating an SD-WAN rule for cloud applications	37
Creating a policy to allow traffic on the hub	37
Appendix A - Products used	38
Appendix B - Documentation references	39
Appendix C - Troubleshooting	40

Change Log

Date	Change Description
2022-05-10	Initial release.
2022-11-03	Updated Branch BGP signaling on page 31.

Introduction

Fortinet Secure SD-WAN documentation is categorized into four distinct documents (called 4-D documents): Define, Design, Deploy, and Demo. Each document is designed for a specific purpose and builds on the other documents by providing you a complete path from beginning to end.

The 4-D documentation series includes the following components:

- **Define:** Conceptual guide meant to introduce the reader to common SD-WAN use cases and the Fortinet Secure SD-WAN solution
- **Design:** Reference architecture guide that provides an overview of the components and architectures to satisfy common uses
- **Deploy:** Deployment guides that provide step-by-step procedures for deploying the desired architecture
- **Demo:** Github repository of the configuration and examples provided by documents

This document will cover the step-by-step procedures required to deploy the Fortinet Secure SD-WAN solution in dual hub regions.

The architecture, components and technology referenced in this document is covered in the [Multiple datacenters \(primary/secondary gateways\) section](#) of the *SD-WAN Architecture for Enterprise* guide.

For additional information and documentation about the topics covered in this document, please see the Fortinet Document Library at <https://docs.fortinet.com>.

This section contains the following topics:

- [Audience on page 5](#)
- [About this guide on page 6](#)
- [Deployment objectives on page 6](#)

Audience

This guide is primarily created for a technical audience, including system architects and design engineers who want to deploy Fortinet Secure SD-WAN in greenfield scenarios. It is assumed that the reader has read the [SD-WAN Architecture for Enterprise](#) guide and has identified the architecture that satisfies their use case and goals. Solution overviews and descriptive explanations of the technologies and components will not be covered in this document.

For implementation, a working knowledge of FortiOS networking and policy configuration is ideal.

About this guide


This guide utilizes FortiManager 7.2.0 and FortiOS 7.2.0 for all configuration examples. FortiOS 7.0 is also supported for FortiGate devices using the same steps and procedures covered in this document. When selecting a firmware to use in your deployment, it is important to reference the FortiManager and FortiOS Release Notes.

Release notes will cover supported FortiGate and FortiManager models, special notices, upgrade information, known issues, and other critical information that should be evaluated for your scenario.

For comments and feedback about this document, visit [Multi-Datacenter \(Primary/Secondary\) Enterprise SD-WAN](#) on [community.fortinet.com](#).

Deployment objectives

This deployment guide is the supporting document to the [Multiple datacenters \(primary/secondary gateways\)](#) section of the *SD-WAN Architecture for Enterprise* guide. The use case covered in this document will support primary/secondary behavior of hubs in the SD-WAN region.



Deployment assumptions

- Greenfield deployment of new Fortinet Secure SD-WAN devices.
- Dual hub FortiGates will provide secure access to remote branch locations that require connectivity to local application and services.
- Primary hub (HUB1) will be the preferred hub location for all branch locations in the region.
- Secondary hub (HUB2) will be the backup hub location for all branch locations in the region.

DEPLOYMENT OBJECTIVES

- Traffic will go through primary location as long as the minimum SLA are being met. Traffic is to fail over when those SLA thresholds are no longer being met.
- Both hubs will advertise the same datacenter network space.
- Both hubs have two, redundant WAN connections.
- Each Branch location has two, redundant WAN connections
- WAN connections are public links that can reach all other devices in the region.
- All WAN interfaces have already been configured and have default gateways configured across both links.

Solution overview

This guide is separated into the following parts:

1. In FortiManager, configure the overlay network using the SD-WAN Overlay Provisioning Template.
One-to-one overlay mapping per underlay: in this design, each branch underlay terminates a new IPsec tunnel to one—and only one—gateway underlay. This is the most common overlay design, and simplifies our configuration, but also provides less redundancy than the subsequent full mesh. Full mesh overlay mapping is generally not recommended for multi-datacenter deployments, unless there is a specific use case by which this may be required.
2. Assign Meta fields to Branch devices.
3. Configure SD-WAN rules for Corporate and Internet traffic
Direct Internet Access (DIA): used when local internet breakout at a branch location is required. This is typically SaaS applications or websites, located on the internet, which the branches will access directly. SD-WAN applies intelligence to select the best WAN link for this access.
Branch to Corporate LAN: Preference is given to the primary DC connections when accessing corporate resources. If the primary DC is unable to meet SLA requirements, the secondary DC is selected.
4. Create a Policy Package for the Branches and Hub.
 - Branches
 - i. Branch to DC
 - ii. Branch to internet.
 - Hub
 - i. Branch to DC
 - ii. SLA-healthcheck
5. Deploy the configuration to the devices.

The majority of the configuration and complexity is handled by the FortiManager SD-WAN Overlay Template, which generates the configuration required for BGP, SD-WAN, IPsec VPN, and CLI configurations for loopback interfaces and BGP.

FortiManager provides continued value post deployment through SD-WAN monitoring, IPsec monitoring, and change management.

Design overview

In this design, branch SD-WAN devices now have two (or more) gateways at separate geo-redundant locations from which to steer traffic. A primary gateway is usually located in the preferred datacenter location while the secondary gateway is at the redundant location. Traffic will flow through the primary gateway under normal conditions and utilize the secondary gateway as a backup. While this section will refer to a traditional datacenter, the gateway can be located in a public or private cloud, customer premise location, or any other location where FortiGate physical or virtual appliance can be configured.

The following sections help describe the solution design:

- [Use cases and topologies on page 9](#)
- [Product prerequisites on page 9](#)

Use cases and topologies

This design includes multiple SD-WAN gateways located at geo-redundant datacenter locations that provides inter-datacenter redundancy. Inter-datacenter redundancy refers to the SD-WAN branch device steering between geo-redundant locations based on the predefined SLAs and steering rules.

This topology may be expanded to include other design features such as cloud on-ramp, direct internet access and AD-VPN to name a few. See [Extensions on page 27](#) for details.

Product prerequisites

- Two hub FortiGates with dual WAN connections
- Branch FortiGate with dual WAN connections
- FortiManager 7.2.0 or later to leverage SD-WAN overlay provisioning template

Deployment procedures

FortiManager is used to configure SD-WAN for a topology that includes multiple datacenter devices (hubs) and multiple branch devices. The deployment instructions include the following topics:

- [Prerequisites on page 10](#)
- [Recommendations on page 10](#)
- [Planning on page 11](#)
- [Assumptions on page 11](#)
- [Configuration steps on page 11](#)

Prerequisites

This guide presumes the following prerequisites have been met:

- Hub and branch FortiGates have been imported into FortiManager.
 - The hub and branch devices have active connections to FortiManager.
- ISP links and other interfaces have been configured on all devices.
 - ISP routing is configured where branches have proper routes to reach the Hub.
 - LAN and other directly connected networks have been assigned.

Recommendations

It is recommended to create a device group in FortiManager for the branch devices before utilizing the SD-WAN Overlay template. With device groups, you can add additional branch devices to the group, and the newly added devices will automatically inherit the configuration for SD-WAN.

In *Device Manager*, use the *Device Group* menu in the banner to create a new device group.

The screenshot shows the FortiManager Device Manager interface. On the left, there is a sidebar with a tree view showing 'Managed FortiGate (4)' with sub-items: Branch1, Branch2, Cloud-Gateway, and HUB1. Below this are links for Scripts, Provisioning Templates, Firmware Templates, and Monitors. The main area displays a table of devices with columns: Device Name, Config Status, Host Name, IP Address, Platform, Description, and Firmware Version. All devices are marked as 'Synchronized'.

Device Name	Config Status	Host Name	IP Address	Platform	Description	Firmware Version
Branch1	✓ Synchronized	Branch1	192.168.100.103	FortiGate-VM64-KVM	FortiGate 7.0.5,build0304 (GA)	FortiGate 7.0.5,build0304 (GA)
Branch2	✓ Synchronized	Branch2	192.168.100.104	FortiGate-VM64-KVM	FortiGate 7.0.5,build0304 (GA)	FortiGate 7.0.5,build0304 (GA)
Cloud-Gateway	✓ Synchronized	Cloud-Gateway	192.168.100.105	FortiGate-VM64-KVM	FortiGate 7.0.5,build0304 (GA)	FortiGate 7.0.5,build0304 (GA)
HUB1	✓ Synchronized	HUB1	192.168.100.101	FortiGate-VM64-KVM	FortiGate 7.0.5,build0304 (GA)	FortiGate 7.0.5,build0304 (GA)

Planning

The deployment example in this guide uses the following settings, including IP networks, BGP AS number, performance SLA criteria, and so on:

1. Overlay network address space:
 - a. This address space is used for the IP addressing of all Hub and Branch devices.
 - b. The default 10.10.0.0/16 is used.
2. Loopback IP address space:
 - a. These addresses are used for Performance SLAs, Router IDs and other admin operations.
 - b. The default 172.16.0.0/16 is used.
3. Autonomous System number for BGP:
 - a. A private number is used and must remain exclusively for this SD-WAN BGP configuration.
 - b. The default of 65000 is used.

Assumptions

The deployment example in this guide uses the following ports and IP addresses:

- HUB1 is located at the primary corporate location (Datacenter 1)
- HUB2 is located at the backup corporate location (Datacenter 2)
- ISP1 is connected to port1 on all FortiGates.
- ISP2 is connected to port2 on all FortiGates.
- LAN is connected to port3 on all FortiGates.
- Corporate Datacenter LAN is 192.168.1.0/24.

Configuration steps

Following is a summary of the steps required to configure SD-WAN using FortiManager:

1. Configure the overlay using the SD-WAN overlay template. See [Creating an overlay template on page 12](#).
2. Assign metadata values to branch devices. See [Assigning meta data values to branch devices on page 15](#).

CONFIGURATION STEPS

3. Configure SD-WAN rules. See [Configuring SD-WAN rules on page 16](#).
4. Create normalized interfaces. See [Creating normalized interfaces on page 17](#).
5. Create policy packages and firewall policies for hub and branch devices. See [Creating policy packages and firewall policies on page 19](#).
6. Install policy packages to devices. See [Installing policy packages on page 23](#).
7. Verify the SD-WAN configuration. See [Verifying the SD-WAN configuration on page 26](#).

Creating an overlay template

This section describes how to use the SD-WAN overlay provisioning template to configure the overlay network.



The SD-WAN overlay provisioning template supports metafields for each input box that displays a magnifying glass.

For more information, see the *FortiManager 7.2 Administration Guide*.

To create an overlay template:

1. In FortiManager, go to *Device Manager > Provisioning Templates > SD-WAN Overlay Templates*.
2. Click *Create New*. The *Create New SD-WAN Overlay Template* dialog box is displayed.

3. Enter a name and description for the template, and click *OK*. The *Region Settings* pane is displayed.
4. Set the region settings:
 - a. Select *Dual Hub (Primary & Secondary)*.
 - b. Expand *Advanced*, and modify the default IP address scheme for loopback and overlay networks, BGP-AS number, and to enable AD-VPN as desired.

CONFIGURATION STEPS

- c. Click *Next*. The *Role Assignment* pane is displayed.
5. Set the role assignment:
 - a. Set *Primary HUB* to *HUB1*.
 - b. Set *Secondary HUB* to *HUB2*.
 - c. Set *Device Group Assignment* to *Branches*.

Create New SD-WAN Overlay Template - Role Assignment (2/5)

Name: ACME SD-WAN Overlay

Topology: Single HUB | **Dual HUB (Primary & Secondary)** | Dual HUB (Primary & Primary)

HUB

Primary HUB: HUB1

Secondary HUB: HUB2

Branch

Device Group Assignment: Branches

< Back | Next > | Cancel

- d. Click *Next*. The *Network Configuration* pane is displayed.
6. Set the network configuration for the primary HUB:
 - a. Under *Primary HUB*, set *WAN Underlay 1* to *port1*.
 - b. Set *WAN Underlay 2* to *port2*.
 - c. Expand *Advanced*.

Edit SD-WAN Overlay Template - Network Configuration (3/5)

Name: ACME SD-WAN Overlay

HUB

Primary HUB: HUB1

WAN Underlay 1: Private Link | port1

WAN Underlay 2: Private Link | port2

Network Advertisement: **Connected** | Static

Interface: +

Advanced: +

Neighbors

#	Neighbor IP	Remote AS	Route Map In	Route Map Out
1	172.16.1.1	65100		

< Back | Next > | Cancel

- d. Click *Create New*. The *Create New Neighbor* pane is displayed.
- e. Set *Neighbor IP* to *172.16.1.1*.
- f. Set *Remote AS* to *65100*.
- g. Click *OK*. The BGP neighbor is created.



When entering the port name, it is case sensitive and must match the port as written on the FortiGate exactly.

Select *Private Link* if the port is on a private circuit, and you do not want to create an overlay network utilizing this link.

Select *Override IP* if you want to manually input an IP address that remote branches will connect to. This is commonly used in public cloud providers where interfaces have private IP address or other NAT'd environments.

7. Set the network configuration for the secondary HUB:
 - a. Under *Secondary HUB*, set *WAN Underlay 1* to *port1*.
 - b. Under *Secondary HUB*, set *WAN Underlay 2* to *port2*.
 - c. Expand *Advanced*.
 - d. Click *Create New*. The *Create New Neighbor* pane is displayed.
 - e. Set *Neighbor IP* to *172.16.2.1*.
 - f. Set *Remote AS* to *65100*.
 - g. Click *OK*. The BGP neighbor is created.



A neighbor is configured for the HUBs to learn the route to the Corporate Datacenter LAN (192.168.1.0/24) over BGP. This is also why there is no need to specify a Network Advertisement; routes learned from an eBGP peer are re-advertised to all iBGP and eBGP peers by default.

8. Set the network configuration for the branches device group:
 - a. Scroll down to *Branch Device Group*, and set *WAN Underlay 1* to *port1*.
 - b. Set *WAN Underlay 2* to *port2*.
 - c. Set *Network Advertisement* to *Connected* and *port3*.



This interface will be advertised to the rest of the SD-WAN region. In this example, port3 is our LAN interface for each branch, and so will advertise the branch's LAN subnet.

- d. Click *Next*. The *SD-WAN Template Options* pane is displayed.
9. Set the SD-WAN template options:
 - a. Enable *Add Overlay Objects to SD-WAN Template*.
 - b. In the list, click *Create New* to create a new SD-WAN template named *Branch_SDWAN*.
No configuration of the template is needed at this time.

CONFIGURATION STEPS

- c. Enable *Add Overlay Interfaces and Zones*.
- d. Enable *Add Healthcheck Servers for Each Hub as Performance SLA*.

Create New SD-WAN Overlay Template - SD-WAN Template Options (4/5)

Add Overlay Objects to SD-WAN Template	<input checked="" type="checkbox"/>	Branch_SDWAN	x
Add Overlay Interfaces and Zones	<input checked="" type="checkbox"/>		
Add Healthcheck Servers for Each HUB as Performance SLA	<input checked="" type="checkbox"/>		

- e. Click *Next*. The *Summary* pane is displayed.
10. Click *Finish* to save the template.

Assigning meta data values to branch devices



Each branch must have a unique *branch_id* mapping value in order to successfully utilize the SD-WAN overlay provisioning template.

To assign meta data values to branch devices:

1. In FortiManager, go to *Device Manager > Device & Groups*, and expand *Managed FortiGates*.
2. Set the variable for Branch1:
 - a. In the content pane, right-click *Branch1* and select *Edit Variable Mapping*. The *Edit Metadata Variable Mapping* dialog box is displayed.
 - b. Click the *Mapping Value* cell, type *1*, and select the checkmark to set the value.

Edit Metadata Variable Mapping - Branch1(global)

#	Variable Name	Mapping Value	Default Value
1	\$(branch_id)	1	<input checked="" type="checkbox"/>

The value is set.

Edit Metadata Variable Mapping - Branch1(global)

#	Variable Name	Mapping Value	Default Value
1	\$(branch_id)	1	<input type="checkbox"/>

OK Cancel

- c. Click *OK* to save the changes.
3. Repeat to set *Branch2* to *2*.

Configuring SD-WAN rules

In this section we are going to edit the SD-WAN template to create a new performance SLA target as well as new SD-WAN rules.

To configure SD-WAN rules:

1. In FortiManager, go to *Provisioning Templates > SD-WAN Templates*.
2. Double-click the *Branch_SDWAN* template to open it for editing.
3. Create a rule named *Corporate_Traffic*:
 - a. Under *SD-WAN Rules*, and click *Create New*. The *Create New SD-WAN Rule* pane opens.
 - b. Set the following options, and click *OK*:

Name	Corporate_Traffic
Source	Branch Network, 10.1.0.0/16 (Create new Address Object)
Destination	Datacenter LAN1, 192.168.100.0/24 (Create new Address Object)
Strategy	Lowest Cost SLA
Interface Preference	HUB1-VPN1, HUB1-VPN2, HUB2-VPN1, HUB2-VPN2
Required SLA Target	HUB1_HC#1, HUB2_HC#1

The SD-WAN rule is created.

4. Define an SLA target for internet traffic:
 - a. Under *Performance SLA*, and click *Create New*. The *Create New Performance SLA* pane opens.
 - b. Set the following options, and click *OK*:

Name	Internet
Server	1.1.1.1
Participants	port1, port2
SLA Targets	<ul style="list-style-type: none">• Latency threshold: 300• Jitter Threshold: 55• Packet Loss Threshold: 3%

The SLA target is created.

5. Create a rule named *Internet Traffic*:
 - a. Under *SD-WAN Rules*, and click *Create New*. The *Create New SD-WAN Rule* pane opens.
 - b. Set the following options, and click *OK*:

Name	Internet_Traffic
Source	Branch Network
Destination	all
Strategy	Lowest Cost SLA
Interface Preference	WAN1, WAN2
Required SLA Target	Internet

The SD-WAN rule is created.

6. Click *OK* to save the SD-WAN template.

Creating normalized interfaces

Because the policy package uses interface objects instead of directly referring to the interface, we must link the interface objects with the actual interfaces on any/all devices. We do this by creating normalized interfaces with per-platform mappings.

To create normalized interfaces:

1. In FortiManager, go to *Policy & Objects > Object Configurations > Normalized Interface*.
2. In the content pane, click *Create New*.
The *Create New Normalized Interface* pane opens.
3. Set *Name* to *HUB1*.
4. Under *Per-Platform Mapping*, click *Create New*.
The *Create New Per-Platform Mapping* dialog box is displayed.

CONFIGURATION STEPS

Create New Per-Platform Mapping

Matched Platform

Click to select

Mapped Interface Name

No Advanced Options Available

OK
Cancel

- Set the following options, and click **OK**:

Matched Platform Select all.

Mapped Interface Name Type *HUB1*.



The mapped interface is case sensitive. It must exactly match the interface on the target FortiGate.

The per-platform mapping is created.

- Repeat this procedure to the following per-platform mappings:

Normalized Interface	Matching Type	Mapped Interface/Zone
HUB1	Matched Platform: all	HUB1
HUB2	Matched Platform: all	HUB2
VPN1	Matched Platform: all	VPN1
VPN2	Matched Platform: all	VPN2
WAN1	Matched Platform: all	WAN1
WAN2	Matched Platform: all	WAN2
HUB-Loopback	Matched Device: HUB1	HUB1-Lo
	Mapped Device: HUB2	HUB2-Lo
LAN	Matched Platform: all	port3

All the per-platform mappings are created:

Policy Packages >

Object Configurations >

Normalized Interface

Normalized Interface

Virtual Wire Pair

Firewall Objects

Security Profiles

Fabric Connectors

User & Authentication

+ Create New Edit Delete Expand All More View

Normalized Interface	Mapping Rule	Mapped Interface/Zone
LAN		
	Per-device (Cloud-Gateway (root))	port2
	Default	port3
HUB-Loopback		
	Per-device (HUB1 (root))	HUB1-Lo
	Per-device (Cloud-Gateway (root))	HUB2-Lo
	Default	HUB-Loopback
WAN2		
	Default	WAN2
WAN1		
	Default	WAN1
VPN2		
	Per-device (Cloud-Gateway (root))	VPN1-2
	Default	VPN2
VPN1		
	Default	VPN1
HUB2		
	Default	HUB2
HUB1		
	Default	HUB1



If you are using different ports for LAN between branches, you can leverage per-device mapping to override the matched platform: all.

Creating policy packages and firewall policies



The following policies are provided to allow traffic to flow between branches and hub. They require further security configuration to secure the communication.

Following is a summary of how to create the policy package:

1. Create a policy package for branch devices. See [Creating the branch policy package and policies on page 19](#).
These firewall policies leverage the SD-WAN zones and interfaces.
2. Create a policy package for the hub device. See [Creating the hub policy package and policies on page 22](#).

Creating the branch policy package and policies

To create the branch policy package and policies:

1. In FortiManager, go to *Policy & Objects*.
2. Create a policy package named *Branches*:
 - a. From the *Policy Package* menu, select *New*.
The *Create New Policy Package* dialog box is displayed.
 - b. Set name to *Branches*, and click *OK*.

The policy package named *Branches* is created.

3. In the branches policy package, create a firewall policy named *Branch to DC*:
 - a. Select the *Branches* policy package, and click *Create New*. The *Create New Firewall Policy* pane opens.
 - b. Set the following options, and click *OK*:

Name	Branch to DC
Incoming Interface	LAN
Outgoing Interface	HUB1, HUB2

CONFIGURATION STEPS

IPv4 Source Address	Branch network
IPv4 Destination Address	Datacenter LAN1
Action	Accept

The firewall policy is created.

4. In the branches policy package, create a firewall policy named *Direct Internet Access*:
 - a. Select the *Branches* policy package, and click *Create New*. The *Create New Firewall Policy* pane opens.
 - b. Set the following options, and click *OK*:

Name	Direct Internet Access
Incoming Interface	LAN
Outgoing Interface	WAN1, WAN2
IPv4 Source Address	Branch network
IPv4 Destination Address	all
Action	Accept
NAT	Enable

The firewall policy is created.

5. Assign the branches policy package to the branch device group:
 - a. On the *Policy & Objects* pane, expand the *Branches* policy package, and select *Installation Targets*.
 - b. In the toolbar, click *Edit*. The *Edit Installation Targets* dialog box opens.
 - c. In the *Available Entries* list, select the *Branches* group, and click the right arrow (>) to move it to the *Selected Entries* list.

- d. Click *OK*.

The installation target for the branches policy package is the *Branches* device group.

Creating the hub policy package and policies

To create the hub policy package and policies:

1. In FortiManager, go to *Policy & Objects*.
2. Create a policy package named *HUB*:
 - a. From the *Policy Package* menu, select *New*.
The *Create New Policy Package* dialog box is displayed.
 - b. Set name to *HUB*, and click *OK*.
The policy package named *HUB* is created.
3. In the *HUB* policy package, create a firewall policy named *SLA-HealthCheck* :
 - a. Select the *HUB* policy package, and click *Create New*. The *Create New Firewall Policy* pane opens.
 - b. Set the following options, and click *OK*:

Name	SLA-HealthCheck
Incoming Interface	VPN1, VPN2
Outgoing Interface	HUB-Loopback
IPv4 Source Address	Overlay Tunnels, 10.10.0.0/16 (create new address object)
IPv4 Destination Address	all
Action	Accept

Edit Firewall Policy

ID: 1

Name: SLA-HealthCheck

ZTNA: ☒ Disable ☐ Full ZTNA ☐ IP/MAC filtering

Incoming Interface: ☒ VPN1 ☒ VPN2

Outgoing Interface: ☒ HUB-Loopback

Source Internet Service: ☐

IPv4 Source Address: ☒ Overlay Tunnels

IPv6 Source Address: ☐ +

Source User: ☐ +

Source User Group: ☐ +

FSSO Groups: ☐ +

Destination Internet Service: ☐

IPv4 Destination Address: ☒ all

IPv6 Destination Address: ☐ +

Service: ☒ ALL

Schedule: ☒ always

Action: ☐ Deny ☒ Accept ☐ IPSEC

Inspection Mode: ☒ Flow-based ☐ Proxy-based

OK **Cancel**

The firewall policy is created.

4. In the *HUB* policy package, create a firewall policy named *Branch to Datacenter*:
 - a. Select the *HUB* policy package, and click *Create New*. The *Create New Firewall Policy* pane opens.
 - b. Set the following options, and click *OK*:

Name	Branch to Datacenter
Incoming Interface	VPN1, VPN2
Outgoing Interface	LAN

IPv4 Source Address	Branch Network
IPv4 Destination Address	Datacenter LAN1
Action	Accept

Edit Firewall Policy

ID

2

Name

Branch to Datacenter

ZTNA

Disable

Full ZTNA

IP/MAC filtering

Incoming Interface

☒ VPN1

☒ VPN2

☒ LAN

Outgoing Interface

Source Internet Service

☐

IPv4 Source Address

Overlay Tunnels

IPv6 Source Address

Source User

Source User Group

FSSO Groups

Destination Internet Service

☐

IPv4 Destination Address

Datacenter LAN1

IPv6 Destination Address

Service

ALL

Schedule

always

Action

Deny

Accept

IPSEC

Inspection Mode

Flow-based

Proxy-based

OK

Cancel

The firewall policy is created.

5. Assign the HUB policy package to the HUB1 and HUB2 devices:
 - a. On the *Policy & Objects* pane, expand the *HUB* policy package, and select *Installation Targets*.
 - b. In the toolbar, click *Edit*. The *Edit Installation Targets* dialog box opens.
 - c. In the *Available Entries* list, select the *HUB1* and *HUB2* devices, and click the right arrow (>) to move it to the *Selected Entries* list.
 - d. Click *OK*.

The installation target for the HUB policy package is the *HUB1* and *HUB2* devices.

Installing policy packages

Because the HUB and branches use separate policy packages, we will install each policy package one one at a time:

1. Install the HUB policy package to the HUB1 device. See [Installing the HUB policy package on page 23](#).
2. Install the branch policy package to branch device group. See [Installing the branch policy package on page 24](#).

Installing the HUB policy package

In this step, we install the HUB policy package to the HUB1 device.

To install the HUB policy package:

1. Go to *Device Manager*, and click *Install Wizard* in the toolbar.
The *Install Wizard* dialog box opens.

CONFIGURATION STEPS

2. Set the following options, and click *Next*:

Install Policy Package & Device Settings

Select

Policy Package

HUB

Install Wizard

☒ Install Policy Package & Device Settings

Install a selected policy package. Any device specific settings for devices associated with the package will also be installed.

Policy Package: HUB

Comment: 0/127

☐ Create ADOM Revision

☐ Schedule Install

☒ Install Device Settings (only)

Next > Cancel

The wizard moves to the next screen:

3. Verify that *HUB1* and *HUB2* are selected, and click *Next*.

The wizard moves to the installation preparation page. When the installation preparation completes, you should see three, green checkmarks that indicate the policy package is ready to install.

4. Review the page, and click *Install*.

You can click *Install Preview* to view more details before installing the policy package.

Installation is complete when the status indicates *install and save finished status=OK*.

Installing the branch policy package

In this step, we install the branch policy package to the branch device group.

To install the branch policy package:

1. Go to *Device Manager*, and click *Install Wizard* in the toolbar.
The *Install Wizard* dialog box opens.
2. Set the following options, and click *Next*:


Install Policy Package & Device Settings

Select

Policy Package

Branches

CONFIGURATION STEPS



Install Wizard

☒ **Install Policy Package & Device Settings**
Install a selected policy package. Any device specific settings for devices associated with the package will also be installed.

Policy Package: Branches

Comment: 0/127


☐ Create ADOM Revision

☐ Schedule Install

☐ Install Device Settings (only)

Next > Cancel

The wizard moves to the next screen:



Install Wizard - Policy Package and Device Setting (Branches)


Please select one or more devices to install (Use checkbox or Ctrl or Shift key for multiple selections)

<input type="checkbox"/>	Device Name	IP Address	Platform
<input checked="" type="checkbox"/>	Branches		

< Back Next > Cancel

3. Verify that *Branches* is selected, and click *Next*.

The wizard moves to the installation preparation page. When the installation preparation completes, you should see three, green checkmarks that indicate the policy package is ready to install.



Install Wizard - Policy Package (Branches)

Installation Preparation Total: 3/3, Success: 3, Warning: 0, Error: 0

- ✓ Interface Validation
- ✓ Policy and Object Validation
- ✓ Ready to Install.

<input type="checkbox"/>	Device Name	Status	Action
<input checked="" type="checkbox"/>	Branch1[root]	Connection Up	
<input checked="" type="checkbox"/>	Branch2[root]	Connection Up	

Install Cancel

4. Review the page, and click *Install*.

You can click *Install Preview* to view more details before installing the policy package.

Installation is complete when the status indicates *install and save finished status=OK*.


Verifying the SD-WAN configuration

You can verify the SD-WAN and overlay configuration in the *Device Manager > Monitor > SD-WAN Monitor* pane.

To verify:


1. Go to *Device Manager > Monitors > SD-WAN Monitor*.

A list of FortiGates are displayed in the map and on the right-hand side.



2. Select a FortiGate to view its SD-WAN status.

In addition to the current SD-WAN selection and status, the monitor section provides a historical view of the link health and SLA server health.



Extensions

Extensions are optional enhancements to the SD-WAN solution. The extensions include:

- Auto-Discovery VPN is used to dynamically build overlay tunnels between devices in an SD-WAN region. The SD-WAN hub is the ADVPN sender that provides branch devices with the necessary details to establish their own tunnels as necessary.
- Adaptive Forward Error Correction (FEC) is a WAN remediation technique that dynamically corrects packet loss based on the detected packet loss on the link.
- SD-WAN self-healing with BGP is used to signal the optimal interface to use for traffic destined back to the spoke. Interfaces that do not meet our pre-defined SLA will be marked as *out-of-sla* to other devices in the SD-WAN network.
- SaaS remote internet breakout is used when branch traffic needs to route a SaaS application (for example, a VoIP solution) through the HUB.

This section contains the following topics:

- [ADVPN on page 27](#)
- [Adaptive FEC on page 28](#)
- [SD-WAN self-healing with BGP on page 31](#)
- [SaaS remote internet breakout on page 36](#)

ADVPN

Following is a summary of enabling ADVPN:

1. Enable ADVPN. See [ADVPN on page 27](#).
2. Edit the branch template to add *Branch_NET* as a destination address. See [Editing branch templates on page 28](#).
3. Make policy routes visible in the GUI for HUB1. See [Display policy routes on page 28](#).

Enabling ADVPN

Edit an SD-WAN overlay template to enable ADVPN, which automatically adds the required settings to the IPsec template and the BGP template.

To enable ADVPN:

1. Go to *Device Manager > Provisioning templates > SD-WAN Overlay Template*, and double-click the *ACME SD-WAN Overlay* template to open it for editing.
2. Expand the *Advanced* menu, and enable the *Auto-Discovery VPN* toggle.
3. Click *Next* five (5) times to complete the wizard.
The required settings are added to the IPsec template and BGP template.

Editing branch templates

Edit the branch template to add *Branch_NET* as a destination address.

To edit the branches template:

1. Go to *SD-WAN Templates*, and double-click the *branches* template to open it for editing.
2. In the *SD-WAN Rules* section, double-click the *Corporate_Traffic* rule to open it for editing.
3. Under *Destination*, add *Branch_NET* as a destination address (in addition to the *Datacenter LAN1* subnet), and click *OK* to save the template.

Display policy routes

Change the display options for HUB1 to make policy routes visible in the GUI.

To display policy routes:

1. In the tree menu under *Managed FortiGates*, select *HUB1*.
2. In the second-from-left pane, click *Display Options*. The *Display Options* dialog box is displayed.
3. Enable *Router > Policy Route*, and click *OK*.

Adaptive FEC

Following is a summary of configuring adaptive FEC:


1. Define the service that FEC will protect. See [Defining a custom service on page 28](#).
2. Define the FEC mapping to specify how many parity bits are sent based on different packet loss conditions. See [Defining FEC mappings on page 29](#).
3. Enable FEC on both HUB VPN phase 1 interfaces. See [Enabling FEC for hub devices on page 30](#).
4. Enable FEC on both branch VPN tunnels. See [Enabling FEC on branch devices on page 30](#).
5. Create policies for hub and branch devices, and install the policy packages. See [Creating policies and installing policy packages on page 30](#).

Defining a custom service

Define the service that FEC will protect. In this example we will define a custom service.

To define a custom service:

1. Go to *Policy & Object > Object Configurations > Firewall Objects > Services*.
2. Click **+Create New > Service**.
3. Specify the name of the service, the protocol and the ports, and click **OK** to save the service.



Defining FEC mappings

Define the FEC mapping to specify how many parity bits are sent based on different packet loss conditions.

To define FEC mappings:

1. From the *Policy & Objects* page, use *Tools* in the banner to select *Display Options*.
2. Select *CLI Only Objects* at the bottom, and click **OK**.
3. Expand *Object Configurations > CLI Only Objects > CLI Only Objects*, and search for FEC.
4. c. Select *fec*, and click **+Create New**. The *create vpn ipsec fec* pane is displayed.
5. In the *Name* box, type *dc_fec*.
6. Under *mappings*, click *Create New*. The *create vpn ipsec fec* mapping pane is displayed.
7. Set the following options, and click **OK** to create the mapping:

base	8
packet-loss-threshold	5
redundant	2

The mapping is created.

8. Under *mappings*, click *Create New* again to create another mapping.
9. Set the following options, and click **OK** to create the mapping:

base	5
packet-loss-threshold	10
redundant	2

10. Click **OK** to save the object with two mappings.

Enabling FEC for hub devices

Enable FEC on both HUB VPN phase 1 interfaces.

To enable FEC for hub devices:

1. Go to *Device Manager > Provisioning Templates > IPsec Tunnel Templates*.
2. Double-click the *ACME SD-WAN Overlay_hub1_ipsec* template to open it for editing.
3. Select *VPN1*, and click *Edit*.
4. Scroll down to and expand *Advanced Options*.
5. Enable *fec-egress* and *fec-ingress*, and click *OK*.
6. Repeat for *HUB1-VPN2*.

Enabling FEC on branch devices

Enable FEC on both branch VPN tunnels.

To enable FEC on branch devices:

1. From *IPsec Tunnel templates*, double-click the *ACME SD-WAN Overlay_branch_ipsec* template to open it for editing.
2. Double-click *HUB1-VPN1* to open it for editing.
3. For *FEC Health Check*, enter *HUB1_HC*.
4. Scroll down and expand *Advanced Options*.
5. Set the following options, and click *OK*.

fec-mapping-profile	dc_fec
fec-egress	enable
fec-ingress	enable

6. Repeat for *HUB1-VPN2*.

Creating policies and installing policy packages

Create policies for the hub and branch devices for the custom application, and then install the policy packages to the devices.

To create policies and install policy packages:

1. Create a policy for the HUB policy package:
 - a. Go to *Policy & Object > Policy Packages > HUB > Firewall Policy*, and click *+Create New*.
 - b. Set the following options, and click *OK*.

Name	Custom App Policy
Incoming Interface	LAN
Outgoing Interface	HUB1
Pv4 Source Address	Branch network

Pv4 Destination Address	Datacenter LAN1
Service	CustomApp-5000
Action	Accept
Advanced Options	fec enabled

c. Move this policy under the *SLA-HealthCheck* policy.

2. Create a policy for the branches policy package:

- a. Go to *Policy & Object > Policy Packages > Branches > Firewall Policy* and click *+Create New*.
- b. Set the following options, and click *OK*.

Name	Custom App Policy
Incoming Interface	LAN
Outgoing Interface	HUB1
Pv4 Source Address	Branch network
Pv4 Destination Address	Datacenter LAN1
Service	CustomApp-5000
Action	Accept
Advanced Options	fec enabled

c. Move this policy under the *Direct Internet Access* policy.

3. Install both HUB and Branch policy packages.

SD-WAN self-healing with BGP

This example demonstrates a scalable configuration using options that help simplify head-end traffic-steering in an SD-WAN setup that uses a hub and spoke topology. In this example, the hub and branches have basic configurations, with one set of SD-WAN rules on the hub to cover all branch instances.

The hub does not need to reference branch addresses in the SD-WAN rules to steer traffic to each branch over the healthy VPN overlay. It also does not need to run health checks to the branches to determine what paths are healthy. Instead, the branches configure health checks to monitor the links, and use BGP and BGP communities to satisfy both requirements by updating the hub with the status of the links over BGP. This avoids manual maintaining health checks from the head-end, allowing for better scalability.

This section contains the following topics:

- [Branch BGP signaling on page 31](#)
- [Hub BGP signaling on page 34](#)

Branch BGP signaling

Following is a summary of enabling route steering on branch devices:

1. Edit BGP neighbors to define an access list for the branch LAN, define route maps that use the access list, and edit the BGP neighbors to send the route maps. See [Editing BGP neighbors on page 32](#).

2. Edit SD-WAN templates to define the conditions for when each route map is sent. See [Editing SD-WAN templates on page 33](#).
3. Install the device settings to the branch and hub devices.

Editing BGP neighbors

Edit the BGP neighbors to:

- Define an access list for the branch LAN.
- Define two (2) route maps using this access list, which adjusts the BGP community sent.
- Edit the BGP neighbors to send these route maps.

To edit the BGP neighbor:

1. Go to *Device Manager > Provisioning Templates > BGP Templates*, and double-click the *ACME SD-WAN Overlay_branch_bgp* template to open it for editing.
2. Edit the neighbor that corresponds to the hub device's VPN1 interface:
 - a. Double-click the neighbor. The *Edit Neighbor* pane is displayed.
 - b. Beside *Route Map Out Preferable*, click the dropdown menu, and click +. The *Create New Route Map* pane is displayed.
 - c. Set the following options:

Name	Primary
ID	1
Rules	<ol style="list-style-type: none"> 1. Click <i>Create New</i>. The <i>Create New Route Map Rule</i> pane is displayed. 2. Toggle on <i>Match IP address</i>. 3. Click the dropdown box, and click + > <i>Access List</i>. The <i>Create New Access List</i> pane is displayed. 4. Set <i>Name</i> to <i>LAN1</i>. 5. Under <i>Rules</i>, click <i>Create New</i>. The <i>Create New Access List Rule</i> pane is displayed. 6. Set <i>Type</i> to <i>Prefix</i>. 7. Set <i>Prefix</i> to <i>Specify</i>, and enter the desired subnet LAN, for example, <i>10.1.1.0/24</i>. Repeat this step for any additional LANs. 8. Click <i>OK</i> to save the access rule. 9. Click <i>OK</i> to save the access list. The <i>Create New Route Map Rule</i> pane is displayed. 10. In the <i>Match IP address</i> list, select the access list. 11. Click <i>OK</i> to save the route map rule.

- d. Click *OK* to save the route map.
- e. In the *Route Map Out Preferable*, select the *Primary* route map.
- f. Under *IPv4 Filtering*, enable *Route Map Out*.
- g. Click the dropdown list, and click +. The *Create New Route Map* pane is displayed.
- h. Set the following options:

Name	Out-Of-SLA
Rules	<ol style="list-style-type: none"> 1. Click <i>Create New</i>. The <i>Create New Route Map Rule</i> pane is displayed.

2. Set ID to 1.
3. Toggle on *Match IP address*.
4. Click the dropdown box, select *LAN1*.
5. Enable *Set Community*, and enter *65000:1*.
6. Click *OK* to save the route map rule.

- i. Click *OK* to save the route map.
 - j. Set *Route Map Out* to *Out-of-SLA*.
 - k. Click *OK* to save the HUB's VPN1 interface neighbor.
3. Edit the second neighbor that corresponds to HUB VPN2 interface:
- a. Double-click the neighbor. The *Edit Neighbor* pane is displayed.
 - b. Beside *Route Map Out Preferable*, click the dropdown menu, and click *+*. The *Create New Route Map* pane is displayed.
 - c. Set the following options:

Name	Secondary
ID	1
Rules	<ol style="list-style-type: none"> 1. Click <i>Create New</i>. The <i>Create New Route Map Rule</i> pane is displayed. 2. Set <i>ID</i> to 1. 3. Set <i>Match IP address</i> to <i>LAN1</i>. 4. Enable <i>Community</i>, and enter <i>65000:2</i>. 5. Click <i>OK</i> to save the route map rule.

- d. Click *OK* to save the route map.
 - e. Set *Route Map Out* to *Out-of-SLA*.
 - f. Click *OK* to save the HUB's VPN2 interface neighbor.
4. Click *OK* to save the BGP template.

Editing SD-WAN templates

Edit the SD-WAN neighbor to define the conditions for when each route map is sent.

To edit the SD-WAN template:

1. Go to *Device Manager > Provisioning Templates > SD-WAN Templates*.
2. Double-click the *Branches* template to open it for editing.
3. Under *Neighbor*, create a new neighbor for HUB's VPN1:
 - a. Click *+Create New*. The *Create New SD-WAN Neighbor* pane is displayed.
 - b. Set the following options, and click *OK*:

IP	Specify the IP address of the HUB's VPN1 interface
Interface Member	HUB1-VPN1
Performance SLA	HUB1_HC
SLA	1
Role	Standalone

4. Under *Neighbor*, create a new neighbor for HUB's VPN2:
 - a. Click **+Create New**. The *Create New SD-WAN Neighbor* pane is displayed.
 - b. Set the following options, and click **OK**:

IP	Specify the IP address of the HUB's VPN2 interface
Interface Member	HUB1-VPN1
Performance SLA	HUB1_HC
SLA	1
Role	Standalone

5. Click **OK** to save the template.
6. Install the device settings to the branch and hub devices.

Hub BGP signaling

Enabling BGP route steering on the HUB is comprised of the following steps:

1. Edit the BGP template to edit neighbor groups *VPN1* and *VPN2* to create a new *Route Map In* with new rules for each neighbor group. See [Editing the BGP template on page 34](#).
2. Edit the SD-WAN template to define which VPN is used based on the received tags. See [Editing the SD-WAN template on page 36](#).
3. Install the device settings to the branch and hub devices.

Editing the BGP template

Edit the BGP template to edit neighbor groups *VPN1* and *VPN2* to create a new *Route Map In* with new rules for each neighbor group. The process:

- Defines router community lists for each of the three (3) communities that may be sent.
- Defining a *Route Map In* for each VPN to set route tags.

To define router community lists:

1. Go to *Device Manager > Provisioning Templates > BGP Templates*.
2. Double-click the *ACME SD-WAN Overlay_hub1_bgp* template to open it for editing.
3. Edit the neighbor group named *VPN1* to create a new *Route Map In* with new rules:
 - a. In the *Neighbor Group* section, double-click the *VPN1* group to open it for editing. The *Edit Neighbor Group* pane is displayed.
 - b. Under *IPv4 Filtering*, enable *Route Map In*.
 - c. Beside *Route Map In*, click the dropdown box, and click **+**. The *Create New Route Map* pane is displayed.
 - d. In the *Name* box, type *VPN1-RouteMap_IN*.
 - e. Create a new rule:
 - i. Under *Rules*, click **Create New**. The *Create New Route Map Rule* pane is displayed
 - ii. Set the following options:

ID	3
Match Community	1. Toggle on.

	<ol style="list-style-type: none"> Click the dropdown, and click +. The <i>Create New Community List</i> pane is displayed. Set <i>Name</i> to 65000:1. Under <i>Rules</i>, click <i>Create New</i>. The <i>Community List Rule Edit</i> pane is displayed. Set <i>ID</i> to 1. Set <i>Match</i> to 65000:1, and click <i>OK</i> to save the rule. Click <i>OK</i> to save the community list. Select the newly created rule named 65000:1 for <i>Match Community</i>.
--	---

Set route tag 1

iii. Click *OK* to save the route map rule.

f. Create another new rule:

- Under *Rules*, click *Create New*. The *Create New Route Map Rule* pane is displayed
- Set the following options:

ID 4

Match Community	<ol style="list-style-type: none"> Toggle on. Click the dropdown, and click +. The <i>Create New Community List</i> pane is displayed. Set <i>Name</i> to 65000:2. Under <i>Rules</i>, click <i>Create New</i>. The <i>Community List Rule Edit</i> pane is displayed. Set <i>ID</i> to 1. Set <i>Match</i> to 65000:2, and click <i>OK</i> to save the rule. Click <i>OK</i> to save the community list. Select the newly created rule named 65000:2 for <i>Match Community</i>.
-----------------	---

Set route tag 2

iii. Click *OK* to save the route map rule.

g. Create a third new rule:

- Under *Rules*, click *Create New*. The *Create New Route Map Rule* pane is displayed
- Set the following options:

ID 5

Match Community	<ol style="list-style-type: none"> Toggle on. Click the dropdown, and click +. The <i>Create New Community List</i> pane is displayed. Set <i>Name</i> to 65000:5. Under <i>Rules</i>, click <i>Create New</i>. The <i>Community List Rule Edit</i> pane is displayed. Set <i>ID</i> to 1. Set <i>Match</i> to 65000:5, and click <i>OK</i> to save the rule. Click <i>OK</i> to save the community list. Select the newly created rule named 65000:5 for <i>Match Community</i>.
-----------------	---

Set route tag 5

- iii. Click *OK* to save the route map rule.
- h. Click *OK* to save the route map. The *Edit Neighbor Group* pane is displayed.
4. For *Route Map In*, select the newly created *VPN1-RouteMap_IN*, and click *OK*.
5. Repeat this procedure for *VPN2*, replacing the *Route Map In* name with *VPN2-RouteMap_IN*.
You can select the previously created communities when creating the three (3) rules for *VPN2*.
6. Click *OK* to save the BGP template.

Editing the SD-WAN template

Edit the SD-WAN template to define which VPN is used based on the received tags.

To edit the SD-WAN template:

1. Go to *Device Manager > Provisioning Templates > SD-WAN Templates*.
2. Double-click the *Hub_SDWAN* template to open it for editing.
3. Under *SD-WAN Rules*, define a new rule:
 - a. Click *+Create New*. The *Create New SD-WAN Rule* pane is displayed.
 - b. Set the following options, and click *OK*:

Name	ToBranches_VPN1
Source Address	all
Route Tag	1
Interface Preference	VPN1

4. Under *SD-WAN Rules*, define a second rule:
 - a. Click *+Create New*. The *Create New SD-WAN Rule* pane is displayed.
 - b. Set the following options, and click *OK*:

Name	ToBranches_VPN2
Source Address	all
Route Tag	2
Interface Preference	VPN2

5. Click *OK* to save the template.
6. Install the device settings to the branch and hub devices.

SaaS remote internet breakout

You can use this configuration to enable SaaS remote internet breakout on the branch devices. This allows branch devices to access cloud applications through the hub device. The spoke device routes only Ringcentral VoIP traffic through hub overlays. The SD-WAN rule is set to *set gateway enable* to override the route table and send traffic that matches this application through the hub.

Following is a summary of configuring SaaS remote internet breakout:

1. Create an SD-WAN rule for cloud applications. See [Creating an SD-WAN rule for cloud applications on page 37](#).

2. Create a policy to allow traffic on the hub. See [Creating a policy to allow traffic on the hub on page 37](#).

Creating an SD-WAN rule for cloud applications

To create an SD-WAN rule:

1. Go to *Device Manager > Provisioning Templates > SD-WAN Templates*.
2. Double-click the *Branches* template to open it for editing.
3. Under *SD-WAN Rules*, click *+Create New*. The *Create New SD-WAN Rule* pane is displayed.
4. Complete the following options, and click *OK* to save the new rule:

Name	Cloud Applications
Destination	<ol style="list-style-type: none"> 1. Select <i>Internet Service</i>. 2. Click the box beside <i>Application Group</i>, and click <i>+</i> to create a new application group. 3. Set <i>Name</i> to <i>Cloud_Applications</i>. 4. Set <i>Application</i> to <i>Ringcentral (ID: 42635)</i>. 5. Click <i>OK</i> to save the application group.
Strategy	Lowest Cost (SLA)
Interface Preference	HUB1-VPN1, HUB1-VPN2
Required SLA Target	Hub1_HC
Advanced Options	Enable <i>gateway</i> .

5. Move the rule to the position two (2) below *Corporate_Traffic*.
6. Click *OK* to save the SD-WAN template.

Creating a policy to allow traffic on the hub

To create a policy to allow traffic on the hub device:

1. Go to *Policy & Objects*.
2. Select the *HUB* policy package, and click *+Create New* to define a new policy.
3. Set the following options, and click *OK*:

Name	Remote Internet Breakout
Incoming Interface	Branches
Outgoing Interface	WAN1, WAN2
IPv4 Source Address	Branch network
IPv4 Destination Address	all
Action	Accept
NAT	Enabled

4. Install the branch and hub policy packages.

Appendix A - Products used

The following product models and firmware were used in this guide:

Product	Model	Firmware
FortiOS	All models supported by FortiManager	7.2.0 and later
FortiManager	All models	7.2.0 and later



Appendix B - Documentation references

Feature documentation:

- [Multiple datacenters \(primary/secondary gateways\) section](#) of the *SD-WAN Architecture for Enterprise* guide.

Solution hub:

- [Secure SD-WAN](#)

Appendix C - Troubleshooting

The following debug commands can be used to troubleshoot SD-WAN issues:

Command	Description
diag vpn ike gateway list	Confirm IPsec is up
get router info bpg summary	Confirm BGP is up and exchanging routes
diagnose sys sdwan health-check status HUB1_HC	Confirm hub device is reachable through SLA



www.fortinet.com

Copyright© 2024 Fortinet, Inc. All rights reserved. Fortinet®, FortiGate®, FortiCare® and FortiGuard®, and certain other marks are registered trademarks of Fortinet, Inc., and other Fortinet names herein may also be registered and/or common law trademarks of Fortinet. All other product or company names may be trademarks of their respective owners. Performance and other metrics contained herein were attained in internal lab tests under ideal conditions, and actual performance and other results may vary. Network variables, different network environments and other conditions may affect performance results. Nothing herein represents any binding commitment by Fortinet, and Fortinet disclaims all warranties, whether express or implied, except to the extent Fortinet enters a binding written contract, signed by Fortinet's Chief Legal Officer, with a purchaser that expressly warrants that the identified product will perform according to certain expressly-identified performance metrics and, in such event, only the specific performance metrics expressly identified in such binding written contract shall be binding on Fortinet. For absolute clarity, any such warranty will be limited to performance in the same ideal conditions as in Fortinet's internal lab tests. Fortinet disclaims in full any covenants, representations, and guarantees pursuant hereto, whether express or implied. Fortinet reserves the right to change, modify, transfer, or otherwise revise this publication without notice, and the most current version of the publication shall be applicable.